

Login Checklist

RQ- 2022-09-19-58

Login Station ID: #4

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 09/28 /2022 9:13

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
0.3				9		X			5859 4729 1462
0.8				11		X			5859 4729 1451

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ✓ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes ✓ No _____

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA X Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____ Containers intact? Yes ✓ No _____

Caps on tight?

Yes ✓ No _____

Sufficient Sample Volume:

Yes ✓ No _____

If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ✓ No _____ Init: R

Chlorine detected? (One container checked per Field ID)

Yes _____ No X Init: R

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH< 2.0?

Yes ✓ No _____ NA _____ Init: R

**W-1-4-DIOX (Green dot on container) preserved to pH< 4.0?

Yes _____ No _____ NA X Init: R

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: X

Date: 09/28 /2022

Event contains NCRs (Y/N)? X 9571

EventID: 2022 SMP : Myakka
SO-DIST-2022-09-28-01 (SMP)

— Date Received: 28-SEP-2022 09:13

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #4 Exp:10/19/2022
pH Test Strips 0 – 6	LOT# 223819AV Exp: AUG 30, 2023
pH Paper 0 – 3	N/A
pH Paper 0 – 13	LOT# 207621 Exp: March 15, 2024
Chlorine Test Strips	LOT# 0070 Exp: Feb. 2023

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 9/26/2022
Customer: SO-DIST
RQ: RQ-2022-09-19-58
Collected By: Gary Snorek, William Mullen
Sampling Agency: FDEP
Project ID: SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 2
Delivery Method: FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
SOUTH CREEK @ HONORE AVE	 G3SD0090
LAKE MYAKKA (LOWER) @ MIDDLE	 G3SD0107
LAKE MYAKKA (UPPER) @ MIDDLE	 G3SD0133

RELINQUISHED BY(SIGNATURE):



DATE/TIME: 9/26/2022
1600 EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By: 

Rec'd/Inspected
Date: 9-28-2022



RQ-2022-09-19-58

Collected By: Gary Snorek, William Mullen

Customer: FDEP

Field Report Prepared by: Gary Snorek, William Mullen

Project ID: SMP

Sampling Agency: FDEP

Comments:

WIN ID/Field ID:



WIN ID/Field ID: G3SD0090

Location:

Location: SOUTH CREEK @ HONORE AVE

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT)
9/26/2022 945	1.52	19.3	27.8	6.87	0.3	0.8	0.9	838	0.41

Parameter Suite	Parameter Methods				Preservation		pH Check	# Bottles sent to Lab	Bottle Group		
Preserved Nutrients (P-500ML)	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP				Ice	H2SO4*	<2				
	Lot #		Exp:								
Metals (P-500ML)	W-ICPMS		W-ICP	W-HARD	Ice	HNO3*	<2				
	Lot #		Exp:								
Filtered Nutrients (P125ML)	W-PO4-F		Field Filtered 0.45 um Filter		Ice						
	Filter Lot #	Syringe Lot #									
BOD (BP-1L)	OV-BODUNIN				Ice						
Chlorophyll (BP-1L)	CHLSUITE-W				Ice						
Physical/Aggregate (Fresh) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY / W-CL-IC / W-COLOR / W-SO4-IC / W- TDS				Ice						
Physical/Aggregate (Marine) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY				Ice						
Macroinvertebrates (PJ-2L)	MI-FW-QLDC	Formalin Lot #			Formalin						
Periphyton (PT-50ML)	ALGAE-ID				Ice						
Microbiology (Contract Lab Bottle)	X	E Coli	F Coli	Enterococci	x	Ice				1	B
	Contract Lab										
Molecular (QPCR-P-500ML)	X	PCR-HF183	X	PCR-BacR	X	PCR-DG3	x	Ice	1	B	
		PCR-GULL2		PCR-GFD							
Tracers (BG-500ML)	X	W-E8321-DI	X	W-E8321-MS	x	Ice	1	B			
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI	W-E8321-MS	W-PSNP-TQ	x	Ice	MCAA Exp.	MCAA Lot#	4	B	
	X	W-PCL-TQ-R	W-CARB-AA (5 ml of MCAA Buffer Solution)	X			W-CT-CL-R				
		W-TR-SQ-R	X	W-PCB-TQ-R							
Phytoplankton		DTY-QN-C	PKD-QN-BV			Ice					
DOC		W-DOC	Field Filtered 0.45 um Filter		Ice	H2SO4*	<2				
	Acid Preservative Expiration Date										



RQ-2022-09-19-58

Collected By: Gary Snorek, William Mullen

Customer: FDEP

Field Report Prepared by: Gary Snorek, William Mullen

Project ID: SMP

Sampling Agency: FDEP

Comments:

WIN ID/Field ID:



WIN ID/Field ID: G3SD0107

Location:

Location: LAKE MYAKKA (LOWER) @ MIDDLE

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT)
9/26/2022 1115	0.82	10.6	28.2	6.11	0.3	0.3	2	204.7	0.1

Parameter Suite	Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group			
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	X	<2	1	A	
	Lot #		132683		Exp:		12/18/22						
Metals (P-500ML)		W-ICPMS		W-ICP	W-HARD		Ice		HNO3*		<2		
	Lot #		Exp:										
Filtered Nutrients (P125ML)		W-PO4-F		Field Filtered 0.45 um Filter			Ice						
	Filter Lot #			Syringe Lot #									
BOD (BP-1L)		OV-BODUNIN					Ice						
Chlorophyll (BP-1L)	X	CHLSUITE-W				X	Ice			1	A		
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-CL-IC / W-COLOR / W-SO4-IC / W-TDS				X	Ice			1	A		
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY					Ice						
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #				Formalin						
Periphyton (PT-50ML)		ALGAE-ID					Ice						
Microbiology (Contract Lab Bottle)		E Coli	F Coli	Enterococci			Ice						
	Contract Lab												
Molecular (QPCR-P-500ML)		PCR-HF183		PCR-BacR	PCR-DG3		Ice						
	PCR-GULL2		PCR-GFD										
Tracers (BG-500ML)		W-E8321-DI		W-E8321-MS			Ice						
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI	W-E8321-MS		W-PSNP-TQ		Ice	MCAA Exp.	MCAA Lot#				
		W-PCL-TQ-R	W-CARB-AA (5 ml of MCAA Buffer Solution)		W-CT-CL-R								
		W-TR-SQ-R	W-PCB-TQ-R										
Phytoplankton		DTY-QN-C		PKD-QN-BV			Ice						
DOC		W-DOC	Field Filtered 0.45 um Filter			Ice	H2SO4*		<2				
	Acid Preservative Expiration Date												



RQ-2022-09-19-58	Collected By: Gary Snorek, William Mullen
Customer: FDEP	Field Report Prepared by: Gary Snorek, William Mullen
Project ID: SMP	Sampling Agency: FDEP
WIN ID/Field ID:  WIN ID/Field ID: G3SD0133	Comments:

Location:

Location: LAKE MYAKKA (UPPER) @ MIDDLE

Matrix: Fresh

(Check One) ☒ Grab ☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT)
9/26/2022 1225	1.84	23.7	28	6.29	0.3	0.4	2.2	206.1	0.1

Parameter Suite	Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group		
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	X	<2	1	C
		Lot #		132683	Exp:		12/18/22					
Metals (P-500ML)		W-ICPMS		W-ICP	W-HARD	Ice		HNO3*		<2		
		Lot #			Exp:							
Filtered Nutrients (P125ML)		W-PO4-F		Field Filtered 0.45 µm Filter			Ice					
		Filter Lot #		Syringe Lot #								
BOD (BP-1L)		OV-BODUNIN				Ice						
Chlorophyll (BP-1L)	X	CHLSUITE-W			X	Ice				1	C	
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-CHC / W-COLOR / W-SO4-IC / W- TDS			X	Ice				1	C	
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY				Ice						
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #			Formalin						
Periphyton (PT-50ML)		ALGAE-ID				Ice						
Microbiology (Contract Lab Bottle)		E Coli	F Coli	Enterococci		Ice						
		Contract Lab										
Molecular (QPCR-P-500ML)		PCR-HF183	PCR-BacR	PCR-DG3		Ice						
		PCR-GULL2	PCR-GFD									
Tracers (BG-500ML)		W-E8321-DI	W-E8321-MS			Ice						
Pesticides (BG-500ML) (BG-1L)	X	W-E8321-DI	X	W-E8321-MS	X	W-PSNP-TQ		MCAA Exp.	MCAA Lot#			
	X	W-PCL-TQ-R	X	W-CARB-AA (5 ml of MCAA Buffer Solution)	X	W-CT-CL-R	X	Ice				
	X	W-TR-SQ-R	X	W-PCB-TQ-R				02/04/23	128343	8	C	
Phytoplankton		DTY-QN-C	PKD-QN-BV			Ice						
DOC		W-DOC	Field Filtered 0.45 µm Filter			Ice		H2SO4*		<2		
		Acid Preservative Expiration Date										

Benchmark EnviroAnalytical, Inc.
1001 Corporate Ave. Suite 102
North Port, FL 34289
(941) 625-3137 / (941) 240-3071 fax

Client Name: FDEP
Address: 2600 Blair Stone Rd.
Tallahassee, FL, 32399
Phone: (239) 344-5719
Email: dep-overflowmicro@dep.state.fl.us

Bill to: Frances Moore
P.O. #: Lab B95341

2022-09-19-58
Project Name: RQ-2021-
Project Run/Location: South Creek Myakka

Laboratory Submission #:

522090747

Station ID	Surface Water Sample Matrix? (Fresh / Marine) Sample Type	Enterococci E.coli (SM9223B Quantitray)	Laboratory Sample #
E.Coli = 250 mL ; Entero = 120 mL ; Fecal Coliform = 120 mL			
G3SD0090 South Creek	(F) M / Grab	E. coli / Entero / Fecal coliform Date & Time: 9/26/22 0945	1
	F / M / Grab	E. coli / Entero / Fecal coliform Date & Time:	
	F / M / Grab	E. coli / Entero / Fecal coliform Date & Time:	
	F / M / Grab	E. coli / Entero / Fecal coliform Date & Time:	
	F / M / Grab	E. coli / Entero / Fecal coliform Date & Time:	
	F / M / Grab	E. coli / Entero / Fecal coliform Date & Time:	
	F / M / Grab	E. coli / Entero / Fecal coliform Date & Time:	
	F / M / Grab	E. coli / Entero / Fecal coliform Date & Time:	
	F / M / Grab	E. coli / Entero / Fecal coliform Date & Time:	
	F / M / Grab	E. coli / Entero / Fecal coliform Date & Time:	
	F / M / Grab	E. coli / Entero / Fecal coliform Date & Time:	

"Sample Type" is used to indicate whether the sample was a grab (G) or whether it was a composite (C).

- 2 "Sample Matrix" is used to indicate whether the sample is being discharged to drinking water (DW), groundwater (GW), surface water (SW), fresh surface water (FSW), saline surface water (SSW), soil, sediment (SDMT), or sludge (SLDG).
3 "Container Type" is used to indicate whether the container is plastic (P) or glass (G).
4 Sample must be refrigerated or stored in wet ice after collection. The maximum temperature during storage should be 6°C (43°F). Under "Preservative," list any preservatives that were added to the sample container.

Instructions:

1. Each bottle has a label identifying sample ID, premeasured preservative contained in the bottle, sample type, client ID, and parameters for analysis.
2. The following information should be added to each bottle label after collection with permanent black ink: date and time of collection, sampler's name or initials, and any field number or ID.
3. All bottles not containing preservative may be used with appropriate sample prior to collection.
4. The client is responsible for documentation of the sampling event. Please note several sampling events on the sample custody form.

Laboratory Sample Acceptability:

pH < 2.0 BEAS Temperature: 4.3°C

1	Collector: Gary Savelle	Date: 9/26/22	Time: 1349	Received By: Melinda Merchant	Date: 9/26/22	Time: 1349
2	Relinquished by:	Date:	Time:	Received By:	Date:	Time:
3	Relinquished by:	Date:	Time:	Received By:	Date:	Time:
4	Relinquished by:	Date:	Time:	Received By:	Date:	Time:
5	Relinquished by:	Date:	Time:	Received By:	Date:	Time:

Date of Request: 01-SEP-2022
 Created By: MULLEN_W On: 01-SEP-2022
 Modified By: AYRES_J On: 06-SEP-2022
 Customer: SO-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: South District
 Event Description: 2022 SMP : Myakka

Send Coolers To:

Phone: 239-344-5716
 FLDEP South District Office
 2295 Victoria Ave. Suite 314
 Fort Myers, FL 33901-3381
 Attn: William Mullen
 Cooler Ship EMail: William.Mullen@FloridaDEP.gov

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 06-SEP-2022
 Biology Request Reviewed By: JASROTIA_P On: 01-SEP-2022
 Sampling Kit Required: YES Ship on: 16-SEP-2022
 Sampling Kit Shipped: YES On: 14-SEP-2022
 Sampling Kit Packed By: SHAIK_A
 Preservatives Needed: YES
 Date to Receive Samples: 27-SEP-2022
 Logged In By: ROBERTS_Z On: 28-SEP-2022

Send Final Report To:

FLDEP South District Office
 2295 Victoria Ave. Suite 364
 Fort Myers, FL 33901-3381
 Attn: William Mullen
 Report Notification EMail:
 Nicole.Reistad@FloridaDEP.gov; John.Barrington@FloridaDEP.gov;
 William.Mullen@FloridaDEP.gov; Monica.Jaeger@FloridaDEP.gov;
 Thomas.J.Baker@FloridaDEP.gov

Comments: Group A: (Lower Myakka) Freshwater Nutrients
 Group B: (South Creek) E. coli, PCR, Tracers, W-CT-Cl-R, W-PCL-TQ-R, W-PCB-TQ-R
 Group C: (Upper Myakka) Freshwater Nutrients, Pesticides

#####

Buffer Solution for W-CARB-AA Bottle Needed

#####

W-TR-SQ-R (sunscreen)

Wash your hands thoroughly and wear gloves. Refrain from using sunscreens on the day of sample collection.

#####

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group B (Water) With 1 Samples:

Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
SD-BES-ECQ	Template: DEFAULT	(SM 9223 Quanti-Tray) E. coli by Colilert/QT by BEA South in North Port
Bottle Type: BG-500ML FILL TO	Number of Bottles: 4	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization
W-PCB-TQ-R	Template: DEFAULT	(EPA 8270E) PCBs in water matrices by GC/MS/MS
W-PCL-TQ-R	Template:	(EPA 8270E) Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS/MS
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: SMP	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Bottle Group C (Water) With 1 Samples:

Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: CH2ClCOOH and Ice
W-CARB-AA	Template: DEFAULT	(EPA 8321B) Carbamates in water matrices by HPLC/MS/MS
Bottle Type: BG-500ML FILL TO	Number of Bottles: 2	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization
W-PCB-TQ-R	Template: DEFAULT	(EPA 8270E) PCBs in water matrices by GC/MS/MS
W-PCL-TQ-R	Template:	(EPA 8270E) Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS/MS
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: SMP	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: BG-1L	Number of Bottles: 4	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS
W-TR-SQ-R	Template: DEFAULT	(EPA 8270E) Analysis of Sunscreen Compounds and Flame Retardants in Water by GC/MS-SIM
Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.