

Login Checklist

RQ- 2022-12-05-51

Login Station ID: 5

Shipping Method: FedEx UPS | HD | Greyhound

Date/Time of Receipt: 12/15 / 22 @ 9:42

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
1.6				1		X			585947313302

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included? Yes X No _____

Micro-Biology Overflow Chain of Custody/ FieldSheet(s) Included? C.P. Yes X No _____

CONTAINER CHECK

Evidence Tape on Bottles? Yes _____ No _____ NA X Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken? Yes _____ No X Containers intact? Yes X No _____

Caps on tight? Yes X No _____

Sufficient Sample Volume: Yes X No _____

If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes X No _____ Init: C.P.

Chlorine detected? (One container checked per Field ID)

Yes _____ No X Init: C.P.

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH< 2.0? Yes X No _____ NA _____ Init: C.P.

**W-1-4-DIOX (Green dot on container) preserved to pH< 4.0? Yes _____ No _____ NA X Init: C.P.

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: C.P. Date: 12/15/22 Event contains NCRs (Y/N)? N

Event ID: SO-DIST-2022-12-15-01 (SMP)
Date Received: 15-DEC-2022 09:42

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	221426058 10/17/23
pH Test Strips 0 – 6	223819AV 08/30/23
pH Paper 0 – 3	NA
pH Paper 0 – 13	210620 4/15/2023
Chlorine Test Strips	0070 02/2023

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 12/14/2022 **Collected By:** Monica Jaeger, William Mullen
Customer: SO-DIST **Sampling Agency:** FDEP
RQ: RQ-2022-12-05-51 **Project ID:** SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 2

Delivery Method: FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
Bonnet Creek @ SR 64	 G4SD0107

RELINQUISHED BY(SIGNATURE):



DATE/TIME: 12/14/2022
1500 EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By: *Chin P*

Rec'd/Inspected
Date: 12-15-22



RQ-2022-12-05-51	Collected By: Monica Jaeger, William Mullen
Customer: FDEP	Field Report Prepared by: Monica Jaeger, William Mullen
Project ID: SMP	Sampling Agency: FDEP

WIN ID/Field ID:



WIN ID/Field ID: G4SD0107

Comments: Microbiology sample(s) submitted to contract laboratory.

Location: Bonnet Creek @ SR 64

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPTH)								
12/14/2022 1030	6.43	69.9	19.3	6.11	0.2	0.4	0.4	159.1	0.07								
Parameter Suite		Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group						
Preserved Nutrients (P-500ML)		X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	X	<2	1	A				
		Lot #		SA2229010		Exp:		08/30/23									
Metals (P-500ML)		x	W-ICPMS		X	W-ICP		X	W-HARD	X	Ice	X	HNO3*	X	<2	1	A
		Lot #		NA1286110		Exp:		11/16/23									
Filtered Nutrients (P125ML)			W-PO4-F		Field Filtered 0.45 um Filter				Ice								
		Filter Lot #		Syringe Lot #													
BOD (BP-1L)			OV-BODUNIN					Ice									
Chlorophyll (BP-1L)		X	CHLSUITE-W				X	Ice				1	A				
Physical/Aggregate (Fresh) (P-1L)		X	Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W- TDS				X	Ice				1	A				
Physical/Aggregate (Marine) (P-1L)			Alkalinity / W-F / W-TSS / TURBIDITY					Ice									
Macroinvertebrates (PJ-2L)			MI-FW-QLDC		Formalin Lot #			Formalin									
Periphyton (PT-50ML)			ALGAE-ID					Ice									
Microbiology (Contract Lab Bottle)		X	E Coli		F Coli			Enterococci	X			Ice	1	A			
		Contract Lab															
Molecular (QPCR-P-500ML)		X	PCR-HF183		X	PCR-BacR		X	PCR-DG3	X	Ice	1	A				
		PCR-GULL2		PCR-GFD													
Tracers (BG-500ML)		X	W-E8321-DI		X	W-E8321-MS			X	Ice	1	A					
Pesticides (BG-500ML) (BG-1L)			W-E8321-DI		W-E8321-MS		W-PSNP-TQ		Ice	MCAA Exp.	MCAA Lot#						
			W-PCL-TQ-R		W-CARB-AA (5 ml of MCAA Buffer Solution)		W-CT-CL-R										
		W-TR-SQ-R		W-PCB-TQ-R													
Phytoplankton			DTY-QN-C		PKD-QN-BV			Ice									
DOC			W-DOC		Field Filtered 0.45 um Filter				Ice		H2SO 4*	<2					
		Add Preservative Expiration Date															
		Add Preservative Lot Number															

Benchmark EnviroAnalytical, Inc.
1001 Corporate Ave. Suite 102
North Port, FL 34289
(941) 625-3137 / (941) 240-3071 fax

BEAS Sample Receipt Temp. 2.6 °C
Checked at Benchmark EA South E85088
With Temperature Gun ID #7

Client Name: FDEP
Address: 2600 Blair Stone Rd.
Tallahassee, FL, 32399
Phone: (239) 344-5718
Email: dep-overflowmicro@dep.state.fl.us

Bill to: Frances Moore
P.O. #: Lab ~~B95341~~
CODEFS

2022-12-05-51
Project Name: RQ-2021-

Project Run/Location: PHYTO LAKES; SMO

Laboratory Submission #:

522120441

Station ID	Surface Water Sample Matrix* (Fresh / Marine) Sample Type	Enterococci E.coli (SM9223B Quantitray)	Laboratory Sample #
		E.Coli = 250 mL ; Entero = 120 mL ; Fecal Coliform = 120 mL	
<u>G4SD0107</u>	<u>F</u> / <u>M</u> / <u>Grab</u>	<u>E. coli</u> / Entero / Fecal coliform Date & Time: <u>12/14/22</u> <u>1030</u>	<u>1</u>
	F / M / Grab	E. coli / Entero / Fecal coliform Date & Time:	
	F / M / Grab	E. coli / Entero / Fecal coliform Date & Time:	
	F / M / Grab	E. coli / Entero / Fecal coliform Date & Time:	
	F / M / Grab	E. coli / Entero / Fecal coliform Date & Time:	
	F / M / Grab	E. coli / Entero / Fecal coliform Date & Time:	
	F / M / Grab	E. coli / Entero / Fecal coliform Date & Time:	
	F / M / Grab	E. coli / Entero / Fecal coliform Date & Time:	
	F / M / Grab	E. coli / Entero / Fecal coliform Date & Time:	
	F / M / Grab	E. coli / Entero / Fecal coliform Date & Time:	
	F / M / Grab	E. coli / Entero / Fecal coliform Date & Time:	

*Sample Type is used to indicate whether the sample was a grab (G) or whether it was a composite (C).

*Sample Matrix is used to indicate whether the sample is being discharged to drinking water (DW), groundwater (GW), surface water (SW), fresh surface water (FSW), saline surface water (SSW), soil, sediment (SDANT), or sludge (SLDG).

*Container Type is used to indicate whether the container is plastic (P) or glass (G).

Sample must be refrigerated or stored in wet ice after collection. The maximum temperature during storage should be 6°C (42.8°F). Under "Preservative," list any preservatives that were added to the sample container.

Instructions:

- Each bottle has a label identifying sample ID, preservative contained in the bottle, sample type, client ID, and parameters for analysis.
- The following information should be added to each bottle label after collection with permanent black ink: date and time of collection, sampler's name or initials, and any field number or ID.
- All bottles not containing preservative may be rinsed with appropriate sample prior to collection.

4. The client is responsible for documentation of the sampling event. Please note special sampling events on the sample custody form.

Laboratory Sample Acceptability:

pH < 2.0 BEAS Temperature: 2.6°C

1	Collector: <u>Monica Jaeger</u>	Date: <u>12/14/22</u>	Time: <u>1512</u>	Received By: <u>Melinda Merchant</u>	Date: <u>12/14/22</u>	Time: <u>1512</u>
2	Relinquished by:	Date:	Time:	Received By:	Date:	Time:
3	Relinquished by:	Date:	Time:	Received By:	Date:	Time:
4	Relinquished by:	Date:	Time:	Received By:	Date:	Time:
5	Relinquished by:	Date:	Time:	Received By:	Date:	Time:

Date of Request: 21-NOV-2022
 Created By: MULLEN_W On: 21-NOV-2022
 Modified By: JASROTIA_P On: 28-NOV-2022
 Customer: SO-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: South District
 Event Description: 2022 SMP : Bonnet + Gopher

Send Coolers To:

Phone: 239-344-5716
 FLDEP South District Office
 2295 Victoria Ave. Suite 314
 Fort Myers, FL 33901-3381
 Attn: William Mullen
 Cooler Ship EMail: William.Mullen@FloridaDEP.gov

Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 22-NOV-2022
 Biology Request Reviewed By: JASROTIA_P On: 28-NOV-2022
 Sampling Kit Required: YES Ship on: 30-NOV-2022
 Sampling Kit Shipped: YES On: 30-NOV-2022
 Sampling Kit Packed By: PENDLETO_C
 Preservatives Needed: NO
 Date to Receive Samples: 15-DEC-2022
 Logged In By:

Send Final Report To:

FLDEP South District Office
 2295 Victoria Ave. Suite 314
 Fort Myers, FL 33901-3381
 Attn: William Mullen
 Report Notification EMail:
 Nicole.Reistad@FloridaDEP.gov;John.Barrington@FloridaDEP.gov;
 William.Mullen@FloridaDEP.gov;Monica.Jaeger@FloridaDEP.gov;
 Thomas.J.Baker@FloridaDEP.gov

Comments: Group A:(Bonnet) Fresh Metals, Freshwater Nutrients, E. coli, PCR, Tracers
 Group B: (Gopher) Fresh Nutrients, E.coli

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2015) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
SD-BES-ECQ	Template: DEFAULT	(SM 9223 Quanti-Tray) E. coli by Colilert/QT by BEA South in North Port
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: SMP	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO ₃
W-HARD	Template: DEFAULT	(SM 2340 B-2011) Hardness by calculation, in aqueous matrices, reported as mg/L CaCO ₃

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-HARD	Template: DEFAULT	(SM 2340 B-2011) Hardness by calculation, in aqueous matrices, reported as mg/L CaCO3
Hardness		
W-ICP	Template: SMP-FRESH	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Calcium		
Iron		
Magnesium		
Potassium		
Sodium		
Strontium		
Tin		
Titanium		
Vanadium		
Zinc		
W-ICPMS	Template: DEFAULT	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
Aluminum		
Antimony		
Arsenic		
Barium		
Beryllium		
Boron		
Cadmium		
Chromium		
Cobalt		
Copper		
Lead		
Manganese		
Molybdenum		
Nickel		
Selenium		
Silver		
Thallium		

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
SD-BES-ECQ	Template: DEFAULT	(SM 9223 Quanti-Tray) E. coli by Colilert/QT by BEA South in North Port
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2015) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Bottle Group B (Water) With 1 Samples:

Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.