

Login Checklist

RQ- 2022-11-14-17

Login Station ID: #3

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 12/ 7 /22 @ 0927

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
1.0				3		X			5859-4729987

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No ☐

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No ☒

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA ☒ Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____

Containers intact? Yes ☒ No _____

Caps on tight?

Yes ☒ No _____

Sufficient Sample Volume:

Yes ☒ No _____

If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes _____ No ☒ Init: BK

Chlorine detected? (One container checked per Field ID)

Yes _____ No _____ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes ☒ No _____ NA _____ Init: BK

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes _____ No _____ NA ☒ Init: BK

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: BK

Date: 12/ 7 /22 Event contains NCRs (Y/N)? N

Event ID: 98 Whaler Run
NW-DIST-2022-12-07-01 (SMP)
Date Received: 07-DEC-2022 09:27

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #3 Exp:10/17/2023
pH Test Strips 0 – 6	Lot#223819AV Exp:8/30/23
pH Paper 0 – 3	
pH Paper 0 – 13	Lot#207621 Exp:3/15/24
Chlorine Test Strips	Lot#0070 Exp:2/23

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encores samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 12/6/2022 **Collected By:** Nathan Mulkey, Frank Butera
Customer: NW-DIST **Sampling Agency:** FDEP
RQ: RQ-2022-11-14-17 **Project ID:** SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1 **Delivery Method:** FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
YELLOW RIVER	 G4NW0031

RELINQUISHED BY(SIGNATURE):



DATE/TIME: 12/6/2022
1600 CEN

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By:

Brian Kneuch

Rec'd/Inspected

Date:

12-7-22 OAT



RQ-2022-11-14-17

Collected By: Nathan Mulkey, Frank Butera

Customer: FDEP

Field Report Prepared by: Nathan Mulkey, Frank Butera

Project ID: SMP

Sampling Agency: FDEP

 WIN ID/Field ID: 
 WIN ID/Field ID: G4NW0031

Comments: Microbiology sample(s) submitted to contract laboratory.

Location: YELLOW RIVER

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {CEN}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPTH)
12/6/2022 935	8.62	89.9	17.8	6.08	0.3		1.3	42.9	0.02

Parameter Suite	Parameter Methods				Preservation		pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	
		Lot #	2145160		Exp:	6/2/23			<2
Metals (P-500ML)		W-ICPMS		W-ICP	W-HARD	Ice		HNO3*	
		Lot #			Exp:				<2
Filtered Nutrients (P125ML)		W-PO4-F	Field Filtered 0.45 µm Filter			Ice			
		Filter Lot #		Syringe Lot #					
BOD (BP-1L)		OV-BODUNIN				Ice			
Chlorophyll (BP-1L)	X	CHLSUITE-W				X	Ice		1 B
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W-TDS				X	Ice		1 B
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY					Ice		
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #			Formalin			
Periphyton (PT-50ML)		ALGAE-ID				Ice			
Microbiology (Contract Lab Bottle)	X	E Coli		F Coli	Enterococci	X	Ice		1 B
	X	Contract Lab							
Molecular (QPCR-P-500ML)		PCR-HF183		PCR-BacR	PCR-DG3		Ice		
		PCR-GULL2		PCR-GFD					
Tracers (BG-500ML)		W-E8321-DI		W-E8321-MS		Ice			
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI	W-E8321-MS		W-PSNP-TQ		MCAA Exp.	MCAA Lot#	
		W-PCL-TQ-R	W-CAR8-AA (5 ml of MCAA Buffer Solution)		W-CT-CL-R	Ice			
		W-TR-SQ-R	W-PCB-TQ-R						
Phytoplankton		DTY-QN-C		PKD-QN-BV		Ice			
DOC		W-DOC		Field Filtered 0.45 µm Filter		Ice		H2SO4*	
			Add Preservative Expiration Date				<2		
			Add Preservative Lot Number						

Document Reference # 05.1.0

Laboratory: UWF Wetlands Research Laboratory

Sampler's initials :

Page 1 of 1

Date/Time: 2/2/20 11342

Date/Time: 12/4/02 11392

CST

[illegible]

Surface water, no chlorine expected

~~RQ - 2022-10-08-56~~

Contact name **Mike King**

Phone: 850-595-8300

Sampler's name: K. H. B. B.

²Type codes: G = grab, C = composite, X =

³ Recorded using IRT-2

Date of Request: 22-SEP-2022
 Created By: SLADE_C On: 22-SEP-2022
 Modified By: AYRES_J On: 15-NOV-2022
 Customer: NW-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Northwest District
 Event Description: 98 Whaler Run

Send Coolers To:

Phone: 850-595-0567
 160 W Government Street
 Suite 208
 Pensacola, FL 32502-5794
 Attn: Stopher Slade
 Cooler Ship Email: christopher.slade@dep.state.fl.us

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 15-NOV-2022
 Biology Request Reviewed By: AYRES_J On: 15-NOV-2022
 Sampling Kit Required: NO Ship on:
 Sampling Kit Shipped: YES On: 31-OCT-2022
 Sampling Kit Packed By: PENDLETO_C
 Preservatives Needed: NO
 Date to Receive Samples: 14-NOV-2022
 Logged In By: KREUCH_B On: 15-NOV-2022

Send Final Report To:

160 W Government Street
 Suite 208
 Pensacola, FL 32502-5794
 Attn: Myranda Butler
 Report Notification EMail:
 christopher.slade@floridadep.gov;Myranda.k.butler@floridadep.gov

Comments: Group A: (WBID 906D) Marine Nutrients, Tracers, Markers, Bacteria, Contract Lab Bacteria

Group B: (WBID 30C) Nutrients, Contract Lab Bacteria

Group C (WBID 784) Marine Nutrients, Contract Lab Bacteria

Packing notes;

FedEx return packing slips

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
FCOLI-MF	Template: DEFAULT	(SM 9222 D) Fecal coliforms by membrane filter method - non-chlorinated water systems
Bottle Type: TEST HAS NO	Number of Bottles: 1	Preserved With: ICE
NW-UWF-ENQ	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert/QT by UWF in Pensacola
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction

Bottle Group A (Water) With 1 Samples:

Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: SMP	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group B (Water) With 1 Samples:

Bottle Type: TEST HAS NO	Number of Bottles: 1	Preserved With: ICE
NW-UWF-ECQ	Template: DEFAULT	(SM 9223 B Quanti-Tray) E. coli by Colilert-18/QT by UWF in Pensacola
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2015) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: TEST HAS NO	Number of Bottles: 1	Preserved With: ICE
NW-UWF-ENQ	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert/QT by UWF in Pensacola
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.