

RQ-20 22-03-21-14 **Login Checklist**

Login Station ID: #2

Shipping Method: ☒ FedEx ☒ UPS ☐ HD ☐ Greyhound

Date/Time of Receipt: 5/19/2022 12:40

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
3.1				1		✓			

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR#
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR#
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR#
- If coolers or samples are received late; identify the affected samples in an NCR. NCR#

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes No ☒

CONTAINER CHECK

Evidence Tape on Bottles?

Yes No NA ☒

Evidence Tape intact? Yes No

If Criminal, photographs taken?

Yes No

Containers intact? Yes ☒ No

Caps on tight?

Yes ☒ No

Sufficient Sample Volume:

Yes ☒ No

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR#

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes No ☒ Init: IM

Chlorine detected? (One container checked per Field ID)

Yes No Init:

If chlorine is detected, generate an NCR listing affected sample IDs . NCR#

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes ☒ No NA Init: IM

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes No NA ☒ Init: IM

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR#

Coolers Unpacked/Checked by: IM

Date: 5/19/2022

Event contains NCRs (Y/N)?

Event ID: Run 2
TLH-ROC-2022-05-19-01 (SMP)
Date Received: 19-MAY-2022 12:40

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #2 exp:10/19/22
pH Test Strips 0 – 6	
pH Paper 0 – 3	
pH Paper 0 – 13	210620 exp: 4/15/23
Chlorine Test Strips	0070 exp: 02/2023

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 5/19/2022
Customer: TLH-DIST
RQ: RQ-2022-03-21-14
Collected By: Jade Burtchett, Trey Fitzgerald
Sampling Agency: FDEP
Project ID: SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1 **Delivery Method:** HandDelivered

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
New River @ SR22	 G2TLHR0091

RELINQUISHED BY(SIGNATURE):



DATE/TIME: 5/19/2022
1600 EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By:

IM

Rec'd/Inspected
Date:

5/19/22



RQ-2022-03-21-14

Customer: FDEP

Project ID: SMP

Collected By: Jade Burtchett, Trey Fitzgerald

Field Report Prepared by: Jade Burtchett, Trey Fitzgerald

Sampling Agency: FDEP

WIN ID/Field ID:



WIN ID/Field ID: G2TLHR0091

Comments:

Location:

Location: New River @ SR22

Matrix: Fresh

(Check One)

☒ Grab

☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT)
5/19/2022 1050	4.74	59.5	26.9	4.47	0.15	0.3	0.3	34.1	0.01

Parameter Suite	Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP				Ice	H2SO4*		<2		
	Lot #		Exp:							
Metals (P-500ML)	X	W-ICPMS	X	W-ICP	X	W-HARD	X	Ice	X	HNO3*
	Lot #		1286110		Exp:		11/22		X	<2
Filtered Nutrients (P125ML)	W-PO4-F		Field Filtered 0.45 µm Filter		Ice					
	Filter Lot #		Syringe Lot #							
BOD (BP-1L)	OV-BODUNIN				Ice					
Chlorophyll (BP-1L)	CHLSUITE-W				Ice					
Physical/Aggregate (Fresh) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY / W-CI-IC / W-COLOR / W-SO4-IC / W-TDS				Ice					
Physical/Aggregate (Marine) (P-1L)	Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY				Ice					
Macroinvertebrates (PJ-2L)	MI-FW-QLDC	Formalin Lot #				Formalin				
Periphyton (PT-50ML)	ALGAE-ID				Ice					
Microbiology (Contract Lab Bottle)	E Coli		F Coli		Enterococci		Ice			
	Contract Lab									
Molecular (QPCR-P-500ML)	PCR-HF183		PCR-BacR		PCR-DG3		Ice			
	PCR-GULL2		PCR-GFD							
Tracers (BG-500ML)	W-E8321-DI		W-E8321-MS		Ice					
Pesticides (BG-500ML) (BG-1L)	W-E8321-DI	W-E8321-MS		W-PSNP-TQ		Ice	MCAA Exp.	MCAA Lot#		
	W-PCL-TQ-R	W-CARB-AA (5 ml of MCAA Buffer Solution)		W-CT-CL-R						
	W-TR-SQ-R	W-PCB-TQ-R								
Phytoplankton	DTY-QN-C		PKD-QN-BV		Ice					

Date of Request: 10-FEB-2022
 Created By: ECKLES_M On: 10-FEB-2022
 Modified By: JASROTIA_P On: 01-MAR-2022
 Customer: TLH-ROC
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Not Applicable
 Event Description: Run 2

Send Coolers To:

Phone: 850-245-7586
 2600 Blair Stone Rd

 Tallahassee, FL 32399
 Attn: Michael Eckles
 Cooler Ship EMail: michael.eckles@dep.state.fl.us

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 01-MAR-2022
 Biology Request Reviewed By: JASROTIA_P On: 01-MAR-2022
 Sampling Kit Required: YES Ship on: 11-MAR-2022
 Sampling Kit Shipped: YES On: 14-MAR-2022
 Sampling Kit Packed By: SHAIK_A
 Preservatives Needed: NO
 Date to Receive Samples: 21-MAR-2022
 Logged In By: SHAIK_A On: 04-APR-2022

Send Final Report To:

2600 Blair Stone Rd

 Tallahassee, FL 32399
 Attn: Michael Eckles
 Report Notification EMail:
 michael.eckles@floridadep.gov; terry.green@floridadep.gov

Comments: Group A WBID 3724 (0115 & 0116)
 Group B WBID 3573B (0065)
 Group C WBID 3603 (0005)

No fedex labels

Bottle Group A (Water) With 2 Samples:

Bottle Type: P-1L	Number of Bottles: 2	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 2	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 2	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems
Bottle Type: P-250ML-WO-THI	Number of Bottles: 2	Preserved With: ICE
FCOLI-MF	Template: DEFAULT	(SM 9222 D) Fecal coliforms by membrane filter method - non-chlorinated water systems
Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
-----------------------------	----------------------	---------------------

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-250ML-WO-THI Number of Bottles: 1 Preserved With: ICE
 ECOLI-18QT Template: DEFAULT (SM 9223 B Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems

Bottle Type: P-500ML Number of Bottles: 1 Preserved With: HNO3
 W-HARD Template: DEFAULT (SM 2340 B-2011) Hardness by calculation, in aqueous matrices, reported as mg/L CaCO3
 Hardness
 W-ICP Template: SMP-FRESH (EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects

Calcium
 Iron
 Magnesium
 Potassium
 Sodium
 Strontium
 Tin
 Titanium
 Vanadium
 Zinc

W-ICPMS Template: DEFAULT (EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects

*Boron
 Aluminum
 Antimony
 Arsenic
 Barium
 Beryllium
 Cadmium
 Chromium
 Cobalt
 Copper
 Lead
 Manganese
 Molybdenum
 Nickel
 Selenium
 Silver
 Thallium

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-250ML-WO-THI Number of Bottles: 1 Preserved With: ICE
 ECOLI-18QT Template: DEFAULT (SM 9223 B Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.