

Chemical Analysis Report

TLH-ROC-2022-07-20-01

Florida Department of Environmental Protection
Central Laboratory
2600 Blair Stone Road
Tallahassee, FL 32399-2400
DOH Accreditation E31780

Event Description: **Run 12**
Request ID: **RQ-2022-06-20-24**
Customer: **TLH-ROC**
Project ID: **SMP**

Send Reports to:
FL Dept. of Environmental Protection
2600 Blair Stone Rd
Tallahassee, FL 32399
Attn: Michael Eckles

For additional information please contact
Colin Wright, Ph.D.
Liang-Tsair Lin, Ph.D.
Kerry Tate, Ph.D.
Dr. rer. nat. Bettina Steinbock
Thekkekalathil Chandrasekhar, Ph.D, QA Officer
Phone (850) 245-8085

Certified by: Dr. rer. nat. Bettina Steinbock, Environmental Administrator

Date Certified: 04-AUG-2022 13:19



Case Narrative

Unless otherwise noted, all samples included in this report were received in accordance with protocols referenced in Chapter 62-160, Florida Administrative Code (F.A.C.). Results published in this report pertain only to the samples as submitted to, and received by the laboratory. All times in this report are adjusted to the applicable Eastern Time Zone (EST or EDT).

Results for the following analytical groups are included in this report: Nutrients and Pesticides.

Scientific notation may be used in reporting very large or small values. Values reported using scientific notation will take the form of the following example: 1.3E+03, which is equivalent to 1.3×10^3 or 1300.

Unless otherwise noted, analytical values for soil and sediment samples are reported on a dry weight basis, and analytical values for waste and tissue samples are reported on a wet weight basis.

Results for TNI accredited tests met requirements established by The NELAC Institute. A double asterisk (**) is used to indicate an analyte/matrix/method for which the laboratory is not TNI accredited by the Florida Department of Health Environmental Laboratory Certification Program or where accreditation for that field of testing is not applicable.

Any significant anomalies or deviations from established protocols are documented in Non-Conformance Reports, which, where appropriate, are included within this analytical report. Additional comments related to specific analytical tests may be included as remarks following the analytical results for each sample. Such comments and remarks are for informational purposes only and are not intended to convey judgement about the usability of the reported data.

A quality control report on the performance of the test method for the submitted samples is included. Uncertainty associated with the analytical results contained in this report can be estimated from the reported quality assurance results and from published quality control acceptance limits for each analytical test. Matrix quality control results (matrix spike recoveries and matrix sample precision) pertain only to the matrix sample tested and do not necessarily reflect test method performance for other samples.

Typical matrix quality control (QC) measurements may include matrix spike recovery, matrix spike duplicate recovery, matrix spike precision and matrix sample precision. Not all matrix QC results may be available or reportable; where they are not an explanation is provided. Typical reasons for unavailable QC results include, but are not limited to, a) insufficient matrix sample to perform some or all QC measurements; b) analyte concentration in the sample replicated was too low for a meaningful measurement of precision and c) analyte concentration in the matrix sample spiked was too high (relative to the amount of analyte spiked) for a meaningful measurement of recovery. Where matrix QC results are unavailable, other method performance metrics (e.g., LCS recovery, LCS precision, surrogate recovery) may be used to assess performance of the method. Comments explaining any missing QC measurements are not intended to convey any adverse conclusions about the quality of the reported data.

Precision is reported as relative percent difference unless otherwise noted.

Quality Control codes as defined below may be used in this report to indicate results that are associated with one or more quality control elements which did not fall within established test method criteria. Such results may be qualified as estimates using a J qualifier as required by 62-160 F.A.C. Explanations are included in the report for any results that were reported as estimates for other reasons.

QC Codes used in this report may include:

- LCS – Recovery for the batch Laboratory Control Sample (LCS) was outside existing control limits;
- MS – Recovery for the batch matrix spike (MS) was outside existing control limits;
- CCV – Recovery for a continuing calibration verification (CCV) standard was outside existing control limits;
- SUR – Recovery of a surrogate (SUR) for associated analytes was outside existing control limits;
- RPD – The precision, measured as relative percent difference (RPD), of batch replicate measurements was outside existing control limits;
- RSD – The precision, measured as relative standard deviation (RSD), of batch replicate measurements was outside existing control limits;
- SMP – Sample - used precision derived from replicate analyses of a sample;

The following data qualifiers are used, where applicable, in this report as specified in 62-160 F.A.C.

- A - Value reported is the mean of two or more determinations.
- B - Results based on colony counts outside the acceptable range.
- I - The reported value is between the laboratory method detection limit and the laboratory practical quantitation limit.
- J - Estimated value and/or the analysis did not meet established quality control criteria.
- K - Actual value is known to be less than value given.
- L - Actual value is known to be greater than value given.
- N - Presumptive evidence of presence of material.
- O - Sampled, but analysis lost or not performed.
- Q - Sample held beyond normal holding time.
- T - Value reported is less than the criterion of detection.
- U - Material was analyzed for but not detected. The reported value is the method detection limit for the sample analyzed.
- V - Analyte was detected in both sample and method blank.
- X - Too few individuals to calculate SCI value.
- Y - The laboratory analysis was from an unpreserved or improperly preserved sample. The data may not be accurate.
- Z - Colonies were too numerous to count (TNTC).

Quality control information from overflow laboratories may not be included in this report. Please refer to the associated report from the overflow laboratory for additional information.

Sample Location: Parker Bayou @ Mouth

Collection Date/Time: 07/20/2022 10:15

Field ID: G3TLHR0043

Matrix: W-SURF-SLT

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2342869	EPA 180.1 Rev. 2.0	Turbidity	2.2		NTU	P416928	
	SM 2320 B-2011	Total Alkalinity	41		mg CaCO3/L	P417217	
	SM 2540 D-2011	TSS	4	I	mg/L	P417293	
	SM 4500-F- C-2011	Fluoride	0.38		mg F/L	P417220	
2342871	EPA 350.1 Rev. 2.0	Ammonia-N	0.023		mg N/L	P417257	
	EPA 351.2 Rev. 2.0	Kjeldahl Nitrogen	0.48		mg N/L	P417235	
	EPA 353.2 Rev. 2.0	NO2NO3-N	0.013		mg N/L	P417166	
	EPA 365.1 Rev. 2.0	Total-P	0.011		mg P/L	P416948	
	SM 5310 B-2011	Organic Carbon	11		mg C/L	P417158	
2342879	EPA 8321B	Acesulfame K	0.10	U	ug/L	P416713	
		2,4-D	0.0075	I	ug/L	P416992	
		AMPA	1.0	U	ug/L	P416713	
		2,4,5-T	0.0040	U	ug/L	P416992	
		Acetaminophen	0.0080	U	ug/L	P416992	
		Acetamiprid	0.0020	U	ug/L	P416992	
		Endothall	0.25	U	ug/L	P416713	MS
		Glufosinate	1.0	U	ug/L	P416713	
		Glyphosate	1.0	U	ug/L	P416713	
		Afidopyropen	0.0020	U	ug/L	P416992	
		Sucralose	0.084		ug/L	P416713	
		Bentazon	8.0E-04	U	ug/L	P416992	
		Benzovindiflupyr	0.0020	U	ug/L	P416992	
		Carbamazepine	8.0E-04	U	ug/L	P416992	
		Clothianidin	0.0020	U	ug/L	P416992	
		Dinotefuran	0.0020	U	ug/L	P416992	
		Diuron	0.0020	U	ug/L	P416992	
		Fenuron	0.032	U	ug/L	P416992	
		Fluridone	8.0E-04	U	ug/L	P416992	
		Imazapyr	0.014	I	ug/L	P416992	
		Hydrocodone	0.0020	U	ug/L	P416992	
		Ibuprofen	0.080	U	ug/L	P416992	
		Imidacloprid	0.0045	I	ug/L	P416992	
		Linuron	0.0040	U	ug/L	P416992	
		Mandestrobin	0.0020	U	ug/L	P416992	
		MCPP	0.0040	U	ug/L	P416992	
		Naproxen	0.0080	U	ug/L	P416992	
		Primidone	0.0040	U	ug/L	P416992	
		Pyraclostrobin	0.0020	U	ug/L	P416992	
		Silvex	0.0040	U	ug/L	P416992	
		Thiamethoxam	0.0020	U	ug/L	P416992	
		Tolfenpyrad	0.0020	U	ug/L	P416992	
		Triclopyr	0.0040	U	ug/L	P416992	

Ref. Method and Comment:

SM 2540 D-2011: Batch relative percent difference is unavailable because of low analyte concentration in the QC sample.

EPA 8321B: Some MDLs are elevated due to required dilution of sample matrix.

Sample Location: Parker Bayou Continuous Monitoring

Collection Date/Time: 07/20/2022 10:30

Field ID: G3TLHR0018

Matrix: W-SURF-SLT

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2342870	EPA 180.1 Rev. 2.0	Turbidity	6.3		NTU	P416928	
	SM 2320 B-2011	Total Alkalinity	64		mg CaCO3/L	P417217	
	SM 2540 D-2011	TSS	4	I	mg/L	P417293	
	SM 4500-F- C-2011	Fluoride	0.58		mg F/L	P417220	
2342872	EPA 350.1 Rev. 2.0	Ammonia-N	0.011		mg N/L	P417257	
	EPA 351.2 Rev. 2.0	Kjeldahl Nitrogen	0.42		mg N/L	P417235	
	EPA 353.2 Rev. 2.0	NO2NO3-N	0.006	I	mg N/L	P417166	
	EPA 365.1 Rev. 2.0	Total-P	0.015		mg P/L	P416948	
	SM 5310 B-2011	Organic Carbon	7.3		mg C/L	P417158	

Ref. Method and Comment:

SM 2540 D-2011: Batch relative percent difference is unavailable because of low analyte concentration in the QC sample.

Quality Assurance Report Method Blank Results

Reference Method: EPA 180.1 Rev. 2.0
Batch ID: P416928

Component	Result	Code	Units
Turbidity	0.10	U	NTU

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P417257

Component	Result	Code	Units
Ammonia-N	0.002	U	mg N/L

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P417235

Component	Result	Code	Units
Kjeldahl Nitrogen	0.080	U	mg N/L

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P417166

Component	Result	Code	Units
NO2NO3-N	0.004	U	mg N/L

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P416948

Component	Result	Code	Units
Total-P	0.002	U	mg P/L

Reference Method: EPA 8321B
Batch ID: P416713

Component	Result	Code	Units
Acesulfame K	0.10	U	ug/L
AMPA	0.10	U	ug/L
Endothall	0.25	U	ug/L
Glufosinate	0.10	U	ug/L
Glyphosate	0.10	U	ug/L
Sucralose	0.010	U	ug/L

Reference Method: EPA 8321B
Batch ID: P416992

Component	Result	Code	Units
2,4-D	0.0020	U	ug/L
2,4,5-T	0.0040	U	ug/L
Acetaminophen	0.0080	U	ug/L
Acetamiprid	0.0020	U	ug/L
Afidopyropen	0.0020	U	ug/L
Bentazon	8.0E-04	U	ug/L
Benzovindiflupyr	0.0020	U	ug/L
Carbamazepine	8.0E-04	U	ug/L
Clothianidin	0.0020	U	ug/L
Dinotefuran	0.0020	U	ug/L
Diuron	0.0020	U	ug/L

Quality Assurance Report

Method Blank Results

Reference Method: EPA 8321B

Batch ID: P416992

Component	Result	Code	Units
Fenuron	0.032	U	ug/L
Fluridone	8.0E-04	U	ug/L
Hydrocodone	0.0020	U	ug/L
Ibuprofen	0.080	U	ug/L
Imazapyr	0.0040	U	ug/L
Imidacloprid	0.0020	U	ug/L
Linuron	0.0040	U	ug/L
Mandestrobin	0.0020	U	ug/L
MCPP	0.0040	U	ug/L
Naproxen	0.0080	U	ug/L
Primidone	0.0040	U	ug/L
Pyraclostrobin	0.0020	U	ug/L
Silvex	0.0040	U	ug/L
Thiamethoxam	0.0020	U	ug/L
Tolfenpyrad	0.0020	U	ug/L
Triclopyr	0.0040	U	ug/L

Reference Method: SM 2320 B-2011

Batch ID: P417217

Component	Result	Code	Units
Total Alkalinity	0.65	U	mg CaCO3/L

Reference Method: SM 2540 D-2011

Batch ID: P417293

Component	Result	Code	Units
TSS	3	U	mg/L

Reference Method: SM 4500-F- C-2011

Batch ID: P417220

Component	Result	Code	Units
Fluoride	0.035	U	mg F/L

Reference Method: SM 5310 B-2011

Batch ID: P417158

Component	Result	Code	Units
Organic Carbon	0.50	U	mg C/L

Quality Assurance Report

Laboratory Control Sample Accuracy

Reference Method: EPA 180.1 Rev. 2.0
Batch ID: P416928

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Turbidity	94.4		P	90 - 110

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P417257

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Ammonia-N	100		P	90 - 110

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P417235

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Kjeldahl Nitrogen	108		P	90 - 110

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P417166

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
NO2NO3-N	103		P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P416948

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Total-P	99.8		P	90 - 110

Reference Method: EPA 8321B
Batch ID: P416713

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Acesulfame K	80.2		P	40 - 150
AMPA	112		P	40 - 150
Endothall	102		P	40 - 150
Glufosinate	128		P	40 - 150
Glyphosate	103		P	40 - 150
Sucralose	102		P	40 - 150

Reference Method: EPA 8321B
Batch ID: P416992

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2,4-D	72.9		P	40 - 150
2,4,5-T	64.6		P	40 - 150
Acetaminophen	85.8		P	30 - 150
Acetamiprid	63.4		P	40 - 150
Afidopyropen	66.2		P	30 - 150
Bentazon	104		P	30 - 150
Benzovindiflupyr	93.8		P	40 - 150
Carbamazepine	92.5		P	40 - 150
Clothianidin	101		P	40 - 150
Dinotefuran	90.9		P	40 - 150
Diuron	80.7		P	40 - 150

Quality Assurance Report Laboratory Control Sample Accuracy

Reference Method: EPA 8321B
Batch ID: P416992

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Fenuron	93.0		P	40 - 150
Fluridone	100		P	40 - 150
Hydrocodone	90.6		P	40 - 150
Ibuprofen	89.2		P	40 - 150
Imazapyr	89.8		P	40 - 150
Imidacloprid	92.2		P	40 - 150
Linuron	87.9		P	40 - 150
Mandestrobin	90.7		P	40 - 150
MCPP	87.6		P	40 - 150
Naproxen	66.2		P	40 - 150
Primidone	79.7		P	40 - 150
Pyraclostrobin	77.1		P	40 - 150
Silvex	55.3		P	40 - 150
Thiamethoxam	90.4		P	40 - 150
Tolfenpyrad	44.8		P	30 - 150
Triclopyr	66.5		P	40 - 150

Reference Method: SM 2320 B-2011
Batch ID: P417217

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Total Alkalinity	100		P	94 - 106

Reference Method: SM 4500-F- C-2011
Batch ID: P417220

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Fluoride	101		P	96 - 104

Reference Method: SM 5310 B-2011
Batch ID: P417158

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Organic Carbon	97.1		P	85 - 115

Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P417257

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2342782	Ammonia-N	101	103	P/P	90 - 110

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P417235

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2343341	Kjeldahl Nitrogen	93.8	93.7	P/P	90 - 110

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P417166

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2342782	NO2NO3-N	106	107	P/P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P416948

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2342195	Total-P	100	100	P/P	90 - 110

Reference Method: EPA 8321B
Batch ID: P416713

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2342112	Acesulfame K	67.2	64.6	P/P	40 - 150
2342112	AMPA	87.5	88.8	P/P	40 - 150
2342112	Endothall	158	148	F/P	40 - 150
2342112	Glufosinate	84.7	85.2	P/P	40 - 150
2342112	Glyphosate	88.0	81.5	P/P	40 - 150
2342112	Sucralose	98.9	96.0	P/P	40 - 150

Reference Method: EPA 8321B
Batch ID: P416992

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2342488	2,4-D	78.5	74.0	P/P	40 - 150
2342488	2,4,5-T	58.5	63.9	P/P	40 - 150
2342488	Acetaminophen	81.5	83.3	P/P	30 - 150
2342488	Acetamiprid	76.2	69.8	P/P	40 - 150
2342488	Afidopyropen	61.9	63.4	P/P	30 - 150
2342488	Bentazon	94.7	109	P/P	30 - 150
2342488	Benzovindiflupyr	75.0	92.8	P/P	40 - 150
2342488	Carbamazepine	84.4	87.8	P/P	40 - 150
2342488	Clothianidin	95.5	94.4	P/P	40 - 150
2342488	Dinotefuran	83.0	87.9	P/P	40 - 150
2342488	Diuron	72.6	74.2	P/P	40 - 150
2342488	Fenuron	87.0	89.2	P/P	40 - 150
2342488	Fluridone	88.2	94.5	P/P	40 - 150
2342488	Hydrocodone	81.8	85.3	P/P	40 - 150
2342488	Ibuprofen	68.7	68.9	P/P	40 - 150
2342488	Imazapyr	75.6	81.9	P/P	40 - 150
2342488	Imidacloprid	89.0	90.5	P/P	40 - 150

Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 8321B
Batch ID: P416992

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2342488	Linuron	83.9	73.8	P/P	40 - 150
2342488	Mandestrobin	79.8	85.4	P/P	40 - 150
2342488	MCPP	79.1	78.8	P/P	40 - 150
2342488	Naproxen	74.4	67.7	P/P	40 - 150
2342488	Primidone	84.8	85.3	P/P	40 - 150
2342488	Pyraclostrobin	74.4	76.0	P/P	40 - 150
2342488	Silvex	59.0	65.8	P/P	40 - 150
2342488	Thiamethoxam	84.9	87.1	P/P	40 - 150
2342488	Tolfenpyrad	47.5	49.4	P/P	30 - 150
2342488	Triclopyr	64.1	68.1	P/P	40 - 150

Reference Method: SM 4500-F- C-2011
Batch ID: P417220

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2343211	Fluoride	99.4	98.6	P/P	94 - 104

Reference Method: SM 5310 B-2011
Batch ID: P417158

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2341796	Organic Carbon	91.1	90.3	P/P	85 - 115

Quality Assurance Report Precision

Reference Method: EPA 180.1 Rev. 2.0
Batch ID: P416928

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2342916	Turbidity	0.613	Sample	P	0 - 20

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P417257

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2342782	Ammonia-N	1.88	Spike	P	0 - 20

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P417235

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2343341	Kjeldahl Nitrogen	0.134	Spike	P	0 - 20

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P417166

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2342782	NO2NO3-N	0.456	Spike	P	0 - 20

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P416948

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2342195	Total-P	0.435	Spike	P	0 - 20

Reference Method: EPA 8321B
Batch ID: P416713

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2342112	Acesulfame K	4.01	Spike	P	0 - 30
2342112	AMPA	1.43	Spike	P	0 - 30
2342112	Endothall	7.17	Spike	P	0 - 30
2342112	Glufosinate	0.539	Spike	P	0 - 30
2342112	Glyphosate	7.69	Spike	P	0 - 30
2342112	Sucralose	2.96	Spike	P	0 - 30

Reference Method: EPA 8321B
Batch ID: P416992

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2342488	2,4-D	5.91	Spike	P	0 - 30
2342488	2,4,5-T	8.79	Spike	P	0 - 30
2342488	Acetaminophen	2.14	Spike	P	0 - 30
2342488	Acetamidrid	8.76	Spike	P	0 - 30

Quality Assurance Report Precision

Reference Method: EPA 8321B
Batch ID: P416992

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2342488	Afidopyropen	2.46	Spike	P	0 - 30
2342488	Bentazon	14.2	Spike	P	0 - 30
2342488	Benzovindiflupyr	21.3	Spike	P	0 - 30
2342488	Carbamazepine	3.87	Spike	P	0 - 30
2342488	Clothianidin	1.10	Spike	P	0 - 30
2342488	Dinotefuran	5.69	Spike	P	0 - 30
2342488	Diuron	2.17	Spike	P	0 - 30
2342488	Fenuron	2.48	Spike	P	0 - 30
2342488	Fluridone	6.89	Spike	P	0 - 30
2342488	Hydrocodone	4.15	Spike	P	0 - 30
2342488	Ibuprofen	0.292	Spike	P	0 - 30
2342488	Imazapyr	7.95	Spike	P	0 - 30
2342488	Imidacloprid	1.70	Spike	P	0 - 30
2342488	Linuron	12.8	Spike	P	0 - 30
2342488	Mandestrobin	6.73	Spike	P	0 - 30
2342488	MCPP	0.342	Spike	P	0 - 30
2342488	Naproxen	9.37	Spike	P	0 - 30
2342488	Primidone	0.636	Spike	P	0 - 30
2342488	Pyraclostrobin	2.16	Spike	P	0 - 30
2342488	Silvex	10.9	Spike	P	0 - 30
2342488	Thiamethoxam	2.59	Spike	P	0 - 30
2342488	Tolfenpyrad	3.91	Spike	P	0 - 30
2342488	Triclopyr	6.00	Spike	P	0 - 30

Reference Method: SM 2320 B-2011
Batch ID: P417217

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2343211	Total Alkalinity	0.165	Sample	P	0 - 3.8

Reference Method: SM 4500-F- C-2011
Batch ID: P417220

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2343211	Fluoride	0.483	Spike	P	0 - 1.6

Reference Method: SM 5310 B-2011
Batch ID: P417158

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2341796	Organic Carbon	0.767	Spike	P	0 - 20

* Sample, spike and/or laboratory control sample precision (LCS) is reported.

Quality Assurance Report Surrogates

Lab Sample ID: 2342879

Field Sample ID: G3TLHR0043

Reference Method	Surrogate	% Rec.	Pass/Fail	Control Limits
EPA 8321B	2,4-D-d3	91.4	P	30 - 160
EPA 8321B	Acetaminophen-d4	100	P	30 - 160
EPA 8321B	Carbamazepine-d10	101	P	30 - 160
EPA 8321B	Diuron-d6	81.7	P	30 - 160
EPA 8321B	Endothall-d6	82.2	P	30 - 160
EPA 8321B	Glyphosate 13C 15N	115	P	30 - 160
EPA 8321B	Ibuprofen-d3	73.6	P	30 - 160
EPA 8321B	Primidone-d5	103	P	30 - 160
EPA 8321B	Sucralose-d6	88.5	P	30 - 160

Quality Assurance Report Calibration Verification

Reference Method: EPA 180.1 Rev. 2.0

Run ID: A113620

Included Lab Sample IDs: 2342869, 2342870

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Turbidity	98.0	98.0	P/P	95 - 105

Reference Method: EPA 8321B

Run ID: A113640

Included Lab Sample IDs: 2342879

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Acesulfame K	82.1	81.2	P/P	60 - 160
Sucralose	99.0	96.7	P/P	60 - 160

Reference Method: EPA 8321B

Run ID: A113642

Included Lab Sample IDs: 2342879

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
AMPA	111	112	P/P	60 - 160
Endothall	99.7	92.9	P/P	60 - 160
Glufosinate	108	98.7	P/P	60 - 160
Glyphosate	106	97.2	P/P	60 - 160

Reference Method: EPA 8321B

Run ID: A113656

Included Lab Sample IDs: 2342879

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
2,4-D	84.4	83.1	P/P	50 - 150
2,4,5-T	99.7	93.3	P/P	50 - 150
Acetaminophen	96.1	98.7	P/P	60 - 160
Acetamiprid	97.4	102	P/P	50 - 150
Afidopyropen	85.7	103	P/P	50 - 150
Bentazon	111	111	P/P	50 - 160
Benzovindiflupyr	107	113	P/P	50 - 150
Carbamazepine	98.7	96.7	P/P	60 - 150
Clothianidin	101	109	P/P	60 - 150
Dinotefuran	97.4	93.7	P/P	50 - 150
Diuron	105	111	P/P	60 - 160
Fenuron	95.0	95.4	P/P	60 - 150
Fluridone	110	109	P/P	60 - 160
Hydrocodone	95.5	97.8	P/P	60 - 150
Ibuprofen	73.1	65.7	P/P	50 - 160
Imazapyr	83.4	77.8	P/P	50 - 150
Imidacloprid	96.0	101	P/P	60 - 150
Linuron	96.8	88.6	P/P	60 - 150
Mandestrobin	102	104	P/P	50 - 150
MCPP	96.6	87.5	P/P	50 - 150
Naproxen	104	117	P/P	50 - 160
Primidone	96.4	95.3	P/P	60 - 150
Pyraclostrobin	96.2	96.3	P/P	60 - 150
Silvex	79.5	84.9	P/P	50 - 150
Thiamethoxam	96.2	99.5	P/P	50 - 150
Tolfenpyrad	96.5	97.0	P/P	60 - 150

Quality Assurance Report Calibration Verification

Reference Method: EPA 8321B
Run ID: A113656
Included Lab Sample IDs: 2342879

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Triclopyr	74.6	86.5	P/P	50 - 150

Reference Method: EPA 365.1 Rev. 2.0
Run ID: A113693
Included Lab Sample IDs: 2342871, 2342872

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Total-P	99.5	100	P/P	90 - 110

Reference Method: SM 5310 B-2011
Run ID: A113703
Included Lab Sample IDs: 2342871, 2342872

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Organic Carbon	91.2	93.4	P/P	90 - 110

Reference Method: EPA 353.2 Rev. 2.0
Run ID: A113707
Included Lab Sample IDs: 2342871, 2342872

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
NO2NO3-N	103	104	P/P	90 - 110

Reference Method: SM 2320 B-2011
Run ID: A113724
Included Lab Sample IDs: 2342869, 2342870

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Total Alkalinity	98.1	99.4	P/P	90 - 110
Total Alkalinity	99.4	98.3	P/P	90 - 110

Reference Method: SM 4500-F- C-2011
Run ID: A113724
Included Lab Sample IDs: 2342869, 2342870

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Fluoride	104	104	P/P	90 - 110

Reference Method: EPA 350.1 Rev. 2.0
Run ID: A113739
Included Lab Sample IDs: 2342871, 2342872

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Ammonia-N	99.6	98.4	P/P	90 - 110

Reference Method: EPA 351.2 Rev. 2.0
Run ID: A113764
Included Lab Sample IDs: 2342871, 2342872

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Kjeldahl Nitrogen	97.5	99.8	P/P	90 - 110

Quality Assurance Report Calibration Verification

Reference Method: EPA 351.2 Rev. 2.0

Run ID: A113764

Included Lab Sample IDs: 2342871, 2342872

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Kjeldahl Nitrogen	99.8	99.6	P/P	90 - 110

* Pass/Fail determinations are made for each bracketing calibration verification check.

Control limits for initial calibration checks may be different from those for continuing checks, depending on method requirements.

Where they are different, both control limits are provided.

Quality Assurance Report Summary

Ref. Method	Analyte	LCS % Recovery	MS % Recovery		Precision SMP	MS
					LCS	
EPA 180.1 Rev. 2.0	Turbidity	94.4			0.613	
EPA 350.1 Rev. 2.0	Ammonia-N	100	101	103		1.88
EPA 351.2 Rev. 2.0	Kjeldahl Nitrogen	108	93.8	93.7		0.134
EPA 353.2 Rev. 2.0	NO ₂ NO ₃ -N	103	106	107		0.456
EPA 365.1 Rev. 2.0	Total-P	99.8	100	100		0.435
EPA 8321B	2,4-D	72.9	78.5	74.0		5.91
	2,4,5-T	64.6	58.5	63.9		8.79
	Acesulfame K	80.2	67.2	64.6		4.01
	Acetaminophen	85.8	81.5	83.3		2.14
	Acetamiprid	63.4	76.2	69.8		8.76
	Afidopyropen	66.2	61.9	63.4		2.46
	AMPA	112	87.5	88.8		1.43
	Bentazon	104	94.7	109		14.2
	Benzovindiflupyr	93.8	75.0	92.8		21.3
	Carbamazepine	92.5	84.4	87.8		3.87
	Clothianidin	101	95.5	94.4		1.10
	Dinotefuran	90.9	83.0	87.9		5.69
	Diuron	80.7	72.6	74.2		2.17
	Endothall	102	158	148		7.17
	Fenuron	93.0	87.0	89.2		2.48
	Fluridone	100	88.2	94.5		6.89
	Glufosinate	128	84.7	85.2		0.539
	Glyphosate	103	88.0	81.5		7.69
	Hydrocodone	90.6	81.8	85.3		4.15
	Ibuprofen	89.2	68.7	68.9		0.292
	Imazapyr	89.8	75.6	81.9		7.95
	Imidacloprid	92.2	89.0	90.5		1.70
	Linuron	87.9	83.9	73.8		12.8
	Mandestrobin	90.7	79.8	85.4		6.73
	MCPP	87.6	79.1	78.8		0.342
	Naproxen	66.2	74.4	67.7		9.37
	Primidone	79.7	84.8	85.3		0.636
	Pyraclostrobin	77.1	74.4	76.0		2.16
	Silvex	55.3	59.0	65.8		10.9
	Sucralose	102	98.9	96.0		2.96
	Thiamethoxam	90.4	84.9	87.1		2.59
	Tolfenpyrad	44.8	47.5	49.4		3.91
	Triclopyr	66.5	64.1	68.1		6.00
SM 2320 B-2011	Total Alkalinity	100			0.165	
SM 4500-F- C-2011	Fluoride	101	99.4	98.6		0.483
SM 5310 B-2011	Organic Carbon	97.1	91.1	90.3		0.767

Reference Method Descriptions

Method	Description	Associated Samples
EPA 180.1 Rev. 2.0	Turbidity in aqueous matrices	2342869, 2342870
EPA 350.1 Rev. 2.0	Ammonia in aqueous matrices as mg N/L	2342871, 2342872
EPA 351.2 Rev. 2.0	Total Kjeldahl Nitrogen in aqueous matrices	2342871, 2342872
EPA 353.2 Rev. 2.0	Nitrite/Nitrate in aqueous matrices as mg N/L	2342871, 2342872
EPA 365.1 Rev. 2.0	Total Phosphorus in aqueous matrices as mg P/L	2342871, 2342872
EPA 8321B	Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS	2342879
SM 2320 B-2011	Alkalinity in aqueous matrices as mg CaCO ₃ /L	2342869, 2342870
SM 2540 D-2011	Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample	2342869, 2342870

Reference Method Descriptions

Method	Description	<u>Associated Samples</u>
SM 4500-F- C-2011	Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)	2342869, 2342870
SM 5310 B-2011	Nonpurgeable Organic Carbon in aqueous matrices	2342871, 2342872

Preparation and Analysis Log

Ref. Method	Received Date	Prep Date/Time	Prepared By	Analysis Date/Time	Analyzed By	Associated Samples
EPA 180.1 Rev. 2.0	07/20/2022			07/20/2022 16:13	Anna M. Plaviak	2342870
	07/20/2022			07/20/2022 16:17	Anna M. Plaviak	2342869
EPA 350.1 Rev. 2.0	07/20/2022			07/27/2022 11:22	Judith K. Clark	2342871
	07/20/2022			07/27/2022 11:23	Judith K. Clark	2342872
EPA 351.2 Rev. 2.0	07/20/2022	07/27/2022 11:55	Simonne.V. Calhoun	07/28/2022 12:21	Samantha L Bates	2342871
	07/20/2022	07/27/2022 11:55	Simonne.V. Calhoun	07/28/2022 12:26	Samantha L Bates	2342872
EPA 353.2 Rev. 2.0	07/20/2022			07/26/2022 11:03	Beverly Y. Sanders	2342871
	07/20/2022			07/26/2022 11:04	Beverly Y. Sanders	2342872
EPA 365.1 Rev. 2.0	07/20/2022	07/22/2022 16:03	Adam P Silver	07/25/2022 14:54	James L Waggerby	2342871
	07/20/2022	07/22/2022 16:03	Adam P Silver	07/25/2022 14:55	James L Waggerby	2342872
EPA 8321B	07/20/2022	07/20/2022 14:30	Umesh Chiluwal	07/20/2022 21:43	Umesh Chiluwal	2342879
	07/20/2022	07/20/2022 14:30	Umesh Chiluwal	07/21/2022 06:09	Umesh Chiluwal	2342879
	07/20/2022	07/20/2022 14:30	Umesh Chiluwal	07/21/2022 09:36	Umesh Chiluwal	2342879
	07/20/2022	07/22/2022 09:30	June Rhew	07/23/2022 11:06	Juyoung Kim	2342879
SM 2320 B-2011	07/20/2022			07/27/2022 03:28	Dale L. Simmons	2342869
	07/20/2022			07/27/2022 06:14	Dale L. Simmons	2342870
SM 2540 D-2011	07/20/2022			07/22/2022 15:32	Yijie Li	2342869, 2342870
SM 4500-F- C-2011	07/20/2022			07/26/2022 23:57	Dale L. Simmons	2342869
	07/20/2022			07/27/2022 00:44	Dale L. Simmons	2342870
SM 5310 B-2011	07/20/2022			07/23/2022 09:09	Touraj Touran	2342871
	07/20/2022			07/23/2022 09:23	Touraj Touran	2342872