

RQ- 2022-08-15-32

Login Checklist

Login Station ID: #1

Shipping Method: FedEx | UPS | HD Greyhound

Date/Time of Receipt: 8/30/22 @ 15:30

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
-0.3				4		☒			

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No ☐

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes ☐ No ☐

CONTAINER CHECK

Evidence Tape on Bottles?

Yes ☐ No ☐ NA ☒Evidence Tape intact? Yes ☐ No ☐

If Criminal, photographs taken?

Yes ☐ No ☐Containers intact? Yes ☒ No ☐

Caps on tight?

Yes ☒ No ☐

Sufficient Sample Volume:

Yes ☒ No ☐If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____**CHLORINE CHECK REQUIRED?** (Blue dot on container)Yes ☐ No ☒ Init: gg

Chlorine detected? (One container checked per Field ID)

Yes ☐ No ☐ Init: gg

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes ☒ No ☐ NA ☐ Init: gg

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes ☐ No ☐ NA ☒ Init: gg

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: gg/kk

Date: 8/30/22

Event contains NCRs (Y/N)? NEvent ID: TLH-ROC-2022-08-30-02

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #1 EXP:10-19-22
pH Test Strips 0 – 6	Lot#223819 EXP:8-30-23
pH Paper 0 – 3	
pH Paper 0 – 13	Lot#207621 EXP:3-15-24
Chlorine Test Strips	Lot#0070 EXP:2-23

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 8/30/2022
Customer: TLH-DIST
RQ: RQ-2022-08-15-32
Collected By: Jonathan Woods, Jade Burchett
Sampling Agency: FDEP
Project ID: SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 2

Delivery Method: HandDelivered

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
Parker Creek @ Park	 G3TLHR0040

RELINQUISHED BY(SIGNATURE):



DATE/TIME: 8/30/2022
1600 EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By: 

Rec'd/Inspected
Date: 08/30/22



RQ-2022-08-15-32	Collected By: Jonathan Woods, Jade Burtchett
Customer: FDEP	Field Report Prepared by: Jonathan Woods, Jade Burtchett
Project ID: SMP	Sampling Agency: FDEP

WIN ID/Field ID: 	Comments:
WIN ID/Field ID: G3TLHR0040	

Location:

Location: Parker Creek @ Park

Matrix: Fresh

(Check One) ☒ Grab ☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. ©	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT _h)											
8/30/2022 1120	5.57	69.3	26.4	6.84	0.3	0.4	1	91.9	0.04											
Parameter Suite		Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group									
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP				X	Ice	X	H2SO4*	X	<2	1	C							
		Lot #		2145160		Exp:	6/2/23													
Metals (P-500ML)		W-ICPMS		W-ICP		W-HARD		Ice		HNO3*		<2								
		Lot #				Exp:														
Filtered Nutrients (P125ML)		W-PO4-F		Field Filtered 0.45 µm Filter			Ice		Ice											
		Filter Lot #	Syringe Lot #																	
BOD (BP-1L)		OV-BODUNIN				Ice														
Chlorophyll (BP-1L)	X	CHLSUITE-W				X	Ice									1	C			
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W- TDS				X	Ice									1	C			
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY				Ice														
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #				Formalin													
Periphyton (PT-50ML)		ALGAE-ID				Ice														
Microbiology (Contract Lab Bottle)	X	E Coli		F Coli		Enterococci		x							Ice		1	C		
		Contract Lab																		
Molecular (QPCR-P-500ML)		PCR-HF183		PCR-BacR		PCR-DG3		Ice												
		PCR-GULL2		PCR-GFD																
Tracers (BG-500ML)		W-E8321-DI		W-E8321-MS			Ice													
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI	W-E8321-MS		W-PSNP-TQ		Ice	MCAA Exp.	MCAA Lot#											
		W-PCL-TQ-R	W-CARB-AA (5 ml of MCAA Buffer Solution)		W-CT-CL-R															
		W-TR-SQ-R	W-PCB-TQ-R																	
Phytoplankton		DTY-QN-C		PKD-QN-BV			Ice													

Bottle Group B (Water) With 1 Samples:

Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: CH ₂ ClCOOH and Ice
W-CARB-AA	Template: DEFAULT	(EPA 8321B) Carbamates in water matrices by HPLC/MS/MS
Bottle Type: BG-500ML FILL TO	Number of Bottles: 2	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization
W-PCB-TQ-R	Template: DEFAULT	(EPA 8270E) PCBs in water matrices by GC/MS/MS
W-PCL-TQ-R	Template: DEFAULT	(EPA 8270E) Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS/MS
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: SMP	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO ₃
W-HARD	Template: DEFAULT	(SM 2340 B-2011) Hardness by calculation, in aqueous matrices, reported as mg/L CaCO ₃
Hardness		
W-ICP	Template: SMP-FRESH	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Calcium		
Iron		
Magnesium		
Potassium		
Sodium		
Strontium		
Tin		
Titanium		
Vanadium		
Zinc		
W-ICPMS	Template: DEFAULT	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
Aluminum		
Antimony		
Arsenic		
Barium		
Beryllium		
Boron		
Cadmium		
Chromium		
Cobalt		
Copper		
Lead		
Manganese		
Molybdenum		
Nickel		
Selenium		
Silver		
Thallium		

Bottle Type: BG-1L	Number of Bottles: 4	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS
W-TR-SQ-R	Template:	(EPA 8270E) Analysis of Sunscreen Compounds and Flame Retardants in Water by GC/MS-SIM

Bottle Group C (Water) With 2 Samples:

Bottle Type: P-1L	Number of Bottles: 2	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices

Date of Request: 20-JUL-2022
 Created By: GREEN_C On: 20-JUL-2022
 Modified By: JASROTIA_P On: 28-JUL-2022
 Customer: TLH-ROC
 Project: SMP
 Division:
 District: Not Applicable
 Event Description: June-Aug. North Run

Send Coolers To:

Phone: 850-245-8413
 2600 Blair Stone Rd

 Tallahassee, FL 32399
 Attn: Chris Green
 Cooler Ship EMail: Terry.Green@FloridaDEP.gov

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 27-JUL-2022
 Biology Request Reviewed By: JASROTIA_P On: 28-JUL-2022
 Sampling Kit Required: YES Ship on: 12-AUG-2022
 Sampling Kit Shipped: YES On: 11-AUG-2022
 Sampling Kit Packed By: GIVENS_G
 Preservatives Needed: YES
 Date to Receive Samples: 15-AUG-2022
 Logged In By: GIVENS_G On: 16-AUG-2022

Send Final Report To:

2600 Blair Stone Rd

 Tallahassee, FL 32399
 Attn: Chris Green
 Report Notification EMail: Terry.Green@FloridaDEP.gov

Comments: bottle A (G2/31)
 bottle B (G2/15)
 bottle C (G3/48 - G3/49)
 bottle D (G1/163 - G3/50)
 bottle E (G2/37 - G1/148)

#####

Buffer Solution for W-CARB-AA Bottle Needed

#####

W-TR-SQ-R (sunscreens)

Wash your hands thoroughly and wear gloves. Refrain from using sunscreens on the day of sample collection.

#####

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 B Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: BG-500ML FILL TO	Number of Bottles: 4	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization
W-PCB-TQ-R	Template: DEFAULT	(EPA 8270E) PCBs in water matrices by GC/MS/MS
W-PCL-TQ-R	Template: DEFAULT	(EPA 8270E) Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS/MS

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 B Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction

Bottle Group D (Water) With 2 Samples:

Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: HNO3
W-ICP	Template: SMP-FRESH	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Potassium		
Sodium		
Strontium		
Tin		
Titanium		
Vanadium		
Zinc		
W-ICPMS	Template: DEFAULT	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
Aluminum		
Antimony		
Arsenic		
Barium		
Beryllium		
Boron		
Cadmium		
Chromium		
Cobalt		
Copper		
Lead		
Manganese		
Molybdenum		
Nickel		
Selenium		
Silver		
Thallium		

Bottle Group E (Water) With 2 Samples:

Bottle Type: P-250ML-WO-THI	Number of Bottles: 2	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 B Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.

Bottle Group C (Water) With 2 Samples:

Bottle Type: P-1L W-TSS	Template: DEFAULT	Number of Bottles: 2 (SM 2540 D-2011)	Preserved With: ICE Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L CHLSUITE-W	Template: DEFAULT	Number of Bottles: 2 (SM 10200 H (mod.))	Preserved With: ICE Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI ECOLI-18QT	Template: DEFAULT	Number of Bottles: 2 (SM 9223 B Quanti-Tray)	Preserved With: ICE Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: P-500ML W-HARD Hardness	Template: DEFAULT	Number of Bottles: 2 (SM 2340 B-2011)	Preserved With: HNO3 Hardness by calculation, in aqueous matrices, reported as mg/L CaCO3
W-ICP	Template: SMP-FRESH	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects	
Calcium			
Iron			
Magnesium			
Potassium			
Sodium			
Strontium			
Tin			
Titanium			
Vanadium			
Zinc			
W-ICPMS	Template: DEFAULT	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects	
Aluminum			
Antimony			
Arsenic			
Barium			
Beryllium			
Boron			
Cadmium			
Chromium			
Cobalt			
Copper			
Lead			
Manganese			
Molybdenum			
Nickel			
Selenium			
Silver			
Thallium			

Bottle Type: P-500ML W-NH3	Template: DEFAULT	Number of Bottles: 2 (EPA 350.1 Rev. 2.0)	Preserved With: ICE And H2SO4 Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0)	Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0)	Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0)	Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011)	Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group D (Water) With 2 Samples:

Bottle Type: P-250ML-WO-THI ECOLI-18QT	Template: DEFAULT	Number of Bottles: 2 (SM 9223 B Quanti-Tray)	Preserved With: ICE Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: P-500ML W-HARD Hardness	Template: DEFAULT	Number of Bottles: 2 (SM 2340 B-2011)	Preserved With: HNO3 Hardness by calculation, in aqueous matrices, reported as mg/L CaCO3
W-ICP	Template: SMP-FRESH	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects	
Calcium			
Iron			
Magnesium			