

Login Checklist

RQ- 2022-11-07-71

Login Station ID: 5

Shipping Method: (FedEx) UPS | HD | Greyhound

Date/Time of Receipt: 11 10/ 22 @ 9:35

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
0.3				6		X			5854 4736 6182
2.1				8		X			5859 4736 5193

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes X No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes X No _____

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA X Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No X

Containers intact? Yes X No _____

Caps on tight?

Yes X No _____

Sufficient Sample Volume:

Yes X No _____

If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes X No _____ Init: C.P

Chlorine detected? (One container checked per Field ID)

Yes _____ No X Init: C.P

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH< 2.0?

Yes X No _____ NA _____ Init: C.P

**W-1-4-DIOX (Green dot on container) preserved to pH< 4.0?

Yes _____ No _____ NA X Init: C.P

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: C.P

Date: 11/ 10 /22 Event contains NCRs (Y/N)? N

Event ID: SW-DIST-2022-11-10-01 (SMP)
Date Received: 10-NOV-2022 09:36

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	221426058 10/17/23
pH Test Strips 0 – 6	223819AV 08/30/23
pH Paper 0 – 3	NA
pH Paper 0 – 13	210620 4/15/2023
Chlorine Test Strips	0070 02/2023

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 11/9/2022 **Collected By:** Ben Paswater, Devin Mathias
Customer: SW-DIST **Sampling:** FDEP
RQ: RQ-2022-11-07-31 **Agency:**
Project ID: SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 2

Delivery Method: FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
Myakka River @ Wauchula Road	 G3SW0028
Mobley Ditch at 70	 G3SW0056

RELINQUISHED BY(SIGNATURE):



DATE/TIME: 11/9/2022

1700 EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By:



Rec'd/Inspected

Date: 11-10-2022



RQ-2022-11-07-31

Customer: FDEP

Project ID: SMP

Collected By: Ben Paswater, Devin Mathias

Field Report Prepared by: Ben Paswater, Devin Mathias

Sampling Agency: FDEP

 WIN ID/Field ID: 
 WIN ID/Field ID: G3SW0028

Comments: Microbiology sample(s) submitted to contract laboratory.

Location: Myakka River @ Wauchula Road

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPTH)
11/9/2022 1200	5.72	65.6	22.2	5.56	0.3	0.6	0.6	220.1	0.1

Parameter Suite	Parameter Methods		Preservation	pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP		Ice	H2SO4*	<2	
	Lot #	Exp:				
Metals (P-500ML)	W-ICPMS / W-ICP / W-HARD		Ice	HNO3*	<2	
	Lot #	Exp:				
Filtered Nutrients (P125ML)	W-PO4-F	Field Filtered 0.45 µm Filter	Ice			
	Filter Lot #	Syringe Lot #				
BOD (BP-1L)	OV-BODUNIN		Ice			
Chlorophyll (BP-1L)	CHLSUITE-W		Ice			
Physical/Aggregate (Fresh) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY / W-CL-IC / W-COLOR / W-SO4-IC / W-TDS		Ice			
Physical/Aggregate (Marine) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY		Ice			
Macroinvertebrates (PJ-2L)	MI-FW-QLDC	Formalin Lot #	Formalin			
Periphyton (PT-50ML)	ALGAE-ID		Ice			
Microbiology (Contract Lab Bottle)	X E Coli	F Coli	Enterococci	x	Ice	
	Contract Lab					
Molecular (QPCR-P-500ML)	PCR-HF183	PCR-BacR	PCR-DG3		Ice	
	PCR-GULL2	PCR-GFD				
Tracers (BG-500ML)	W-E8321-DI	W-E8321-MS	Ice			
Pesticides (BG-500ML) (BG-1L)	W-E8321-DI	W-E8321-MS	W-PSNP-TQ		Ice	
	W-PCL-TQ-R	W-CARB-AA (5 ml of MCAA Buffer Solution)	W-CT-CL-R			
	W-TR-SQ-R	W-PCB-TQ-R				
Phytoplankton	DTY-QN-C	PKD-QN-BV	Ice			
DOC	W-DOC	Field Filtered 0.45 µm Filter	Ice	H2SO4*	<2	
		Acid Preservative Expiration Date				
		Acid Preservative Lot Number				



RQ-2022-11-07-31

Customer: FDEP

Project ID: SMP

Collected By: Ben Paswater, Devin Mathias

Field Report Prepared by: Ben Paswater, Devin Mathias

Sampling Agency: FDEP

WIN ID/Field ID:



WIN ID/Field ID: G3SW0056

Comments: Microbiology sample(s) submitted to contract laboratory.

Location: Mobley Ditch at 70

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT)
11/9/2022 1225	2.53	29.4	22.6	7.11	0.3	0.3	1.1	738	0.36

Parameter Suite	Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group		
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	X	<2	1	A
		Lot #		SA2229010	Exp:		8/30/23					
Metals (P-500ML)		W-ICPMS		W-ICP	W-HARD	Ice	HNO3*			<2		
		Lot #			Exp:							
Filtered Nutrients (P125ML)	X	W-PO4-F		X	Field Filtered 0.45 µm Filter		X	Ice			1	A
		Filter Lot #	17232873	Syringe Lot #	1145497							
BOD (BP-1L)		OV-BODUNIN					Ice					
Chlorophyll (BP-1L)	X	CHLSUIE-W				X	Ice			1	A	
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-CL-IC / W-COLOR / W-SO4-IC / W-TDS				X	Ice			1	A	
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY					Ice					
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #				Formalin					
Periphyton (PT-50ML)		ALGAE-ID					Ice					
Microbiology (Contract Lab Bottle)	X	E Coli		F Coli		Enterococci	X	Ice			1	A
	X	Contract Lab										
Molecular (QPCR-P-500ML)		PCR-HF183		PCR-BacR	PCR-DG3		Ice					
		PCR-GULL2		PCR-GFD								
Tracers (BG-500ML)		W-E8321-DI		W-E8321-MS			Ice					
Pesticides (BG-500ML) (BG-1L)	X	W-E8321-DI	X	W-E8321-MS	X	W-PSNP-TQ	X	Ice	MCAA Exp.	MCAA Lot#	10	A
	X	W-PCL-TQ-R	X	W-CAR8-AA (5 ml of MCAA Buffer Solution)	X	W-CT-CL-R			2/4/23	128343		
	X	W-TR-SQ-R	X	W-PCB-TQ-R								
Phytoplankton		DTY-QN-C		PKD-QN-BV			Ice					
DOC		W-DOC		Field Filtered 0.45 µm Filter			Ice		H2SO4*		<2	
				Acid Preservative Expiration Date								
				Acid Preservative Lot Number								

Benchmark EnviroAnalytical, Inc
1711 12th Street East
Palmetto, FL 34221
941-723-9986
941-723-6061 Fax

Client Information: DEP: SW-DIST
Address: 13051 N. Telecom Parkway
Tampa FL 33604
Phone # 815-470-5878

PO#_C00EF5

Report to: benjamin.paswater@dep.state.fl.us
DEP-Overflomicro@dep.state.fl.us

Invoice to: FDEP Micro Overflow

Project Name: RQ-2022-11-07-3

Laboratory Submission # 22110518

Sample Name	Sample Type / Sample Matrix ²	Collection		Container		Preservative ⁴	Parameters for Analysis	Laboratory Sample #
		Date	Time	Qty	Type ³			
G3SW0028	SW	11/9/22	1200	1	250mL	P	E-Coli	1
G3SW0056	SW	↓	1225	1	250mL	P	E-Coli	2
	SW				250mL	P		
	SW				250mL	P		
	SW				250mL	P		
	SW				250mL	P		
	SW				250mL	P		
	SW				250mL	P		

¹ "Sample Type" is used to indicate whether the sample was a grab (G) or whether it was a composite (C).
² "Sample Matrix" is used to indicate whether the sample is being analyzed for drinking water (DW), groundwater (GW), surface water (SW), fresh surface water (FSW), saline surface water (SSW), soil, sediment (SD), or sludge (SL).
³ "Container Type" is used to indicate the type of container used for the sample. The container should be labeled with the sample ID and the date and time of collection. The container should be clean and free of any residue.
⁴ "Preservative" is used to indicate the type of preservative used for the sample. The preservative should be added to the sample immediately after collection and before the sample is analyzed.

⁵ "Temperature" is used to indicate the temperature of the sample at the time of collection. The temperature should be recorded in degrees Celsius (°C) or degrees Fahrenheit (°F).
⁶ "Date and Time of Collection" is used to indicate the date and time of collection. The date and time should be recorded in the format MM/DD/YYYY HH:MM.
⁷ "Date and Time of Analysis" is used to indicate the date and time of analysis. The date and time should be recorded in the format MM/DD/YYYY HH:MM.

Laboratory Sample Acceptability:
Temperature: 19°C

1	Collected / Relinquished By: Ben Paswater	Date: 11/9/22	Time: 1310	Received By: Nathan Hadsoe	Date: 11-9-22	Time: 1310
2	Relinquished By:	Date:	Time:	Received By:	Date:	Time:

Date of Request: 17-OCT-2022
 Created By: PASWATER_B On: 17-OCT-2022
 Modified By: JASROTIA_P On: 20-OCT-2022
 Customer: SW-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Southwest District
 Event Description: Run 8

Send Coolers To:

Phone: 813-632-7600
 FL Dept. of Environmental Protection
 13051 N. Telecom Parkway
 Temple Terrace, FL 33637-0926
 Attn: Ben Paswater
 Cooler Ship EMail: benjamin.paswater@dep.state.fl.us

Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 20-OCT-2022
 Biology Request Reviewed By: JASROTIA_P On: 20-OCT-2022
 Sampling Kit Required: YES Ship on: 28-OCT-2022
 Sampling Kit Shipped: YES On: 31-OCT-2022
 Sampling Kit Packed By: ROBERTS_Z
 Preservatives Needed: YES
 Date to Receive Samples: 07-NOV-2022
 Logged In By:

Send Final Report To:

FL Dept. of Environmental Protection
 13051 N. Telecom Parkway
 Temple Terrace, FL 33637-0926
 Attn: Ben Paswater
 Report Notification EMail:
 benjamin.paswater@dep.state.fl.us;sarah.meyer@dep.state.fl.us
 ;jacob.yodzis@FloridaDEP.gov

Comments: Owen Creek, Myakka

#####

Buffer Solution for W-CARB-AA Bottle
 1 vial per bottle

#####

W-TR-SQ-R (sunscreens)

Wash your hands thoroughly and wear gloves. Refrain from using sunscreens on the day of sample collection.

#####

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2015) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
SW-BEA-ECQ	Template: DEFAULT	(SM 9223 B Quanti-Tray) E. coli by Colilert/QT by BEA in Palmetto
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: CH ₂ ClCOOH and Ice
W-CARB-AA	Template: DEFAULT	(EPA 8321B) Carbamates in water matrices by HPLC/MS/MS

Bottle Group A (Water) With 1 Samples:

Bottle Type: BG-500ML FILL TO	Number of Bottles: 4	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization
W-PCB-TQ-R	Template: DEFAULT	(EPA 8270E) PCBs in water matrices by GC/MS/MS
W-PCL-TQ-R	Template:	(EPA 8270E) Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS/MS
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: SMP	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
Bottle Type: BG-1L	Number of Bottles: 4	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS
W-TR-SQ-R	Template: DEFAULT	(EPA 8270E) Analysis of Sunscreen Compounds and Flame Retardants in Water by GC/MS-SIM

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
SW-BEA-ECQ	Template: DEFAULT	(SM 9223 B Quanti-Tray) E. coli by Colilert/QT by BEA in Palmetto

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.