

RQ-2022-06-27-07

Login Checklist

Login Station ID: #2

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 7/22/2022 9:22

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
1.8				3		✓			5225 5549 1081

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes _____ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No _____

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA _____

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____

Containers intact? Yes _____ No _____

Caps on tight?

Yes _____ No _____

Sufficient Sample Volume:

Yes _____ No _____

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes _____ No _____ Init: IM

Chlorine detected? (One container checked per Field ID)

Yes _____ No _____ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes _____ No _____ NA _____ Init: IM

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes _____ No _____ NA _____ Init: IM

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: IM

Date: 7/22/2022

Event contains NCRs (Y/N)?

Event ID: _____

Run 10

SW-DIST-2022-07-22-01 (SMP)

Page 1 of 2, 06/15/2020

Date Received: 22-JUL-2022 09:22

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #2 exp:10/19/22
pH Test Strips 0 – 6	
pH Paper 0 – 3	
pH Paper 0 – 13	210620 exp: 4/15/23
Chlorine Test Strips	0070 exp: 02/2023

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 7/21/2022 **Collected By:** Sarah Meyer, Natalie Abdo
Customer: SW-DIST **Sampling Agency:** FDEP
RQ: RQ-2022-06-27-07 **Project ID:** SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1

Delivery Method: FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
White Trout Lake @ Center	 G1SW0104

RELINQUISHED BY(SIGNATURE):

Sarah Meyer

DATE/TIME: 7/21/2022

1600 EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By:

Rec'd/Inspected

Date:



RQ-2022-06-27-07	Collected By: Sarah Meyer, Natalie Abdo
Customer: FDEP	Field Report Prepared by: Sarah Meyer, Natalie Abdo
Project ID: SMP	Sampling Agency: FDEP

WIN ID/Field ID: 	Comments:
WIN ID/Field ID: G1SW0104	

Location:

Location: White Trout Lake @ Center

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. ©	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT _h)							
7/21/2022 950	7.5	101.9	31.5	7.79	0.3	2.5	5	237.4	0.11							
Parameter Suite		Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group					
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP				X	Ice	X	H2SO4*	X	<2	1	B			
		Lot #		SA1308030		Exp:		12/01/2022								
Metals (P-500ML)		W-ICPMS		W-ICP		W-HARD		Ice		HNO3*		<2				
		Lot #				Exp:										
Filtered Nutrients (P125ML)		W-PO4-F		Field Filtered 0.45 um Filter			Ice									
		Filter Lot #	Syringe Lot #													
BOD (BP-1L)		OV-80DUNIN				Ice										
Chlorophyll (BP-1L)	X	CHLSUITE-W				X	Ice							1	B	
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-CL-IC / W-COLOR / W-SO4-IC / W- TDS				X	Ice							1	B	
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY					Ice									
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #				Formalin									
Periphyton (PT-50ML)		ALGAE-ID				Ice										
Microbiology (Contract Lab Bottle)		E Coli		F Coli		Enterococci								Ice		
		Contract Lab														
Molecular (QPCR-P-500ML)		PCR-HF183		PCR-BacR		PCR-DG3								Ice		
		PCR-GULL2		PCR-GFD												
Tracers (BG-500ML)		W-E8321-DI		W-E8321-MS			Ice									
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI	W-E8321-MS		W-PSNP-TQ		Ice	MCAA Exp.	MCAA Lot#							
		W-PCL-TQ-R	W-CARB-AA (5 ml of MCAA Buffer Solution)		W-CT-CL-R											
		W-TR-SQ-R		W-PCB-TQ-R												
Phytoplankton		DTY-QN-C		PKD-QN-BV			Ice									

Date of Request: 15-FEB-2022
 Created By: PASWATER_B On: 15-FEB-2022
 Modified By: AYRES_J On: 27-JUN-2022
 Customer: SW-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Southwest District
 Event Description: Run 10

Send Coolers To:

Phone: 813-632-7600
 FL Dept. of Environmental Protection
 13051 N. Telecom Parkway
 Temple Terrace, FL 33637-0926
 Attn: Ben Paswater
 Cooler Ship EMail: benjamin.paswater@dep.state.fl.us

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 08-JUN-2022
 Biology Request Reviewed By: JASROTIA_P On: 08-JUN-2022
 Sampling Kit Required: YES Ship on: 01-JUL-2022
 Sampling Kit Shipped: YES On: 30-JUN-2022
 Sampling Kit Packed By: SHAIK_A
 Preservatives Needed: YES
 Date to Receive Samples: 27-JUN-2022
 Logged In By: MCCOY_I On: 08-JUL-2022

Send Final Report To:

FL Dept. of Environmental Protection
 13051 N. Telecom Parkway
 Temple Terrace, FL 33637-0926
 Attn: Ben Paswater
 Report Notification EMail:
 benjamin.paswater@dep.state.fl.us;sarah.meyer@dep.state.fl.us
 jacob.yodzis@FloridaDEP.gov

Comments: #####

Buffer Solution for W-CARB-AA Bottle Needed

 W-TR-SQ-R (sunscreen)

Wash your hands thoroughly and wear gloves. Refrain from using sunscreens on the day of sample collection.

#####

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: CH ₂ CICOOH and Ice
W-CARB-AA	Template: DEFAULT	(EPA 8321B) Carbamates in water matrices by HPLC/MS/MS
Bottle Type: BG-500ML FILL TO	Number of Bottles: 4	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization
W-PCB-TQ-R	Template: DEFAULT	(EPA 8270E) PCBs in water matrices by GC/MS/MS

Bottle Group A (Water) With 1 Samples:

Bottle Type: BG-500ML FILL TO	Number of Bottles: 4	Preserved With: ICE
W-PCL-TQ-R Template:	(EPA 8270E)	Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS/MS
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI Template: DEFAULT	(EPA 8321B)	Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS Template: SMP	(EPA 8321B)	Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3 Template: DEFAULT	(EPA 350.1 Rev. 2.0)	Ammonia in aqueous matrices as mg N/L
W-NO2NO3 Template: DEFAULT	(EPA 353.2 Rev. 2.0)	Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP Template: DEFAULT	(EPA 365.1 Rev. 2.0)	Total Phosphorus in aqueous matrices as mg P/L
W-TKN Template: DEFAULT	(EPA 351.2 Rev. 2.0)	Total Kjeldahl Nitrogen in aqueous matrices
W-TOC Template: DEFAULT	(SM 5310 B-2011)	Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F Template: DEFAULT	(EPA 365.1 Rev. 2.0)	Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
W-SO4-IC-F Template: DEFAULT	(EPA 300.0 Rev. 2.1)	Sulfate, dissolved, in filtered, aqueous matrices
Bottle Type: BG-1L	Number of Bottles: 4	Preserved With: ICE
W-PSNP-TQ Template: DEFAULT	(EPA 8270E)	Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS
W-TR-SQ-R Template:	(EPA 8270E)	Analysis of Sunscreen Compounds and Flame Retardants in Water by GC/MS-SIM

Bottle Group B (Water) With 3 Samples:

Bottle Type: P-1L	Number of Bottles: 3	Preserved With: ICE
ALKALINITY Template: DEFAULT	(SM 2320 B-2011)	Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY Template: DEFAULT	(EPA 180.1 Rev. 2.0)	Turbidity in aqueous matrices
W-CL-IC Template: DEFAULT	(EPA 300.0 Rev. 2.1)	Chloride in aqueous matrices
W-COLOR Template: DEFAULT	(DEP SOP: NU-094-1)	True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F Template: DEFAULT	(SM 4500-F- C-2011)	Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TDS Template: DEFAULT	(SM 2540 C-2011)	Total Dissolved Solids in aqueous matrices
W-TSS Template: DEFAULT	(SM 2540 D-2011)	Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 3	Preserved With: ICE
CHLSUITE-W Template: DEFAULT	(SM 10200 H (mod.))	Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-500ML	Number of Bottles: 3	Preserved With: ICE And H2SO4
W-NH3 Template: DEFAULT	(EPA 350.1 Rev. 2.0)	Ammonia in aqueous matrices as mg N/L
W-NO2NO3 Template: DEFAULT	(EPA 353.2 Rev. 2.0)	Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP Template: DEFAULT	(EPA 365.1 Rev. 2.0)	Total Phosphorus in aqueous matrices as mg P/L
W-TKN Template: DEFAULT	(EPA 351.2 Rev. 2.0)	Total Kjeldahl Nitrogen in aqueous matrices
W-TOC Template: DEFAULT	(SM 5310 B-2011)	Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 3	Preserved With: FILTER-ICE
W-PO4-F Template: DEFAULT	(EPA 365.1 Rev. 2.0)	Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
W-SO4-IC-F Template: DEFAULT	(EPA 300.0 Rev. 2.1)	Sulfate, dissolved, in filtered, aqueous matrices

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.