

Login Checklist

RQ- 2022-08-29-01

Login Station ID: #4

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 09/ 1 /22 @ 9:40

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
1.6				6		X			5859-4728 6897

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ✓ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes ✓ No _____

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA X

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____

Containers intact? Yes ✓ No _____

Caps on tight?

Yes ✓ No _____

Sufficient Sample Volume:

Yes ✓ No _____

If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ✓ No _____ Init: R

Chlorine detected? (One container checked per Field ID)

Yes _____ No X Init: R

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH< 2.0?

Yes _____ No _____ NA X Init: R

**W-1-4-DIOX (Green dot on container) preserved to pH<4.0?

Yes _____ No _____ NA X Init: R

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unchecked by: R

Date: 09/ 1 /22

Event contains NCRs (Y/N)? N

Event ID: SW-DIST-2022-09-01-05 (SMP)

Date Received: 01-SEP-2022 09:40

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	#4 Temp Gun EXP:10/19/2022
pH Test Strips 0 – 6	223819AV EXP:08/30/2023
pH Paper 0 – 3	N/A
pH Paper 0 – 13	207621 EXP:03/15/2024
Chlorine Test Strips	0070 EXP:02/2023

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 8/31/2022 **Collected By:** Megan Maloney, Jacob Yodzis
Customer: SW-DIST **Sampling Agency:** FDEP
RQ: RQ-2022-08-29-01 **Project ID:** SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 2

Delivery Method: FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
Wares Crk @ 9th Ave	 G2SW0029
Wares Creek Tidal by Watertower	 G2SW0108
West Cedar Hammock @ American Legion	 G3SW0109

RELINQUISHED BY(SIGNATURE):

Megan Maloney

DATE/TIME: 8/31/2022

1700 EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By: *R*

Rec'd/Inspected Date: 9-1-2022



RQ-2022-08-29-01

Collected By: Megan Maloney, Jacob Yodzis

Customer: FDEP

Field Report Prepared by: Megan Maloney, Jacob Yodzis

Project ID: SMP

Sampling Agency: FDEP

WIN ID/Field ID:



WIN ID/Field ID: G2SW0029

Comments: Microbiology sample(s) submitted to contract laboratory.

Location:

Location: Wares Crk @ 9th Ave

Matrix: Marine

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT)
8/31/2022 915	3.64	48.8	29.5	7.04	0.15	0.3	0.3	5035	2.68

Parameter Suite	Parameter Methods		Preservation	pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP		Ice	H2SO4*		
	Lot #	Exp:		<2		
Metals (P-500ML)	W-ICPMS / W-ICP / W-HARD		Ice	HNO3*		
	Lot #	Exp:		<2		
Filtered Nutrients (P125ML)	W-PO4-F	Field Filtered 0.45 um Filter	Ice			
	Filter Lot #	Syringe Lot #				
BOD (BP-1L)	OV-BODUNIN		Ice			
Chlorophyll (BP-1L)	CHLSUITE-W		Ice			
Physical/Aggregate (Fresh) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W- TDS		Ice			
Physical/Aggregate (Marine) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY		Ice			
Macroinvertebrates (PJ-2L)	MI-FW-QLDC	Formalin Lot #	Formalin			
Periphyton (PT-50ML)	ALGAE-ID		Ice			
Microbiology (Contract Lab Bottle)	E Coli	F Coli	X	Enterococci	x	Ice
	X	Contract Lab				
Molecular (QPCR-P-500ML)	PCR-HF183	PCR-BacR		PCR-DG3		Ice
	PCR-GULL2	PCR-GFD				
Tracers (BG-500ML)	X	W-E8321-DI	X	W-E8321-MS	x	Ice
Pesticides (BG-500ML) (BG-1L)	W-E8321-DI	W-E8321-MS	W-PSNP-TQ			
	W-PCL-TQ-R	W-CAR8-AA (5 ml of MCAA Buffer Solution)	W-CT-CL-R			
	W-TR-SQ-R	W-PCB-TQ-R				
Phytoplankton	DTY-QN-C	PKD-QN-BV				



RQ-2022-08-29-01	Collected By: Megan Maloney, Jacob Yodzis
Customer: FDEP	Field Report Prepared by: Megan Maloney, Jacob Yodzis
Project ID: SMP	Sampling Agency: FDEP

WIN ID/Field ID:



WIN ID/Field ID: G2SW0108

Comments: Microbiology sample(s) submitted to contract laboratory.

Location:

Location: Wares Creek Tidal by Watertower

Matrix: Fresh

(Check One) ☒ Grab ☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. ©	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT)						
8/31/2022 930	4.32	59.3	29.1	7.36	0.3	0.6	0.6	666	0.31						
Parameter Suite		Parameter Methods				Preservation		pH Check	# Bottles sent to Lab	Bottle Group					
Preserved Nutrients (P-500ML)		W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP				Ice		H2SO4*	<2						
		Lot #		Exp:											
Metals (P-500ML)		W-ICPMS		W-ICP		W-HARD		Ice	HNO3*	<2					
		Lot #		Exp:											
Filtered Nutrients (P125ML)		W-PO4-F		Field Filtered 0.45 µm Filter				Ice							
		Filter Lot #		Syringe Lot #											
BOD (BP-1L)		OV-BODUNIN				Ice									
Chlorophyll (BP-1L)		CHLSUITE-W				Ice									
Physical/Aggregate (Fresh) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY / W-CL-IC / W-COLOR / W-SO4-IC / W- TDS				Ice									
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY				Ice									
Macroinvertebrates (PJ-2L)		MI-FW-QLDC		Formalin Lot #		Formalin									
Periphyton (PT-50ML)		ALGAE-ID				Ice									
Microbiology (Contract Lab Bottle)		E Coli		F Coli		X	Enterococci	x					Ice		
		Contract Lab													
Molecular (QPCR-P-500ML)		PCR- HF183		PCR-BacR			PCR-DG3	Ice							
		PCR-GULL2		PCR-GFD											
Tracers (BG-500ML)		W-E8321-DI		W-E8321-MS				Ice							
Pesticides (BG-500ML) (BG-1L)		X	W-E8321-DI	X	W-E8321-MS		X	W-PSNP-TQ	x	Ice	MCAA Exp.	MCAA Lot#	10	A	
		X	W-PCL-TQ-R		X	W-CARB-AA (5 ml of MCAA Buffer Solution)		X			W-CT-CL-R	2/4/23			128343
		X	W-TR-SQ-R		X	W-PCB-TQ-R									
Phytoplankton		DTY-QN-C		PKD-QN-BV				Ice							



RQ-2022-08-29-01

Collected By: Megan Maloney, Jacob Yodzis

Customer: FDEP

Field Report Prepared by: Megan Maloney, Jacob Yodzis

Project ID: SMP

Sampling Agency: FDEP

 WIN ID/Field ID: 
 WIN ID/Field ID: G3SW0109

Comments: Microbiology sample(s) submitted to contract laboratory.

Location:

Location: West Cedar Hammock @ American Legion

Matrix: Fresh

(Check One) ☒ Grab ☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT)
8/31/2022 1000	5.35	69.5	28.7	7.13	0.2	0.4	0.4	1049	0.51

Parameter Suite	Parameter Methods	Preservation	pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP Lot # _____ Exp: _____	Ice H2SO4*	<2		
Metals (P-500ML)	W-ICPMS W-ICP W-HARD Lot # _____ Exp: _____	Ice HNO3*	<2		
Filtered Nutrients (P125ML)	W-PO4-F Field Filtered 0.45 µm Filter Filter Lot # _____ Syringe Lot # _____	Ice			
BOD (BP-1L)	OV-BODUNIN	Ice			
Chlorophyll (BP-1L)	CHLSUITF-W	Ice			
Physical/Aggregate (Fresh) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY / W-CL-IC / W-COLOR / W-SO4-IC / W- TDS	Ice			
Physical/Aggregate (Marine) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY	Ice			
Macroinvertebrates (PJ-2L)	MI-FW-QLDC Formalin Lot # _____	Formalin			
Periphyton (PT-50ML)	ALGAE-ID	Ice			
Microbiology (Contract Lab Bottle)	E Coli F Coli X Enterococci X Contract Lab	x Ice		1	B
Molecular (QPCR-P-500ML)	X PCR-HF183 X PCR-BacR X PCR-DG3 PCR-GULL2 PCR-GFD	x Ice		1	B
Tracers (BG-500ML)	X W-E8321-DI X W-E8321-MS	x Ice		1	B
Pesticides (BG-500ML) (BG-1L)	W-E8321-DI W-E8321-MS W-PSNP-TQ	Ice MCAA Exp. MCAA Lot#			
	W-PCL-TQ-R W-CARB-AA (5 ml of MCAA Buffer Solution) W-CT-CL-R				
	W-TR-SQ-R W-PCB-TQ-R				
Phytoplankton	DTY-QN-C PKD-QN-BV	Ice			

Benchmark EnviroAnalytical, Inc
1711 12th Street East
Palmetto, FL 34221
941-723-9986
941-723-6061 Fax

PO# C00EF5

Client Information: DEP: SW-DIST

Address: 13051 N. Telecom Parkway
Tampa FL 33604

Phone # 815-470-5878

Report to: benjamin.paswater@dep.state.fl.us
DEP-Overflomicro@dep.state.fl.us

Invoice to: FDEP Micro Overflow

Project Name: RQ-2022- 08-29-01

Laboratory Submission # 2208 1840

Sample Name	Sample Type ¹ / Sample Matrix ²	Collection		Qty	Container		Preservative ⁴	Parameters for Analysis	Laboratory Sample #
		Date	Time		Capacity	Type ³			
G2SW0029	SW	8-31-22	9:15	1	250mL	P	Plain (on Ice)	Enteroc	1
G2SW0108	SW	8-31-22	9:30	1	250mL	P	Plain (on Ice)	Enteroc	2
G3SW0109	SW	8-31-22	10:00	1	250mL	P	Plain (on Ice)	Enteroc	3
	SW				250mL	P	Plain (on Ice)		
	SW				250mL	P	Plain (on Ice)		
	SW				250mL	P	Plain (on Ice)		
	SW				250mL	P	Plain (on Ice)		

¹ "Sample Type" is used to indicate whether the sample was a grab (G) or whether it was a composite (C).
² "Sample Matrix" is used to indicate whether the sample is being discharged to drinking water (DW), groundwater (GW), surface water (SW), fresh surface water (FSW), saline surface water (SSW), soil sediment (SIMP), or sludge (SLD).
³ "Container Type" is used to indicate whether the container is plastic (P) or glass (G).
⁴ Sample must be refrigerated or stored in cool box after collection. The temperature during storage should be less than or equal to 4°C (42.8°F).
Under "Preservative," list any preservatives that were added to the sample container.

Instructions:
1. Each bottle has a label identifying sample ID, preservative contained in the bottle, sample type, date and time of collection, sample name or initials, and any field number or ID.
2. The following information should be added to each bottle label after collection with permanent black ink: date and time of collection, sample name or initials, and any field number or ID.
3. All bottles not containing preservative may be rinsed with appropriate sample prior to collection.
4. The client is responsible for documentation of the sampling event. Please use special sampling events on the sample custody form.

Laboratory Sample Acceptability:
Temperature: 2.3°C

1	Collected / Relinquished By: <u>Megan Maloney</u>	Date <u>8-31-22</u>	Time <u>11:00</u>	Received By: <u>Nathan Hadsell</u>	BEA	Date <u>8-31-22</u>	Time <u>1100</u>
2	Relinquished By:	Date	Time	Received By:		Date	Time

Cooler Packing Worksheet for Request: RQ-2022-08-29-01

2022 Run 9

Ship Cooler On: 8/19/2022

Customer/Project: SW-DIST/SMP

Assigned To: GIVENS_G

Requester: Benjamin Paswater

Priority: 3

813-632-7600
FL Dept. of Environmental Protection
13051 N. Telecom Parkway
Temple Terrace, FL 33637-0926

Attn: Ben Paswater

Please return
packing list with
sample submittal
forms.

Comments:

#####

Buffer Solution for W-CARB-AA Bottle Needed

#####

W-TR-SQ-R (sunscreen)

Wash your hands thoroughly and wear gloves. Refrain from using sunscreens on the day of sample collection.

#####

Requested Analyses:

Bottle Group: A

of Sites: 1

Container ID: P-250ML-WI-THI Qty: 1 Preservation: ICE

Lot # L19246

Description: 250 ml Sterilized with tablet

Analysis

SW-BEA-ENQ

Description

Enterococci by Enterolert/QT by BEA in Palmetto

Container ID: BG-500ML

Qty: 1

Preservation: CH2ClCOOH and Ice

Lot # 00083239

Description: Brown Glass Bottle 500ML *FILL
Completely*

Affix BLUE dot to container.

Analysis

W-CARB-AA

Description

Carbamates in water matrices by HPLC/MS/MS

Container ID: BG-500ML FILL TO TOP Qty: 4

Preservation: ICE

Lot # 00083239

Description: Brown Glass Bottle 500ML *Fill
Completely*

Affix BLUE dot to container.

Analysis

W-CT-CI-R

Description

Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization

W-PCB-TQ-R

PCBs in water matrices by GC/MS/MS

W-PCL-TQ-R

Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS/MS

Container ID: BG-500ML

Qty: 1

Preservation: ICE

Lot # 00083239

Description: Brown Glass Bottle 500ML *FILL Completely*

Affix BLUE dot to container.

Analysis

W-E8321-DI

W-E8321-MS

Description

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Container ID: BG-1L

Qty: 4

Preservation: ICE

Lot # 00083446

Description: Brown Glass Bottle 1L

Affix BLUE dot to container.

Analysis

W-PSNP-TQ

W-TR-SQ-R

Description

Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS

Analysis of Sunscreen Compounds and Flame Retardants in Water by GC/MS-SIM

Bottle Group: B

of Sites: 1

Container ID: QPCR-P-500ML

Qty: 1

Preservation: ICE

Lot # 00076606

Description: 500ml Sterile Nalgene

Analysis

PCR-BACR

PCR-DG3

PCR-HF183

Description

Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction

Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction

Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction

Container ID: P-250ML-WI-THI

Qty: 1

Preservation: ICE

Lot # L19246

Description: 250 ml Sterilized with tablet

Analysis

SW-BEA-ENQ

Description

Enterococci by Enterolert/QT by BEA in Palmetto

Container ID: BG-500ML

Qty: 1

Preservation: ICE

Lot # 00083239

Description: Brown Glass Bottle 500ML *FILL Completely*

Affix BLUE dot to container.

Analysis

W-E8321-DI

W-E8321-MS

Description

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Bottle Group: C

of Sites: 1

Container ID: P-250ML-WI-THI

Qty: 1

Preservation: ICE

Lot # 419246

Description: 250 ml Sterilized with tablet

Analysis

SW-BEA-ENQ

Description

Enterococci by Enterolert/QT by BEA in Palmetto

Container ID: BG-500ML

Qty: 1

Preservation: ICE

Lot # 00083239

Description: Brown Glass Bottle 500ML *FILL
Completely*

Affix BLUE dot to container.

Analysis

W-E8321-DI

W-E8321-MS

Description

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Cooler Packed By: gg

Number of Coolers: 2

Date: 08-16-22

Kit must also include:

- ☒ Field Sheets
- ☒ Temperature Control Bottle
- ☒ FedEx Bills, if applicable
- ☒ Plastic Bags/Zip Ties
- ☐ Acid Labels (sets of 24)

If Preservation Included:

ID	MCAA BUFFER SOL.	Exp	Lot #
ID	SER: # 128343	Exp	Lot #
ID	EXP: 02/04/2023	Exp	Lot #
ID		Exp	Lot #
ID		Exp	Lot #
ID		Exp	Lot #

PLEASE RETURN ALL COOLERS FOR RQ-2022-08-29-01

Date of Request: 09-FEB-2022
 Created By: PASWATER_B On: 09-FEB-2022
 Modified By: JASROTIA_P On: 10-AUG-2022
 Customer: SW-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Southwest District
 Event Description: 2022 Run 9

Send Coolers To:

Phone: 813-632-7600
 FL Dept. of Environmental Protection
 13051 N. Telecom Parkway
 Temple Terrace, FL 33637-0926
 Attn: Ben Paswater
 Cooler Ship EMail: benjamin.paswater@dep.state.fl.us

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 10-AUG-2022
 Biology Request Reviewed By: JASROTIA_P On: 10-AUG-2022
 Sampling Kit Required: YES Ship on: 19-AUG-2022
 Sampling Kit Shipped: YES On: 16-AUG-2022
 Sampling Kit Packed By: GIVENS_G
 Preservatives Needed: YES
 Date to Receive Samples: 29-AUG-2022
 Logged In By: ROBERTS_Z On: 01-SEP-2022

Send Final Report To:

13051 N. Telecom Parkway

 Temple Terrace, FL 33637-0926
 Attn: Ben Paswater
 Report Notification EMail:
 benjamin.paswater@dep.state.fl.us;sarah.meyer@dep.state.fl.us
 ;Jacob.Yodzis@FloridaDEP.gov

Comments:

#####

Buffer Solution for W-CARB-AA Bottle Needed

#####

W-TR-SQ-R (sunscreens)

Wash your hands thoroughly and wear gloves. Refrain from using sunscreens on the day of sample collection.

#####

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
SW-BEA-ENQ	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert/QT by BEA in Palmetto
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: CH ₂ CICOOH and Ice
W-CARB-AA	Template: DEFAULT	(EPA 8321B) Carbamates in water matrices by HPLC/MS/MS
Bottle Type: BG-500ML FILL TO	Number of Bottles: 4	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization
W-PCB-TQ-R	Template: DEFAULT	(EPA 8270E) PCBs in water matrices by GC/MS/MS
W-PCL-TQ-R	Template:	(EPA 8270E) Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS/MS
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: SMP	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: BG-1L	Number of Bottles: 4	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS
W-TR-SQ-R	Template:	(EPA 8270E) Analysis of Sunscreen Compounds and Flame Retardants in Water by GC/MS-SIM

Bottle Group B (Water) With 1 Samples:

Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction

Bottle Group B (Water) With 1 Samples:

Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
SW-BEA-ENQ	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert/QT by BEA in Palmetto
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: SMP	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Bottle Group C (Water) With 1 Samples:

Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: SMP	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
SW-BEA-ENQ	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert/QT by BEA in Palmetto

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.