

Login Checklist

RQ- **2022 - 08 - 29 - 02**

Login Station ID: **# 2**

Shipping Method: **FedEx | UPS | HD | Greyhound**

Date/Time of Receipt: **09/16/2022 / 09:44**

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
2.1C				8					5859 4727 9071

COOLER CHECK

***All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.**

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. **NCR#** _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. **NCR#** _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. **NCR#** _____
- If coolers or samples are received late; identify the affected samples in an NCR. **NCR#** _____

Chain of Custody/ Field Sheet(s) Included? Yes ☒ No _____

Micro-Biology Overflow Chain of Custody/ FieldSheet(s) Included? Yes _____ No ☒

CONTAINER CHECK

Evidence Tape on Bottles? Yes _____ No _____ NA ☒ Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken? Yes _____ No _____ Containers intact? Yes ☒ No _____

Caps on tight? Yes ☒ No _____

Sufficient Sample Volume: Yes ☒ No _____

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. **NCR#** _____

CHLORINE CHECK REQUIRED? (Blue dot on container) Yes _____ No ☒ Init: **ABS /**

Chlorine detected? (One container checked per Field ID) Yes _____ No _____ Init: **ABS /**

If chlorine is detected, generate an NCR listing affected sample IDs . **NCR#** _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

****Acid Preserved Samples:** pH< 2.0? Yes ☒ No _____ NA _____ Init: **ABS /**

****W-1-4-DIOX (Green dot on container)** preserved to pH< 4.0? Yes _____ No _____ NA ☒ Init: **ABS /**

If samples were not preserved correctly, generate an NCR listing affected sample IDs . **NCR#** _____

Coolers Unpacked/Checked by: **ABS /** Date: **09/16/2022** Event contains NCRs(Y/N)? **N**

EventID: **SW - DIST - 2022 - 09 - 16 - 01**

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IRTG # 2 EXP:10/19/2022
pH Test Strips 0 – 6	LOT#223819AV EXP:8/30/23
pH Paper 0 – 3	N/A
pH Paper 0 – 13	LOT#207621 EXP:3/15/2024
Chlorine Test Strips	0070 / 2023 / 02

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: ABS

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 9/15/2022
Customer: SW-DIST
RQ: RQ-2022-08-29-02
Collected By: Ben Paswater, Devin Mathias
Sampling Agency: FDEP
Project ID: SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1 **Delivery Method:** FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
Lake Jackson @ Center	 G1SW0124
Lake Dan @ Center	 G5SW0161

RELINQUISHED BY(SIGNATURE):



DATE/TIME: 9/15/2022
1700 EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By: A.SHAIK

**Rec'd/Inspected
Date:**

09/16/2022



RQ-2022-08-29-02	Collected By: Ben Paswater, Devin Mathias
Customer: FDEP	Field Report Prepared by: Ben Paswater, Devin Mathias
Project ID: SMP	Sampling Agency: FDEP

WIN ID/Field ID:



WIN ID/Field ID: G1SW0124

Comments:

Location:

Location: Lake Jackson @ Center

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. ©	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPTH)										
9/15/2022 950	3.83	49	27.9	6.1	0.3	1.6	4.2	142.6	0.07										
Parameter Suite		Parameter Methods				Preservation		pH Check	# Bottles sent to Lab	Bottle Group									
Preserved Nutrients (P-500ML)		X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	X	<2	1	B						
		Lot #		SA1308030		Exp:		12/01/2022											
Metals (P-500ML)			W-ICPMS			W-ICP			W-HARD			Ice		HNO3*		<2			
		Lot #				Exp:													
Filtered Nutrients (P125ML)		X	W-PO4-F		X	Field Filtered 0.45 um Filter			X	Ice			1	B					
		Filter Lot #		17232873		Syringe Lot #		1145497											
BOD (BP-1L)			OV-BODUNIN					Ice											
Chlorophyll (BP-1L)		X	CHLSUITE-W				X	Ice							1	B			
Physical/Aggregate (Fresh) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W- TDS							Ice										
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY							Ice										
Macroinvertebrates (PJ-2L)		MI-FW-QLDC		Formalin Lot #					Formalin										
Periphyton (PT-50ML)		ALGAE-ID							Ice										
Microbiology (Contract Lab Bottle)		E Coli				F Coli				Enterococci						Ice			
		Contract Lab																	
Molecular (QPCR-P-500ML)		PCR-HF183				PCR-BacR				PCR-DG3		Ice							
		PCR-GULL2				PCR-GFD													
Tracers (BG-500ML)		W-E8321-DI				W-E8321-MS					Ice								
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI				W-E8321-MS				W-PSNP-TQ	Ice	MCAA Exp.	MCAA Lot#						
		W-PCL-TQ-R				W-CARB-AA (5 ml of MCAA Buffer Solution)				W-CT-CL-R									
		W-TR-SQ-R				W-PCB-TQ-R													
Phytoplankton		DTY-QN-C				PKD-QN-BV					Ice								



RQ-2022-08-29-02

Collected By: Ben Paswater, Devin Mathias

Customer: FDEP

Field Report Prepared by: Ben Paswater, Devin Mathias

Project ID: SMP

Sampling Agency: FDEP

WIN ID/Field ID:



WIN ID/Field ID: G5SW0161

Comments:

Location:

Location: Lake Dan @ Center

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPTH)
9/15/2022 1030	6.3	81.9	29.1	7.38	0.3	1.8	4.2	130.8	0.06

Parameter Suite	Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group		
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	X	<2	1	B
	Lot #		SA1308030		Exp:		12/1/22					
Metals (P-500ML)		W-ICPMS		W-ICP	W-HARD		Ice	HNO3*		<2		
	Lot #		Exp:									
Filtered Nutrients (P125ML)	X	W-PO4-F		X	Field Filtered 0.45 µm Filter		X	Ice		1	B	
	Filter Lot #		17232873		Syringe Lot #		1145497					
BOD (BP-1L)		OV-BODUNIN					Ice					
Chlorophyll (BP-1L)	X	CHLSUITE-W				X	Ice			1	B	
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W-TDS				X	Ice			1	B	
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY					Ice					
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #			Formalin						
Periphyton (PT-50ML)		ALGAE-ID					Ice					
Microbiology (Contract Lab Bottle)		E Coli		F Coli	Enterococci		Ice					
	Contract Lab											
Molecular (QPCR-P-500ML)		PCR-HF183		PCR-BacR	PCR-DG3		Ice					
	PCR-GULL2		PCR-GFD									
Tracers (BG-500ML)		W-E8321-DI		W-E8321-MS			Ice					
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI	W-E8321-MS		W-PSNP-TQ		Ice	MCAA Exp.	MCAA Lot#			
		W-PCL-TQ-R	W-CARB-AA (5 ml of MCAA Buffer Solution)		W-CT-CL-R							
		W-TR-SQ-R	W-PCB-TQ-R									
Phytoplankton		DTY-QN-C		PKD-QN-BV			Ice					

Date of Request: 15-FEB-2022
 Created By: PASWATER_B On: 15-FEB-2022
 Modified By: AYRES_J On: 09-SEP-2022
 Customer: SW-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Southwest District
 Event Description: Run 10

Send Coolers To:

Phone: 813-632-7600
 FL Dept. of Environmental Protection
 13051 N. Telecom Parkway
 Temple Terrace, FL 33637-0926
 Attn: Ben Paswater
 Cooler Ship EMail: benjamin.paswater@dep.state.fl.us

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 09-SEP-2022
 Biology Request Reviewed By: AYRES_J On: 09-SEP-2022
 Sampling Kit Required: NO Ship on:
 Sampling Kit Shipped: YES On: 15-AUG-2022
 Sampling Kit Packed By: GIVENS_G
 Preservatives Needed: NO
 Date to Receive Samples: 29-AUG-2022
 Logged In By: SHAIK_A On: 16-SEP-2022

Send Final Report To:

FL Dept. of Environmental Protection
 13051 N. Telecom Parkway
 Temple Terrace, FL 33637-0926
 Attn: Ben Paswater
 Report Notification EMail:
 benjamin.paswater@dep.state.fl.us;sarah.meyer@dep.state.fl.us
 ;jacob.yodzis@FloridaDEP.gov

Comments: #####

Buffer Solution for W-CARB-AA Bottle Needed

 W-TR-SQ-R (sunscreen)

Wash your hands thoroughly and wear gloves. Refrain from using sunscreens on the day of sample collection.

#####

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: CH ₂ ClCOOH and Ice
W-CARB-AA	Template: DEFAULT	(EPA 8321B) Carbamates in water matrices by HPLC/MS/MS
Bottle Type: BG-500ML FILL TO	Number of Bottles: 4	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization
W-PCB-TQ-R	Template: DEFAULT	(EPA 8270E) PCBs in water matrices by GC/MS/MS

Bottle Group A (Water) With 1 Samples:

Bottle Type: BG-500ML FILL TO	Number of Bottles: 4	Preserved With: ICE
W-PCL-TQ-R Template:	(EPA 8270E)	Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS/MS
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI Template: DEFAULT	(EPA 8321B)	Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS Template: SMP	(EPA 8321B)	Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3 Template: DEFAULT	(EPA 350.1 Rev. 2.0)	Ammonia in aqueous matrices as mg N/L
W-NO2NO3 Template: DEFAULT	(EPA 353.2 Rev. 2.0)	Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP Template: DEFAULT	(EPA 365.1 Rev. 2.0)	Total Phosphorus in aqueous matrices as mg P/L
W-TKN Template: DEFAULT	(EPA 351.2 Rev. 2.0)	Total Kjeldahl Nitrogen in aqueous matrices
W-TOC Template: DEFAULT	(SM 5310 B-2011)	Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F Template: DEFAULT	(EPA 365.1 Rev. 2.0)	Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
W-SO4-IC-F Template: DEFAULT	(EPA 300.0 Rev. 2.1)	Sulfate, dissolved, in filtered, aqueous matrices
Bottle Type: BG-1L	Number of Bottles: 4	Preserved With: ICE
W-PSNP-TQ Template: DEFAULT	(EPA 8270E)	Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS
W-TR-SQ-R Template:	(EPA 8270E)	Analysis of Sunscreen Compounds and Flame Retardants in Water by GC/MS-SIM

Bottle Group B (Water) With 3 Samples:

Bottle Type: P-1L	Number of Bottles: 3	Preserved With: ICE
ALKALINITY Template: DEFAULT	(SM 2320 B-2011)	Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY Template: DEFAULT	(EPA 180.1 Rev. 2.0)	Turbidity in aqueous matrices
W-CL-IC Template: DEFAULT	(EPA 300.0 Rev. 2.1)	Chloride in aqueous matrices
W-COLOR Template: DEFAULT	(DEP SOP: NU-094-1)	True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F Template: DEFAULT	(SM 4500-F- C-2011)	Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TDS Template: DEFAULT	(SM 2540 C-2011)	Total Dissolved Solids in aqueous matrices
W-TSS Template: DEFAULT	(SM 2540 D-2011)	Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 3	Preserved With: ICE
CHLSUITE-W Template: DEFAULT	(SM 10200 H (mod.))	Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-500ML	Number of Bottles: 3	Preserved With: ICE And H2SO4
W-NH3 Template: DEFAULT	(EPA 350.1 Rev. 2.0)	Ammonia in aqueous matrices as mg N/L
W-NO2NO3 Template: DEFAULT	(EPA 353.2 Rev. 2.0)	Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP Template: DEFAULT	(EPA 365.1 Rev. 2.0)	Total Phosphorus in aqueous matrices as mg P/L
W-TKN Template: DEFAULT	(EPA 351.2 Rev. 2.0)	Total Kjeldahl Nitrogen in aqueous matrices
W-TOC Template: DEFAULT	(SM 5310 B-2011)	Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 3	Preserved With: FILTER-ICE
W-PO4-F Template: DEFAULT	(EPA 365.1 Rev. 2.0)	Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
W-SO4-IC-F Template: DEFAULT	(EPA 300.0 Rev. 2.1)	Sulfate, dissolved, in filtered, aqueous matrices

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY Template: DEFAULT	(SM 2320 B-2011)	Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY Template: DEFAULT	(EPA 180.1 Rev. 2.0)	Turbidity in aqueous matrices
W-CL-IC Template: DEFAULT	(EPA 300.0 Rev. 2.1)	Chloride in aqueous matrices
W-COLOR Template: DEFAULT	(DEP SOP: NU-094-1)	True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F Template: DEFAULT	(SM 4500-F- C-2011)	Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TDS Template: DEFAULT	(SM 2540 C-2011)	Total Dissolved Solids in aqueous matrices
W-TSS Template: DEFAULT	(SM 2540 D-2011)	Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3 Template: DEFAULT	(EPA 350.1 Rev. 2.0)	Ammonia in aqueous matrices as mg N/L
W-NO2NO3 Template: DEFAULT	(EPA 353.2 Rev. 2.0)	Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP Template: DEFAULT	(EPA 365.1 Rev. 2.0)	Total Phosphorus in aqueous matrices as mg P/L
W-TKN Template: DEFAULT	(EPA 351.2 Rev. 2.0)	Total Kjeldahl Nitrogen in aqueous matrices
W-TOC Template: DEFAULT	(SM 5310 B-2011)	Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
W-SO4-IC-F	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate, dissolved, in filtered, aqueous matrices

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.

