

Login Checklist

RQ- 2022-10-03-20

Login Station ID: #1

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 12/ 6 /22 @ 9:27

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
1.1				11		✓			5859 4731 3162

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included? Yes ✓ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes ✓ No _____

CONTAINER CHECK

Evidence Tape on Bottles? Yes _____ No _____ NA ✓ Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken? Yes _____ No _____ Containers intact? Yes ✓ No _____

Caps on tight? Yes ✓ No _____

Sufficient Sample Volume: Yes ✓ No _____

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ✓ No _____ Init: HK

Chlorine detected? (One container checked per Field ID)

Yes _____ No ✓ Init: HK

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH< 2.0? Yes ✓ No _____ NA _____ Init: HK

**W-1-4-DIOX (Green dot on container) preserved to pH< 4.0? Yes _____ No _____ NA ✓ Init: HK

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: HK Date: 12/ 6 /22 Event contains NCRs (Y/N)? N

EventID: SCIs Gilly and Gamble
SW-DIST-2022-12-06-02 (SMP)

-Date Received: 06-DEC-2022 09:27

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #1 Exp:10/17/2023
pH Test Strips 0 – 6	Lot# 223819AV Exp:8/30/23
pH Paper 0 – 3	
pH Paper 0 – 13	Lot# 207621 Exp:3/15/24
Chlorine Test Strips	Lot# 0070 Exp:2/23

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 12/5/2022
Customer: SW-DIST
RQ: RQ-2022-10-03-20

Collected By: Ben Paswater, Devin Mathias
Sampling Agency: FDEP
Project ID: SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB


Number of Coolers Shipped: 2

Delivery Method: FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
Gilley Creek downstream	 G2SW0039

RELINQUISHED BY(SIGNATURE):



DATE/TIME: 12/5/2022
1700 EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By: 

Rec'd/Inspected

Date: 12-6-22 / 0927



RQ-2022-10-03-20

Customer: FDEP

Project ID: SMP

Collected By: Ben Paswater, Devin Mathias

Field Report Prepared by: Ben Paswater, Devin Mathias

Sampling Agency: FDEP

WIN ID/Field ID:



WIN ID/Field ID: G2SW0039

Comments:

Location: Gilley Creek downstream

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT)
12/5/2022 1400	8.5	95.8	21.2	7.05	0.3	1.4	1.4	164.1	0.08

Parameter Suite	Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group					
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	X	<2	1	A			
		Lot #	SA2229010		Exp:	8/30/23									
Metals (P-500ML)	X	W-ICPMS		X	W-ICP	X	W-HARD	X	Ice	X	HNO3*	X	<2	1	A
		Lot #	NA1105100		Exp:	6/7/22									
Filtered Nutrients (P125ML)	X	W-PO4-F		X	Field Filtered 0.45 µm Filter			X	Ice		1	A			
		Filter Lot #	17232873	Syringe Lot #	1145497										
BOD (BP-1L)		OV-BODUNIN					Ice								
Chlorophyll (BP-1L)	X	CHLSUITE-W				X	Ice	1	A						
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-CI-IC / W-COLOR / W-SO4-IC / W-TDS				X	Ice	1	A						
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY					Ice								
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #	928091819TR			Formalin								
Periphyton (PT-50ML)		ALGAE-ID					Ice								
Microbiology (Contract Lab Bottle)		E Coli		F Coli		Enterococci		Ice							
		Contract Lab													
Molecular (QPCR-P-500ML)		PCR-HF183			PCR-BacR		PCR-DG3		Ice						
		PCR-GULL2			PCR-GFD										
Tracers (BG-500ML)	X	W-E8321-DI		X	W-E8321-MS		X	Ice	1	A					
Pesticides (BG-500ML) (BG-1L)	X	W-E8321-DI	X	W-E8321-MS		X	W-PSNP-TQ	X	Ice	MCAA Exp.	MCAA Lot#	5	A		
		W-PCL-TQ-R		W-CARB-AA (5 ml of MCAA Buffer Solution)			W-CT-CL-R								
	X	W-TR-SQ-R			W-PCB-TQ-R										
Phytoplankton		DTY-QN-C			PKD-QN-BV			Ice							
DOC		W-DOC		Field Filtered 0.45 µm Filter			Ice		H2SO 4*		<2				
			Acid Preservative Expiration Date												
			Acid Preservative Lot Number												

Benchmark EnviroAnalytical, Inc
1711 12th Street East
Palmetto, FL 34221
941-723-9986
941-723-6061 Fax

PO#_C00EF5

Client Information: DEP: SW-DIST

Address: 13051 N. Telecom Parkway
Tampa FL 33604

Phone # 815-470-5878

Report to: benjamin.paswater@dep.state.fl.us
DEP-Overflomicro@dep.state.fl.us

Invoice to: FDEP Micro Overflow

Project Name: RQ-2022- 10-03-20

Laboratory Submission #

22120221

Sample Name	Sample Type ¹ / Sample Matrix ²	Collection		Container		Preservative ⁴	Parameters for Analysis	Laboratory Sample #
		Date	Time	Qty	Capacity	Type ³		
G2SW0039	SW	12/5/22	1400	1	250mL	P	Plain (on Ice)	E. Coli
	SW				250mL	P	Plain (on Ice)	
	SW				250mL	P	Plain (on Ice)	
	SW				250mL	P	Plain (on Ice)	
	SW				250mL	P	Plain (on Ice)	
	SW				250mL	P	Plain (on Ice)	
	SW				250mL	P	Plain (on Ice)	

¹Sample Type¹ is used to indicate whether the sample was a grab (G) or whether it was a composite (C).

²Sample Matrix² is used to indicate whether the sample is being discharged to drinking water (DW), ground water (GW), surface water (SW), fresh surface water (FSW), saline surface water (SSW), soil, sediment (SMT), or sludge (SLUG).

³Container Type³ is used to indicate whether the container is plastic (P) or glass (G).

⁴Sample must be refrigerated or stored in wet ice after collection. The temperature during storage should be less than or equal to 6°C (43°F).

Under "Preservative," list any preservatives that were added to the sample container.

Instructions:

1. Each bottle has a label identifying sample ID, preservative contained in the bottle, sample type, client ID, and parameters for analysis.

2. The following information should be added to each bottle label after collection with permanent black ink: date and time of collection, sample's name or initials, and any field number or ID.

3. All bottles not containing preservative may be rinsed with appropriate sample prior to collection.

4. The client is responsible for documentation of the sampling event. Please note special sampling events on the sample custody form.

Laboratory Sample Acceptability:

Temperature: 1.3 °C

1	Collected / Relinquished By:	Date	Time	Received By:	Date	Time
2	Relinquished By:	Date	Time	Received By:	Date	Time

Date of Request: 24-AUG-2022
 Created By: PASWATER_B On: 24-AUG-2022
 Modified By: AYRES_J On: 16-SEP-2022
 Customer: SW-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Southwest District
 Event Description: SCIs Gilly and Gamble

Send Coolers To:

Phone: 813-632-7600
 FL Dept. of Environmental Protection
 13051 N. Telecom Parkway
 Temple Terrace, FL 33637-0926
 Attn: Ben Paswater
 Cooler Ship EMail: benjamin.paswater@dep.state.fl.us

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 16-SEP-2022
 Biology Request Reviewed By: JASROTIA_P On: 30-AUG-2022
 Sampling Kit Required: YES Ship on: 23-SEP-2022
 Sampling Kit Shipped: YES On: 20-SEP-2022
 Sampling Kit Packed By: ROBERTS_Z
 Preservatives Needed: NO
 Date to Receive Samples: 03-OCT-2022
 Logged In By: SHAIK_A On: 25-OCT-2022

Send Final Report To:

13051 N. Telecom Parkway
 Temple Terrace, FL 33637-0926
 Attn: Ben Paswater
 Report Notification EMail:
 benjamin.paswater@dep.state.fl.us;sarah.meyer@dep.state.fl.us
 ;Jacob.Yodzis@FloridaDEP.gov

Comments:**Bottle Group A (Water) With 2 Samples:**

Bottle Type: P-1L	Number of Bottles: 2	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2015) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 2	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WI-THI	Number of Bottles: 2	Preserved With: ICE
SW-BEA-ECQ	Template: DEFAULT	(SM 9223 B Quanti-Tray) E. coli by Colilert/QT by BEA in Palmetto
Bottle Type: BG-500ML	Number of Bottles: 2	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: SMP	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: HNO ₃
W-HARD	Template: DEFAULT	(SM 2340 B-2011) Hardness by calculation, in aqueous matrices, reported as mg/L CaCO ₃
Hardness		
W-ICP	Template: SMP-FRESH	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Calcium		
Iron		
Magnesium		
Potassium		
Sodium		

Bottle Group A (Water) With 2 Samples:

Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: HNO3
W-ICP	Template: SMP-FRESH	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Strontium		
Tin		
Titanium		
Vanadium		
Zinc		
W-ICPMS	Template: DEFAULT	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
Aluminum		
Antimony		
Arsenic		
Barium		
Beryllium		
Boron		
Cadmium		
Chromium		
Cobalt		
Copper		
Lead		
Manganese		
Molybdenum		
Nickel		
Selenium		
Silver		
Thallium		

Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 2	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
Bottle Type: BG-1L	Number of Bottles: 6	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS
W-TR-SQ-R	Template: DEFAULT	(EPA 8270E) Analysis of Sunscreen Compounds and Flame Retardants in Water by GC/MS-SIM

Bottle Group B (Biological) With 2 Samples:

Bottle Type: PJ-2L	Number of Bottles: 4	Preserved With: Formalin
MI-FW-QLDC	Template: DEFAULT	(SOP-IZ06) No. Taxa of FW macroinverts, qual samp, 20 dipnets.
Bottle Type: PT-50ML	Number of Bottles: 2	Preserved With: ICE
ALGAL_ID	Template: DEFAULT	(SOP-AB18) Qualitative assessment of algal taxa present without counts

Bottle Group C (Water) With 1 Samples:

Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.