

Login Checklist

RQ- 2022-10-10-31

Login Station ID: 5

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 10/11/22 @ 9:10

*Cooler Temperature	Samples Frozen? YES	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
		HNO ₃	Formalin		Present?		*Intact?		
					Yes	No	Yes	No	
<u>-1.6</u>				<u>5</u>		<u>X</u>			<u>5859 47296410</u>

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes X No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No X

CONTAINER CHECK

Evidence Tape on Bottles? Yes _____ No _____ NA X Evidence Tape intact? Yes _____ No X

If Criminal, photographs taken? Yes _____ No X Containers intact? Yes _____ No _____

Caps on tight? Yes X No _____

Sufficient Sample Volume: Yes X No _____

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes _____ No X Init: C.P

Chlorine detected? (One container checked per Field ID)

Yes _____ No _____ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0? Yes X No _____ NA _____ Init: C.P

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes _____ No _____ NA X Init: C.P

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: C.P Date: 10/11/22 Event contains NCRs (Y/N)? N

Event ID: SE-DIST-2022-10-11-01 (SMP)
Date Received: 11-OCT-2022 09:10

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #5 10/19/22
pH Test Strips 0 – 6	223819av 8/30/2023
pH Paper 0 – 3	NA
pH Paper 0 – 13	210820 4/15/2023
Chlorine Test Strips	0070 02/2023

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 10/10/2022
Collected By: Charlie Hoey, Andrew Luering
Customer:
Sampling Agency: FDEP
RQ: RQ-2022-10-10-31
Project ID: SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1
Delivery Method: FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
Tidal Creek to Lox	 G2SE0027
Danforth Creek @ SW Citrus Blvd.	 G2SE0058

RELINQUISHED BY(SIGNATURE):



DATE/TIME: 10/10/2022

1600 EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By: C.P.

Rec'd/Inspected

Date: 10/11/22



RQ-2022-10-10-31

Customer: FDEP

Project ID: SMP

Collected By: Charlie Hoey, Andrew Luering

Field Report Prepared by: Charlie Hoey, Andrew Luering

Sampling Agency: FDEP

Comments:

WIN ID/Field ID:



WIN ID/Field ID: G2SE0027

Location: Tidal Creek to Lox

Matrix: Marine

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT)
10/10/2022 920	4.02	57.1	27.1	7.55	0.3	0.9	1.13	34529	21.6

Parameter Suite	Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group		
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	X	<2	1	A
		Lot #		SA2145160	Exp:		06/02/2023					
Metals (P-500ML)		W-ICPMS		W-ICP	W-HARD	Ice		HNO3*		<2		
		Lot #		Exp:								
Filtered Nutrients (P125ML)		W-PO4-F		Field Filtered 0.45 µm Filter		Ice						
		Filter Lot #	Syringe Lot #									
BOD (BP-1L)		OV-BODUNIN			Ice							
Chlorophyll (BP-1L)	X	CHLSUITE-W			X	Ice				1	A	
Physical/Aggregate (Fresh) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W-TDS			Ice							
Physical/Aggregate (Marine) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY			X	Ice				1	A	
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #		Formalin							
Periphyton (PT-50ML)		ALGAE-ID			Ice							
Microbiology (Contract Lab Bottle)		E Coli	F Coli	X	Enterococci	X	Ice			1	A	
		Contract Lab										
Molecular (QPCR-P-500ML)		PCR-HF183	PCR-BacR	PCR-DG3	Ice							
		PCR-GULL2	PCR-GFD									
Tracers (BG-500ML)		W-E8321-DI	W-E8321-MS		Ice							
		W-PCL-TQ-R	W-CARB-AA (5 ml of MCAA Buffer Solution)		W-CT-CL-R	Ice	MCAA Exp.	MCAA Lot#				
		W-TR-SQ-R	W-PCB-TQ-R									
Phytoplankton		DTY-QN-C	PKD-QN-BV		Ice							
DOC		W-DOC	Field Filtered 0.45 µm Filter		Ice		H2SO4*		<2			
		Acid Preservative Expiration Date										
		Acid Preservative Lot Number										



RQ-2022-10-10-31

Customer: FDEP

Project ID: SMP

Collected By: Charlie Hoey, Andrew Luering

Field Report Prepared by: Charlie Hoey, Andrew Luering

Sampling Agency: FDEP

Comments:

WIN ID/Field ID:



WIN ID/Field ID: G2SE0058

Location: Danforth Creek @ SW Citrus Blvd.

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT)			
10/10/2022 1000	1.07	13.2	25.1	7	0.1	0.2	0.2	409.6	0.2			
Parameter Suite		Parameter Methods				Preservation		pH Check	# Bottles sent to Lab	Bottle Group		
Preserved Nutrients (P-500ML)		W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP				Ice		H2SO4*	<2			
		Lot #		Exp:								
Metals (P-500ML)		W-ICPMS / W-ICP / W-HARD				Ice		HNO3*				
		Lot #		Exp:								
Filtered Nutrients (P125ML)		W-PO4-F / Field Filtered 0.45 µm Filter				Ice						
		Filter Lot #		Syringe Lot #								
BOD (BP-1L)		OV-BODUNIN				Ice						
Chlorophyll (BP-1L)		CHLSUITE-W				Ice						
Physical/Aggregate (Fresh) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W- TDS				Ice						
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY				Ice						
Macroinvertebrates (PJ-2L)		MI-FW-QLDC / Formalin Lot #				Formalin						
Periphyton (PT-50ML)		ALGAE-ID				Ice						
Microbiology (Contract Lab Bottle)		X E Coli / Contract Lab / F Coli / Enterococci				x Ice			1	B		
Molecular (QPCR-P-500ML)		PCR-HF183 / PCR-BacR / PCR-DG3 / PCR-GULL2 / PCR-GFD				Ice						
Tracers (BG-500ML)		W-E8321-DI / W-E8321-MS				Ice						
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI / W-E8321-MS / W-PSNP-TQ / W-PCL-TQ-R / W-CARB-AA (5 ml of MCAA Buffer Solution) / W-CT-CL-R / W-TR-SQ-R / W-PCB-TQ-R				Ice		MCAA Exp. / MCAA Lot#				
Phytoplankton		DTY-QN-C / PKD-QN-BV				Ice						
DOC		W-DOC / Field Filtered 0.45 µm Filter				Ice		H2SO 4*	<2			
		Acid Preservative Expiration Date										
		Acid Preservative Lot Number										

Date of Request: 15-SEP-2022
 Created By: LUERING_A On: 15-SEP-2022
 Modified By: JASROTIA_P On: 26-SEP-2022
 Customer: SE-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Southeast District
 Event Description: Tidal Lox and Danforth Creek

Send Coolers To:

Phone: (772) 380-5572
 FL Dept. of Environmental Protection
 2199 South Rock Road
 Fort Pierce, FL 34945
 Attn: Jordan Skaggs
 Cooler Ship EMail: Jordan.Skaggs@FloridaDEP.gov

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 21-SEP-2022
 Biology Request Reviewed By: JASROTIA_P On: 26-SEP-2022
 Sampling Kit Required: YES Ship on: 03-OCT-2022
 Sampling Kit Shipped: YES On: 03-OCT-2022
 Sampling Kit Packed By: KLUG_K
 Preservatives Needed: NO
 Date to Receive Samples: 11-OCT-2022
 Logged In By: PENDLETO_C On: 11-OCT-2022

Send Final Report To:

FL Dept. of Environmental Protection
 2199 South Rock Road
 Fort Pierce, FL 34945
 Attn: Jordan Skaggs
 Report Notification EMail:
 Jordan.Skaggs@FloridaDEP.gov;Andrew.Lueling@FloridaDEP.gov

Comments:

Bottle Group A (Fresh Nutrients and E. coli)
G2SE0027

Bottle Group B (Enterococci)
G2SE0058

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-500ML Number of Bottles: 1 Preserved With: ICE And H2SO4
W-TOC Template: DEFAULT (SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-250ML-WO-THI Number of Bottles: 1 Preserved With: ICE
ENT-24-QT Template: DEFAULT (Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems