

Login Checklist

RQ- 2023-04-17-22

Login Station ID: #3

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 04/25/23 @ 0910

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
1.4				11		x			585947348373

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes X No _____

Micro-Biology Overflow Chain of Custody/ FieldSheet(s) Included?

Yes _____ No X

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA X Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____ Containers intact? Yes X No _____

Caps on tight?

Yes X No _____

Sufficient Sample Volume:

Yes X No _____

If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes X No _____ Init: BKK

Chlorine detected? (One container checked per Field ID)

Yes _____ No X Init: BKK

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH< 2.0?

Yes X No _____ NA _____ Init: BKK

**W-1-4-DIOX (Green dot on container) preserved to pH< 4.0?

Yes _____ No _____ NA X Init: BKK

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: BKK

Date: 04/25/23

Event contains NCRs (Y/N)? N

Run 23
EventID: CEN-DIST-2023-04-25-01 (SMP)
-Date Received: 25-APR-2023 09:10

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #3 Exp:10/17/2023
pH Test Strips 0 – 6	Lot#223819AV Exp:8/30/23
pH Paper 0 – 3	
pH Paper 0 – 13	Lot#210620 Exp:3/15/24
Chlorine Test Strips	Lot#1196 Exp:2/24

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 4/24/2023 **Collected By:** Katie March, Victoria Schwartz
Customer: CEN-DIST **Sampling Agency:** FDEP
RQ: RQ-2023-04-17-22 **Project ID:** SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1

Delivery Method: FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
DEAD RIVER AT 50M FROM S OF US 441 (2817C)	 G1CE0100
HICKS DITCH SE OF EAST RD	 G1CE0126
FB	 FB_04242023

RELINQUISHED BY(SIGNATURE):



DATE/TIME: 4/24/2023

1600 EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By:



Rec'd/Inspected

Date: 4/25/2023 0910

RQ-2023-04-17-22	Collected By: Katie March, Victoria Schwartz
Customer: FDEP	Field Report Prepared by: Katie March, Victoria Schwartz
Project ID: SMP	Sampling Agency: FDEP

WIN ID/Field ID:  WIN ID/Field ID: G1CE0100	Comments:
---	------------------

Matrix: Fresh

(Check One)

✓ Grab

☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT _h)							
4/24/2023 1138	7.54	90.9	24.7	7.83	0.3	0.5	2.5	276.4	0.13							
Parameter Suite	Parameter Methods					Preservation		pH Check		# Bottles sent to Lab	Bottle Group					
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP				X	Ice	X	H2SO4*	X	<2	1	B			
		Lot #		SA3013020		Exp:	1/25/24									
Metals (P-500ML)		W-ICPMS		W-ICP		W-HARD			Ice		HNO3*		<2			
		Lot #			Exp:											
Filtered Nutrients (P125ML)		W-PO4-F		Field Filtered 0.45 µm Filter				Ice								
		Filter Lot #		Syringe Lot #												
BOD (BP-1L)		OV-BODUNIN						Ice								
Chlorophyll (BP-1L)	X	CHLSUITE-W					X	Ice						1	B	
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W- TDS					X	Ice						1	B	
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY						Ice								
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #				Formalin									
Periphyton (PT-50ML)		ALGAE-ID						Ice								
Microbiology (Contract Lab Bottle)	X	E Coli		F Coli		Enterococci		X	Ice					1	B	
		Contract Lab														
Molecular (QPCR-P-500ML)		PCR-HF1B3		PCR-BacR		PCR-DG3			Ice							
		PCR-GULL2		PCR-GFD												
Tracers (BG-500ML)		W-E8321-DI		W-E8321-MS				Ice								
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI	W-E8321-MS		W-PSNP-TQ		Ice	MCAA Exp.	MCAA Lot#							
		W-PCL-TQ-R	W-CARB-AA (5 ml of MCAA Buffer Solution)		W-CT-CL-R											
		W-TR-SQ-R		W-PCB-TQ-R												
Phytoplankton		DTY-QN-C		PKD-QN-BV			Ice									
DOC		W-DOC		Field Filtered 0.45 µm Filter				Ice		H2SO 4*		<2				
			Acid Preservative Expiration Date													
			Acid Preservative Lot Number													



RQ-2023-04-17-22	Collected By: Katie March, Victoria Schwartz
Customer: FDEP	Field Report Prepared by: Katie March, Victoria Schwartz
Project ID: SMP	Sampling Agency: FDEP

WIN ID/Field ID:



WIN ID/Field ID: G1CE0126

Comments:

Location: HICKS DITCH SE OF EAST RD

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPTH)	
4/24/2023 1310	1.03	11.8	21.8	6.77	0.15	0.1	0.3	158.2	0.07	
Parameter Suite	Parameter Methods				Preservation		pH Check	# Bottles sent to Lab	Bottle Group	
Preserved Nutrients (P-500ML)	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP				Ice H2SO4*		<2			
	Lot #		Exp:							
Metals (P-500ML)	x	W-ICPMS	x	W-ICP	x	W-HARD	x	Ice	x	HNO3*
	Lot #		NA2230040		Exp:		9/1/23	X	<2	1
Filtered Nutrients (P125ML)	W-PO4-F				Field Filtered 0.45 um Filter					
	Filter Lot #	Syringe Lot #								
BOD (BP-1L)	OV-BODUNIN				Ice					
Chlorophyll (BP-1L)	CHLSUITE-W				Ice					
Physical/Aggregate (Fresh) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY / W-CL-IC / W-COLOR / W-SO4-IC / W-TDS				Ice					
Physical/Aggregate (Marine) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY				Ice					
Macroinvertebrates (PJ-2L)	MI-FW-QLDC		Formalin Lot #		Formalin					
Periphyton (PT-50ML)	ALGAE-ID				Ice					
Microbiology (Contract Lab Bottle)	X	E Coli		F Coli		Enterococci	x	Ice		1
	Contract Lab									A
Molecular (QPCR-P-500ML)	X	PCR-HF183	X	PCR-BacR	X	PCR-DG3	x	Ice		1
	PCR-GULL2		PCR-GFD							A
Tracers (BG-500ML)	X	W-E8321-DI	X	W-E8321-MS			x	Ice		1
Pesticides (BG-500ML) (BG-1L)	W-E8321-DI		W-E8321-MS		W-PSNP-TQ			MCAA Exp.	MCAA Lot#	
	W-PCL-TQ-R		W-CAR8-AA (5 ml of MCAA Buffer Solution)		W-CT-CL-R		Ice			
	W-TR-SQ-R		W-PCB-TQ-R							
Phytoplankton	DTY-QN-C		PKD-QN-BV				Ice			
DOC	W-DOC		Field Filtered 0.45 um Filter		Ice		H2SO4*		<2	
			Acid Preservative Expiration Date							
			Acid Preservative Lot Number							



RQ-2023-04-17-22	Collected By: Katie March, Victoria Schwartz
Customer: FDEP	Field Report Prepared by: Katie March, Victoria Schwartz
Project ID: SMP	Sampling Agency: FDEP

WIN ID/Field ID:  WIN ID/Field ID: FB_04242023	Comments:
--	-----------

Location: FB

Matrix: W-FIELD-BLANK	(Check One) ☒ Grab ☐ Composite
-----------------------	---

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPTH)		
4/24/2023 1330											
Parameter Suite		Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP					Ice	H2SO4*	<2	1	C	
	Lot #		SA3013020		Exp: 1/25/24						
Metals (P-500ML)	W-ICPMS		W-ICP		W-HARD		Ice	HNO3*	<2		
	Lot #		Exp:								
Filtered Nutrients (P125ML)	W-PO4-F		Field Filtered 0.45 µm Filter			Ice					
	Filter Lot #	Syringe Lot #									
BOD (BP-1L)	OV-BODUNIN					Ice					
Chlorophyll (BP-1L)	CHLSUITE-W					Ice					
Physical/Aggregate (Fresh) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W-TDS					Ice		1	C		
Physical/Aggregate (Marine) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY					Ice					
Macroinvertebrates (PJ-2L)	MI-FW-QLDC		Formalin Lot #		Formalin						
Periphyton (PT-50ML)	ALGAE-ID					Ice					
Microbiology (Contract Lab Bottle)	E Coli		F Coli		Enterococci			Ice			
	Contract Lab										
Molecular (QPCR-P-500ML)	PCR-HF183		PCR-BacR		PCR-DG3			Ice			
	PCR-GULL2		PCR-GFD								
Tracers (BG-500ML)	X	W-E8321-DI	X	W-E8321-MS	x	Ice	1	C			
Pesticides (BG-500ML) (BG-1L)	W-E8321-DI	W-E8321-MS		W-PSNP-TQ		Ice	MCAA Exp.	MCAA Lot#			
	W-PCL-TQ-R	W-CARB-AA (5 ml of MCAA Buffer Solution)		W-CT-CL-R							
	W-TR-SQ-R	W-PCB-TQ-R									
Phytoplankton	DTY-QN-C		PKD-QN-BV			Ice					
DOC	W-DOC	Field Filtered 0.45 µm Filter			Ice	H2SO 4*	<2				
		Acid Preservative Expiration Date									
		Acid Preservative Lot Number									

Date of Request: 14-MAR-2023
 Created By: BEARDEN_M On: 14-MAR-2023
 Modified By: JASROTIA_P On: 29-MAR-2023
 Customer: CEN-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Central District
 Event Description: Run 23

Send Coolers To:

Phone: 407-897-4123
 FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Matthew Bearden
 Cooler Ship EMail: matthew.bearden@floridadep.gov

Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 28-MAR-2023
 Biology Request Reviewed By: JASROTIA_P On: 29-MAR-2023
 Sampling Kit Required: YES Ship on: 07-APR-2023
 Sampling Kit Shipped: YES On: 29-MAR-2023
 Sampling Kit Packed By: PENDLETO_C
 Preservatives Needed: NO
 Date to Receive Samples: 19-APR-2023
 Logged In By:

Send Final Report To:

FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Matthew Bearden
 Report Notification EMail:
 matthew.bearden@floridadep.gov;jessie.atchison@floridadep.gov
 v

Comments:**Bottle Group A (Water) With 1 Samples:**

Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 B Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: SMP	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-HARD	Template: DEFAULT	(SM 2340 B-2011) Hardness by calculation, in aqueous matrices, reported as mg/L CaCO3
Hardness		
W-ICP	Template: SMP-FRESH	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Calcium		
Iron		
Magnesium		
Potassium		
Sodium		
Strontium		
Tin		
Titanium		
Vanadium		
Zinc		
W-ICPMS	Template: DEFAULT	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-ICPMS	Template: DEFAULT	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
Aluminum		
Antimony		
Arsenic		
Barium		
Beryllium		
Boron		
Cadmium		
Chromium		
Cobalt		
Copper		
Lead		
Manganese		
Molybdenum		
Nickel		
Selenium		
Silver		
Thallium		

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2015) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10150 B) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 B Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group C (Water) With 1 Samples:

Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: SMP	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
W-TDS	Template: DEFAULT	(SM 2540 C-2015) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.