

Login Checklist

RQ- 2023-05-01-23

Login Station ID: #4

Shipping Method: ☒ FedEx | ☐ UPS | ☐ HD | ☐ Greyhound

Date/Time of Receipt: 05/ 4 /2023@09:30

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
2.8				2		X			585947351277

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included? Yes ☒ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes _____ No ☒

CONTAINER CHECK

Evidence Tape on Bottles? Yes _____ No _____ NA ☒ Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken? Yes _____ No _____ Containers intact? Yes ☒ No _____

Caps on tight? Yes ☒ No _____

Sufficient Sample Volume: Yes _____ No ☒

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container) Yes _____ No ☒ Init: TL

Chlorine detected? (One container checked per Field ID) Yes _____ No _____ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH< 2.0? Yes _____ No _____ NA ☒ Init: TL

**W-1-4-DIOX (Green dot on container) preserved to pH< 4.0? Yes _____ No _____ NA ☒ Init: TL

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: TL Date: 05/ 4 /2023 Event contains NCRs (Y/N)? N

Event ID: CEN-DIST-2023-05-04-02

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #4 Exp:10/17/2023
pH Test Strips 0 – 6	LOT# 223819AV Exp: AUG 30, 2023
pH Paper 0 – 3	N/A
pH Paper 0 – 13	LOT# 207621 Exp: March 15, 2024
Chlorine Test Strips	LOT# 1196 Exp: Feb. 2024

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 5/3/2023 **Collected By:** Matt Bearden, Leif Boman
Customer: CEN-DIST **Sampling Agency:** FDEP
RQ: RQ-2023-05-01-23 **Project ID:** SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1

Delivery Method: FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
SPRUCE CREEK AT RUSSEL PROPERTY	 G5CE0159

RELINQUISHED BY (SIGNATURE):



DATE/TIME: 5/3/2023 1600
EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By: TL

**Rec'd/Inspected
Date:**

5/4/23 @ 10:11



RQ-2023-05-01-23	Collected By: Matt Bearden, Leif Boman
Customer: FDEP	Field Report Prepared by: Matt Bearden, Leif Boman
Project ID: SMP	Sampling Agency: FDEP

WIN ID/Field ID: 
WIN ID/Field ID: G5CE0159

Comments:

Location: SPRUCE CREEK AT RUSSEL PROPERTY

Matrix: Marine

(Check One) ☒ Grab ☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT)						
5/3/2023 1000	5.57	66	23.5	6.99	0.3	1.4	3.2	1818	0.92						
Parameter Suite		Parameter Methods				Preservation		pH Check	# Bottles sent to Lab	Bottle Group					
Preserved Nutrients (P-500ML)		W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP				Ice		H2SO4*	<2						
		Lot #		Exp:											
Metals (P-500ML)		W-ICPMS / W-ICP / W-HARD				Ice		HNO3*	<2						
		Lot #		Exp:											
Filtered Nutrients (P125ML)		W-P04-F / Field Filtered 0.45 µm Filter				Ice									
		Filter Lot #	Syringe Lot #												
BOD (BP-1L)		OV-BODUNIN				Ice									
Chlorophyll (BP-1L)		CHLSUITE-W				Ice									
Physical/Aggregate (Fresh) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W-TDS				Ice									
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY				Ice									
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #			Formalin									
Periphyton (PT-50ML)		ALGAE-ID				Ice									
Microbiology (Contract Lab Bottle)		E Coli / F Coli / X / Enterococci				x Ice									
		Contract Lab													
Molecular (QPCR-P-500ML)		PCR-HF183 / PCR-BacR / PCR-DG3				Ice									
		PCR-GULL2 / PCR-GFD													
Tracers (BG-500ML)		W-E8321-DI / W-E8321-MS				Ice									
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI	W-E8321-MS		W-PSNP-TQ		Ice	MCAA Exp.	MCAA Lot#						
		W-PCL-TQ-R	W-CARB-AA (5 ml of MCAA Buffer Solution)		W-CT-CL-R										
		W-TR-SQ-R	W-PCB-TQ-R												
Phytoplankton		DTY-QN-C / PKD-QN-BV				Ice									
DOC		Field Filtered 0.45 µm Filter				Ice		H2SO4*	<2						
		W-DOC													
		Acid Preservative Expiration Date													
		Acid Preservative Lot Number													

~~A~~ C TL

Date of Request: 04-APR-2023
 Created By: BEARDEN_M On: 04-APR-2023
 Modified By: JASROTIA_P On: 13-APR-2023
 Customer: CEN-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Central District
 Event Description: Run 21 plus Spruce deployment

Send Coolers To:

Phone: 407-897-4123
 FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Matthew Bearden
 Cooler Ship EMail: matthew.bearden@floridadep.gov

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 13-APR-2023
 Biology Request Reviewed By: JASROTIA_P On: 13-APR-2023
 Sampling Kit Required: YES Ship on: 21-APR-2023
 Sampling Kit Shipped: YES On: 17-APR-2023
 Sampling Kit Packed By: LEBRUN_T
 Preservatives Needed: YES
 Date to Receive Samples: 04-MAY-2023
 Logged In By: LEBRUN_T On: 04-MAY-2023

Send Final Report To:

FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Matthew Bearden
 Report Notification EMail:
 matthew.bearden@floridadep.gov;jessie.atchison@floridadep.gov
 v

Comments:**Bottle Group A (Water) With 1 Samples:**

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2015) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10150 B) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: BG-500ML FILL TO	Number of Bottles: 4	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Chlordane and Toxaphene in water matrices by GC/MS with Negative Chemical Ionization
W-PCB-TQ-R	Template: DEFAULT	(EPA 8270E) PCBs in water matrices by GC/MS/MS
W-PCL-TQ-R	Template:	(EPA 8270E) Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NQ ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L		Number of Bottles: 1	Preserved With: ICE
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices	
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices	
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)	
Color (true)			
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)	
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices	
W-TDS	Template: DEFAULT	(SM 2540 C-2015) Total Dissolved Solids in aqueous matrices	
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample	
Bottle Type: BP-1L		Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10150 B) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry	
Bottle Type: P-500ML		Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L	
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L	
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L	
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices	
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices	

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-250ML-WO-THI		Number of Bottles: 1	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems	

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.