

Chemical Analysis Report

CEN-DIST-2023-05-17-01

Florida DEP Laboratory
2600 Blair Stone Road
Tallahassee, FL 32399-2400
DOH Accreditation E31780

Event Description: **Henderson Lake LVI**
Request ID: **RQ-2023-05-15-68**
Customer: **CEN-DIST**
Project ID: **SMP**

Send Reports to:
FL Dept. of Environmental Protection
FL Dept. of Environmental Protection
3319 Maguire Blvd., Suite 232
Orlando, FL 32803-3767
Attn: Matthew Bearden

For additional information please contact
Colin Wright, Ph.D.
Chris Bowen, B.S.
Kerry Tate, Ph.D.
Dr. rer. nat. Bettina Steinbock
Thekkekalathil Chandrasekhar, Ph.D, QA Officer
Phone (850) 245-8085

Certified by: Colin Wright, Program Administrator

Date Certified: 06-JUN-2023 09:18



Case Narrative

Unless otherwise noted, all samples included in this report were received in accordance with protocols referenced in Chapter 62-160, Florida Administrative Code (F.A.C.). Results published in this report pertain only to the samples as submitted to, and received by the laboratory. All times in this report are adjusted to the applicable Eastern Time Zone (EST or EDT).

Results for the following analytical groups are included in this report: Metals, Nutrients and Pesticides.

Scientific notation may be used in reporting very large or small values. Values reported using scientific notation will take the form of the following example: 1.3E+03, which is equivalent to 1.3×10^3 or 1300.

Unless otherwise noted, analytical values for soil and sediment samples are reported on a dry weight basis, and analytical values for waste and tissue samples are reported on a wet weight basis.

Results for TNI accredited tests met requirements established by The NELAC Institute. A double asterisk (**) is used to indicate an analyte/matrix/method for which the laboratory is not TNI accredited by the Florida Department of Health Environmental Laboratory Certification Program or where accreditation for that field of testing is not applicable.

Any significant anomalies or deviations from established protocols are documented in Non-Conformance Reports, which, where appropriate, are included within this analytical report. Additional comments related to specific analytical tests may be included as remarks following the analytical results for each sample. Such comments and remarks are for informational purposes only and are not intended to convey judgement about the usability of the reported data.

A quality control report on the performance of the test method for the submitted samples is included. Uncertainty associated with the analytical results contained in this report can be estimated from the reported quality assurance results and from published quality control acceptance limits for each analytical test. Matrix quality control results (matrix spike recoveries and matrix sample precision) pertain only to the matrix sample tested and do not necessarily reflect test method performance for other samples.

Typical matrix quality control (QC) measurements may include matrix spike recovery, matrix spike duplicate recovery, matrix spike precision and matrix sample precision. Not all matrix QC results may be available or reportable; where they are not an explanation is provided. Typical reasons for unavailable QC results include, but are not limited to, a) insufficient matrix sample to perform some or all QC measurements; b) analyte concentration in the sample replicated was too low for a meaningful measurement of precision and c) analyte concentration in the matrix sample spiked was too high (relative to the amount of analyte spiked) for a meaningful measurement of recovery. Where matrix QC results are unavailable, other method performance metrics (e.g., LCS recovery, LCS precision, surrogate recovery) may be used to assess performance of the method. Comments explaining any missing QC measurements are not intended to convey any adverse conclusions about the quality of the reported data.

Precision is reported as relative percent difference unless otherwise noted.

Quality Control codes as defined below may be used in this report to indicate results that are associated with one or more quality control elements which did not fall within established test method criteria. Such results may be qualified as estimates using a J qualifier as required by 62-160 F.A.C. Explanations are included in the report for any results that were reported as estimates for other reasons.

QC Codes used in this report may include:

- LCS – Recovery for the batch Laboratory Control Sample (LCS) was outside existing control limits;
- MS – Recovery for the batch matrix spike (MS) was outside existing control limits;
- CCV – Recovery for a continuing calibration verification (CCV) standard was outside existing control limits;
- SUR – Recovery of a surrogate (SUR) for associated analytes was outside existing control limits;
- RPD – The precision, measured as relative percent difference (RPD), of batch replicate measurements was outside existing control limits;
- RSD – The precision, measured as relative standard deviation (RSD), of batch replicate measurements was outside existing control limits;
- SMP – Sample - used precision derived from replicate analyses of a sample;

The following data qualifiers are used, where applicable, in this report as specified in 62-160 F.A.C.

- A - Value reported is the mean of two or more determinations.
- B - Results based on colony counts outside the acceptable range.
- I - The reported value is between the laboratory method detection limit and the laboratory practical quantitation limit.
- J - Estimated value and/or the analysis did not meet established quality control criteria.
- K - Actual value is known to be less than value given.
- L - Actual value is known to be greater than value given.
- N - Presumptive evidence of presence of material.
- O - Sampled, but analysis lost or not performed.
- Q - Sample held beyond normal holding time.
- T - Value reported is less than the criterion of detection.
- U - Material was analyzed for but not detected. The reported value is the method detection limit for the sample analyzed.
- V - Analyte was detected in both sample and method blank.
- X - Too few individuals to calculate SCI value.
- Y - The laboratory analysis was from an unpreserved or improperly preserved sample. The data may not be accurate.
- Z - Colonies were too numerous to count (TNTC).

Quality control information from overflow laboratories may not be included in this report. Please refer to the associated report from the overflow laboratory for additional information.

Sample Location: HENDERSON LAKE AT CENTER

Collection Date/Time: 05/16/2023 12:23

Field ID: G4CE0232

Matrix: W-SURF-FRH

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2410531	DEP SOP: NU-094-1	Color (true)	24		PCU	P430002	
	EPA 180.1 Rev. 2.0	Turbidity	3.8		NTU	P430010	
	EPA 300.0 Rev. 2.1	Chloride	16		mg Cl/L	P430367	
		Sulfate	1.5		mg SO4/L	P430370	
	SM 2320 B-2011	Total Alkalinity	57		mg CaCO3/L	P430439	
	SM 2540 C-2015	TDS	116		mg/L	P430682	
	SM 2540 D-2015	TSS	4	I	mg/L	P430519	
2410532	SM 4500-F- C-2011	Fluoride	0.074	I	mg F/L	P430531	
	EPA 350.1 Rev. 2.0	Ammonia-N	0.006		mg N/L	P430338	
	EPA 351.2 Rev. 2.0	Kjeldahl Nitrogen	1.0		mg N/L	P430089	
	EPA 353.2 Rev. 2.0	NO2NO3-N	0.004	U	mg N/L	P430404	
	EPA 365.1 Rev. 2.0	Total-P	0.016		mg P/L	P430096	
2410533	SM 5310 B-2011	Organic Carbon	13		mg C/L	P430150	
2410537	EPA 365.1 Rev. 2.0 dissolved	O-Phosphate-P	0.004	I	mg P/L	P429991	
	EPA 8321B	2,4-D	0.041		ug/L	P430178	
		Acesulfame K	0.10	U	ug/L	P429908	
		2,4,5-T	0.0040	U	ug/L	P430178	
		AMPA	0.10	U	ug/L	P429908	
		Acetaminophen	0.0080	U	ug/L	P430178	
		Acetamiprid	0.0020	U	ug/L	P430178	
		Endothall	0.25	U	ug/L	P429908	
		Glufosinate	0.10	U	ug/L	P429908	
		Glyphosate	0.10	U	ug/L	P429908	
		Afidopyrophen	0.0020	U	ug/L	P430178	
		Bentazon	8.0E-04	U	ug/L	P430178	
		Sucralose	0.13		ug/L	P429908	
		Benzovindiflupyr	0.0020	U	ug/L	P430178	
		Carbamazepine	8.0E-04	U	ug/L	P430178	
		Clothianidin	0.0020	U	ug/L	P430178	
		Dinotefuran	0.0020	U	ug/L	P430178	
		Diuron	0.0020	U	ug/L	P430178	
		Fenuron	0.032	U	ug/L	P430178	
		Fluridone	0.024		ug/L	P430178	
		Imazapyr	0.0040	U	ug/L	P430178	
		Hydrocodone	0.0020	U	ug/L	P430178	
		Ibuprofen	0.080	U	ug/L	P430178	
		Imidacloprid	0.0020	U	ug/L	P430178	MS
		Linuron	0.0040	U	ug/L	P430178	
		Mandestrobin	0.0020	U	ug/L	P430178	
		MCPP	0.0020	U	ug/L	P430178	
		Naproxen	0.0080	U	ug/L	P430178	
		Primidone	0.0040	U	ug/L	P430178	
		Pyraclostrobin	0.0020	U	ug/L	P430178	

Field ID: G4CE0232

Matrix: W-SURF-FRH

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2410537	EPA 8321B	Silvex	0.0040	U	ug/L	P430178	
		Thiamethoxam	0.0020	U	ug/L	P430178	
		Tolfenpyrad	0.0020	U	ug/L	P430178	
		Triclopyr	0.0040	U	ug/L	P430178	
2410538	EPA 200.7 Rev. 4.4	Calcium	23.7		mg/L	P430036	
		Iron	30	I	ug/L	P430036	
		Magnesium	1.98		mg/L	P430036	
		Potassium	0.63	I	mg/L	P430036	
		Sodium	7.8		mg/L	P430036	
		Strontium	63.5		ug/L	P430036	
		Tin	3.0	U	ug/L	P430036	
		Titanium	0.75	U	ug/L	P430036	
		Vanadium	2.0	U	ug/L	P430036	
		Zinc	5.0	U	ug/L	P430036	
	EPA 200.8 Rev. 5.4	Aluminum	11	I	ug/L	P430036	
		Antimony	0.052	I	ug/L	P430036	
		Arsenic	0.92		ug/L	P430036	
		Barium	6.11		ug/L	P430036	
		Beryllium	0.010	U	ug/L	P430036	
		Boron	22.6		ug/L	P430036	
		Cadmium	0.020	U	ug/L	P430036	
		Chromium	0.40	U	ug/L	P430036	
		Cobalt	0.020	U	ug/L	P430036	
		Copper	0.40	U	ug/L	P430036	
		Lead	0.20	U	ug/L	P430036	
		Manganese	4.91		ug/L	P430036	
		Molybdenum	0.15	U	ug/L	P430036	
		Nickel	0.50	U	ug/L	P430036	
		Selenium	0.20	U	ug/L	P430036	
		Silver	0.010	U	ug/L	P430036	
		Thallium	0.10	U	ug/L	P430036	
		Hardness	67.3		mg/L	P430036	
2410539	SM 2340 B-2011	Oxybenzone**	10	U	ng/L	P430033	
	EPA 8270E	Acetochlor	0.20	U	ng/L	P430033	
		Octinoxate**	20	U	ng/L	P430033	
		Alachlor	0.41	U	ng/L	P430033	
		Avobenzone**	100	U	ng/L	P430033	MS
		Ametryn	1.1	U	ng/L	P430033	
		Atrazine	3.4		ng/L	P430033	
		PBDE-47**	4.1	U	ng/L	P430033	
		Atrazine Desethyl	1.3	U	ng/L	P430033	
		PBDE-99**	5.1	U	ng/L	P430033	
		Azinphos Methyl	3.1	U	ng/L	P430033	
		Tri-o-cresyl Phosphate**	6.1	U	ng/L	P430033	
		Azoxystrobin	0.41	U	ng/L	P430033	

Field ID: G4CE0232

Matrix: W-SURF-FRH

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2410539	EPA 8270E	Bromacil	0.61	U	ng/L	P430033	
		2-Ethylhexyl	12	UJ	ng/L	P430033	LCS
		2,3,4,5-tetrabromobenzoate (EHTBB)**					
		Butylate	0.20	U	ng/L	P430033	
		Dechlorane Plus**	31	U	ng/L	P430033	
		Caffeine**	30	I	ng/L	P430033	
		Dechlorane 602**	5.1	U	ng/L	P430033	RPD
		Carbophenothion	0.51	U	ng/L	P430033	
		Dechlorane 603**	4.1	U	ng/L	P430033	
		Carfentrazone Ethyl	0.15	U	ng/L	P430033	
		Hexabromobenzene**	6.1	U	ng/L	P430033	
		Chlorfenapyr	0.31	U	ng/L	P430033	
		PBB-153**	8.2	U	ng/L	P430033	MS, RPD
		Chlorpyrifos Ethyl	0.31	U	ng/L	P430033	
		Pentabromotoluene**	3.1	U	ng/L	P430033	
		Chlorpyrifos Methyl	0.10	U	ng/L	P430033	
		Tris(2-chloroethyl) phosphate (TCEP)**	71	U	ng/L	P430033	
		Coumaphos	1.1	U	ng/L	P430033	RPD
		Tris(1-chloro-2-propyl) phosphate (TCPP)**	20	I	ng/L	P430033	
		Cyanazine	5.1	U	ng/L	P430033	
		Tris(1,3-dichloro-2-propyl) phosphate (TDCPP)**	19		ng/L	P430033	
		Cyprodinil	0.20	U	ng/L	P430033	
		Tetradecachloro-m-terphenyl**	7.7	U	ng/L	P430033	MS
		Demeton	3.6	U	ng/L	P430033	
		Diazinon	0.13	U	ng/L	P430033	
		Difenoconazole	0.61	U	ng/L	P430033	MS, RPD
		Dimethenamid	0.10	U	ng/L	P430033	
		Dimethomorph	0.31	U	ng/L	P430033	
		Disulfoton	0.61	U	ng/L	P430033	
		Dithiopyr	1.0	U	ng/L	P430033	
		EPTC	0.51	U	ng/L	P430033	
		Ethion	0.31	U	ng/L	P430033	
		Ethoprop	0.13	U	ng/L	P430033	
		Etridiazole	0.10	U	ng/L	P430033	
		Fenamiphos	0.46	U	ng/L	P430033	
		Fenbuconazole	0.51	U	ng/L	P430033	MS
		Fipronil	0.20	U	ng/L	P430033	
		Fipronil Desulfinyl**	0.24	I	ng/L	P430033	
		Fipronil Sulfide	0.10	U	ng/L	P430033	
		Fipronil Sulfone	0.10	U	ng/L	P430033	
		Fluazifop-P-butyl	0.10	U	ng/L	P430033	
		Fludioxonil	0.10	U	ng/L	P430033	
		Flumioxazin	3.1	U	ng/L	P430033	RPD
		Flutolanil	0.10	U	ng/L	P430033	
		Fluxapyroxad	0.26	U	ng/L	P430033	

Field ID: G4CE0232

Matrix: W-SURF-FRH

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2410539	EPA 8270E	Fonofos	0.15	U	ng/L	P430033	
		Hexazinone	0.51	U	ng/L	P430033	
		Imazalil	0.66	U	ng/L	P430033	
		Iprodione	0.51	U	ng/L	P430033	RPD
		Loratadine**	0.31	U	ng/L	P430033	
		Malathion	0.36	U	ng/L	P430033	
		Metalaxyl	0.51	U	ng/L	P430033	
		Metolachlor	0.77	U	ng/L	P430033	
		Metribuzin	0.41	U	ng/L	P430033	
		Mevinphos	1.0	U	ng/L	P430033	
		Molinate	0.26	U	ng/L	P430033	
		Myclobutanil	0.36	U	ng/L	P430033	
		Naled	2.6	U	ng/L	P430033	
		Napropamide	0.71	U	ng/L	P430033	
		Norflurazon	1.0	U	ng/L	P430033	
		Oxadiazon	0.36	U	ng/L	P430033	
		Oxyfluorfen	0.20	U	ng/L	P430033	
		Parathion Ethyl	0.15	U	ng/L	P430033	
		Parathion Methyl	0.20	U	ng/L	P430033	
		Pendimethalin	0.77	U	ng/L	P430033	
		Phenytol**	5.4	U	ng/L	P430033	
		Phorate	0.26	U	ng/L	P430033	
		Prodiamine	0.20	U	ng/L	P430033	
		Prometon	3.1	U	ng/L	P430033	
		Prometryn	0.36	U	ng/L	P430033	
		Pronamide	0.10	U	ng/L	P430033	
		Propanil	0.10	U	ng/L	P430033	
		Propargite	0.82	U	ng/L	P430033	
		Propiconazole	0.61	U	ng/L	P430033	
		Pyraflufen Ethyl	0.31	U	ng/L	P430033	
		Pyridaben	1.4	U	ng/L	P430033	RPD
		Pyriproxyfen	0.26	U	ng/L	P430033	
		Simazine	0.26	U	ng/L	P430033	
		Stirophos	0.41	U	ng/L	P430033	
		Sulfentrazone	1.4	U	ng/L	P430033	
		Tebuconazole	1.4	U	ng/L	P430033	
		Terbufos	0.20	U	ng/L	P430033	
		Terbuthylazine	0.20	U	ng/L	P430033	
		Thiobencarb	0.51	U	ng/L	P430033	RPD
		Triadimefon	0.15	U	ng/L	P430033	

Ref. Method and Comment:

SM 2540 C-2015: Batch relative percent difference is unavailable because of low analyte concentration in the QC sample.

SM 2540 D-2015: Batch relative percent difference is unavailable because of low analyte concentration in the QC sample.

EPA 8321B: MS accuracy and/or precision for several analytes could not be assessed due to high concentration of parameter in the spiked sample.

EPA 8270E: Refer to the Lab Analysis Report for an explanation of QC Codes.

EPA 8270E: MS accuracy for atrazine not assessed due to high content of this parameter in the sample spiked

Quality Assurance Report Method Blank Results

Reference Method: DEP SOP: NU-094-1
Batch ID: P430002

Component	Result	Code	Units
Color (true)	2.5	U	PCU

Reference Method: EPA 180.1 Rev. 2.0
Batch ID: P430010

Component	Result	Code	Units
Turbidity	0.10	U	NTU

Reference Method: EPA 200.7 Rev. 4.4
Batch ID: P430036

Component	Result	Code	Units
Calcium	0.075	U	mg/L
Iron	30	U	ug/L
Magnesium	0.040	U	mg/L
Potassium	0.30	U	mg/L
Sodium	0.50	U	mg/L
Strontium	2.0	U	ug/L
Tin	3.0	U	ug/L
Titanium	0.75	U	ug/L
Vanadium	2.0	U	ug/L
Zinc	5.0	U	ug/L

Reference Method: EPA 200.8 Rev. 5.4
Batch ID: P430036

Component	Result	Code	Units
Aluminum	5.0	U	ug/L
Antimony	0.050	U	ug/L
Arsenic	0.050	U	ug/L
Barium	0.20	U	ug/L
Beryllium	0.010	U	ug/L
Boron	2.0	U	ug/L
Cadmium	0.020	U	ug/L
Chromium	0.40	U	ug/L
Cobalt	0.020	U	ug/L
Copper	0.40	U	ug/L
Lead	0.20	U	ug/L
Manganese	0.10	U	ug/L
Molybdenum	0.15	U	ug/L
Nickel	0.50	U	ug/L
Selenium	0.20	U	ug/L
Silver	0.010	U	ug/L
Thallium	0.10	U	ug/L

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P430367

Component	Result	Code	Units
Chloride	0.20	U	mg Cl/L

Quality Assurance Report Method Blank Results

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P430370

Component	Result	Code	Units
Sulfate	0.20	U	mg SO4/L

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P430338

Component	Result	Code	Units
Ammonia-N	0.002	U	mg N/L

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P430089

Component	Result	Code	Units
Kjeldahl Nitrogen	0.080	U	mg N/L

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P430404

Component	Result	Code	Units
NO2NO3-N	0.004	U	mg N/L

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P430096

Component	Result	Code	Units
Total-P	0.002	U	mg P/L

Reference Method: EPA 365.1 Rev. 2.0 dissolved
Batch ID: P429991

Component	Result	Code	Units
O-Phosphate-P	0.004	U	mg P/L

Reference Method: EPA 8270E
Batch ID: P430033

Component	Result	Code	Units
2-Ethylhexyl 2,3,4,5-tetrabromobenzoate (EHTBB)	12	U	ng/L
2-Ethylhexyl 2,3,4,5-tetrabromobenzoate (EHTBB)	12	U	ng/L
Acetochlor	0.20	U	ng/L
Acetochlor	0.20	U	ng/L
Alachlor	0.40	U	ng/L
Alachlor	0.40	U	ng/L
Ametryn	1.1	U	ng/L
Ametryn	1.1	U	ng/L
Atrazine	0.20	U	ng/L
Atrazine	0.20	U	ng/L
Atrazine Desethyl	1.3	U	ng/L
Atrazine Desethyl	1.3	U	ng/L
Avobenzone	100	U	ng/L
Avobenzone	100	U	ng/L
Azinphos Methyl	3.0	U	ng/L
Azinphos Methyl	3.0	U	ng/L

Quality Assurance Report

Method Blank Results

Reference Method: EPA 8270E

Batch ID: P430033

Component	Result	Code	Units
Azoxystrobin	0.40	U	ng/L
Azoxystrobin	0.40	U	ng/L
Bromacil	0.60	U	ng/L
Bromacil	0.60	U	ng/L
Butylate	0.20	U	ng/L
Butylate	0.20	U	ng/L
Caffeine	7.5	U	ng/L
Caffeine	7.5	U	ng/L
Carbophenothion	0.50	U	ng/L
Carbophenothion	0.50	U	ng/L
Carfentrazone Ethyl	0.15	U	ng/L
Carfentrazone Ethyl	0.15	U	ng/L
Chlorfenapyr	0.30	U	ng/L
Chlorfenapyr	0.30	U	ng/L
Chlorpyrifos Ethyl	0.30	U	ng/L
Chlorpyrifos Ethyl	0.30	U	ng/L
Chlorpyrifos Methyl	0.10	U	ng/L
Chlorpyrifos Methyl	0.10	U	ng/L
Coumaphos	1.0	U	ng/L
Coumaphos	1.0	U	ng/L
Cyanazine	5.0	U	ng/L
Cyanazine	5.0	U	ng/L
Cyprodinil	0.20	U	ng/L
Cyprodinil	0.20	U	ng/L
Dechlorane 602	5.0	U	ng/L
Dechlorane 602	5.0	U	ng/L
Dechlorane 603	4.0	U	ng/L
Dechlorane 603	4.0	U	ng/L
Dechlorane Plus	30	U	ng/L
Dechlorane Plus	30	U	ng/L
Demeton	3.5	U	ng/L
Demeton	3.5	U	ng/L
Diazinon	0.12	U	ng/L
Diazinon	0.12	U	ng/L
Difenoconazole	0.60	U	ng/L
Difenoconazole	0.60	U	ng/L
Dimethenamid	0.10	U	ng/L
Dimethenamid	0.10	U	ng/L
Dimethomorph	0.30	U	ng/L
Dimethomorph	0.30	U	ng/L
Disulfoton	0.60	U	ng/L
Disulfoton	0.60	U	ng/L
Dithiopyr	1.0	U	ng/L
Dithiopyr	1.0	U	ng/L
EPTC	0.50	U	ng/L
EPTC	0.50	U	ng/L
Ethion	0.30	U	ng/L
Ethion	0.30	U	ng/L
Ethoprop	0.12	U	ng/L
Ethoprop	0.12	U	ng/L
Etridiazole	0.10	U	ng/L
Etridiazole	0.10	U	ng/L

Quality Assurance Report

Method Blank Results

Reference Method: EPA 8270E

Batch ID: P430033

Component	Result	Code	Units
Fenamiphos	0.45	U	ng/L
Fenamiphos	0.45	U	ng/L
Fenbuconazole	0.50	U	ng/L
Fenbuconazole	0.50	U	ng/L
Fipronil	0.20	U	ng/L
Fipronil	0.20	U	ng/L
Fipronil Desulfinyl	0.10	U	ng/L
Fipronil Desulfinyl	0.10	U	ng/L
Fipronil Sulfide	0.10	U	ng/L
Fipronil Sulfide	0.10	U	ng/L
Fipronil Sulfone	0.10	U	ng/L
Fipronil Sulfone	0.10	U	ng/L
Fluazifop-P-butyl	0.10	U	ng/L
Fluazifop-P-butyl	0.10	U	ng/L
Fludioxonil	0.10	U	ng/L
Fludioxonil	0.10	U	ng/L
Flumioxazin	3.0	U	ng/L
Flumioxazin	3.0	U	ng/L
Flutolanil	0.10	U	ng/L
Flutolanil	0.10	U	ng/L
Fluxapyroxad	0.25	U	ng/L
Fluxapyroxad	0.25	U	ng/L
Fonofos	0.15	U	ng/L
Fonofos	0.15	U	ng/L
Hexabromobenzene	6.0	U	ng/L
Hexabromobenzene	6.0	U	ng/L
Hexazinone	0.50	U	ng/L
Hexazinone	0.50	U	ng/L
Imazalil	0.65	U	ng/L
Imazalil	0.65	U	ng/L
Iprodione	0.50	U	ng/L
Iprodione	0.50	U	ng/L
Loratadine	0.30	U	ng/L
Loratadine	0.30	U	ng/L
Malathion	0.35	U	ng/L
Malathion	0.35	U	ng/L
Metalaxyl	0.50	U	ng/L
Metalaxyl	0.50	U	ng/L
Metolachlor	0.75	U	ng/L
Metolachlor	0.75	U	ng/L
Metribuzin	0.40	U	ng/L
Metribuzin	0.40	U	ng/L
Mevinphos	1.0	U	ng/L
Mevinphos	1.0	U	ng/L
Molinate	0.25	U	ng/L
Molinate	0.25	U	ng/L
Myclobutanil	0.35	U	ng/L
Myclobutanil	0.35	U	ng/L
Naled	2.5	U	ng/L
Naled	2.5	U	ng/L
Napropamide	0.70	U	ng/L
Napropamide	0.70	U	ng/L

Quality Assurance Report

Method Blank Results

Reference Method: EPA 8270E

Batch ID: P430033

Component	Result	Code	Units
Norflurazon	1.0	U	ng/L
Norflurazon	1.0	U	ng/L
Octinoxate	20	U	ng/L
Octinoxate	20	U	ng/L
Oxadiazon	0.35	U	ng/L
Oxadiazon	0.35	U	ng/L
Oxybenzone	10	U	ng/L
Oxybenzone	10	U	ng/L
Oxyfluorfen	0.20	U	ng/L
Oxyfluorfen	0.20	U	ng/L
Parathion Ethyl	0.15	U	ng/L
Parathion Ethyl	0.15	U	ng/L
Parathion Methyl	0.20	U	ng/L
Parathion Methyl	0.20	U	ng/L
PBB-153	8.0	U	ng/L
PBB-153	8.0	U	ng/L
PBDE-47	4.0	U	ng/L
PBDE-47	4.0	U	ng/L
PBDE-99	5.0	U	ng/L
PBDE-99	5.0	U	ng/L
Pendimethalin	0.75	U	ng/L
Pendimethalin	0.75	U	ng/L
Pentabromotoluene	3.0	U	ng/L
Pentabromotoluene	3.0	U	ng/L
Phenytoin	5.3	U	ng/L
Phenytoin	5.3	U	ng/L
Phorate	0.25	U	ng/L
Phorate	0.25	U	ng/L
Prodiamine	0.20	U	ng/L
Prodiamine	0.20	U	ng/L
Prometon	3.0	U	ng/L
Prometon	3.0	U	ng/L
Prometryn	0.35	U	ng/L
Prometryn	0.35	U	ng/L
Pronamide	0.10	U	ng/L
Pronamide	0.10	U	ng/L
Propanil	0.10	U	ng/L
Propanil	0.10	U	ng/L
Propargite	0.80	U	ng/L
Propargite	0.80	U	ng/L
Propiconazole	0.60	U	ng/L
Propiconazole	0.60	U	ng/L
Pyraflufen Ethyl	0.30	U	ng/L
Pyraflufen Ethyl	0.30	U	ng/L
Pyridaben	1.4	U	ng/L
Pyridaben	1.4	U	ng/L
Pyriproxyfen	0.25	U	ng/L
Pyriproxyfen	0.25	U	ng/L
Simazine	0.25	U	ng/L
Simazine	0.25	U	ng/L
Stirophos	0.40	U	ng/L
Stirophos	0.40	U	ng/L

Quality Assurance Report

Method Blank Results

Reference Method: EPA 8270E

Batch ID: P430033

Component	Result	Code	Units
Sulfentrazone	1.4	U	ng/L
Sulfentrazone	1.4	U	ng/L
Tebuconazole	1.4	U	ng/L
Tebuconazole	1.4	U	ng/L
Terbufos	0.20	U	ng/L
Terbufos	0.20	U	ng/L
Terbutylazine	0.20	U	ng/L
Terbutylazine	0.20	U	ng/L
Tetradecachloro-m-terphenyl	7.5	U	ng/L
Tetradecachloro-m-terphenyl	7.5	U	ng/L
Thiobencarb	0.50	U	ng/L
Thiobencarb	0.50	U	ng/L
Tri-o-cresyl Phosphate	6.0	U	ng/L
Tri-o-cresyl Phosphate	6.0	U	ng/L
Triadimefon	0.15	U	ng/L
Triadimefon	0.15	U	ng/L
Tris(1-chloro-2-propyl) phosphate (TCPP)	15	U	ng/L
Tris(1-chloro-2-propyl) phosphate (TCPP)	15	U	ng/L
Tris(1,3-dichloro-2-propyl) phosphate (TDCPP)	2.5	U	ng/L
Tris(1,3-dichloro-2-propyl) phosphate (TDCPP)	2.5	U	ng/L
Tris(2-chloroethyl) phosphate (TCEP)	70	U	ng/L
Tris(2-chloroethyl) phosphate (TCEP)	70	U	ng/L

Reference Method: EPA 8321B

Batch ID: P429908

Component	Result	Code	Units
Acesulfame K	0.10	U	ug/L
AMPA	0.10	U	ug/L
Endothall	0.25	U	ug/L
Glufosinate	0.10	U	ug/L
Glyphosate	0.10	U	ug/L
Sucralose	0.010	U	ug/L

Reference Method: EPA 8321B

Batch ID: P430178

Component	Result	Code	Units
2,4-D	0.0020	U	ug/L
2,4,5-T	0.0040	U	ug/L
Acetaminophen	0.0080	U	ug/L
Acetamiprid	0.0020	U	ug/L
Afidopyopen	0.0020	U	ug/L
Bentazon	8.0E-04	U	ug/L
Benzovindiflupyr	0.0020	U	ug/L
Carbamazepine	8.0E-04	U	ug/L
Clothianidin	0.0020	U	ug/L
Dinotefuran	0.0020	U	ug/L
Diuron	0.0020	U	ug/L
Fenuron	0.032	U	ug/L
Fluridone	8.0E-04	U	ug/L
Hydrocodone	0.0020	U	ug/L

Quality Assurance Report

Method Blank Results

Reference Method: EPA 8321B

Batch ID: P430178

Component	Result	Code	Units
Ibuprofen	0.080	U	ug/L
Imazapyr	0.0040	U	ug/L
Imidacloprid	0.0020	U	ug/L
Linuron	0.0040	U	ug/L
Mandestrobin	0.0020	U	ug/L
MCPP	0.0020	U	ug/L
Naproxen	0.0080	U	ug/L
Primidone	0.0040	U	ug/L
Pyraclostrobin	0.0020	U	ug/L
Silvex	0.0040	U	ug/L
Thiamethoxam	0.0020	U	ug/L
Tolfenpyrad	0.0020	U	ug/L
Triclopyr	0.0040	U	ug/L

Reference Method: SM 2320 B-2011

Batch ID: P430439

Component	Result	Code	Units
Total Alkalinity	0.65	U	mg CaCO3/L

Reference Method: SM 2540 C-2015

Batch ID: P430682

Component	Result	Code	Units
TDS	15	U	mg/L

Reference Method: SM 2540 D-2015

Batch ID: P430519

Component	Result	Code	Units
TSS	2	U	mg/L

Reference Method: SM 4500-F- C-2011

Batch ID: P430531

Component	Result	Code	Units
Fluoride	0.025	U	mg F/L

Reference Method: SM 5310 B-2011

Batch ID: P430150

Component	Result	Code	Units
Organic Carbon	0.50	U	mg C/L

Quality Assurance Report

Laboratory Control Sample Accuracy

Reference Method: DEP SOP: NU-094-1
Batch ID: P430002

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Color (true)	93.4		P	90 - 110

Reference Method: EPA 180.1 Rev. 2.0
Batch ID: P430010

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Turbidity	97.2		P	90 - 110

Reference Method: EPA 200.7 Rev. 4.4
Batch ID: P430036

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Calcium	103		P	80 - 120
Iron	104		P	80 - 120
Magnesium	103		P	80 - 120
Potassium	101		P	80 - 120
Sodium	95.4		P	80 - 120
Strontium	99.9		P	80 - 120
Tin	106		P	80 - 120
Titanium	102		P	80 - 120
Vanadium	102		P	80 - 120
Zinc	102		P	80 - 120

Reference Method: EPA 200.8 Rev. 5.4
Batch ID: P430036

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Aluminum	99.6		P	85 - 115
Antimony	104		P	85 - 115
Arsenic	99.7		P	85 - 115
Barium	103		P	85 - 115
Beryllium	94.6		P	85 - 115
Boron	98.5		P	85 - 115
Cadmium	101		P	85 - 115
Chromium	95.1		P	85 - 115
Cobalt	99.8		P	85 - 115
Copper	96.8		P	85 - 115
Lead	102		P	85 - 115
Manganese	97.6		P	85 - 115
Molybdenum	98.8		P	85 - 115
Nickel	98.6		P	85 - 115
Selenium	99.4		P	85 - 115
Silver	103		P	85 - 115
Thallium	101		P	85 - 115

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P430367

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Chloride	101		P	90 - 110

Quality Assurance Report Laboratory Control Sample Accuracy

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P430370

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Sulfate	99.9		P	90 - 110

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P430338

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Ammonia-N	97.4		P	90 - 110

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P430089

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Kjeldahl Nitrogen	100		P	90 - 110

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P430404

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
NO2NO3-N	95.5		P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P430096

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Total-P	99.6		P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0 dissolved
Batch ID: P429991

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
O-Phosphate-P	102		P	90 - 110

Reference Method: EPA 8270E
Batch ID: P430033

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2-Ethylhexyl 2,3,4,5-tetrabromobenzoate (EHTBB)	34.7		F	42 - 162
Acetochlor	83.3		P	69 - 123
Alachlor	117		P	65 - 118
Ametryn	97.7		P	58 - 141
Atrazine	92.1		P	73 - 118
Atrazine Desethyl	93.9		P	32 - 125
Avobenzone	168		P	40 - 203
Azinphos Methyl	94.7		P	36 - 197
Azoxystrobin	104		P	58 - 226
Bromacil	92.9		P	48 - 120
Butylate	61.6		P	27 - 85.0
Caffeine	107		P	40 - 137
Carbophenothion	130		P	54 - 132
Carfentrazone Ethyl	101		P	60 - 142
Chlorfenapyr	85.0		P	53 - 117
Chlorpyrifos Ethyl	86.7		P	59 - 116

Quality Assurance Report

Laboratory Control Sample Accuracy

Reference Method: EPA 8270E

Batch ID: P430033

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Chlorpyrifos Methyl	94.1		P	66 - 119
Coumaphos	114		P	11 - 234
Cyanazine	202		P	61 - 248
Cyprodinil	95.6		P	50 - 147
Dechlorane 602	99.8		P	50 - 150
Dechlorane 603	124		P	50 - 150
Dechlorane Plus	129		P	47 - 182
Demeton	65.6		P	30 - 138
Diazinon	92.8		P	67 - 126
Difenoconazole	116		P	38 - 205
Dimethenamid	91.3		P	57 - 111
Dimethomorph	132		P	16 - 212
Disulfoton	83.7		P	46 - 126
Dithiopyr	89.4		P	62 - 115
EPTC	47.0		P	28 - 80.0
Ethion	82.1		P	24 - 122
Ethoprop	80.9		P	62 - 113
Etridiazole	87.2		P	28 - 92.0
Fenamiphos	84.1		P	57 - 128
Fenbuconazole	86.9		P	52 - 155
Fipronil	125		P	63 - 130
Fipronil Desulfinyl	127		P	61 - 130
Fipronil Sulfide	91.3		P	56 - 117
Fipronil Sulfone	88.2		P	52 - 118
Fluazifop-P-butyl	80.4		P	61 - 128
Fludioxonil	95.3		P	59 - 129
Flumioxazin	111		P	30 - 250
Flutolanil	96.3		P	53 - 127
Fluxapyroxad	124		P	42 - 132
Fonofos	88.3		P	61 - 110
Hexabromobenzene	116		P	50 - 150
Hexazinone	92.0		P	46 - 139
Imazalil	97.7		P	40 - 139
Iprodione	132		P	40 - 146
Loratadine	120		P	10 - 224
Malathion	129		P	61 - 135
Metaxyl	112		P	58 - 121
Metolachlor	106		P	64 - 118
Metribuzin	100		P	45 - 245
Mevinphos	88.0		P	49 - 118
Molinate	58.2		P	42 - 92.0
Myclobutanil	89.5		P	55 - 127
Naled	43.1		P	10 - 114
Napropamide	81.3		P	39 - 121
Norflurazon	77.8		P	55 - 129
Octinoxate	120		P	26 - 166
Oxadiazon	81.1		P	54 - 115
Oxybenzone	119		P	49 - 135
Oxyfluorfen	108		P	64 - 139
Parathion Ethyl	98.3		P	70 - 111
Parathion Methyl	92.7		P	76 - 136
PBB-153	89.0		P	50 - 150

Quality Assurance Report Laboratory Control Sample Accuracy

Reference Method: EPA 8270E

Batch ID: P430033

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
PBDE-47	104		P	41 - 148
PBDE-99	64.6		P	38 - 147
Pendimethalin	103		P	52 - 118
Pentabromotoluene	111		P	50 - 150
Phenytoin	58.2		P	10 - 162
Phorate	84.4		P	40 - 122
Prodiamine	72.1		P	26 - 141
Prometon	85.5		P	54 - 122
Prometryn	128		P	61 - 128
Pronamide	93.6		P	72 - 121
Propanil	139		P	45 - 144
Propargite	119		P	10 - 199
Propiconazole	86.4		P	56 - 127
Pyraflufen Ethyl	68.1		P	56 - 140
Pyridaben	119		P	26 - 211
Pyriproxyfen	130		P	33 - 194
Simazine	79.7		P	67 - 121
Stirophos	105		P	20 - 142
Sulfentrazone	108		P	21 - 144
Tebuconazole	101		P	10 - 122
Terbufos	87.2		P	60 - 129
Terbutylazine	105		P	69 - 113
Tetradecachloro-m-terphenyl	180		P	70 - 200
Thiobencarb	84.2		P	51 - 120
Tri-o-cresyl Phosphate	123		P	49 - 150
Triadimefon	79.3		P	56 - 114
Tris(1-chloro-2-propyl) phosphate (TCPP)	125		P	50 - 150
Tris(1,3-dichloro-2-propyl) phosphate (TDCPP)	110		P	50 - 150
Tris(2-chloroethyl) phosphate (TCEP)	123		P	70 - 180

Reference Method: EPA 8321B

Batch ID: P429908

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Acesulfame K	92.2		P	40 - 150
AMPA	106		P	40 - 150
Endothall	85.6		P	40 - 150
Glufosinate	84.6		P	40 - 150
Glyphosate	102		P	40 - 150
Sucralose	117		P	40 - 150

Reference Method: EPA 8321B

Batch ID: P430178

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2,4-D	95.5		P	40 - 150
2,4,5-T	80.0		P	40 - 150
Acetaminophen	86.0		P	30 - 150
Acetamiprid	73.5		P	40 - 150
Afidopyropen	77.3		P	30 - 150
Bentazon	98.3		P	30 - 150
Benzovindiflupyr	77.9		P	40 - 150

Quality Assurance Report

Laboratory Control Sample Accuracy

Reference Method: EPA 8321B

Batch ID: P430178

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Carbamazepine	75.7		P	40 - 150
Clothianidin	90.2		P	40 - 150
Dinotefuran	88.8		P	40 - 150
Diuron	76.7		P	40 - 150
Fenuron	87.0		P	40 - 150
Fluridone	88.4		P	40 - 150
Hydrocodone	83.5		P	40 - 150
Ibuprofen	81.1		P	40 - 150
Imazapyr	89.0		P	40 - 150
Imidacloprid	84.5		P	40 - 150
Linuron	79.8		P	40 - 150
Mandestrobin	76.3		P	40 - 150
MCPP	93.6		P	40 - 150
Naproxen	60.5		P	40 - 150
Primidone	81.1		P	40 - 150
Pyraclostrobin	78.0		P	40 - 150
Silvex	88.6		P	40 - 150
Thiamethoxam	89.7		P	40 - 150
Tolfenpyrad	63.7		P	30 - 150
Triclopyr	84.5		P	40 - 150

Reference Method: SM 2320 B-2011

Batch ID: P430439

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Total Alkalinity	100		P	92 - 105

Reference Method: SM 2540 C-2015

Batch ID: P430682

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
TDS	96.8		P	90 - 110

Reference Method: SM 2540 D-2015

Batch ID: P430519

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
TSS	93.3		P	85 - 106

Reference Method: SM 4500-F- C-2011

Batch ID: P430531

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Fluoride	99.6		P	94 - 106

Reference Method: SM 5310 B-2011

Batch ID: P430150

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Organic Carbon	98.5		P	85 - 115

Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 200.7 Rev. 4.4

Batch ID: P430036

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2410005	Calcium	102	102	P/P	80 - 120
2410005	Iron	104	102	P/P	80 - 120
2410005	Magnesium	102	100	P/P	80 - 120
2410005	Potassium	102	101	P/P	80 - 120
2410005	Sodium	93.3	91.9	P/P	80 - 120
2410005	Strontium	96.9	96.4	P/P	80 - 120
2410005	Tin	103	101	P/P	80 - 120
2410005	Titanium	99.3	99.0	P/P	80 - 120
2410005	Vanadium	98.4	98.5	P/P	80 - 120
2410005	Zinc	99.1	99.1	P/P	80 - 120

Reference Method: EPA 200.8 Rev. 5.4

Batch ID: P430036

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2410005	Aluminum	99.5	101	P/P	80 - 120
2410005	Antimony	105	105	P/P	80 - 120
2410005	Arsenic	100	100	P/P	80 - 120
2410005	Barium	105	103	P/P	80 - 120
2410005	Beryllium	94.0	94.6	P/P	80 - 120
2410005	Boron	98.3	99.6	P/P	80 - 120
2410005	Cadmium	102	99.5	P/P	80 - 120
2410005	Chromium	93.8	96.4	P/P	80 - 120
2410005	Cobalt	99.1	101	P/P	80 - 120
2410005	Copper	96.2	99.2	P/P	80 - 120
2410005	Lead	103	103	P/P	80 - 120
2410005	Manganese	96.8	99.3	P/P	80 - 120
2410005	Molybdenum	98.8	98.6	P/P	80 - 120
2410005	Nickel	96.7	98.8	P/P	80 - 120
2410005	Selenium	99.9	99.8	P/P	80 - 120
2410005	Silver	102	101	P/P	80 - 120
2410005	Thallium	101	102	P/P	80 - 120

Reference Method: EPA 300.0 Rev. 2.1

Batch ID: P430367

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2410488	Chloride	101		P	90 - 110
2410592	Chloride	99.0		P	90 - 110

Reference Method: EPA 300.0 Rev. 2.1

Batch ID: P430370

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2410488	Sulfate	98.7		P	90 - 110
2410592	Sulfate	99.1		P	90 - 110

Reference Method: EPA 350.1 Rev. 2.0

Batch ID: P430338

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2410490	Ammonia-N	97.4	98.2	P/P	90 - 110

Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P430089

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2410234	Kjeldahl Nitrogen	101	109	P/P	90 - 110

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P430404

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2410527	NO2NO3-N	102	96.8	P/P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P430096

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2410593	Total-P	105	105	P/P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0 dissolved
Batch ID: P429991

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2410465	O-Phosphate-P	98.7	98.3	P/P	90 - 110

Reference Method: EPA 8270E
Batch ID: P430033

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2410434	2-Ethylhexyl 2,3,4,5-tetrabromobenzoate (EHTBB)	95.3	127	P/P	26 - 165
2410434	Acetochlor	72.7	79.9	P/P	67 - 124
2410434	Alachlor	89.0	94.0	P/P	60 - 120
2410434	Ametryn	121	93.8	P/P	54 - 216
2410434	Atrazine Desethyl	86.2	107	P/P	15 - 122
2410434	Avobenzone	135	184	P/F	37 - 178
2410434	Azinphos Methyl	65.9	85.7	P/P	40 - 292
2410434	Azoxystrobin	81.3	96.4	P/P	35 - 220
2410434	Bromacil	65.4	76.4	P/P	45 - 127
2410434	Butylate	62.0	59.5	P/P	20 - 83.0
2410434	Caffeine	106	131	P/P	10 - 194
2410434	Carbophenothion	100	118	P/P	57 - 127
2410434	Carfentrazone Ethyl	69.1	77.1	P/P	51 - 141
2410434	Chlorfenapyr	68.7	75.3	P/P	46 - 111
2410434	Chlorpyrifos Ethyl	108	85.3	P/P	52 - 120
2410434	Chlorpyrifos Methyl	79.0	81.6	P/P	63 - 119
2410434	Coumaphos	61.4	92.8	P/P	10 - 228
2410434	Cyanazine	164	237	P/P	59 - 241
2410434	Cyprodinil	84.3	87.8	P/P	47 - 146
2410434	Dechlorane 602	75.7	109	P/P	50 - 150
2410434	Dechlorane 603	102	135	P/P	50 - 150
2410434	Dechlorane Plus	106	93.5	P/P	50 - 150
2410434	Demeton	63.1	70.6	P/P	40 - 136
2410434	Diazinon	89.5	86.1	P/P	69 - 132
2410434	Difenoconazole	45.9	114	F/P	57 - 258
2410434	Dimethenamid	72.9	84.6	P/P	54 - 110
2410434	Dimethomorph	143	101	P/P	28 - 210
2410434	Disulfoton	75.7	84.7	P/P	43 - 133

Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 8270E

Batch ID: P430033

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2410434	Dithiopyr	76.0	80.0	P/P	39 - 116
2410434	EPTC	51.0	49.6	P/P	20 - 78.0
2410434	Ethion	95.9	111	P/P	17 - 119
2410434	Ethoprop	100	94.8	P/P	66 - 120
2410434	Etridiazole	77.1	85.9	P/P	28 - 96.0
2410434	Fenamiphos	68.7	61.9	P/P	41 - 126
2410434	Fenbuconazole	37.4	73.6	F/P	42 - 169
2410434	Fipronil	98.6	111	P/P	61 - 132
2410434	Fipronil Desulfinyl	94.9	105	P/P	56 - 132
2410434	Fipronil Sulfide	75.5	86.7	P/P	48 - 119
2410434	Fipronil Sulfone	68.2	78.9	P/P	42 - 131
2410434	Fluazifop-P-butyl	75.1	77.3	P/P	53 - 131
2410434	Fludioxonil	73.9	84.7	P/P	56 - 127
2410434	Flumioxazin	57.0	112	P/P	19 - 300
2410434	Flutolanil	91.8	101	P/P	41 - 127
2410434	Fluxapyroxad	92.7	118	P/P	42 - 172
2410434	Fonofos	91.8	81.9	P/P	59 - 113
2410434	Hexabromobenzene	124	133	P/P	50 - 150
2410434	Hexazinone	97.6	84.9	P/P	66 - 122
2410434	Imazalil	178	104	P/P	21 - 283
2410434	Iprodione	81.2	53.7	P/P	43 - 150
2410434	Loratadine	146	90.5	P/P	23 - 201
2410434	Malathion	75.7	96.0	P/P	58 - 136
2410434	Metalaxyl	101	114	P/P	55 - 120
2410434	Metolachlor	91.2	97.0	P/P	57 - 121
2410434	Metribuzin	94.3	94.5	P/P	58 - 294
2410434	Mevinphos	81.2	73.6	P/P	50 - 126
2410434	Molinate	57.7	61.5	P/P	42 - 93.0
2410434	Myclobutanil	72.4	80.7	P/P	55 - 125
2410434	Naled	37.9	40.9	P/P	18 - 200
2410434	Napropamide	62.2	73.3	P/P	39 - 110
2410434	Norflurazon	57.0	68.2	P/P	48 - 128
2410434	Octinoxate	106	116	P/P	21 - 159
2410434	Oxadiazon	65.1	74.1	P/P	43 - 112
2410434	Oxybenzone	114	124	P/P	41 - 142
2410434	Oxyfluorfen	100	97.1	P/P	64 - 153
2410434	Parathion Ethyl	93.8	96.5	P/P	69 - 114
2410434	Parathion Methyl	94.7	86.5	P/P	79 - 139
2410434	PBB-153	107	150	P/F	50 - 150
2410434	PBDE-47	101	118	P/P	27 - 144
2410434	PBDE-99	78.0	112	P/P	18 - 150
2410434	Pendimethalin	109	100	P/P	50 - 139
2410434	Pentabromotoluene	109	117	P/P	50 - 150
2410434	Phenytoin	65.8	58.1	P/P	10 - 146
2410434	Phorate	83.1	96.7	P/P	54 - 161
2410434	Prodiamine	57.9	59.8	P/P	30 - 161
2410434	Prometon	110	86.4	P/P	45 - 134
2410434	Prometryn	99.4	117	P/P	45 - 137
2410434	Pronamide	82.4	84.1	P/P	65 - 133
2410434	Propanil	125	126	P/P	49 - 142
2410434	Propargite	85.7	97.5	P/P	10 - 203
2410434	Propiconazole	63.7	67.5	P/P	38 - 146

Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 8270E

Batch ID: P430033

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2410434	Pyraflufen Ethyl	58.6	70.3	P/P	34 - 153
2410434	Pyridaben	71.8	111	P/P	12 - 192
2410434	Pyriproxyfen	90.8	122	P/P	33 - 180
2410434	Simazine	72.2	72.4	P/P	51 - 157
2410434	Stirophos	79.3	98.0	P/P	10 - 128
2410434	Sulfentrazone	92.8	111	P/P	53 - 186
2410434	Tebuconazole	76.8	82.6	P/P	10 - 133
2410434	Terbufos	90.9	80.0	P/P	65 - 139
2410434	Terbuthylazine	96.9	94.6	P/P	66 - 117
2410434	Tetradecachloro-m-terphenyl	193	215	P/F	70 - 200
2410434	Thiobencarb	55.0	75.8	P/P	51 - 119
2410434	Tri-o-cresyl Phosphate	100	120	P/P	31 - 144
2410434	Triadimefon	77.4	83.8	P/P	48 - 119
2410434	Tris(1-chloro-2-propyl) phosphate (TCPP)	107	89.7	P/P	50 - 150
2410434	Tris(1,3-dichloro-2-propyl) phosphate (TDCPP)	103	114	P/P	50 - 150
2410434	Tris(2-chloroethyl) phosphate (TCEP)	118	119	P/P	70 - 180

Reference Method: EPA 8321B

Batch ID: P429908

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2409832	Acesulfame K	80.8	81.0	P/P	40 - 150
2409832	AMPA	97.6	102	P/P	40 - 150
2409832	Endothall	95.1	92.9	P/P	40 - 150
2409832	Glufosinate	74.2	82.1	P/P	40 - 150
2409832	Glyphosate	90.3	100	P/P	40 - 150
2409832	Sucralose	119	96.2	P/P	40 - 150

Reference Method: EPA 8321B

Batch ID: P430178

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2410774	2,4-D	85.5	83.4	P/P	40 - 150
2410774	2,4,5-T	98.1	96.2	P/P	40 - 150
2410774	Acetaminophen	93.3	92.7	P/P	30 - 150
2410774	Acetamiprid	68.3	71.1	P/P	40 - 150
2410774	Afidopyropen	69.2	72.0	P/P	30 - 150
2410774	Benzovindiflupyr	83.4	86.7	P/P	40 - 150
2410774	Carbamazepine	71.8	70.0	P/P	40 - 150
2410774	Clothianidin	96.8	109	P/P	40 - 150
2410774	Dinotefuran	87.4	85.9	P/P	40 - 150
2410774	Diuron	72.9	66.0	P/P	40 - 150
2410774	Fenuron	65.0	66.6	P/P	40 - 150
2410774	Hydrocodone	70.5	69.2	P/P	40 - 150
2410774	Ibuprofen	51.8	50.0	P/P	40 - 150
2410774	Imidacloprid	148	155	P/F	40 - 150
2410774	Linuron	68.9	76.2	P/P	40 - 150
2410774	Mandestrobin	81.2	80.3	P/P	40 - 150
2410774	MCP	101	101	P/P	40 - 150
2410774	Naproxen	65.3	60.7	P/P	40 - 150
2410774	Primidone	83.1	84.6	P/P	40 - 150
2410774	Pyraclostrobin	85.4	83.8	P/P	40 - 150

Quality Assurance Report

Matrix Spike Accuracy

Reference Method: EPA 8321B
Batch ID: P430178

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2410774	Silvex	80.8	93.5	P/P	40 - 150
2410774	Thiamethoxam	110	113	P/P	40 - 150
2410774	Tolfenpyrad	63.0	59.2	P/P	30 - 150
2410774	Triclopyr	88.1	93.4	P/P	40 - 150

Reference Method: SM 4500-F- C-2011
Batch ID: P430531

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2410591	Fluoride	99.2	100	P/P	94 - 106

Reference Method: SM 5310 B-2011
Batch ID: P430150

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2410490	Organic Carbon	95.5	95.2	P/P	85 - 115

Quality Assurance Report Precision

Reference Method: DEP SOP: NU-094-1
Batch ID: P430002

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2410488	Color (true)	0.152	Sample	P	0 - 20

Reference Method: EPA 180.1 Rev. 2.0
Batch ID: P430010

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2410488	Turbidity	10.5	Sample	P	0 - 20

Reference Method: EPA 200.7 Rev. 4.4
Batch ID: P430036

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2410005	Calcium	0.797	Spike	P	0 - 20
2410005	Iron	1.51	Spike	P	0 - 20
2410005	Magnesium	1.81	Spike	P	0 - 20
2410005	Potassium	0.926	Spike	P	0 - 20
2410005	Sodium	1.16	Spike	P	0 - 20
2410005	Strontium	0.517	Spike	P	0 - 20
2410005	Tin	1.88	Spike	P	0 - 20
2410005	Titanium	0.310	Spike	P	0 - 20
2410005	Vanadium	0.0937	Spike	P	0 - 20
2410005	Zinc	0.0255	Spike	P	0 - 20

Reference Method: EPA 200.8 Rev. 5.4
Batch ID: P430036

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2410005	Aluminum	1.33	Spike	P	0 - 20
2410005	Antimony	0.522	Spike	P	0 - 20
2410005	Arsenic	0.0372	Spike	P	0 - 20
2410005	Barium	1.82	Spike	P	0 - 20
2410005	Beryllium	0.654	Spike	P	0 - 20
2410005	Boron	1.09	Spike	P	0 - 20
2410005	Cadmium	2.57	Spike	P	0 - 20
2410005	Chromium	2.68	Spike	P	0 - 20
2410005	Cobalt	2.30	Spike	P	0 - 20
2410005	Copper	3.12	Spike	P	0 - 20
2410005	Lead	0.0983	Spike	P	0 - 20
2410005	Manganese	2.14	Spike	P	0 - 20
2410005	Molybdenum	0.197	Spike	P	0 - 20
2410005	Nickel	2.10	Spike	P	0 - 20
2410005	Selenium	0.152	Spike	P	0 - 20
2410005	Silver	0.379	Spike	P	0 - 20
2410005	Thallium	1.01	Spike	P	0 - 20

Quality Assurance Report Precision

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P430367

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2410488	Chloride	1.37	Sample	P	0 - 20

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P430370

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2410488	Sulfate	1.71	Sample	P	0 - 20

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P430338

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2410490	Ammonia-N	0.598	Spike	P	0 - 20

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P430089

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2410234	Kjeldahl Nitrogen	5.59	Spike	P	0 - 20

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P430404

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2410527	NO2NO3-N	4.72	Spike	P	0 - 20

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P430096

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2410593	Total-P	0.452	Spike	P	0 - 20

Reference Method: EPA 365.1 Rev. 2.0 dissolved
Batch ID: P429991

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2410465	O-Phosphate-P	0.330	Spike	P	0 - 20

Reference Method: EPA 8270E
Batch ID: P430033

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2410434	2-Ethylhexyl 2,3,4,5-tetrabromobenzoate (EHTBB)	28.5	Spike	P	0 - 37
2410434	Acetochlor	9.52	Spike	P	0 - 28

Quality Assurance Report

Precision

Reference Method: EPA 8270E

Batch ID: P430033

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2410434	Alachlor	5.43	Spike	P	0 - 30
2410434	Ametryn	25.7	Spike	P	0 - 32
2410434	Atrazine	6.70	Spike	P	0 - 41
2410434	Atrazine Desethyl	21.8	Spike	P	0 - 36
2410434	Avobenzone	31.1	Spike	P	0 - 36
2410434	Azinphos Methyl	26.1	Spike	P	0 - 75
2410434	Azoxystrobin	17.0	Spike	P	0 - 39
2410434	Bromacil	15.6	Spike	P	0 - 33
2410434	Butylate	4.20	Spike	P	0 - 44
2410434	Caffeine	20.8	Spike	P	0 - 74
2410434	Carbophenothion	15.7	Spike	P	0 - 25
2410434	Carfentrazone Ethyl	10.9	Spike	P	0 - 27
2410434	Chlorfenapyr	9.20	Spike	P	0 - 24
2410434	Chlorpyrifos Ethyl	23.7	Spike	P	0 - 26
2410434	Chlorpyrifos Methyl	3.17	Spike	P	0 - 26
2410434	Coumaphos	40.7	Spike	F	0 - 28
2410434	Cyanazine	36.1	Spike	P	0 - 48
2410434	Cyprodinil	4.09	Spike	P	0 - 29
2410434	Dechlorane 602	35.8	Spike	F	0 - 30
2410434	Dechlorane 603	28.4	Spike	P	0 - 30
2410434	Dechlorane Plus	12.9	Spike	P	0 - 30
2410434	Demeton	11.3	Spike	P	0 - 33
2410434	Diazinon	3.86	Spike	P	0 - 29
2410434	Difenoconazole	84.9	Spike	F	0 - 34
2410434	Dimethenamid	15.0	Spike	P	0 - 39
2410434	Dimethomorph	34.5	Spike	P	0 - 51
2410434	Disulfoton	11.2	Spike	P	0 - 30
2410434	Dithiopyr	5.10	Spike	P	0 - 26
2410434	EPTC	2.66	Spike	P	0 - 43
2410434	Ethion	14.8	Spike	P	0 - 79
2410434	Ethoprop	5.55	Spike	P	0 - 29
2410434	Etridiazole	10.8	Spike	P	0 - 33
2410434	Fenamiphos	10.5	Spike	P	0 - 40
2410434	Fenbuconazole	65.3	Spike	P	0 - 74
2410434	Fipronil	11.8	Spike	P	0 - 29
2410434	Fipronil Desulfinyl	9.71	Spike	P	0 - 32
2410434	Fipronil Sulfide	13.8	Spike	P	0 - 30
2410434	Fipronil Sulfone	14.6	Spike	P	0 - 33
2410434	Fluazifop-P-butyl	2.92	Spike	P	0 - 38
2410434	Fludioxonil	13.7	Spike	P	0 - 29
2410434	Flumioxazin	65.0	Spike	F	0 - 51
2410434	Flutolanil	9.07	Spike	P	0 - 25
2410434	Fluxapyroxad	23.8	Spike	P	0 - 45
2410434	Fonofos	11.4	Spike	P	0 - 27
2410434	Hexabromobenzene	6.74	Spike	P	0 - 30
2410434	Hexazinone	13.9	Spike	P	0 - 30
2410434	Imazalil	52.4	Spike	P	0 - 100
2410434	Iprodione	40.9	Spike	F	0 - 33
2410434	Loratadine	46.9	Spike	P	0 - 56
2410434	Malathion	23.6	Spike	P	0 - 37
2410434	Metalaxyl	11.4	Spike	P	0 - 40

Quality Assurance Report

Precision

Reference Method: EPA 8270E

Batch ID: P430033

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2410434	Metolachlor	5.30	Spike	P	0 - 29
2410434	Metribuzin	0.195	Spike	P	0 - 45
2410434	Mevinphos	9.86	Spike	P	0 - 29
2410434	Molinate	6.38	Spike	P	0 - 33
2410434	Myclobutanil	10.8	Spike	P	0 - 26
2410434	Naled	7.60	Spike	P	0 - 37
2410434	Napropamide	16.3	Spike	P	0 - 44
2410434	Norflurazon	17.9	Spike	P	0 - 30
2410434	Octinoxate	9.85	Spike	P	0 - 45
2410434	Oxadiazon	12.9	Spike	P	0 - 28
2410434	Oxybenzone	8.10	Spike	P	0 - 46
2410434	Oxyfluorfen	3.10	Spike	P	0 - 28
2410434	Parathion Ethyl	2.81	Spike	P	0 - 31
2410434	Parathion Methyl	9.08	Spike	P	0 - 29
2410434	PBB-153	33.8	Spike	F	0 - 30
2410434	PBDE-47	15.4	Spike	P	0 - 36
2410434	PBDE-99	35.7	Spike	P	0 - 40
2410434	Pendimethalin	8.60	Spike	P	0 - 33
2410434	Pentabromotoluene	6.72	Spike	P	0 - 30
2410434	Phenytoin	12.4	Spike	P	0 - 100
2410434	Phorate	15.1	Spike	P	0 - 36
2410434	Prodiamine	3.24	Spike	P	0 - 71
2410434	Prometon	23.9	Spike	P	0 - 36
2410434	Prometryn	16.6	Spike	P	0 - 28
2410434	Pronamide	2.10	Spike	P	0 - 24
2410434	Propanil	1.03	Spike	P	0 - 28
2410434	Propargite	12.9	Spike	P	0 - 43
2410434	Propiconazole	5.70	Spike	P	0 - 33
2410434	Pyraflufen Ethyl	18.1	Spike	P	0 - 29
2410434	Pyridaben	43.2	Spike	F	0 - 30
2410434	Pyriproxyfen	29.1	Spike	P	0 - 79
2410434	Simazine	0.139	Spike	P	0 - 29
2410434	Stirophos	21.1	Spike	P	0 - 61
2410434	Sulfentrazone	17.8	Spike	P	0 - 33
2410434	Tebuconazole	7.27	Spike	P	0 - 69
2410434	Terbufos	12.8	Spike	P	0 - 29
2410434	Terbuthylazine	2.43	Spike	P	0 - 32
2410434	Tetradecachloro-m-terphenyl	10.4	Spike	P	0 - 30
2410434	Thiobencarb	31.7	Spike	F	0 - 26
2410434	Tri-o-cresyl Phosphate	17.8	Spike	P	0 - 33
2410434	Triadimefon	7.92	Spike	P	0 - 28
2410434	Tris(1-chloro-2-propyl) phosphate (TCPP)	18.0	Spike	P	0 - 30
2410434	Tris(1,3-dichloro-2-propyl) phosphate (TDCPP)	9.69	Spike	P	0 - 30
2410434	Tris(2-chloroethyl) phosphate (TCEP)	0.807	Spike	P	0 - 30

Reference Method: EPA 8321B

Batch ID: P429908

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2409832	Acesulfame K	0.158	Spike	P	0 - 30

Quality Assurance Report Precision

Reference Method: EPA 8321B

Batch ID: P429908

Replicated

Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2409832	AMPA	4.23	Spike	P	0 - 30
2409832	Endothall	2.43	Spike	P	0 - 30
2409832	Glufosinate	10.1	Spike	P	0 - 30
2409832	Glyphosate	9.05	Spike	P	0 - 30
2409832	Sucralose	14.0	Spike	P	0 - 30

Reference Method: EPA 8321B

Batch ID: P430178

Replicated

Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2410774	2,4-D	1.47	Spike	P	0 - 30
2410774	2,4,5-T	1.99	Spike	P	0 - 30
2410774	Acetaminophen	0.607	Spike	P	0 - 30
2410774	Acetamiprid	4.09	Spike	P	0 - 30
2410774	Afidopyropen	3.91	Spike	P	0 - 30
2410774	Benzovindiflupyr	3.86	Spike	P	0 - 30
2410774	Carbamazepine	2.21	Spike	P	0 - 30
2410774	Clothianidin	7.91	Spike	P	0 - 30
2410774	Dinotefuran	1.71	Spike	P	0 - 30
2410774	Diuron	9.91	Spike	P	0 - 30
2410774	Fenuron	2.49	Spike	P	0 - 30
2410774	Fluridone	0.155	Spike	P	0 - 30
2410774	Hydrocodone	1.85	Spike	P	0 - 30
2410774	Ibuprofen	3.43	Spike	P	0 - 30
2410774	Imazapyr	1.27	Spike	P	0 - 30
2410774	Imidacloprid	3.81	Spike	P	0 - 30
2410774	Linuron	10.2	Spike	P	0 - 30
2410774	Mandestrobin	1.10	Spike	P	0 - 30
2410774	MCPP	0.226	Spike	P	0 - 30
2410774	Naproxen	7.29	Spike	P	0 - 30
2410774	Primidone	1.53	Spike	P	0 - 30
2410774	Pyraclostrobin	1.93	Spike	P	0 - 30
2410774	Silvex	14.6	Spike	P	0 - 30
2410774	Thiamethoxam	2.74	Spike	P	0 - 30
2410774	Tolfenpyrad	6.36	Spike	P	0 - 30
2410774	Triclopyr	5.80	Spike	P	0 - 30

Reference Method: SM 2320 B-2011

Batch ID: P430439

Replicated

Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2410458	Total Alkalinity	0.522	Sample	P	0 - 3.9

Reference Method: SM 4500-F- C-2011

Batch ID: P430531

Replicated

Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2410591	Fluoride	0.953	Spike	P	0 - 1.9

Quality Assurance Report Precision

Reference Method: SM 5310 B-2011
Batch ID: P430150

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2410490	Organic Carbon	0.210	Spike	P	0 - 20

* Sample, spike and/or laboratory control sample precision (LCS) is reported.

Quality Assurance Report Surrogates

Lab Sample ID: 2410537
Field Sample ID: G4CE0232

Reference Method	Surrogate	% Rec.	Pass/Fail	Control Limits
EPA 8321B	2,4-D-d3	94.6	P	30 - 160
EPA 8321B	Acetaminophen-d4	95.6	P	30 - 160
EPA 8321B	Carbamazepine-d10	79.3	P	30 - 160
EPA 8321B	Diuron-d6	75.4	P	30 - 160
EPA 8321B	Endothall-d6	95.0	P	30 - 160
EPA 8321B	Glyphosate 13C 15N	86.1	P	30 - 160
EPA 8321B	Ibuprofen-d3	62.8	P	30 - 160
EPA 8321B	Primidone-d5	85.0	P	30 - 160
EPA 8321B	Sucralose-d6	101	P	30 - 160

Lab Sample ID: 2410539
Field Sample ID: G4CE0232

Reference Method	Surrogate	% Rec.	Pass/Fail	Control Limits
EPA 8270E	Caffeine-d9	85.9	P	20 - 200
EPA 8270E	Simazine-d10	70.4	P	62 - 142
EPA 8270E	Terbufos-d10	68.3	P	58 - 132
EPA 8270E	Terphenyl-d14	91.5	P	52 - 137

Quality Assurance Report Calibration Verification

Reference Method: EPA 365.1 Rev. 2.0 dissolved

Run ID: A119222

Included Lab Sample IDs: 2410533

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
O-Phosphate-P	97.1	98.1	P/P	90 - 110

Reference Method: DEP SOP: NU-094-1

Run ID: A119229

Included Lab Sample IDs: 2410531

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Color (true)	98.9	98.9	P/P	90 - 110

Reference Method: EPA 180.1 Rev. 2.0

Run ID: A119231

Included Lab Sample IDs: 2410531

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Turbidity	97.5	97.5	P/P	95 - 105

Reference Method: EPA 200.7 Rev. 4.4

Run ID: A119269

Included Lab Sample IDs: 2410538

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Calcium	97.8	98.8	P/P	90 - 110
Iron	98.9	100	P/P	90 - 110
Magnesium	97.7	98.9	P/P	90 - 110
Potassium	99.9	101	P/P	90 - 110
Sodium	92.6	94.7	P/P	90 - 110
Strontium	102	102	P/P	90 - 110
Tin	101	102	P/P	90 - 110
Titanium	102	102	P/P	90 - 110
Vanadium	101	100	P/P	90 - 110
Zinc	97.6	98.5	P/P	90 - 110

Reference Method: EPA 8321B

Run ID: A119295

Included Lab Sample IDs: 2410537

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Acesulfame K	98.9	100	P/P	60 - 160
Sucralose	127	119	P/P	60 - 160

Reference Method: EPA 200.8 Rev. 5.4

Run ID: A119298

Included Lab Sample IDs: 2410538

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Aluminum	98.5	98.1	P/P	90 - 110
Antimony	103	103	P/P	90 - 110
Arsenic	99.3	98.6	P/P	90 - 110
Barium	100	100	P/P	90 - 110
Beryllium	95.8	95.9	P/P	90 - 110
Boron	95.5	99.1	P/P	90 - 110

Quality Assurance Report Calibration Verification

Reference Method: EPA 200.8 Rev. 5.4

Run ID: A119298

Included Lab Sample IDs: 2410538

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Cadmium	99.5	100	P/P	90 - 110
Chromium	95.2	96.4	P/P	90 - 110
Cobalt	98.8	99.3	P/P	90 - 110
Copper	96.3	96.3	P/P	90 - 110
Lead	101	100	P/P	90 - 110
Manganese	96.8	97.5	P/P	90 - 110
Molybdenum	98.1	97.7	P/P	90 - 110
Nickel	96.4	96.8	P/P	90 - 110
Selenium	101	100	P/P	90 - 110
Silver	102	102	P/P	90 - 110
Thallium	99.3	98.7	P/P	90 - 110

Reference Method: SM 5310 B-2011

Run ID: A119300

Included Lab Sample IDs: 2410532

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Organic Carbon	98.8	98.2	P/P	90 - 110

Reference Method: EPA 8321B

Run ID: A119309

Included Lab Sample IDs: 2410537

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
AMPA	118	122	P/P	60 - 160
Endothall	87.4	86.1	P/P	60 - 160
Glufosinate	90.1	89.6	P/P	60 - 160
Glyphosate	114	108	P/P	60 - 160

Reference Method: EPA 365.1 Rev. 2.0

Run ID: A119340

Included Lab Sample IDs: 2410532

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Total-P	97.5	97.2	P/P	90 - 110

Reference Method: EPA 351.2 Rev. 2.0

Run ID: A119348

Included Lab Sample IDs: 2410532

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Kjeldahl Nitrogen	97.2	104	P/P	90 - 110

Reference Method: EPA 300.0 Rev. 2.1

Run ID: A119351

Included Lab Sample IDs: 2410531

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Chloride	99.3	98.2	P/P	90 - 110
Sulfate	97.5	96.2	P/P	90 - 110

Quality Assurance Report Calibration Verification

Reference Method: EPA 350.1 Rev. 2.0

Run ID: A119381

Included Lab Sample IDs: 2410532

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Ammonia-N	98.8	99.2	P/P	90 - 110

Reference Method: EPA 8270E

Run ID: A119398

Included Lab Sample IDs: 2410539

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
2-Ethylhexyl 2,3,4,5-tetrabromobenzoate (EHTBB)	101		P	80 - 120
Avobenzone	104		P	80 - 120
Dechlorane 602	100		P	80 - 120
Dechlorane 603	99.4		P	80 - 120
Dechlorane Plus	93.8		P	80 - 120
Hexabromobenzene	100		P	80 - 120
Octinoxate	97.5		P	80 - 120
Oxybenzone	96.9		P	80 - 120
PBB-153	100		P	80 - 120
PBDE-47	98.6		P	80 - 120
PBDE-99	101		P	80 - 120
Pentabromotoluene	101		P	80 - 120
Tetradecachloro-m-terphenyl	107		P	80 - 120
Tri-o-cresyl Phosphate	97.1		P	80 - 120
Tris(1-chloro-2-propyl) phosphate (TCPP)	83.8		P	80 - 120
Tris(1,3-dichloro-2-propyl) phosphate (TDCPP)	94.3		P	80 - 120
Tris(2-chloroethyl) phosphate (TCEP)	93.5		P	80 - 120

Reference Method: EPA 353.2 Rev. 2.0

Run ID: A119404

Included Lab Sample IDs: 2410532

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
NO2NO3-N	99.0	94.0	P/P	90 - 110

Reference Method: EPA 8270E

Run ID: A119420

Included Lab Sample IDs: 2410539

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Acetochlor	88.9		P	80 - 120
Alachlor	96.1		P	80 - 120
Ametryn	106		P	80 - 120
Atrazine	89.9		P	80 - 120
Atrazine Desethyl	108		P	80 - 120
Azinphos Methyl	89.8		P	80 - 120
Azoxystrobin	97.7		P	80 - 120
Bromacil	103		P	80 - 120
Butylate	98.3		P	80 - 120
Caffeine	103		P	80 - 120
Carbophenothion	106		P	80 - 120
Carfentrazone Ethyl	104		P	80 - 120
Chlorfenapyr	92.6		P	80 - 120
Chlorpyrifos Ethyl	87.8		P	80 - 120

Quality Assurance Report Calibration Verification

Reference Method: EPA 8270E
Run ID: A119420
Included Lab Sample IDs: 2410539

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Chlorpyrifos Methyl	95.7		P	80 - 120
Coumaphos	106		P	80 - 120
Cyanazine	102		P	80 - 120
Cyprodinil	94.8		P	80 - 120
Demeton	100		P	80 - 120
Diazinon	104		P	80 - 120
Difenoconazole	102		P	80 - 120
Dimethenamid	104		P	80 - 120
Dimethomorph	95.7		P	80 - 120
Disulfoton	101		P	80 - 120
Dithiopyr	106		P	80 - 120
EPTC	96.5		P	80 - 120
Ethion	84.7		P	80 - 120
Ethoprop	101		P	80 - 120
Etridiazole	101		P	80 - 120
Fenamiphos	91.3		P	80 - 120
Fenbuconazole	88.6		P	80 - 120
Fipronil	92.8		P	80 - 120
Fipronil Desulfinyl	103		P	80 - 120
Fipronil Sulfide	105		P	80 - 120
Fipronil Sulfone	106		P	80 - 120
Fluazifop-P-butyl	115		P	80 - 120
Fludioxonil	99.5		P	80 - 120
Flumioxazin	103		P	80 - 120
Flutolanil	87.4		P	80 - 120
Fluxapyroxad	107		P	80 - 120
Fonofos	103		P	80 - 120
Hexazinone	98.1		P	80 - 120
Imazalil	105		P	80 - 120
Iprodione	88.3		P	80 - 120
Loratadine	92.7		P	80 - 120
Malathion	91.5		P	80 - 120
Metaxyl	89.8		P	80 - 120
Metolachlor	98.7		P	80 - 120
Metribuzin	103		P	80 - 120
Mevinphos	93.2		P	80 - 120
Molinate	85.2		P	80 - 120
Myclobutanil	96.3		P	80 - 120
Naled	94.2		P	80 - 120
Napropamide	98.3		P	80 - 120
Norflurazon	105		P	80 - 120
Oxadiazon	107		P	80 - 120
Oxyfluorfen	95.0		P	80 - 120
Parathion Ethyl	101		P	80 - 120
Parathion Methyl	87.1		P	80 - 120
Pendimethalin	104		P	80 - 120
Phenytol	95.7		P	80 - 120
Phorate	95.5		P	80 - 120
Prodiamine	102		P	80 - 120
Prometon	100		P	80 - 120
Prometryn	108		P	80 - 120

Quality Assurance Report Calibration Verification

Reference Method: EPA 8270E
Run ID: A119420
Included Lab Sample IDs: 2410539

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Pronamide	104		P	80 - 120
Propanil	94.0		P	80 - 120
Propargite	108		P	80 - 120
Propiconazole	91.6		P	80 - 120
Pyraflufen Ethyl	112		P	80 - 120
Pyridaben	111		P	80 - 120
Pyriproxyfen	110		P	80 - 120
Simazine	91.8		P	80 - 120
Stirophos	85.4		P	80 - 120
Sulfentrazone	107		P	80 - 120
Tebuconazole	103		P	80 - 120
Terbufos	102		P	80 - 120
Terbuthylazine	90.3		P	80 - 120
Thiobencarb	107		P	80 - 120
Triadimefon	109		P	80 - 120

Reference Method: SM 2320 B-2011
Run ID: A119421
Included Lab Sample IDs: 2410531

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Total Alkalinity	98.0	97.9	P/P	90 - 110

Reference Method: EPA 8321B
Run ID: A119438
Included Lab Sample IDs: 2410537

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
2,4-D	101	99.2	P/P	50 - 150
2,4,5-T	99.1	97.3	P/P	50 - 150
Acetaminophen	97.8	106	P/P	60 - 160
Acetamiprid	114	118	P/P	50 - 150
Afidopyropen	111	90.5	P/P	50 - 150
Bentazon	140	129	P/P	50 - 160
Benzovindiflupyr	109	106	P/P	50 - 150
Carbamazepine	114	106	P/P	60 - 150
Clothianidin	109	117	P/P	60 - 150
Dinotefuran	110	115	P/P	50 - 150
Diuron	106	114	P/P	60 - 160
Fenuron	110	113	P/P	60 - 150
Fluridone	107	120	P/P	60 - 160
Hydrocodone	109	113	P/P	60 - 150
Ibuprofen	109	115	P/P	50 - 160
Imazapyr	110	102	P/P	50 - 150
Imidacloprid	105	107	P/P	60 - 150
Linuron	106	99.8	P/P	60 - 150
Mandestrobin	100	101	P/P	50 - 150
MCPP	104	107	P/P	50 - 150
Naproxen	115	96.2	P/P	50 - 160
Primidone	105	110	P/P	60 - 150
Pyraclostrobin	116	110	P/P	60 - 150

Quality Assurance Report Calibration Verification

Reference Method: EPA 8321B
Run ID: A119438
Included Lab Sample IDs: 2410537

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Silvex	109	117	P/P	50 - 150
Thiamethoxam	115	117	P/P	50 - 150
Tolfenpyrad	117	118	P/P	60 - 150
Triclopyr	79.7	109	P/P	50 - 150

Reference Method: SM 4500-F- C-2011
Run ID: A119457
Included Lab Sample IDs: 2410531

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Fluoride	101	101	P/P	90 - 110

* Pass/Fail determinations are made for each bracketing calibration verification check.
Control limits for initial calibration checks may be different from those for continuing checks, depending on method requirements.
Where they are different, both control limits are provided.

Quality Assurance Report Summary

Ref. Method	Analyte	LCS % Recovery	MS % Recovery		LCS	Precision SMP	MS
DEP SOP: NU-094-1	Color (true)	93.4				0.152	
EPA 180.1 Rev. 2.0	Turbidity	97.2				10.5	
EPA 200.7 Rev. 4.4	Calcium	103	102	102			0.797
	Iron	104	104	102			1.51
	Magnesium	103	102	100			1.81
	Potassium	101	102	101			0.926
	Sodium	95.4	93.3	91.9			1.16
	Strontium	99.9	96.9	96.4			0.517
	Tin	106	103	101			1.88
	Titanium	102	99.3	99.0			0.310
	Vanadium	102	98.4	98.5			0.0937
	Zinc	102	99.1	99.1			0.0255
EPA 200.8 Rev. 5.4	Aluminum	99.6	99.5	101			1.33
	Antimony	104	105	105			0.522
	Arsenic	99.7	100	100			0.0372
	Barium	103	105	103			1.82
	Beryllium	94.6	94.0	94.6			0.654
	Boron	98.5	98.3	99.6			1.09
	Cadmium	101	102	99.5			2.57
	Chromium	95.1	93.8	96.4			2.68
	Cobalt	99.8	99.1	101			2.30
	Copper	96.8	96.2	99.2			3.12
	Lead	102	103	103			0.0983
	Manganese	97.6	96.8	99.3			2.14
	Molybdenum	98.8	98.8	98.6			0.197
	Nickel	98.6	96.7	98.8			2.10
	Selenium	99.4	99.9	99.8			0.152
	Silver	103	102	101			0.379
	Thallium	101	101	102			1.01
EPA 300.0 Rev. 2.1	Chloride	101	101	99.0		1.37	
	Sulfate	99.9	98.7	99.1		1.71	
EPA 350.1 Rev. 2.0	Ammonia-N	97.4	97.4	98.2			0.598
EPA 351.2 Rev. 2.0	Kjeldahl Nitrogen	100	101	109			5.59
EPA 353.2 Rev. 2.0	NO2NO3-N	95.5	102	96.8			4.72
EPA 365.1 Rev. 2.0	Total-P	99.6	105	105			0.452
EPA 365.1 Rev. 2.0 dissolved	O-Phosphate-P	102	98.7	98.3			0.330
EPA 8270E	2-Ethylhexyl 2,3,4,5-tetrabromobenzoate (EHTBB)	34.7	95.3	127			28.5
	Acetochlor	83.3	72.7	79.9			9.52
	Alachlor	117	89.0	94.0			5.43
	Ametryn	97.7	121	93.8			25.7
	Atrazine	92.1					6.70
	Atrazine Desethyl	93.9	86.2	107			21.8
	Avobenzone	168	135	184			31.1
	Azinphos Methyl	94.7	65.9	85.7			26.1
	Azoxystrobin	104	81.3	96.4			17.0
	Bromacil	92.9	65.4	76.4			15.6
	Butylate	61.6	62.0	59.5			4.20
	Caffeine	107	106	131			20.8
	Carbophenothion	130	100	118			15.7
	Carfentrazone Ethyl	101	69.1	77.1			10.9
	Chlorfenapyr	85.0	68.7	75.3			9.20
	Chlorpyrifos Ethyl	86.7	108	85.3			23.7

Quality Assurance Report Summary

Ref. Method	Analyte	LCS % Recovery	MS % Recovery		LCS	Precision	MS
						SMP	
EPA 8270E	Chlorpyrifos Methyl	94.1	79.0	81.6			3.17
	Coumaphos	114	61.4	92.8			40.7
	Cyanazine	202	164	237			36.1
	Cyprodinil	95.6	84.3	87.8			4.09
	Dechlorane 602	99.8	75.7	109			35.8
	Dechlorane 603	124	102	135			28.4
	Dechlorane Plus	129	106	93.5			12.9
	Demeton	65.6	63.1	70.6			11.3
	Diazinon	92.8	89.5	86.1			3.86
	Difenoconazole	116	45.9	114			84.9
	Dimethenamid	91.3	72.9	84.6			15.0
	Dimethomorph	132	143	101			34.5
	Disulfoton	83.7	75.7	84.7			11.2
	Dithiopyr	89.4	76.0	80.0			5.10
	EPTC	47.0	51.0	49.6			2.66
	Ethion	82.1	95.9	111			14.8
	Ethoprop	80.9	100	94.8			5.55
	Etridiazole	87.2	77.1	85.9			10.8
	Fenamiphos	84.1	68.7	61.9			10.5
	Fenbuconazole	86.9	37.4	73.6			65.3
	Fipronil	125	98.6	111			11.8
	Fipronil Desulfinyl	127	94.9	105			9.71
	Fipronil Sulfide	91.3	75.5	86.7			13.8
	Fipronil Sulfone	88.2	68.2	78.9			14.6
	Fluazifop-P-butyl	80.4	75.1	77.3			2.92
	Fludioxonil	95.3	73.9	84.7			13.7
	Flumioxazin	111	57.0	112			65.0
	Flutolanil	96.3	91.8	101			9.07
	Fluxapyroxad	124	92.7	118			23.8
	Fonofos	88.3	91.8	81.9			11.4
	Hexabromobenzene	116	124	133			6.74
	Hexazinone	92.0	97.6	84.9			13.9
	Imazalil	97.7	178	104			52.4
	Iprodione	132	81.2	53.7			40.9
	Loratadine	120	146	90.5			46.9
	Malathion	129	75.7	96.0			23.6
	Metalaxyl	112	101	114			11.4
	Metolachlor	106	91.2	97.0			5.30
	Metribuzin	100	94.3	94.5			0.195
	Mevinphos	88.0	81.2	73.6			9.86
	Molinate	58.2	57.7	61.5			6.38
	Myclobutanil	89.5	80.7	72.4			10.8
	Naled	43.1	40.9	37.9			7.60
	Napropamide	81.3	73.3	62.2			16.3
	Norflurazon	77.8	68.2	57.0			17.9
	Octinoxate	120	106	116			9.85
	Oxadiazon	81.1	74.1	65.1			12.9
	Oxybenzone	119	114	124			8.10
	Oxyfluorfen	108	97.1	100			3.10
	Parathion Ethyl	98.3	96.5	93.8			2.81
	Parathion Methyl	92.7	86.5	94.7			9.08
	PBB-153	89.0	107	150			33.8
	PBDE-47	104	101	118			15.4
	PBDE-99	64.6	78.0	112			35.7

Quality Assurance Report Summary

Ref. Method	Analyte	LCS % Recovery	MS % Recovery		Precision SMP	MS
			LCS			
EPA 8270E	Pendimethalin	103	100	109		8.60
	Pentabromotoluene	111	109	117		6.72
	Phenytain	58.2	58.1	65.8		12.4
	Phorate	84.4	96.7	83.1		15.1
	Prodiamine	72.1	59.8	57.9		3.24
	Prometon	85.5	86.4	110		23.9
	Prometryn	128	117	99.4		16.6
	Pronamide	93.6	84.1	82.4		2.10
	Propanil	139	126	125		1.03
	Propargite	119	97.5	85.7		12.9
	Propiconazole	86.4	67.5	63.7		5.70
	Pyraflufen Ethyl	68.1	70.3	58.6		18.1
	Pyridaben	119	111	71.8		43.2
	Pyriproxyfen	130	122	90.8		29.1
	Simazine	79.7	72.4	72.2		0.139
	Stiropfos	105	98.0	79.3		21.1
	Sulfentrazone	108	111	92.8		17.8
	Tebuconazole	101	82.6	76.8		7.27
	Terbufos	87.2	80.0	90.9		12.8
	Terbutylazine	105	94.6	96.9		2.43
	Tetradecachloro-m-terphenyl	180	193	215		10.4
	Thiobencarb	84.2	75.8	55.0		31.7
	Tri-o-cresyl Phosphate	123	100	120		17.8
	Triadimefon	79.3	83.8	77.4		7.92
	Tris(1-chloro-2-propyl) phosphate (TCPP)	125	107	89.7		18.0
	Tris(1,3-dichloro-2-propyl) phosphate (TDCPP)	110	103	114		9.69
	Tris(2-chloroethyl) phosphate (TCEP)	123	118	119		0.807
EPA 8321B	2,4-D	95.5	85.5	83.4		1.47
	2,4,5-T	80.0	98.1	96.2		1.99
	Acesulfame K	92.2	80.8	81.0		0.158
	Acetaminophen	86.0	93.3	92.7		0.607
	Acetamiprid	73.5	68.3	71.1		4.09
	Afidopyropen	77.3	69.2	72.0		3.91
	AMPA	106	97.6	102		4.23
	Bentazon	98.3				
	Benzovindiflupyr	77.9	83.4	86.7		3.86
	Carbamazepine	75.7	71.8	70.0		2.21
	Clothianidin	90.2	96.8	109		7.91
	Dinotefuran	88.8	87.4	85.9		1.71
	Diuron	76.7	72.9	66.0		9.91
	Endothall	85.6	95.1	92.9		2.43
	Fenuron	87.0	65.0	66.6		2.49
	Fluridone	88.4				0.155
	Glufosinate	84.6	74.2	82.1		10.1
	Glyphosate	102	90.3	100		9.05
	Hydrocodone	83.5	70.5	69.2		1.85
	Ibuprofen	81.1	51.8	50.0		3.43
	Imazapyr	89.0				1.27
	Imidacloprid	84.5	148	155		3.81
	Linuron	79.8	68.9	76.2		10.2
	Mandestrobin	76.3	81.2	80.3		1.10

Quality Assurance Report Summary

Ref. Method	Analyte	LCS % Recovery	MS % Recovery		Precision LCS	SMP	MS
EPA 8321B	MCP	93.6	101	101			0.226
	Naproxen	60.5	65.3	60.7			7.29
	Primidone	81.1	83.1	84.6			1.53
	Pyraclostrobin	78.0	85.4	83.8			1.93
	Silvex	88.6	80.8	93.5			14.6
	Sucralose	117	119	96.2			14.0
	Thiamethoxam	89.7	110	113			2.74
	Tolfenpyrad	63.7	63.0	59.2			6.36
	Triclopyr	84.5	88.1	93.4			5.80
SM 2320 B-2011	Total Alkalinity	100				0.522	
SM 2540 C-2015	TDS	96.8					
SM 2540 D-2015	TSS	93.3					
SM 4500-F- C-2011	Fluoride	99.6	99.2	100			0.953
SM 5310 B-2011	Organic Carbon	98.5	95.5	95.2			0.210

Reference Method Descriptions

Method	Description	Associated Samples
DEP SOP: NU-094-1	True Color measured at 450 nm (not valid for NPDES monitoring)	2410531
EPA 180.1 Rev. 2.0	Turbidity in aqueous matrices	2410531
EPA 200.7 Rev. 4.4	Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects	2410538
EPA 200.8 Rev. 5.4	Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects	2410538
EPA 300.0 Rev. 2.1	Chloride in aqueous matrices	2410531
EPA 300.0 Rev. 2.1	Sulfate in aqueous matrices	2410531
EPA 350.1 Rev. 2.0	Ammonia in aqueous matrices as mg N/L	2410532
EPA 351.2 Rev. 2.0	Total Kjeldahl Nitrogen in aqueous matrices	2410532
EPA 353.2 Rev. 2.0	Nitrite/Nitrate in aqueous matrices as mg N/L	2410532
EPA 365.1 Rev. 2.0	Total Phosphorus in aqueous matrices as mg P/L	2410532
EPA 365.1 Rev. 2.0 dissolved	Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L	2410533
EPA 8270E	Analysis of Sunscreen Compounds and Flame Retardants in Water by GC/MS-SIM	2410539
EPA 8270E	Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS	2410539
EPA 8321B	Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS	2410537
SM 2320 B-2011	Alkalinity in aqueous matrices as mg CaCO ₃ /L	2410531
SM 2340 B-2011	Hardness by calculation, in aqueous matrices, reported as mg/L CaCO ₃	2410538
SM 2540 C-2015	Total Dissolved Solids in aqueous matrices	2410531
SM 2540 D-2015	Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample	2410531
SM 4500-F- C-2011	Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)	2410531
SM 5310 B-2011	Nonpurgeable Organic Carbon in aqueous matrices	2410532

Preparation and Analysis Log

Ref. Method	Received Date	Prep Date/Time	Prepared By	Analysis Date/Time	Analyzed By	Associated Samples
DEP SOP: NU-094-1	05/17/2023			05/17/2023 14:56	Anna M. Plaviak	2410531
EPA 180.1 Rev. 2.0	05/17/2023			05/17/2023 14:37	Khloe J Berg	2410531
EPA 200.7 Rev. 4.4	05/17/2023	05/18/2023 09:30	George D Taylor	05/18/2023 18:14	McKinley C Carter	2410538
EPA 200.8 Rev. 5.4	05/17/2023	05/18/2023 09:30	George D Taylor	05/19/2023 17:06	Conrad Hartmann	2410538
EPA 300.0 Rev. 2.1	05/17/2023			05/24/2023 21:56	James L Waggeberby	2410531
EPA 350.1 Rev. 2.0	05/17/2023			05/24/2023 13:32	Khloe J Berg	2410532
EPA 351.2 Rev. 2.0	05/17/2023	05/19/2023 08:44	Samantha L Bates	05/23/2023 12:44	Samantha L Bates	2410532
EPA 353.2 Rev. 2.0	05/17/2023			05/25/2023 11:01	Beverly Y. Sanders	2410532
EPA 365.1 Rev. 2.0	05/17/2023	05/19/2023 11:40	Adam P Silver	05/23/2023 10:54	James L Waggeberby	2410532
EPA 365.1 Rev. 2.0 dissolved	05/17/2023			05/17/2023 13:44	Elise M. Gillis	2410533
EPA 8270E	05/17/2023	05/22/2023 08:00	Fe-Val Siddell	05/23/2023 16:05	Vandana T. Nagar	2410539
	05/17/2023	05/22/2023 08:00	Fe-Val Siddell	05/24/2023 17:26	Arthur Maknenko	2410539
EPA 8321B	05/17/2023	05/19/2023 09:00	Manjita Shrestha	05/19/2023 23:25	Manjita Shrestha	2410537
	05/17/2023	05/19/2023 09:00	Manjita Shrestha	05/21/2023 01:01	Manjita Shrestha	2410537
	05/17/2023	05/23/2023 09:00	Hoor Shaik	05/26/2023 00:35	Juyoung Kim	2410537
SM 2320 B-2011	05/17/2023			05/25/2023 04:30	Dale L. Simmons	2410531
SM 2340 B-2011	05/17/2023			05/18/2023 18:14	McKinley C Carter	2410538
SM 2540 C-2015	05/17/2023			05/19/2023 16:01	Yijie Li	2410531
SM 2540 D-2015	05/17/2023			05/19/2023 16:01	Yijie Li	2410531
SM 4500-F- C-2011	05/17/2023			05/27/2023 10:07	Dale L. Simmons	2410531
SM 5310 B-2011	05/17/2023			05/19/2023 22:10	Elise M. Gillis	2410532