

RQ- 2023-08-14-16

Login Checklist

Login Station ID: 5

Shipping Method: FedEx UPS | HD | Greyhound

Date/Time of Receipt: 8/17/23 @ 4:18

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
2-3				11		X			645457 3020

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No ☒

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA ☒ Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No ☒ Containers intact? Yes ☒ No _____

Caps on tight?

Yes ☒ No _____

Sufficient Sample Volume:

Yes ☒ No _____If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ☒ No _____ Init: C-P

Chlorine detected? (One container checked per Field ID)

Yes _____ No ☒ Init: C-P

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes ☒ No _____ NA _____ Init: C-P

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes _____ No _____ NA ☒ Init: C-P

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: C-P

Date: 8/17/23

Event contains NCRs (Y/N)? N

EventID: CEN-DIST-2023-08-17-02 (SMP)

Date Received: 17-AUG-2023 09:28

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	221426058 10/17/23
pH Test Strips 0 – 6	207621 03/15/2024
pH Paper 0 – 3	NA
pH Paper 0 – 13	20762103 03/15/2024
Chlorine Test Strips	1196 02/2024

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 8/16/2023 **Collected By:** Jessie Atchison, Katie March
Customer: CEN-DIST **Sampling Agency:** FDEP
RQ: RQ-2023-08-14-16 **Project ID:** SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1

Delivery Method: FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
UNNAMED DITCH AT 100M US OF MADELINE AVE	 G5CE0092
REED CANAL AT REED CANAL PARK	 G5CE0156

RELINQUISHED BY(SIGNATURE):




DATE/TIME: 8/16/2023

1600 EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By:



Rec'd/Inspected

Date: 8-17-23



RQ-2023-08-14-16	Collected By: Katie March, Jessie Atchison
Customer: FDEP	Field Report Prepared by: Katie March, Jessie Atchison
Project ID: SMP	Sampling Agency: FDEP

WIN ID/Field ID: 	Comments:
WIN ID/Field ID: G5CE0092	

Location: UNNAMED DITCH AT 100M US OF MADELINE AVE

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT)					
8/16/2023 1235	5.56	73.8	30.1	7.2	0.3	0.6	0.6	541	0.26					
Parameter Suite		Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group			
Preserved Nutrients (P-500ML)		W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP				Ice		H2SO4*		<2				
		Lot #		Exp:										
Metals (P-500ML)		W-ICPMS		W-ICP		W-HARD		Ice		HNO3*				
		Lot #		Exp:				<2						
Filtered Nutrients (P125ML)		W-PO4-F		Field Filtered 0.45 µm Filter				Ice						
		Filter Lot #	Syringe Lot #											
BOD (BP-1L)		OV-BODUNIN				Ice								
Chlorophyll (BP-1L)		CHLSUITE-W				Ice								
Physical/Aggregate (Fresh) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W- TDS				Ice								
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY				Ice								
Macroinvertebrates (PJ-2L)		MI-FW-QLDC		Formalin Lot #		Formalin								
Periphyton (PT-50ML)		ALGAE-ID				Ice								
Microbiology (Contract Lab Bottle)		X	E Coli		F Coli		Enterococci		x			Ice	1	B
		Contract Lab												
Molecular (QPCR-P-500ML)		PCR-HF183		PCR-BacR		PCR-DG3		Ice						
		PCR-GULL2		PCR-GFD										
Tracers (BG-500ML)		W-E8321-DI		W-E8321-MS				Ice						
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI		W-E8321-MS		W-PSNP-TQ		MCAA Exp.		MCAA Lot#		4	B	
		X	W-PCL-TQ-R		W-CARB-AA (5 ml of MCAA Buffer Solution)		X	W-CT-CL-R						
		W-TR-SQ-R		X	W-PCB-TQ-R									
Phytoplankton (BP-1L)		DTY-QN-C		PKD-QN-BV				Ice						
DOC (P-500ML)		W-DOC		Field Filtered 0.45 µm Filter				Ice		H2SO4*		<2		
				Acid Preservative Expiration Date										
				Acid Preservative Lot Number										



RQ-2023-08-14-16

Customer: FDEP

Project ID: SMP

Collected By: Jessie Atchison, Katie March

Field Report Prepared by: Jessie Atchison, Katie March

Sampling Agency: FDEP

Comments:

WIN ID/Field ID:



WIN ID/Field ID: G5CE0156

Location: REED CANAL AT REED CANAL PARK

Matrix: Marine

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT)			
8/16/2023 1213	1.67	21.7	28.7	7.17	0.3	0.6	0.6	658	0.32			
Parameter Suite	Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group		
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	X	<2	1	A
		Lot #		SA3013020	Exp:	01/25/2024						
Metals (P-500ML)		W-ICPMS		W-ICP	W-HARD	Ice	HNO3*		<2			
		Lot #		Exp:								
Filtered Nutrients (P125ML)		W-PO4-F		Field Filtered 0.45 µm Filter		Ice						
		Filter Lot #		Syringe Lot #								
BOD (BP-1L)		OV-BODUNIN				Ice						
Chlorophyll (BP-1L)	X	CHLSUITE-W			X	Ice				1	A	
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W-TDS			X	Ice				1	A	
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY				Ice						
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #			Formalin						
Periphyton (PT-50ML)		ALGAE-ID				Ice						
Microbiology (Contract Lab Bottle)		E Coli		F Coli	X	Enterococci	X	Ice		1	A	
		Contract Lab										
Molecular (QPCR-P-500ML)	X	PCR-HF183	X	PCR-BacR	X	PCR-DG3	X	Ice		1	A	
		PCR-GULL2		PCR-GFD								
Tracers (BG-500ML)	X	W-E8321-DI	X	W-E8321-MS	X	Ice				1	A	
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI	W-E8321-MS	W-PSNP-TQ		Ice	MCAA Exp.	MCAA Lot#				
		W-PCL-TQ-R	W-CARB-AA (5 ml of MCAA Buffer Solution)	W-CT-CL-R								
		W-TR-SQ-R	W-PCB-TQ-R									
Phytoplankton (BP-1L)		DTY-QN-C	PKD-QN-BV			Ice						
DOC (P-500ML)		W-DOC	Field Filtered 0.45 µm Filter		Ice		H2SO4*		<2			
		Acid Preservative Expiration Date										
		Acid Preservative Lot Number										

Date of Request: 10-JUL-2023
 Created By: BEARDEN_M On: 10-JUL-2023
 Modified By: JASROTIA_P On: 27-JUL-2023
 Customer: CEN-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Central District
 Event Description: Run 1

Send Coolers To:

Phone: 407-897-4123
 FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Matthew Bearden
 Cooler Ship EMail: matthew.bearden@floridadep.gov

Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 26-JUL-2023
 Biology Request Reviewed By: JASROTIA_P On: 27-JUL-2023
 Sampling Kit Required: YES Ship on: 07-AUG-2023
 Sampling Kit Shipped: YES On: 01-AUG-2023
 Sampling Kit Packed By: KREUCH_B
 Preservatives Needed: NO
 Date to Receive Samples: 17-AUG-2023
 Logged In By:

Send Final Report To:

FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Matthew Bearden
 Report Notification EMail:
 matthew.bearden@floridadep.gov;jessie.atchison@floridadep.gov
 v

Comments:**Bottle Group A (Water) With 1 Samples:**

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2015) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10150 B) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: SMP	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 B Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: BG-500ML FILL TO	Number of Bottles: 4	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Chlordane and Toxaphene in water matrices by GC/MS with Negative Chemical Ionization
W-PCB-TQ-R	Template: DEFAULT	(EPA 8270E) PCBs in water matrices by GC/MS/MS
W-PCL-TQ-R	Template: DEFAULT	(EPA 8270E) Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS/MS

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 B Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.