

Login Checklist

RQ-2023-03-06-33

Login Station ID: #3

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 03/16/23 @ 0906

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
0.8				7		x			5859 4733 7869
						x			
						x			
						x			
						x			
						x			

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes X No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No X

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA X Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____ Containers intact? Yes X No _____

Caps on tight?

Yes X No _____

Sufficient Sample Volume:

Yes X No _____

If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes _____ No X Init: BKK

Chlorine detected? (One container checked per Field ID)

Yes _____ No _____ Init: BKK

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH< 2.0?

Yes X No _____ NA _____ Init: BKK

**W-1-4-DIOX (Green dot on container) preserved to pH< 4.0?

Yes _____ No _____ NA X Init: BKK

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: BKK

Date: 03/16/23

Event contains NCRs (Y/N)? N

Event ID: 2023 SMP: Continuous Pickup
SO-DIST-2023-03-16-01 (SMP)

Date Received: 16-MAR-2023 09:06

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #3 Exp:10/17/2023
pH Test Strips 0 – 6	Lot#223819AV Exp:8/30/23
pH Paper 0 – 3	
pH Paper 0 – 13	Lot#210620 Exp:4/15/23
Chlorine Test Strips	Lot#0129 Exp:3/23

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 3/15/2023 **Collected By:** Nicole Reistad, William Mullen
Customer: SO-DIST **Sampling Agency:** FDEP
RQ: RQ-2023-03-06-33 **Project ID:** SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1

Delivery Method: FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
CLEVELAND CEMETARY DITCH @ RIVERSIDE RD	 G3SD0076
YuccaFlatwoods Mid	 G2SD0052

RELINQUISHED BY(SIGNATURE):



DATE/TIME: 3/15/2023
1500 EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By: Brian Kreuch

Rec'd/Inspected
Date: 3/16/23 0906

WIN ID/Field ID:  WIN ID/Field ID: G3SD0076	Comments: Microbiology sample(s) submitted to contract laboratory.
---	---

Matrix: Marine

(Check One)

✓ Grab

☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPTH)										
3/15/2023 1040	0.47	6.1	23.9	6.63	0.3	0.2	0.7	22392	13.5										
Parameter Suite		Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group								
Preserved Nutrients (P-500ML)		X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	X	<2	1	B						
		Lot #		SA2299040		Exp:		11/04/23											
Metals (P-500ML)		X	W-ICPMS		X	W-ICP		W-HARD	X	Ice	X	HNO3*	X	<2	1	B			
		Lot #		NA1105100		Exp:		06/07/23											
Filtered Nutrients (P125ML)		W-PO4-F		Field Filtered 0.45 um Filter			Ice												
		Filter Lot #		Syringe Lot #															
BOD (BP-1L)		OV-BODUNIN					Ice												
Chlorophyll (BP-1L)		X	CHLSUITE-W					X									Ice	1	B
Physical/Aggregate (Fresh) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W- TD5					Ice												
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY					Ice												
Macroinvertebrates (PJ-2L)		MI-FW-QLDC		Formalin Lot #			Formalin												
Periphyton (PT-50ML)		ALGAE-ID					Ice												
Microbiology (Contract Lab Bottle)		E Coli		F Coli		X	Enterococci	X									Ice	1	B
		Contract Lab																	
Molecular (QPCR-P-500ML)		PCR- HF183		PCR-BacR		PCR-DG3		Ice											
		PCR-GULL2		PCR-GFD															
Tracers (BG-500ML)		W-E8321-DI		W-E8321-MS			Ice												
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI		W-E8321-MS		W-PSNP-TQ		Ice	MCAA Exp.	MCAA Lot#									
		W-PCL-TQ-R		W-CARB-AA (5 ml of MCAA Buffer Solution)		W-CT-CL-R													
		W-TR-SQ-R		W-PCB-TQ-R															
Phytoplankton		DTY-QN-C		PKD-QN-BV			Ice												
DOC		W-DOC		Field Filtered 0.45 um Filter			Ice		H2SO 4*		<2								
				Acid Preservative Expiration Date															
				Acid Preservative Lot Number															



RQ-2023-03-06-33

Customer: FDEP

Project ID: SMP

Collected By: Nicole Reistad, William Mullen

Field Report Prepared by: Nicole Reistad, William Mullen

Sampling Agency: FDEP

WIN ID/Field ID:



WIN ID/Field ID: G2SD0052

Comments: Microbiology sample(s) submitted to contract laboratory.

Location: YuccaFlatwoods Mid

Matrix: Marine

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT)
3/15/2023 1145	1.56	20.9	20.1	5.86	0.15	0.3	0.3	50230	32.99

Parameter Suite	Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group		
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	X	<2	1	A
		Lot #	SA2299040	Exp:	11/04/23							
Metals (P-500ML)		W-ICPMS		W-ICP	W-HARD	Ice	HNO3*		<2			
		Lot #		Exp:								
Filtered Nutrients (P125ML)		W-PO4-F	Field Filtered 0.45 um Filter				Ice					
		Filter Lot #		Syringe Lot #								
BOD (BP-1L)		OV-BODUNIN					Ice					
Chlorophyll (BP-1L)	X	CHLSUITE-W				X	Ice			1	A	
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W- TDS				X	Ice			1	A	
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY					Ice					
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #				Formalin					
Periphyton (PT-50ML)		ALGAE-ID					Ice					
Microbiology (Contract Lab Bottle)		E Coli	X	F Coli	X	Enterococci	X	Ice		2	A	
	X	Contract Lab										
Molecular (QPCR-P-500ML)		PCR-HF183		PCR-BacR	PCR-DG3		Ice					
		PCR-GULL2		PCR-GFD								
Tracers (BG-500ML)		W-E8321-DI		W-E8321-MS			Ice					
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI	W-E8321-MS		W-PSNP-TQ		Ice	MCAA Exp.	MCAA Lot#			
		W-PCL-TQ-R	W-CARB-AA (5 ml of MCAA Buffer Solution)		W-CT-CL-R							
		W-TR-SQ-R	W-PCB-TQ-R									
Phytoplankton		DTY-QN-C		PKD-QN-BV			Ice					
DOC		W-DOC	Field Filtered 0.45 um Filter			Ice	H2SO4*		<2			
	Acid Preservative Expiration Date											
	Acid Preservative Lot Number											

Date of Request: 06-FEB-2023
 Created By: MULLEN_W On: 06-FEB-2023
 Modified By: JASROTIA_P On: 17-FEB-2023
 Customer: SO-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: South District
 Event Description: 2023 SMP: Continuous Pickup

Send Coolers To:

Phone: 239-344-5716
 FLDEP South District Office
 2295 Victoria Ave. Suite 314
 Fort Myers, FL 33901-3381
 Attn: William Mullen
 Cooler Ship EMail: William.Mullen@FloridaDEP.gov

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 16-FEB-2023
 Biology Request Reviewed By: JASROTIA_P On: 17-FEB-2023
 Sampling Kit Required: YES Ship on: 24-FEB-2023
 Sampling Kit Shipped: YES On: 22-FEB-2023
 Sampling Kit Packed By: KREUCH_B
 Preservatives Needed: NO
 Date to Receive Samples: 06-MAR-2023
 Logged In By: KREUCH_B On: 16-MAR-2023

Send Final Report To:

FLDEP South District Office
 2295 Victoria Ave. Suite 314
 Fort Myers, FL 33901-3381
 Attn: William Mullen
 Report Notification EMail:
 Nicole.Reistad@FloridaDEP.gov; John.Barrington@FloridaDEP.gov;
 William.Mullen@FloridaDEP.gov; Monica.Jaeger@FloridaDEP.gov

Comments: Group A: Entero, Fecal, Marine Nutrients
 Group B: Entero, Marine Nutrient, Metals

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WI-THI	Number of Bottles: 2	Preserved With: ICE
SD-SND-ENQ	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert/QT by Sanders in Fort Myers
SD-SND-FC	Template: DEFAULT	(SM 9222 D) Fecal coliforms by MF by Sanders in Fort Myers
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE

Bottle Group B (Water) With 1 Samples:

Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
SD-SND-ENQ	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert/QT by Sanders in Fort Myers
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-ICP	Template: SMP-MARINE	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Calcium		
Iron		
Magnesium		
Strontium		
Tin		
Titanium		
Vanadium		
Zinc		
W-ICPMS	Template: SMP-MARINE	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
*Strontium		
Aluminum		
Antimony		
Arsenic		
Beryllium		
Cadmium		
Chromium		
Cobalt		
Copper		
Lead		
Manganese		
Molybdenum		
Nickel		
Selenium		
Silver		
Thallium		
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.