

Login Checklist

RQ- 2023-05-15-29

Login Station ID: #1

Shipping Method: ~~FedEx~~ | UPS | HD | Greyhound

Date/Time of Receipt: 5/ 26 /23 @ 9:20

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
1.4				12		✓			5859 4735 6577

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No ☒

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA ☒ Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____ Containers intact? Yes ☒ No _____

Caps on tight?

Yes ☒ No _____

Sufficient Sample Volume:

Yes ☒ No _____

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ☒ No _____ Init: hik

Chlorine detected? (One container checked per Field ID)

Yes _____ No ☒ Init: hik

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH< 2.0?

Yes ☒ No _____ NA _____ Init: hik

**W-1-4-DIOX (Green dot on container) preserved to pH< 4.0?

Yes _____ No _____ NA ☒ Init: hik

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: hik

Date: 5/ 26 /23

Event contains NCRs(Y/N)? N

EventID: 2022 SMP : Myakka
SO-DIST-2023-05-26-01 (SMP)

Date Received: 26-MAY-2023 09:20

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #1 Exp:10/17/2023
pH Test Strips 0 – 6	Lot# 223819AV Exp:8/30/23
pH Paper 0 – 3	
pH Paper 0 – 13	Lot# 207621 Exp:3/15/24
Chlorine Test Strips	Lot# 1196 Exp:2/24

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 5/25/2023 **Collected By:** Nicole Reistad, Monica Jaeger
Customer: SO-DIST **Sampling Agency:** FDEP
RQ: RQ-2023-05-15-29 **Project ID:** SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1 **Delivery Method:** FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
LAKE MYAKKA (UPPER) AT MIDDLE	 G3SD0133
LAKE MYAKKA (LOWER) AT MIDDLE	 G3SD0107
FB	 FB_05252023

RELINQUISHED BY(SIGNATURE):



DATE/TIME: 5/25/2023
1500 EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By: 

Rec'd/Inspected

Date: 5-26-23 / 0920



RQ-2023-05-15-29

Customer: FDEP

Project ID: SMP

Collected By: Nicole Reistad, Monica Jaeger

Field Report Prepared by: Nicole Reistad, Monica Jaeger

Sampling Agency: FDEP

 WIN ID/Field ID: 
 WIN ID/Field ID: G3SD0133

Comments:

Location: LAKE MYAKKA (UPPER) AT MIDDLE

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT)
5/25/2023 1015	6.71	81.1	24.8	7.01	0.25	0.3	0.5	671	0.33

Parameter Suite	Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group		
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	X	<2	1	B
		Lot # SA3013020		Exp:	01/25/24							
Metals (P-500ML)		W-ICPMS		W-ICP	W-HARD	Ice	HNO3*		<2			
		Lot #		Exp:								
Filtered Nutrients (P125ML)		W-PO4-F		Field Filtered 0.45 µm Filter		Ice						
		Filter Lot #	Syringe Lot #									
BOD (BP-1L)		OV-BODUNIN				Ice						
Chlorophyll (BP-1L)	X	CHL5UITE-W				X	Ice			1	B	
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W-TDS				X	Ice			1	B	
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY					Ice					
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #			Formalin						
Periphyton (PT-50ML)		ALGAE-ID				Ice						
Microbiology (Contract Lab Bottle)		E Coli	F Coli	Enterococci		Ice						
		Contract Lab										
Molecular (QPCR-P-500ML)		PCR-HF1B3	PCR-BacR	PCR-DG3		Ice						
		PCR-GULL2	PCR-GFD									
Tracers (BG-500ML)		W-E8321-DI	W-E8321-MS			Ice						
		W-E8321-DI	W-E8321-MS	W-PSNP-TQ				MCAA Exp.	MCAA Lot#			
Pesticides (BG-500ML) (BG-1L)	X	W-PCL-TQ-R	W-CARB-AA (5 ml of MCAA Buffer Solution)		X	W-CT-CL-R	X	Ice			4	B
		W-TR-SQ-R	X	W-PCB-TQ-R								
Phytoplankton		DTY-QN-C	PKD-QN-BV			Ice						
DOC		W-DOC	Field Filtered 0.45 µm Filter			Ice		H2SO 4*		<2		
		Acid Preservative Expiration Date										
		Acid Preservative Lot Number										



RQ-2023-05-15-29	Collected By: Nicole Reistad, Monica Jaeger
Customer: FDEP	Field Report Prepared by: Nicole Reistad, Monica Jaeger
Project ID: SMP	Sampling Agency: FDEP
WIN ID/Field ID:  WIN ID/Field ID: G3SD0107	Comments:

Location: LAKE MYAKKA (LOWER) AT MIDDLE

Matrix: Fresh

(Check One) ☒ **Grab** ☐ **Composite**

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT)
5/25/2023 1125	8.25	102.9	26.5	6.43	0.15	0.3	0.3	859	0.42

Parameter Suite	Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group			
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	X	<2	1	C	
		Lot # SA3013020		Exp:	0/25/24								
Metals (P-500ML)		W-ICPMS		W-ICP	W-HARD		Ice		HNO3*		<2		
		Lot #		Exp:									
Filtered Nutrients (P125ML)		W-PO4-F		Field Filtered 0.45 µm Filter			Ice						
		Filter Lot #	Syringe Lot #										
BOD (BP-1L)		OV-BODUNIN					Ice						
Chlorophyll (BP-1L)	X	CHLSUITE-W				X	Ice			1	C		
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W- TDS				X	Ice			1	C		
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY					Ice						
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #				Formalin						
Periphyton (PT-50ML)		ALGAE-ID					Ice						
Microbiology (Contract Lab Bottle)		E Coli	F Coli	Enterococci			Ice						
		Contract Lab											
Molecular (QPCR-P-500ML)		PCR-HF183	PCR-BacR	PCR-DG3			Ice						
		PCR-GULL2	PCR-GFD										
Tracers (BG-500ML)		W-E8321-DI	W-E8321-MS				Ice						
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI	W-E8321-MS	W-PSNP-TQ			Ice	MCAA Exp.	MCAA Lot#				
		W-PCL-TQ-R	W-CARB-AA (5 ml of MCAA Buffer Solution)		W-CT-CL-R								
		W-TR-SQ-R	W-PCB-TQ-R										
Phytoplankton		DTY-QN-C	PKD-QN-BV				Ice						
DOC		W-DOC	Field Filtered 0.45 µm Filter			Ice	H2SO4*						
	Acid Preservative Expiration Date												
	Acid Preservative Lot Number												



RQ-2023-05-15-29

Collected By: Nicole Reistad, Monica Jaeger

Customer: FDEP

Field Report Prepared by: Nicole Reistad, Monica Jaeger

Project ID: SMP

Sampling Agency: FDEP

WIN ID/Field ID:



WIN ID/Field ID: FB_05252023

Comments:

Location: FB

Matrix: W-FIELD-BLANK

(Check One)

✓ Grab

□ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPTH)	
5/25/2023 1400										
Parameter Suite	Parameter Methods				Preservation		pH Check	# Bottles sent to Lab	Bottle Group	
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	H2SO4*	<2	1	D
		Lot #	SA3013020	Exp:	01/25/24					
Metals (P-500ML)		W-ICPMS		W-ICP	W-HARD	Ice	HNO3*	<2		
		Lot #			Exp:					
Filtered Nutrients (P125ML)		W-PO4-F		Field Filtered 0.45 µm Filter		Ice				
		Filter Lot #	Syringe Lot #							
BOD (BP-1L)		OV-BODUNIN				Ice				
Chlorophyll (BP-1L)		CHLSUITE-W				Ice				
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W-TDS				X	Ice	1	D	
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY					Ice			
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #		Formalin					
Periphyton (PT-50ML)		ALGAE-ID				Ice				
Microbiology (Contract Lab Bottle)		E Coli	F Coli	Enterococci		Ice				
		Contract Lab								
Molecular (QPCR-P-500ML)		PCR-HF183	PCR-BacR	PCR-DG3		Ice				
		PCR-GULL2	PCR-GFD							
Tracers (BG-500ML)		W-E8321-DI		W-E8321-MS		Ice				
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI	W-E8321-MS	W-PSNP-TQ		Ice	MCAA Exp.	MCAA Lot#		
		W-PCL-TQ-R	W-CARB-AA (5 ml of MCAA Buffer Solution)	W-CT-CL-R						
		W-TR-SQ-R	W-PCB-TQ-R							
Phytoplankton		DTY-QN-C	PKD-QN-BV		Ice					
DOC		W-DOC	Field Filtered 0.45 µm Filter		Ice	H2SO4*	<2			
		Acid Preservative Expiration Date								
		Acid Preservative Lot Number								

Date of Request: 17-APR-2023
 Created By: MULLEN_W On: 17-APR-2023
 Modified By: JASROTIA_P On: 26-APR-2023
 Customer: SO-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: South District
 Event Description: 2022 SMP : Myakka

Send Coolers To:

Phone: 239-344-5716
 FLDEP South District Office
 2295 Victoria Ave. Suite 314
 Fort Myers, FL 33901-3381
 Attn: William Mullen
 Cooler Ship EMail: William.Mullen@FloridaDEP.gov

Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 26-APR-2023
 Biology Request Reviewed By: JASROTIA_P On: 26-APR-2023
 Sampling Kit Required: YES Ship on: 05-MAY-2023
 Sampling Kit Shipped: YES On: 01-MAY-2023
 Sampling Kit Packed By: PENDLETO_C
 Preservatives Needed: NO
 Date to Receive Samples: 15-MAY-2023
 Logged In By:

Send Final Report To:

FLDEP South District Office
 2295 Victoria Ave. Suite 314
 Fort Myers, FL 33901-3381
 Attn: William Mullen
 Report Notification EMail:
 Nicole.Reistad@FloridaDEP.gov; John.Barrington@FloridaDEP.gov;
 William.Mullen@FloridaDEP.gov; Monica.Jaeger@FloridaDEP.gov

Comments: Group A: (Lower Myakka) Freshwater Nutrients
 Group B: (Brandy Branch) E. coli, PCR, Tracers, W-CT-CI-R, W-PCL-TQ-R, W-PCB-TQ-R
 Group C: (Upper Myakka) Freshwater Nutrients, W-CT-CI-R/W-PCL-TQ-R/W-PCB-TQ-R
 Group D: Nutrients BLANK

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2015) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10150 B) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group B (Water) With 1 Samples:

Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction

Bottle Group B (Water) With 1 Samples:

Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
SD-BES-ECQ	Template: DEFAULT	(SM 9223 Quanti-Tray) E. coli by Colilert/QT by BEA South in North Port
Bottle Type: BG-500ML FILL TO	Number of Bottles: 4	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Chlordane and Toxaphene in water matrices by GC/MS with Negative Chemical Ionization
W-PCB-TQ-R	Template: DEFAULT	(EPA 8270E) PCBs in water matrices by GC/MS/MS
W-PCL-TQ-R	Template:	(EPA 8270E) Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS/MS
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: SMP	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Bottle Group C (Water) With 1 Samples:

Bottle Type: BG-500ML FILL TO	Number of Bottles: 2	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Chlordane and Toxaphene in water matrices by GC/MS with Negative Chemical Ionization
W-PCB-TQ-R	Template: DEFAULT	(EPA 8270E) PCBs in water matrices by GC/MS/MS
W-PCL-TQ-R	Template:	(EPA 8270E) Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2015) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10150 B) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Bottle Group D (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2015) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.
