

Login Checklist

RQ- 2023-07-24-46

Login Station ID: #3

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 07/28/23 @ 0853

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #	
					Present?		*Intact?			
					Yes	No	Yes	No		
2.5				10		x			58947308483	

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes X No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No X

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA X Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____ Containers intact? Yes X No _____

Caps on tight?

Yes X No _____

Sufficient Sample Volume:

Yes X No _____

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes X No _____ Init: BKK

Chlorine detected? (One container checked per Field ID)

Yes _____ No X Init: X BKK

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes X No _____ NA _____ Init: BKK

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes _____ No _____ NA X Init: BKK

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: BKK

Date: 07/28/23

Event contains NCRs (Y/N)? X

EventID: 2023 SMP : Land O' Lakes
SQ-DIST-2023-07-28-02 (SMP)
Date Received: 28-JUL-2023 08:53

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #3 Exp:10/17/2023
pH Test Strips 0 – 6	Lot#223819AV Exp:8/30/23
pH Paper 0 – 3	
pH Paper 0 – 13	Lot#207621 Exp:3/15/24
Chlorine Test Strips	Lot#1196 Exp:2/24

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 7/27/2023
Customer: SO-DIST
RQ: RQ-2023-07-24-46
Collected By: Nicole Reistad, Monica Jaeger
Sampling Agency: FDEP
Project ID: SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1

Delivery Method: FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
LAKE JUNE IN WINTER	 G4SD0186

RELINQUISHED BY(SIGNATURE):

DATE/TIME: 7/27/2023
1300 EST

W. J. P. P.

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By:

Brian Kneen

Rec'd/Inspected

Date:

7/28/23 0853



RQ-2023-07-24-46	Collected By: Nicole Reistad, Monica Jaeger
Customer: FDEP	Field Report Prepared by: Nicole Reistad, Monica Jaeger
Project ID: SMP	Sampling Agency: FDEP

WIN ID/Field ID: 
WIN ID/Field ID: G4SD0186

Comments:

Location: LAKE JUNE IN WINTER

Matrix: Fresh

(Check One) ☒ Grab ☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT)					
7/27/2023 1000	6.96	93.4	30.8	6.36	0.3	1.7	8.9	178.8	0.08					
Parameter Suite	Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group				
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP				X	Ice	X	H2SO4*	X	<2	1	A	
		Lot #	SA3013020	Exp:	01/25/2024									
Metals (P-500ML)	X	W-ICPMS	X	W-ICP	X	W-HARD	X	Ice	X	HNO3*	X	<2	1	A
		Lot #	NA2230040	Exp:	09/01/2023									
Filtered Nutrients (P125ML)	X	W-PO4-F	X	Field Filtered 0.45 µm Filter		X	Ice					1	A	
		Filter Lot #	17347262	Syringe Lot #	3066846									
BOD (BP-1L)		OV-BODUNIN					Ice							
Chlorophyll (BP-1L)	X	CHLSUITE-W				X	Ice					1	A	
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W- TDS				X	Ice					1	A	
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY					Ice							
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #				Formalin							
Periphyton (PT-50ML)		ALGAE-ID					Ice							
Microbiology (Contract Lab Bottle)		E Coli		F Coli		Enterococci	Ice							
		Contract Lab												
Molecular (QPCR-P-500ML)		PCR-HF183		PCR-BacR		PCR-DG3	Ice							
		PCR-GULL2		PCR-GFD										
Tracers (BG-500ML)	X	W-E8321-DI	X	W-E8321-MS		X	Ice					1	A	
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI		W-E8321-MS	X	W-PSNP-TQ	X	Ice	MCAA Exp.	MCAA Lot#		4	A	
		W-PCL-TQ-R		W-CARB-AA (5 ml of MCAA Buffer Solution)		W-CT-CL-R								
	X	W-TR-SQ-R		W-PCB-TQ-R										
Phytoplankton (BP-1L)		DTY-QN-C		PKD-QN-BV			Ice							
DOC (P-500ML)		W-DOC		Field Filtered 0.45 µm Filter			Ice		H2SO4*	<2				
				Acid Preservative Expiration Date										
				Acid Preservative Lot Number										

Date of Request: 11-JUL-2023
 Created By: JAEGER_M On: 11-JUL-2023
 Modified By: SWANSON_C On: 13-JUL-2023
 Customer: SO-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: South District
 Event Description: 2023 SMP : Land O' Lakes

Send Coolers To:

Phone: 239-344-5716
 FLDEP South District Office
 2295 Victoria Ave. Suite 314
 Fort Myers, FL 33901-3381
 Attn: Monica Jaeger
 Cooler Ship EMail: Monica.Jaeger@FloridaDEP.gov

Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 12-JUL-2023
 Biology Request Reviewed By: SWANSON_C On: 13-JUL-2023
 Sampling Kit Required: YES Ship on: 21-JUL-2023
 Sampling Kit Shipped: YES On: 18-JUL-2023
 Sampling Kit Packed By: SHAIK_A
 Preservatives Needed: NO
 Date to Receive Samples: 28-JUL-2023
 Logged In By:

Send Final Report To:

FLDEP South District Office
 2295 Victoria Ave. Suite 314
 Fort Myers, FL 33901-3381
 Attn: Monica Jaeger
 Report Notification EMail:
 Nicole.Reistad@FloridaDEP.gov;John.Barrington@FloridaDEP.gov;Monica.Jaeger@FloridaDEP.gov

Comments: Group A: Lake June) Freshwater Nutrients

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2015) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10150 B) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO ₃
W-HARD	Template: DEFAULT	(SM 2340 B-2011) Hardness by calculation, in aqueous matrices, reported as mg/L CaCO ₃
Hardness		
W-ICP	Template: SMP-FRESH	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Calcium		
Iron		
Magnesium		
Potassium		
Sodium		
Strontium		
Tin		
Titanium		
Vanadium		
Zinc		

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-500ML Number of Bottles: 1 Preserved With: HNO3
 W-ICPMS Template: DEFAULT (EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects

Aluminum
 Antimony
 Arsenic
 Barium
 Beryllium
 Boron
 Cadmium
 Chromium
 Cobalt
 Copper
 Lead
 Manganese
 Molybdenum
 Nickel
 Selenium
 Silver
 Thallium

Bottle Type: P-500ML Number of Bottles: 1 Preserved With: ICE And H2SO4
 W-NH3 Template: DEFAULT (EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
 W-NO2NO3 Template: DEFAULT (EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
 W-S-A-TP Template: DEFAULT (EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
 W-TKN Template: DEFAULT (EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
 W-TOC Template: DEFAULT (SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Type: BG-500ML FILL TO Number of Bottles: 4 Preserved With: ICE
 W-PCL-TQ-R Template: DEFAULT (EPA 8270E) Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS/MS
 Bottle Type: P-125ML Number of Bottles: 1 Preserved With: FILTER-ICE
 W-PO4-F Template: DEFAULT (EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
 Bottle Type: BG-500ML Number of Bottles: 4 Preserved With: ICE
 W-PSNP-TQ Template: DEFAULT (EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS
 W-TR-SQ-R Template: DEFAULT (EPA 8270E) Analysis of Sunscreen Compounds and Flame Retardants in Water by GC/MS-SIM

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.