

Login Checklist

RQ- 2023-08-07-57

Login Station ID: 5

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 8/ 8 / 23 @ 10:00

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #	
		YES	HNO ₃		Formalin	Present?		*Intact?		
						Yes	No	Yes		No
2.7				12		X			64848 4567844	

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes X No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes X No _____

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA X Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No X

Containers intact? Yes X No _____

Caps on tight?

Yes X No _____

Sufficient Sample Volume:

Yes X No _____

If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes X No _____ Init: C-P

Chlorine detected? (One container checked per Field ID)

Yes _____ No X Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes X No _____ NA _____ Init: C-P

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes _____ No _____ NA X Init: C-P

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: C-P

Date: 8/ 8 /23

Event contains NCRs (Y/N)? N

Event ID:

SO-DIST-2023-08-08-01 (SMP)
Date Received: 08-AUG-2023 10:00

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	221426058 10/17/23
pH Test Strips 0 – 6	207621 03/15/2024
pH Paper 0 – 3	NA
pH Paper 0 – 13	20762103 03/15/2024
Chlorine Test Strips	1196 02/2024

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 8/7/2023 **Collected By:** Nicole Reistad, Other
Customer: SO-DIST **Sampling Agency:** FDEP
RQ: RQ-2023-08-07-57 **Project ID:** SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1

Delivery Method: FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
BURNT STORE MARINA ENTRANCE	 G2SD0055
YUCCA PEN MARINE AT N OF OLD BURNTSTORE	 G2SD0015
FORD CANAL AT GALLEE WAY	 G3SD0136
MANUEL BRANCH AT BROADWAY	 G3SD0078

RELINQUISHED BY(SIGNATURE):



DATE/TIME: 8/7/2023 1300
EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By: *Chirp*

Rec'd/Inspected
Date: 8-8-23



RQ-2023-08-07-57

Customer: FDEP

Project ID: SMP

Collected By: Nicole Reistad, Other

Field Report Prepared by: Nicole Reistad, Other

Sampling Agency: FDEP

WIN ID/Field ID:



WIN ID/Field ID: G2SD0055

Comments:

Location: BURNT STORE MARINA ENTRANCE

Matrix: Marine

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT)
8/7/2023 830	1.85	30	32.5	7.47	0.3	0.9	1.4	46440	29.91

Parameter Suite	Parameter Methods	Preservation	pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP Lot # _____ Exp: _____	Ice H2SO4*	<2		
Metals (P-500ML)	W-ICPMS W-ICP W-HARD Lot # _____ Exp: _____	Ice HNO3*	<2		
Filtered Nutrients (P125ML)	W-PO4-F Field Filtered 0.45 µm Filter Filter Lot # _____ Syringe Lot # _____	Ice			
BOD (BP-1L)	OV-80DUNIN	Ice			
Chlorophyll (BP-1L)	CHLSUITE-W	Ice			
Physical/Aggregate (Fresh) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W- TDS	Ice			
Physical/Aggregate (Marine) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY	Ice			
Macroinvertebrates (PJ-2L)	MI-FW-QLDC Formalin Lot # _____	Formalin			
Periphyton (PT-50ML)	ALGAE-ID	Ice			
Microbiology (Contract Lab Bottle)	E Coli F Coli X Enterococci X Contract Lab	X Ice		1	A
Molecular (QPCR-P-500ML)	PCR-HF183 PCR-BacR PCR-DG3 PCR-GULL2 PCR-GFD	Ice			
Tracers (BG-500ML)	W-E8321-DI W-E8321-MS	Ice			
Pesticides (BG-500ML) (BG-1L)	W-E8321-DI W-E8321-MS W-PSNP-TQ W-PCL-TQ-R W-CARB-AA (5 ml of MCAA Buffer Solution) W-CT-CL-R W-TR-SQ-R W-PCB-TQ-R	Ice MCAA Exp. MCAA Lot#			
Phytoplankton (BP-1L)	DTY-QN-C PKD-QN-BV	Ice			
DOC (P-500ML)	W-DOC Field Filtered 0.45 µm Filter Acid Preservative Expiration Date _____ Acid Preservative Lot Number _____	Ice H2SO4* <2			



RQ-2023-08-07-57

Collected By: Nicole Reistad, Other

Customer: FDEP

Field Report Prepared by: Nicole Reistad, Other

Project ID: SMP

Sampling Agency: FDEP

WIN ID/Field ID:



Comments: Microbiology sample(s) submitted to contract laboratory.

WIN ID/Field ID: G2SD0015

Location: YUCCA PEN MARINE AT N OF OLD BURNTSTORE

Matrix: Marine

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT)							
8/7/2023 915	1.05	16.6	28.6	6.46	0.3	0.7	0.7	37415	23.64							
Parameter Suite		Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group					
Preserved Nutrients (P-500ML)		X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	X	<2	1	B			
		Lot #		SA3013020		Exp:		01/25/2024								
Metals (P-500ML)		W-ICPMS		W-ICP		W-HARD		Ice	HNO3*		<2					
		Lot #		Exp:												
Filtered Nutrients (P125ML)		W-PO4-F		Field Filtered 0.45 um Filter		Ice										
		Filter Lot #	Syringe Lot #													
BOD (BP-1L)		OV-BODUNIN				Ice										
Chlorophyll (BP-1L)		X	CHLSUITE-W			X	Ice			1		B				
Physical/Aggregate (Fresh) (P-1L)		X	Alkalinity / W-F / W-TSS / TURBIDITY / W-CL-IC / W-COLOR / W-SO4-IC / W-TDS			X	Ice			1		B				
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY				Ice										
Macroinvertebrates (PJ-2L)		MI-FW-QLDC		Formalin Lot #		Formalin										
Periphyton (PT-50ML)		ALGAE-ID				Ice										
Microbiology (Contract Lab Bottle)		E Coli		F Coli		X	Enterococci	X	Ice	1		B				
		Contract Lab														
Molecular (QPCR-P-500ML)		PCR-HF183		PCR-BacR		PCR-DG3		Ice								
		PCR-GULL2		PCR-GFD												
Tracers (BG-500ML)		W-E8321-D1		W-E8321-MS		Ice										
		W-E8321-D1		W-E8321-MS		W-PSNP-TQ		MCAA Exp.		MCAA Lot#						
Pesticides (BG-500ML) (BG-1L)		W-PCL-TQ-R		W-CARB-AA (5 ml of MCAA Buffer Solution)		W-CT-CL-R		Ice								
		W-TR-SQ-R		W-PCB-TQ-R												
Phytoplankton (BP-1L)		DTY-QN-C		PKD-QN-BV		Ice										
DOC (P-500ML)		W-DOC		Field Filtered 0.45 um Filter		Ice	H2SO4*			<2						
		Acid Preservative Expiration Date														
		Acid Preservative Lot Number														

Collected By: Nicole Reistad, Other

Field Report Prepared by: Nicole Reistad, Other

Sampling Agency: FDEP



Comments: Microbiology sample(s) submitted to contract laboratory.

Location: FORD CANAL AT GALLEE WAY

Matrix: Fresh

(Check One)

✓ Grab

☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPTH)					
8/7/2023 1010	1.03	13.9	28.2	7.34	0.3	0.8	0.8	651	0.31					
Parameter Suite		Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group			
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP				X	Ice	X	H2SO4*	X	<2	1	C	
	Lot #		SA3013020		Exp:	01/25/2024								
Metals (P-500ML)		W-ICPMS		W-ICP			Ice		HNO3*		<2			
	Lot #		Exp:											
Filtered Nutrients (P125ML)		W-PO4-F		Field Filtered 0.45 µm Filter				Ice						
	Filter Lot #	Syringe Lot #												
BOD (BP-1L)		OV-BODUNIN					Ice							
Chlorophyll (BP-1L)	X	CHLSUITE-W				X	Ice							
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W-TDS				X	Ice							
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY					Ice							
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #				Formalin							
Periphyton (PT-50ML)		ALGAE-ID					Ice							
Microbiology (Contract Lab Bottle)	X	E Coli		F Coli			Enterococci	X						Ice
	X	Contract Lab												
Molecular (QPCR-P-500ML)	X	PCR-HF183		X	PCR-BacR	X	PCR-DG3	X	Ice					
		PCR-GULL2		PCR-GFD										
Tracers (BG-500ML)	X	W-E8321-DI		X	W-E8321-MS			X	Ice					
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI	W-E8321-MS		W-PSNP-TQ		Ice	MCAA Exp.	MCAA Lot#					
		W-PCL-TQ-R	W-CARB-AA (5 ml of MCAA Buffer Solution)		W-CT-CL-R									
		W-TR-SQ-R	W-PCB-TQ-R											
Phytoplankton (BP-1L)		DTY-QN-C		PKD-QN-BV				Ice						
DOC (P-500ML)		W-DOC	Field Filtered 0.45 µm Filter				Ice		H2SO 4*		<2			
	Acid Preservative Expiration Date													
	Acid Preservative Lot Number													



RQ-2023-08-07-57

Collected By: Nicole Reistad, Other

Customer: FDEP

Field Report Prepared by: Nicole Reistad, Other

Project ID: SMP

Sampling Agency: FDEP

WIN ID/Field ID:



WIN ID/Field ID: G3SD0078

Comments:

Location: MANUEL BRANCH AT BROADWAY

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT)
8/7/2023 1035	1.76	23.3	29.7	7.51	0.3	0.6	0.6	532	0.25

Parameter Suite	Parameter Methods				Preservation	pH Check	# Bottles sent to Lab	Bottle Group	
Preserved Nutrients (P-500ML)	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP				Ice	H2SO4*	<2		
	Lot #		Exp:						
Metals (P-500ML)	W-ICPMS		W-ICP	W-HARD	Ice	HNO3*	<2		
	Lot #		Exp:						
Filtered Nutrients (P125ML)	W-PO4-F	Field Filtered 0.45 µm Filter			Ice				
	Filter Lot #		Syringe Lot #						
BOD (BP-1L)	OV-BODUNIN				Ice				
Chlorophyll (BP-1L)	CHLSUITE-W				Ice				
Physical/Aggregate (Fresh) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W-TDS				Ice				
Physical/Aggregate (Marine) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY				Ice				
Macroinvertebrates (PJ-2L)	MI-FW-QLDC	Formalin Lot #			Formalin				
Periphyton (PT-50ML)	ALGAE-ID				Ice				
Microbiology (Contract Lab Bottle)	E Coli	F Coli	Enterococci		Ice				
	Contract Lab								
Molecular (QPCR-P-500ML)	PCR-HF183	PCR-BacR	PCR-DG3		Ice				
	PCR-GULL2	PCR-GFD							
Tracers (BG-500ML)	W-E8321-DI	W-E8321-MS			Ice				
			W-PSNP-TQ						
Pesticides (BG-500ML) (BG-1L)	X W-PCL-TQ-R	W-CARB-AA (5 ml of MCAA Buffer Solution)	X	W-CT-CL-R	X Ice	MCAA Exp.	MCAA Lot#	4 or 4	D
	W-TR-SQ-R	X	W-PCB-TQ-R						
Phytoplankton (BP-1L)	DTY-QN-C	PKD-QN-BV			Ice				
DOC (P-500ML)	W-DOC	Field Filtered 0.45 µm Filter			Ice	H2SO4*	<2		
		Acid Preservative Expiration Date							
		Acid Preservative Lot Number							



CHAIN OF CUSTODY RECORD

Project #
(Lab Use Only)

Client Florida Dept. of Environmental Protection
Address 2600 Blairstone Rd. Tallahassee, FL 32399

Report To: DEP-OverflowMicro@dep.state.fl.us

Bill to: Carina Tull

P.O. # LAB #C0136A

Phone 239-344-5719

Preservative: HCL = H, HNO₃ = N, Na₂S₂O₃ = ST

H₂SO₄ = S, NaOH = SH, NH₄Cl = NH

Project Name:

Project Location:

Customer Type:

Klt #:

Requested Due Date:

Sampled By (PRINT)

Sampler Signature Nicole Restad

Micro Sample Description

salt G2SD0055

salt G2SD0015

Fresh G3SD0136

Sample

Date

Time

Type

Grab

Grab

Grab

Preservatives

H

N

S

SH

NH

Bottle Lot #

Samples are ambient water

2023-08-07-57
RQ-2022-

Okay to Run
As Is

Client Initial:

Samples On
Ice

Yes No

Requisitioned By/Affiliation

DA-R-62

FDEP-SORC

Date

Time

Accepted By/Affiliation

Date

Time

Analysis Requested

E. coli (Quantitay)

Enterococci

Fecal Coliform

Sample ID #
(Lab Use Only)

Date of Request: 11-JUL-2023
 Created By: JAEGER_M On: 11-JUL-2023
 Modified By: AYRES_J On: 19-JUL-2023
 Customer: SO-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: South District
 Event Description: 2023 SMP: Burnt Store & More

Send Coolers To:

Phone: 239-344-5716
 FLDEP South District Office
 2295 Victoria Ave. Suite 314
 Fort Myers, FL 33901-3381
 Attn: Monica Jaeger
 Cooler Ship EMail: Monica.Jaeger@FloridaDEP.gov

Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 19-JUL-2023
 Biology Request Reviewed By: SWANSON_C On: 14-JUL-2023
 Sampling Kit Required: YES Ship on: 28-JUL-2023
 Sampling Kit Shipped: YES On: 24-JUL-2023
 Sampling Kit Packed By: KREUCH_B
 Preservatives Needed: NO
 Date to Receive Samples: 08-AUG-2023
 Logged In By:

Send Final Report To:

FLDEP South District Office
 2295 Victoria Ave. Suite 314
 Fort Myers, FL 33901-3381
 Attn: Monica.Jaeger
 Report Notification EMail:
 Nicole.Reistad@FloridaDEP.gov;John.Barrington@FloridaDEP.gov;Monica.Jaeger@FloridaDEP.gov

Comments: Group A: (Marina) Entero
 Group B: (Yucca Pen) Nutrients, Entero
 Group C: Nutrients, E. coli, PCR, Tracers
 Group D: W-CT-CI-R/W-PCL-TQ-R/W-PCB-TQ-R

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-250ML-WI-THI Number of Bottles: 1 Preserved With: ICE
 SD-SND-ENQ Template: DEFAULT (Enterolert/QT) Enterococci by Enterolert/QT by Sanders in Fort Myers

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L Number of Bottles: 1 Preserved With: ICE
 ALKALINITY Template: DEFAULT (SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
 TURBIDITY Template: DEFAULT (EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
 W-CL-IC Template: DEFAULT (EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
 W-COLOR Template: DEFAULT (DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
 Color (true)
 W-F Template: DEFAULT (SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
 W-SO4-IC Template: DEFAULT (EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
 W-TDS Template: DEFAULT (SM 2540 C-2015) Total Dissolved Solids in aqueous matrices
 W-TSS Template: DEFAULT (SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Bottle Type: BP-1L Number of Bottles: 1 Preserved With: ICE
 CHLSUITE-W Template: DEFAULT (SM 10150 B) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Bottle Type: P-250ML-WI-THI Number of Bottles: 1 Preserved With: ICE
 SD-SND-ENQ Template: DEFAULT (Enterolert/QT) Enterococci by Enterolert/QT by Sanders in Fort Myers

Bottle Type: P-500ML Number of Bottles: 1 Preserved With: ICE And H2SO4
 W-NH3 Template: DEFAULT (EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
 W-NO2NO3 Template: DEFAULT (EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
 W-S-A-TP Template: DEFAULT (EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
 W-TKN Template: DEFAULT (EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
 W-TOC Template: DEFAULT (SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group C (Water) With 1 Samples:

Bottle Type: BG-500ML		Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B)	Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: SMP	(EPA 8321B)	Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML		Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0)	Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0)	Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0)	Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0)	Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011)	Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-1L		Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011)	Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0)	Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1)	Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1)	True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)			
W-F	Template: DEFAULT	(SM 4500-F- C-2011)	Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1)	Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2015)	Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2015)	Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L		Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10150 B)	Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: QPCR-P-500ML		Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4)	Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5)	Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0)	Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: P-250ML-WI-THI		Number of Bottles: 1	Preserved With: ICE
SD-SND-ECQ	Template: DEFAULT	(Colilert-18)	E. coli by Colilert-18/QT by Sanders in Fort Myers

Bottle Group D (Water) With 1 Samples:

Bottle Type: BG-500ML FILL TO		Number of Bottles: 4	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276)	Chlordane and Toxaphene in water matrices by GC/MS with Negative Chemical Ionization
W-PCB-TQ-R	Template: DEFAULT	(EPA 8270E)	PCBs in water matrices by GC/MS/MS
W-PCL-TQ-R	Template:	(EPA 8270E)	Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS/MS

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.