

Login Checklist

RQ-2023-12-11-38

Login Station ID: 5

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 12/14/23 @ 9:17

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
- 0.4 0.1				6 8		X X			C48484607418 C48484607407

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes X No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes X No _____

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA X

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No X

Containers intact? Yes X No _____

Caps on tight?

Yes X No _____

Sufficient Sample Volume:

Yes X No _____

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes X No _____ Init: C-P

Chlorine detected? (One container checked per Field ID)

Yes _____ No X Init: C-P

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes X No _____ NA _____ Init: C-P

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes _____ No _____ NA X Init: C-P

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: C-P

Date: 12/14/23

Event contains NCRs (Y/N)? N

EventID: SO-DIST-2023-12-14-01 (SMP)
Date Received: 14-DEC-2023 09:17

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Infrared Thermometer ID:	IR TEMP GUN #5 10/16/24
pH Test Strips 0 – 6	223819av 03/15/2024
pH Paper 0 – 3	NA
pH Paper 0 – 13	210820 3/15/2024
Chlorine Test Strips	0070 02/2023

Additional Comments:

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 12/13/2023 **Collected By:** Nicole Reistad, Other
Customer: SO-DIST **Sampling Agency:** FDEP
RQ: RQ-2023-12-11-38 **Project ID:** SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 2

Delivery Method: FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
BRANDYBRANCH AT NW LILY CORD	 G3SD0201
LAKE MYAKKA (UPPER) AT MIDDLE	 G3SD0133
LAKE MYAKKA (LOWER) AT MIDDLE	 G3SD0107

RELINQUISHED BY (SIGNATURE):

DATE/TIME: 12/13/2023

1400 EST



THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By:



Rec'd/Inspected

Date: 12-14-23



RQ-2023-12-11-38

Customer: FDEP

Project ID: SMP

Collected By: Nicole Reistad, Other

Field Report Prepared by: Nicole Reistad, Other

Sampling Agency: FDEP

WIN ID/Field ID:



WIN ID/Field ID: G3SD0201

Comments: Microbiology sample(s) submitted to contract laboratory.

Location: BRANDYBRANCHATNWLILYCORD

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT)
12/13/2023 925	3.49	35.7	16.4	4.96	0.3	0.5	0.8	201.4	0.1

Parameter Suite	Parameter Methods				Preservation	pH Check	# Bottles sent to Lab	Bottle Group	
Preserved Nutrients (P-500ML)	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP				Ice	H2SO4*	<2		
	Lot #		Exp:						
Metals (P-500ML)	W-ICPMS		W-ICP	W-HARD	Ice	HNO3*	<2		
	Lot #		Exp:						
Filtered Nutrients (P125ML)	W-PO4-F		Field Filtered 0.45 um Filter		Ice				
	Filter Lot #		Syringe Lot #						
BOD (BP-1L)	OV-BODUNIN				Ice				
Chlorophyll (BP-1L)	CHLSUITE-W				Ice				
Physical/Aggregate (Fresh) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY / W-CH-IC / W-COLOR / W-SO4-IC / W-TDS				Ice				
Physical/Aggregate (Marine) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY				Ice				
Macroinvertebrates (PJ-2L)	MI-FW-QLDC	Formalin Lot #			Formalin				
Periphyton (PT-50ML)	ALGAE-ID				Ice				
Microbiology (Contract Lab Bottle)	X	E Coli	F Coli	Enterococci	x	Ice	1	A	
	X	Contract Lab							
Molecular (QPCR-P-500ML)	X	PCR-HF183	X	PCR-BacR	X	PCR-DG3	1	A	
		PCR-GULL2		PCR-GFD					
Tracers (BG-500ML)	X	W-E8321-DI	X	W-E8321-MS	x	Ice	1	A	
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI	W-E8321-MS	W-PSNP-TQ		MCAA Exp.	MCAA Lot#		
	X	W-PCL-TQ-R	W-CARB-AA (5 ml of MCAA Buffer Solution)	X	W-CT-CL-R	x	Ice	4	A
		W-TR-SQ-R	X	W-PCB-TQ-R					
Phytoplankton (BP-1L)		DTY-QN-C	PKD-QN-BV		Ice				
DOC (P-500ML)		W-DOC	Field Filtered 0.45 um Filter		Ice	H2SO4*	<2		
			Acid Preservative Expiration Date						
			Acid Preservative Lot Number						



RQ-2023-12-11-38

Collected By: Nicole Reistad, Other

Customer: FDEP

Field Report Prepared by: Nicole Reistad, Other

Project ID: SMP

Sampling Agency: FDEP

 WIN ID/Field ID: 
 WIN ID/Field ID: G3SD0133

Comments:

Location: LAKE MYAKKA (UPPER) AT MIDDLE

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPTH)
12/13/2023 1100	9.48	98.1	17	5.99	0.3	0.2	0.6	511	0.25

Parameter Suite	Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group		
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	X	<2	1	B
		Lot #	SA3193140		Exp:	07/31/2024						
Metals (P-500ML)		W-ICPMS		W-ICP	W-HARD	Ice	HNO3*			<2		
		Lot #			Exp:							
Filtered Nutrients (P125ML)		W-PO4-F		Field Filtered 0.45 µm Filter		Ice						
		Filter Lot #	Syringe Lot #									
BOD (BP-1L)		OV-BODUNIN				Ice						
Chlorophyll (BP-1L)	X	CHLSUITE-W				x			Ice	1	B	
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-C-IC / W-COLOR / W-SO4-IC / W- TDS				x			Ice	1	B	
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY				Ice						
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #			Formalin						
Periphyton (PT-50ML)		ALGAE-ID				Ice						
Microbiology (Contract Lab Bottle)		E Coli	F Coli	Enterococci		Ice						
		Contract Lab										
Molecular (QPCR-P-500ML)		PCR-HF183	PCR-BacR	PCR-DG3		Ice						
		PCR-GULL2	PCR-GFD									
Tracers (BG-500ML)		W-E8321-DI	W-E8321-MS			Ice						
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI	W-E8321-MS		W-PSNP-TQ	x	Ice	MCAA Exp.	MCAA Lot#	2	B	
	X	W-PCL-TQ-R	W-CARB-AA (5 ml of MCAA Buffer Solution)		X							W-CT-CL-R
		W-TR-SQ-R	X	W-PCB-TQ-R								
Phytoplankton (BP-1L)		DTY-QN-C		PKD-QN-BV		Ice						
DOC (P-500ML)		W-DOC	Field Filtered 0.45 µm Filter		Ice		H2SO4*	<2				
			Acid Preservative Expiration Date									
			Acid Preservative Lot Number									



RQ-2023-12-11-38

Collected By: Nicole Reistad, Other

Customer: FDEP

Field Report Prepared by: Nicole Reistad, Other

Project ID: SMP

Sampling Agency: FDEP

WIN ID/Field ID: 
WIN ID/Field ID: G3SD0107

Comments:

Location: LAKE MYAKKA (LOWER) AT MIDDLE

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPTH)
12/13/2023 1220	9.61	101.1	17.8	6.81	0.25	0.2	0.5	441.9	0.21

Parameter Suite	Parameter Methods			Preservation	pH Check	# Bottles sent to Lab	Bottle Group		
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP	X	Ice	X	H2SO4*	X <2	1	C
		Lot # SA3193140	Exp:	07/31/2024					
Metals (P-500ML)		W-ICPMS	W-ICP	W-HARD	Ice	HNO3*	<2		
		Lot #	Exp:						
Filtered Nutrients (P125ML)		W-PO4-F	Field Filtered 0.45 um Filter		Ice				
		Filter Lot #	Syringe Lot #						
BOD (BP-1L)		OV-BODUNIN			Ice				
Chlorophyll (BP-1L)	X	CHLSUITE-W			X	Ice		1	C
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-Q-IC / W-COLOR / W-SO4-IC / W- TDS			X	Ice		1	C
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY				Ice			
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #		Formalin				
Periphyton (PT-50ML)		ALGAE-ID			Ice				
Microbiology (Contract Lab Bottle)		E Coli	F Coli	Enterococci	Ice				
		Contract Lab							
Molecular (QPCR-P-500ML)		PCR-HF183	PCR-BacR	PCR-DG3	Ice				
		PCR-GULL2	PCR-GFD						
Tracers (BG-500ML)		W-E8321-DI	W-E8321-MS		Ice				
		W-E8321-DI	W-E8321-MS	W-PSNP-TQ		MCAA Exp.	MCAA Lot#		
Pesticides (BG-500ML) (BG-1L)		W-PCL-TQ-R	W-CARB-AA (5 ml of MCAA Buffer Solution)		Ice				
		W-TR-SQ-R	W-PCB-TQ-R						
Phytoplankton (BP-1L)		DTY-QN-C	PKD-QN-8V		Ice				
DOC (P-500ML)		W-DOC	Field Filtered 0.45 um Filter		Ice	H2SO4*		<2	
			Acid Preservative Expiration Date						
			Acid Preservative Lot Number						

Benchmark EnviroAnalytical, Inc.
1001 Corporate Ave. Suite 102
North Port, FL 34289
(941) 625-3137 / (941) 240-3071 fax

BEAS Sample Receipt Temp. 21 °C
Checked at Benchmark EA South E85086
With Temperature Gun ID #7

Client Name: FDEP
Address: 2600 Blair Stone Rd.
Tallahassee, FL, 32399
Phone: (239) 344-5718
Email: dep-overflowmicro@dep.state.fl.us

Bill to: Frances Moore
P.O. #: Lab CIEFCB

Project Name: RQ-2023-12-11-38
Project Run/Location: Mya WKA

Station ID

Surface Water
Sample Matrix
(Fresh / Marine)
Sample Type

Enterococci
E.coli (SM9223B Quantitray)

Laboratory
Sample #

E.Coli = 250 mL ; Entero = 120 mL ; Fecal Coliform = 120 mL

G3SD0201	F / M / Grab	E. coli	Entero / Fecal coliform	Date & Time: 12/13/23 9:25	1
G3SD0133 EA	F / M / Grab	E. coli / Entero / Fecal coliform	Date & Time:		
G3SD0107 EA	F / M / Grab	E. coli / Entero / Fecal coliform	Date & Time:		
	F / M / Grab	E. coli / Entero / Fecal coliform	Date & Time:		
	F / M / Grab	E. coli / Entero / Fecal coliform	Date & Time:		
	F / M / Grab	E. coli / Entero / Fecal coliform	Date & Time:		
	F / M / Grab	E. coli / Entero / Fecal coliform	Date & Time:		
	F / M / Grab	E. coli / Entero / Fecal coliform	Date & Time:		
	F / M / Grab	E. coli / Entero / Fecal coliform	Date & Time:		
	F / M / Grab	E. coli / Entero / Fecal coliform	Date & Time:		
	F / M / Grab	E. coli / Entero / Fecal coliform	Date & Time:		

Laboratory Sample Acceptability:
pH < 10 BEAS Temperature: 9.1°C

- Sample Type: If used to indicate whether the sample was a grab (G) or whether it was a composite (C).
Sample Matrix: If used to indicate whether the sample is being collected for drinking water (DW), ground water (GW), surface water (SW), fresh surface water (FSW), saline surface water (SSW), soil, sediment (SOM), or sludge (SLDG).
Container Type: Is used to indicate whether the container is plastic (P) or glass (G).
Sample must be refrigerated or stored in ice after collection. The maximum temperature during storage should be 4°C (42°F). Under "Preservative" list any preservative that was added to the sample container.
1. Each bottle has a label identifying sample ID, preservation preservative contained in the bottle, sample type, client ID, and parameters for analysis.
2. The following information should be added to each bottle label after collection with permanent black ink: date and time of collection, sample's name or initials, and any field number or ID.
3. All bottles not containing preservative may be stored in a flat appropriate sample prior to collection.
4. The client is responsible for documentation of the sampling event. Please note special sampling events on the sample custody form.

1	Collector: <u>Gunny Ottobona</u>	Date: 12/13/23	Time: 1341	Received By: <u>Metinda Merchant</u>	Date: 12/13/23	Time: 1341
2	Relinquished by:	Date:	Time:	Received By:	Date:	Time:
3	Relinquished by:	Date:	Time:	Received By:	Date:	Time:
4	Relinquished by:	Date:	Time:	Received By:	Date:	Time:
5	Relinquished by:	Date:	Time:	Received By:	Date:	Time:

Date of Request: 28-NOV-2023
 Created By: REISTAD_N On: 28-NOV-2023
 Modified By: JASROTIA_P On: 29-NOV-2023
 Customer: SO-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: South District
 Event Description: 2023 SMP : Myakka

Send Coolers To:

Phone: 239-344-5718
 FLDEP South District Office
 2295 Victoria Ave. Suite 314
 Fort Myers, FL 33901-3381
 Attn: Nicole Reistad
 Cooler Ship EMail: Nicole.Reistad@FloridaDEP.gov

Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 29-NOV-2023
 Biology Request Reviewed By: JASROTIA_P On: 29-NOV-2023
 Sampling Kit Required: YES Ship on: 04-DEC-2023
 Sampling Kit Shipped: YES On: 05-DEC-2023
 Sampling Kit Packed By: LEBRUN_T
 Preservatives Needed: NO
 Date to Receive Samples: 14-DEC-2023
 Logged In By:

Send Final Report To:

FLDEP South District Office
 2295 Victoria Ave. Suite 314
 Fort Myers, FL 33901-3381
 Attn: Nicole Reistad
 Report Notification EMail:
 Nicole.Reistad@FloridaDEP.gov; Monica.Jaeger@FloridaDEP.gov; Samantha.Gelinas@FloridaDEP.gov

Comments: Group A: (Brandy Branch) E. coli, PCR, Tracers, W-CT-CI-R, W-PCL-TQ-R, W-PCB-TQ-R
 Group B: (Upper Myakka) Nutrients, W-CT-CI-R, W-PCL-TQ-R, W-PCB-TQ-R
 Group C: (Lower Myakka) Nutrients

Bottle Group A (Water) With 1 Samples:

Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
SD-BES-ECQ	Template: DEFAULT	(SM 9223 Quanti-Tray) E. coli by Colilert/QT by BEA South in North Port
Bottle Type: BG-500ML FILL TO	Number of Bottles: 4	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Chlordane and Toxaphene in water matrices by GC/MS with Negative Chemical Ionization
W-PCB-TQ-R	Template: DEFAULT	(EPA 8270E) PCBs in water matrices by GC/MS/MS
W-PCL-TQ-R	Template:	(EPA 8270E) Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS/MS
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: SMP	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2015) Total Dissolved Solids in aqueous matrices

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L W-TSS	Template: DEFAULT	Number of Bottles: 1 (SM 2540 D-2015)	Preserved With: ICE Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L CHLSUITE-W	Template: DEFAULT	Number of Bottles: 1 (SM 10150 B)	Preserved With: ICE Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: BG-500ML FILL TO W-CT-CI-R	Template: DEFAULT	Number of Bottles: 2 (EPA 8276)	Preserved With: ICE Chlordane and Toxaphene in water matrices by GC/MS with Negative Chemical Ionization
W-PCB-TQ-R	Template: DEFAULT	(EPA 8270E)	PCBs in water matrices by GC/MS/MS
W-PCL-TQ-R	Template:	(EPA 8270E)	Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS/MS
Bottle Type: P-500ML W-NH3	Template: DEFAULT	Number of Bottles: 1 (EPA 350.1 Rev. 2.0)	Preserved With: ICE And H2SO4 Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0)	Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0)	Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0)	Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2014)	Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group C (Water) With 1 Samples:

Bottle Type: BP-1L CHLSUITE-W	Template: DEFAULT	Number of Bottles: 1 (SM 10150 B)	Preserved With: ICE Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-500ML W-NH3	Template: DEFAULT	Number of Bottles: 1 (EPA 350.1 Rev. 2.0)	Preserved With: ICE And H2SO4 Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0)	Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0)	Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0)	Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2014)	Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-1L ALKALINITY	Template: DEFAULT	Number of Bottles: 1 (SM 2320 B-2011)	Preserved With: ICE Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0)	Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1)	Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1)	True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)			
W-F	Template: DEFAULT	(SM 4500-F- C-2011)	Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1)	Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2015)	Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2015)	Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.