

# Chemical Analysis Report

**NW-DIST-2023-09-27-01**

Florida DEP Laboratory  
2600 Blair Stone Road  
Tallahassee, FL 32399-2400  
DOH Accreditation E31780

Event Description: **Niceville Run**  
Request ID: **RQ-2023-09-18-23**  
Customer: **NW-DIST**  
Project ID: **SMP**

Send Reports to:  
FL Dept. of Environmental Protection  
160 W Government Street  
Suite 208  
Pensacola, FL 32502-5794  
Attn: Myranda Butler

For additional information please contact  
Colin Wright, Ph.D.  
Chris Bowen, B.S.  
Kerry Tate, Ph.D.  
Dr. rer. nat. Bettina Steinbock  
Thekkekalathil Chandrasekhar, Ph.D, QA Officer  
Phone (850) 245-8085

Certified by: Chris Bowen, Environmental Administrator

Date Certified: 23-OCT-2023 11:34



## Case Narrative

Unless otherwise noted, all samples included in this report were received in accordance with protocols referenced in Chapter 62-160, Florida Administrative Code (F.A.C.). Results published in this report pertain only to the samples as submitted to, and received by the laboratory. All times in this report are adjusted to the applicable Eastern Time Zone (EST or EDT).

Results for the following analytical groups are included in this report: Metals, Nutrients and Pesticides.

Scientific notation may be used in reporting very large or small values. Values reported using scientific notation will take the form of the following example: 1.3E+03, which is equivalent to  $1.3 \times 10^3$  or 1300.

Unless otherwise noted, analytical values for soil and sediment samples are reported on a dry weight basis, and analytical values for waste and tissue samples are reported on a wet weight basis.

Results for TNI accredited tests met requirements established by The NELAC Institute. A double asterisk (\*\*) is used to indicate an analyte/matrix/method for which the laboratory is not TNI accredited by the Florida Department of Health Environmental Laboratory Certification Program or where accreditation for that field of testing is not applicable.

Any significant anomalies or deviations from established protocols are documented in Non-Conformance Reports, which, where appropriate, are included within this analytical report. Additional comments related to specific analytical tests may be included as remarks following the analytical results for each sample. Such comments and remarks are for informational purposes only and are not intended to convey judgement about the usability of the reported data.

A quality control report on the performance of the test method for the submitted samples is included. Uncertainty associated with the analytical results contained in this report can be estimated from the reported quality assurance results and from published quality control acceptance limits for each analytical test. Matrix quality control results (matrix spike recoveries and matrix sample precision) pertain only to the matrix sample tested and do not necessarily reflect test method performance for other samples.

Typical matrix quality control (QC) measurements may include matrix spike recovery, matrix spike duplicate recovery, matrix spike precision and matrix sample precision. Not all matrix QC results may be available or reportable; where they are not an explanation is provided. Typical reasons for unavailable QC results include, but are not limited to, a) insufficient matrix sample to perform some or all QC measurements; b) analyte concentration in the sample replicated was too low for a meaningful measurement of precision and c) analyte concentration in the matrix sample spiked was too high (relative to the amount of analyte spiked) for a meaningful measurement of recovery. Where matrix QC results are unavailable, other method performance metrics (e.g., LCS recovery, LCS precision, surrogate recovery) may be used to assess performance of the method. Comments explaining any missing QC measurements are not intended to convey any adverse conclusions about the quality of the reported data.

Precision is reported as relative percent difference unless otherwise noted.

Quality Control codes as defined below may be used in this report to indicate results that are associated with one or more quality control elements which did not fall within established test method criteria. Such results may be qualified as estimates using a J qualifier as required by 62-160 F.A.C. Explanations are included in the report for any results that were reported as estimates for other reasons.

QC Codes used in this report may include:

- LCS – Recovery for the batch Laboratory Control Sample (LCS) was outside existing control limits;
- MS – Recovery for the batch matrix spike (MS) was outside existing control limits;
- CCV – Recovery for a continuing calibration verification (CCV) standard was outside existing control limits;
- SUR – Recovery of a surrogate (SUR) for associated analytes was outside existing control limits;
- RPD – The precision, measured as relative percent difference (RPD), of batch replicate measurements was outside existing control limits;
- RSD – The precision, measured as relative standard deviation (RSD), of batch replicate measurements was outside existing control limits;
- SMP – Sample - used precision derived from replicate analyses of a sample;

The following data qualifiers are used, where applicable, in this report as specified in 62-160 F.A.C.

- A - Value reported is the mean of two or more determinations.
- B - Results based on colony counts outside the acceptable range.
- I - The reported value is between the laboratory method detection limit and the laboratory practical quantitation limit.
- J - Estimated value and/or the analysis did not meet established quality control criteria.
- K - Actual value is known to be less than value given.
- L - Actual value is known to be greater than value given.
- N - Presumptive evidence of presence of material.
- O - Sampled, but analysis lost or not performed.
- Q - Sample held beyond normal holding time.
- T - Value reported is less than the criterion of detection.
- U - Material was analyzed for but not detected. The reported value is the method detection limit for the sample analyzed.
- V - Analyte was detected in both sample and method blank.
- X - Too few individuals to calculate SCI value.
- Y - The laboratory analysis was from an unpreserved or improperly preserved sample. The data may not be accurate.
- Z - Colonies were too numerous to count (TNTC).

Quality control information from overflow laboratories may not be included in this report. Please refer to the associated report from the overflow laboratory for additional information.

**Sample Location: Unnamed Lake**

**Collection Date/Time: 09/26/2023 10:10**

**Field ID: G3NW0223**

**Matrix: W-SURF-FRH**

| Sample ID | Ref. Method        | Component         | Result | Code | Units      | Batch ID | QC Codes |
|-----------|--------------------|-------------------|--------|------|------------|----------|----------|
| 2440547   | DEP SOP: NU-094-1  | Color (true)      | 10     |      | PCU        | P435606  |          |
|           | EPA 180.1 Rev. 2.0 | Turbidity         | 23     |      | NTU        | P435617  |          |
|           | EPA 300.0 Rev. 2.1 | Chloride          | 6.8    |      | mg Cl/L    | P436046  |          |
|           |                    | Sulfate           | 4.8    |      | mg SO4/L   | P436049  |          |
|           | SM 2320 B-2011     | Total Alkalinity  | 5.0    |      | mg CaCO3/L | P435768  |          |
|           | SM 2540 C-2015     | TDS               | 36     |      | mg/L       | P436283  |          |
|           | SM 2540 D-2015     | TSS               | 40     |      | mg/L       | P436015  |          |
|           | SM 4500-F- C-2011  | Fluoride          | 0.025  | U    | mg F/L     | P435770  |          |
| 2440548   | EPA 350.1 Rev. 2.0 | Ammonia-N         | 0.01   |      | mg N/L     | P435750  |          |
|           | EPA 351.2 Rev. 2.0 | Kjeldahl Nitrogen | 0.28   |      | mg N/L     | P435772  |          |
|           | EPA 353.2 Rev. 2.0 | NO2NO3-N          | 0.21   |      | mg N/L     | P436261  |          |
|           | EPA 365.1 Rev. 2.0 | Total-P           | 0.085  |      | mg P/L     | P435710  |          |
|           | SM 5310 B-2011     | Organic Carbon    | 3.1    |      | mg C/L     | P435847  |          |

Ref. Method and Comment:

SM 2540 D-2015: Batch relative percent difference is unavailable because of low analyte concentration in the QC sample.

**Sample Location: Direct Runoff to Choctawhatchee Bay Below Oregon Drive**

**Collection Date/Time: 09/26/2023 10:50**

**Field ID: G3NW0001**

**Matrix: W-SURF-SLT**

| Sample ID | Ref. Method        | Component         | Result   | Code | Units      | Batch ID | QC Codes |
|-----------|--------------------|-------------------|----------|------|------------|----------|----------|
| 2440549   | DEP SOP: NU-094-1  | Color (true)      | 40       |      | PCU        | P435608  |          |
|           | EPA 180.1 Rev. 2.0 | Turbidity         | 7.0      |      | NTU        | P435617  |          |
|           | EPA 300.0 Rev. 2.1 | Chloride          | 1.4E+03  |      | mg Cl/L    | P436046  |          |
|           |                    | Sulfate           | 190      |      | mg SO4/L   | P436049  |          |
|           | SM 2320 B-2011     | Total Alkalinity  | 56       |      | mg CaCO3/L | P435872  |          |
|           | SM 2540 C-2015     | TDS               | 2.46E+03 |      | mg/L       | P436285  |          |
|           | SM 2540 D-2015     | TSS               | 5        | I    | mg/L       | P436019  |          |
|           | SM 4500-F- C-2011  | Fluoride          | 0.14     |      | mg F/L     | P436026  |          |
| 2440551   | EPA 350.1 Rev. 2.0 | Ammonia-N         | 0.027    |      | mg N/L     | P435811  |          |
|           | EPA 351.2 Rev. 2.0 | Kjeldahl Nitrogen | 0.46     |      | mg N/L     | P435773  |          |
|           | EPA 353.2 Rev. 2.0 | NO2NO3-N          | 0.049    |      | mg N/L     | P436140  |          |
|           | EPA 365.1 Rev. 2.0 | Total-P           | 0.039    |      | mg P/L     | P435709  |          |
|           | SM 5310 B-2011     | Organic Carbon    | 7.8      |      | mg C/L     | P436004  |          |

Ref. Method and Comment:

DEP SOP: NU-094-1: Batch relative percent difference is unavailable because of analytical difficulties.

SM 2540 C-2015: The reported result is consistent with the conductivity measured in the laboratory, 4680 umhos/cm.

Sample Location: Gap Creek South of Gail La Rue Cul De Sac

Collection Date/Time: 09/26/2023 11:50

Field ID: G3NW0208

Matrix: W-SURF-FRH

| Sample ID | Ref. Method        | Component        | Result  | Code | Units | Batch ID | QC Codes |
|-----------|--------------------|------------------|---------|------|-------|----------|----------|
| 2440570   | EPA 8321B          | 2,4-D            | 0.0020  | U    | ug/L  | P435567  |          |
|           |                    | Acesulfame K     | 0.10    | U    | ug/L  | P435496  |          |
|           |                    | 2,4,5-T          | 0.0040  | U    | ug/L  | P435567  |          |
|           |                    | AMPA             | 0.10    | U    | ug/L  | P435496  |          |
|           |                    | Acetaminophen    | 0.0080  | U    | ug/L  | P435567  |          |
|           |                    | Acetamiprid      | 0.0020  | U    | ug/L  | P435567  |          |
|           |                    | Endothall        | 0.25    | U    | ug/L  | P435496  | MS       |
|           |                    | Glufosinate      | 0.10    | U    | ug/L  | P435496  |          |
|           |                    | Glyphosate       | 0.10    | U    | ug/L  | P435496  |          |
|           |                    | Afidopyropen     | 0.0020  | U    | ug/L  | P435567  |          |
|           |                    | Bentazon         | 8.0E-04 | U    | ug/L  | P435567  |          |
|           |                    | Sucralose        | 0.12    |      | ug/L  | P435496  |          |
|           |                    | Benzovindiflupyr | 0.0020  | U    | ug/L  | P435567  |          |
|           |                    | Carbamazepine    | 8.0E-04 | U    | ug/L  | P435567  |          |
|           |                    | Clothianidin     | 0.0020  | U    | ug/L  | P435567  |          |
|           |                    | Dinotefuran      | 0.0020  | U    | ug/L  | P435567  |          |
|           |                    | Diuron           | 0.0020  | U    | ug/L  | P435567  |          |
|           |                    | Fenuron          | 0.032   | U    | ug/L  | P435567  |          |
|           |                    | Fluridone        | 8.0E-04 | U    | ug/L  | P435567  | MS       |
|           |                    | Imazapyr         | 0.015   | I    | ug/L  | P435567  |          |
|           |                    | Hydrocodone      | 0.0020  | U    | ug/L  | P435567  |          |
|           |                    | Ibuprofen        | 0.080   | U    | ug/L  | P435567  |          |
|           |                    | Imidacloprid     | 0.0035  | I    | ug/L  | P435567  |          |
|           |                    | Linuron          | 0.0040  | U    | ug/L  | P435567  |          |
|           |                    | Mandestrobin     | 0.0020  | U    | ug/L  | P435567  |          |
|           |                    | MCPP             | 0.0020  | U    | ug/L  | P435567  |          |
|           |                    | Naproxen         | 0.0080  | U    | ug/L  | P435567  |          |
|           |                    | Primidone        | 0.0040  | U    | ug/L  | P435567  |          |
|           |                    | Pyraclostrobin   | 0.0020  | U    | ug/L  | P435567  |          |
|           |                    | Silvex           | 0.0040  | U    | ug/L  | P435567  |          |
|           |                    | Thiamethoxam     | 0.0020  | U    | ug/L  | P435567  |          |
|           |                    | Tolfenpyrad      | 0.0020  | U    | ug/L  | P435567  |          |
|           |                    | Triclopyr        | 0.0040  | U    | ug/L  | P435567  |          |
| 2440574   | EPA 200.7 Rev. 4.4 | Calcium          | 15.1    |      | mg/L  | P435682  |          |
|           |                    | Iron             | 880     |      | ug/L  | P435682  |          |
|           |                    | Magnesium        | 1.62    |      | mg/L  | P435682  |          |
|           |                    | Potassium        | 0.86    | I    | mg/L  | P435682  |          |
|           |                    | Sodium           | 10.1    |      | mg/L  | P435682  |          |
|           |                    | Strontium        | 79.1    |      | ug/L  | P435682  |          |
|           |                    | Tin              | 4.4     | I    | ug/L  | P435682  |          |
|           |                    | Titanium         | 0.75    | U    | ug/L  | P435682  |          |
|           |                    | Vanadium         | 2.0     | U    | ug/L  | P435682  |          |
|           |                    | Zinc             | 5.0     | U    | ug/L  | P435682  |          |
|           | EPA 200.8 Rev. 5.4 | Aluminum         | 154     |      | ug/L  | P435682  |          |

Field ID: G3NW0208

Matrix: W-SURF-FRH

| Sample ID | Ref. Method        | Component  | Result | Code | Units | Batch ID | QC Codes |
|-----------|--------------------|------------|--------|------|-------|----------|----------|
| 2440574   | EPA 200.8 Rev. 5.4 | Antimony   | 0.050  | U    | ug/L  | P435682  |          |
|           |                    | Arsenic    | 0.76   |      | ug/L  | P435682  |          |
|           |                    | Barium     | 16.3   |      | ug/L  | P435682  |          |
|           |                    | Beryllium  | 0.010  | U    | ug/L  | P435682  |          |
|           |                    | Boron      | 33.9   |      | ug/L  | P435682  |          |
|           |                    | Cadmium    | 0.020  | U    | ug/L  | P435682  |          |
|           |                    | Chromium   | 0.46   | I    | ug/L  | P435682  |          |
|           |                    | Cobalt     | 0.111  |      | ug/L  | P435682  |          |
|           |                    | Copper     | 0.40   | U    | ug/L  | P435682  |          |
|           |                    | Lead       | 0.21   | I    | ug/L  | P435682  |          |
|           |                    | Manganese  | 21.9   |      | ug/L  | P435682  |          |
|           |                    | Molybdenum | 0.15   | U    | ug/L  | P435682  |          |
|           |                    | Nickel     | 0.50   | U    | ug/L  | P435682  |          |
|           |                    | Selenium   | 0.20   | U    | ug/L  | P435682  |          |
|           |                    | Silver     | 0.010  | U    | ug/L  | P435682  |          |
|           | SM 2340 B-2011     | Thallium   | 0.10   | U    | ug/L  | P435682  |          |
|           |                    | Hardness   | 44.4   |      | mg/L  | P435682  |          |

Ref. Method and Comment:  
 EPA 8321B: MS accuracy for some analytes could not be assessed due to high concentration of parameter in the spiked sample.

**Sample Location: Direct Runoff to Choctawhatchee Bay at City Park**

**Collection Date/Time: 09/26/2023 11:00**

**Field ID: G3NW0002**

**Matrix: W-SURF-SLT**

| Sample ID | Ref. Method        | Component         | Result   | Code | Units      | Batch ID | QC Codes |
|-----------|--------------------|-------------------|----------|------|------------|----------|----------|
| 2440550   | DEP SOP: NU-094-1  | Color (true)      | 23       |      | PCU        | P435606  |          |
|           | EPA 180.1 Rev. 2.0 | Turbidity         | 10       |      | NTU        | P435617  |          |
|           | EPA 300.0 Rev. 2.1 | Chloride          | 1.1E+04  |      | mg Cl/L    | P436046  |          |
|           |                    | Sulfate           | 1.5E+03  |      | mg SO4/L   | P436049  |          |
|           | SM 2320 B-2011     | Total Alkalinity  | 81       |      | mg CaCO3/L | P435872  |          |
|           | SM 2540 C-2015     | TDS               | 1.84E+04 |      | mg/L       | P436285  |          |
|           | SM 2540 D-2015     | TSS               | 12       | A    | mg/L       | P436019  |          |
|           | SM 4500-F- C-2011  | Fluoride          | 0.74     |      | mg F/L     | P435874  |          |
| 2440552   | EPA 350.1 Rev. 2.0 | Ammonia-N         | 0.010    |      | mg N/L     | P435811  |          |
|           | EPA 351.2 Rev. 2.0 | Kjeldahl Nitrogen | 0.53     |      | mg N/L     | P435773  |          |
|           | EPA 353.2 Rev. 2.0 | NO2NO3-N          | 0.012    |      | mg N/L     | P436205  |          |
|           | EPA 365.1 Rev. 2.0 | Total-P           | 0.049    |      | mg P/L     | P435709  |          |
|           | SM 5310 B-2011     | Organic Carbon    | 5.8      |      | mg C/L     | P436004  |          |

Sample Location: Gap Creek Powerline South of Overbrook Drive Collection Date/Time: 09/26/2023 12:15

Field ID: G3NW0142

Matrix: W-SURF-FRH

| Sample ID | Ref. Method | Component           | Result  | Code | Units | Batch ID | QC Codes |
|-----------|-------------|---------------------|---------|------|-------|----------|----------|
| 2440568   | EPA 8321B   | Aldicarb            | 0.020   | U    | ug/L  | P435381  |          |
|           |             | Aldicarb Sulfone    | 0.0020  | U    | ug/L  | P435381  |          |
|           |             | Aldicarb Sulfoxide  | 0.0020  | U    | ug/L  | P435381  | MS       |
|           |             | Carbaryl            | 0.0020  | U    | ug/L  | P435381  |          |
|           |             | Carbofuran          | 0.0020  | U    | ug/L  | P435381  |          |
|           |             | 3-Hydroxycarbofuran | 0.0020  | U    | ug/L  | P435381  |          |
|           |             | Methiocarb          | 0.0020  | U    | ug/L  | P435381  |          |
|           |             | Methomyl            | 0.0020  | U    | ug/L  | P435381  |          |
|           |             | Oxamyl              | 0.0020  | U    | ug/L  | P435381  |          |
|           |             | Propoxur            | 0.0020  | U    | ug/L  | P435381  |          |
| 2440569   |             | 2,4-D               | 0.0020  | U    | ug/L  | P435567  |          |
|           |             | Acesulfame K        | 0.28    | I    | ug/L  | P435496  |          |
|           |             | 2,4,5-T             | 0.0040  | U    | ug/L  | P435567  |          |
|           |             | AMPA                | 0.29    | I    | ug/L  | P435496  |          |
|           |             | Acetaminophen       | 0.0080  | U    | ug/L  | P435567  |          |
|           |             | Acetamiprid         | 0.0020  | U    | ug/L  | P435567  |          |
|           |             | Endothall           | 0.25    | U    | ug/L  | P435496  | MS       |
|           |             | Glufosinate         | 0.10    | U    | ug/L  | P435496  |          |
|           |             | Glyphosate          | 0.10    | U    | ug/L  | P435496  |          |
|           |             | Afidopyropen        | 0.0020  | U    | ug/L  | P435567  |          |
|           |             | Bentazon            | 8.0E-04 | U    | ug/L  | P435567  |          |
|           |             | Sucralose           | 0.22    |      | ug/L  | P435496  |          |
|           |             | Benzovindiflupyr    | 0.0020  | U    | ug/L  | P435567  |          |
|           |             | Carbamazepine       | 8.0E-04 | U    | ug/L  | P435567  |          |
|           |             | Clothianidin        | 0.0020  | U    | ug/L  | P435567  |          |
|           |             | Dinotefuran         | 0.0020  | U    | ug/L  | P435567  |          |
|           |             | Diuron              | 0.0020  | U    | ug/L  | P435567  |          |
|           |             | Fenuron             | 0.032   | U    | ug/L  | P435567  |          |
|           |             | Fluridone           | 0.014   |      | ug/L  | P435567  | MS       |
|           |             | Imazapyr            | 0.011   | I    | ug/L  | P435567  |          |
|           |             | Hydrocodone         | 0.0020  | U    | ug/L  | P435567  |          |
|           |             | Ibuprofen           | 0.080   | U    | ug/L  | P435567  |          |
|           |             | Imidacloprid        | 0.020   |      | ug/L  | P435567  |          |
|           |             | Linuron             | 0.0040  | U    | ug/L  | P435567  |          |
|           |             | Mandestrobin        | 0.0020  | U    | ug/L  | P435567  |          |
|           |             | MCPP                | 0.0020  | U    | ug/L  | P435567  |          |
|           |             | Naproxen            | 0.0080  | U    | ug/L  | P435567  |          |
|           |             | Primidone           | 0.0040  | U    | ug/L  | P435567  |          |
|           |             | Pyraclostrobin      | 0.0020  | U    | ug/L  | P435567  |          |
|           |             | Silvex              | 0.0040  | U    | ug/L  | P435567  |          |
|           |             | Thiamethoxam        | 0.0020  | U    | ug/L  | P435567  |          |
|           |             | Tolfenpyrad         | 0.0020  | U    | ug/L  | P435567  |          |
|           |             | Triclopyr           | 0.0040  | U    | ug/L  | P435567  |          |
| 2440571   | EPA 8270E   | Aldrin              | 0.67    | U    | ng/L  | P435653  |          |

Field ID: G3NW0142

Matrix: W-SURF-FRH

| Sample ID | Ref. Method | Component           | Result | Code | Units | Batch ID | QC Codes |
|-----------|-------------|---------------------|--------|------|-------|----------|----------|
| 2440571   | EPA 8270E   | Alpha-BHC           | 0.10   | U    | ng/L  | P435653  | RPD      |
|           |             | Alpha-Chlordane     | 0.21   | U    | ng/L  | P435653  |          |
|           |             | PCB-1016            | 2.1    | U    | ng/L  | P435653  |          |
|           |             | Beta-BHC            | 0.10   | U    | ng/L  | P435653  |          |
|           |             | PCB-1221            | 2.1    | U    | ng/L  | P435653  |          |
|           |             | Beta-Cyfluthrin     | 1.3    | U    | ng/L  | P435653  |          |
|           |             | PCB-1232            | 2.1    | U    | ng/L  | P435653  |          |
|           |             | Bifenthrin          | 0.52   | U    | ng/L  | P435653  |          |
|           |             | PCB-1242            | 2.1    | U    | ng/L  | P435653  |          |
|           |             | PCB-1248            | 2.1    | U    | ng/L  | P435653  |          |
|           |             | Chlorothalonil      | 3.7    | U    | ng/L  | P435653  |          |
|           |             | PCB-1254            | 2.1    | U    | ng/L  | P435653  |          |
|           |             | Cis-Nonachlor       | 0.21   | U    | ng/L  | P435653  |          |
|           |             | PCB-1260            | 2.1    | U    | ng/L  | P435653  |          |
|           |             | Cypermethrin        | 1.5    | U    | ng/L  | P435653  |          |
|           |             | Dacthal             | 0.15   | U    | ng/L  | P435653  |          |
|           |             | DDD-p,p'            | 0.26   | U    | ng/L  | P435653  |          |
|           |             | DDE-p,p'            | 0.21   | U    | ng/L  | P435653  |          |
|           |             | DDT-p,p'            | 0.83   | U    | ng/L  | P435653  |          |
|           |             | Delta-BHC           | 0.41   | U    | ng/L  | P435653  |          |
|           |             | Deltamethrin        | 1.3    | U    | ng/L  | P435653  |          |
|           |             | Dichlobenil         | 0.26   | U    | ng/L  | P435653  |          |
|           |             | Dicofol             | 1.3    | U    | ng/L  | P435653  |          |
|           |             | Dieldrin            | 0.41   | U    | ng/L  | P435653  |          |
|           |             | Endosulfan I        | 0.41   | U    | ng/L  | P435653  |          |
|           |             | Endosulfan II       | 0.93   | U    | ng/L  | P435653  |          |
|           |             | Endosulfan Sulfate  | 0.31   | U    | ng/L  | P435653  |          |
|           |             | Endrin              | 0.93   | U    | ng/L  | P435653  |          |
|           |             | Endrin Aldehyde     | 0.77   | U    | ng/L  | P435653  |          |
|           |             | Endrin Ketone       | 0.41   | U    | ng/L  | P435653  |          |
|           |             | Esfenvalerate       | 0.77   | U    | ng/L  | P435653  |          |
|           |             | Ethalfuralin        | 0.15   | U    | ng/L  | P435653  |          |
|           |             | Fenpropathrin       | 0.26   | U    | ng/L  | P435653  |          |
|           |             | Gamma-BHC           | 0.13   | U    | ng/L  | P435653  |          |
|           |             | Gamma-Chlordane     | 0.21   | U    | ng/L  | P435653  |          |
|           |             | Heptachlor          | 0.21   | U    | ng/L  | P435653  |          |
|           |             | Heptachlor Epoxide  | 0.47   | I    | ng/L  | P435653  |          |
|           |             | Hexachlorobenzene** | 1.0    | U    | ng/L  | P435653  |          |
|           |             | Kepone              | 14     | U    | ng/L  | P435653  |          |
|           |             | Lambda-Cyhalothrin  | 0.77   | U    | ng/L  | P435653  |          |
|           |             | Methoprene          | 0.77   | U    | ng/L  | P435653  |          |
|           |             | Methoxychlor        | 0.31   | U    | ng/L  | P435653  |          |
|           |             | MGK-264             | 0.21   | U    | ng/L  | P435653  |          |
|           |             | Mirex               | 0.36   | U    | ng/L  | P435653  |          |
|           |             | Oxychlordane        | 0.31   | U    | ng/L  | P435653  |          |

Field ID: G3NW0142

Matrix: W-SURF-FRH

| Sample ID | Ref. Method | Component                                            | Result | Code | Units | Batch ID | QC Codes |
|-----------|-------------|------------------------------------------------------|--------|------|-------|----------|----------|
| 2440571   | EPA 8270E   | Permethrin                                           | 1.7    | U    | ng/L  | P435653  |          |
|           |             | Phenothrin                                           | 0.93   | U    | ng/L  | P435653  |          |
|           |             | Piperonyl Butoxide                                   | 0.32   | I    | ng/L  | P435653  |          |
|           |             | Prallethrin                                          | 2.1    | U    | ng/L  | P435653  |          |
|           |             | Tau-Fluvalinate                                      | 0.26   | U    | ng/L  | P435653  |          |
|           |             | Tetramethrin                                         | 0.77   | U    | ng/L  | P435653  |          |
|           |             | Trans-Nonachlor                                      | 0.21   | U    | ng/L  | P435653  |          |
|           |             | Triclosan Methyl                                     | 0.15   | U    | ng/L  | P435653  |          |
|           |             | Trifluralin                                          | 0.21   | U    | ng/L  | P435653  |          |
|           |             | Chlordane                                            | 2.1    | U    | ng/L  | P435653  |          |
|           | EPA 8276    | Toxaphene                                            | 15     | U    | ng/L  | P435653  |          |
|           |             | Oxybenzone**                                         | 10     | U    | ng/L  | P435493  |          |
|           |             | Acetochlor                                           | 0.21   | U    | ng/L  | P435493  |          |
|           |             | Octinoxate**                                         | 150    | U    | ng/L  | P435493  |          |
|           |             | Alachlor                                             | 0.41   | U    | ng/L  | P435493  |          |
|           |             | Avobenzone**                                         | 100    | U    | ng/L  | P435493  |          |
|           |             | Ametryn                                              | 1.1    | U    | ng/L  | P435493  |          |
|           |             | Atrazine                                             | 11     |      | ng/L  | P435493  |          |
|           |             | PBDE-47**                                            | 4.1    | U    | ng/L  | P435493  |          |
|           |             | Atrazine Desethyl                                    | 2.4    | I    | ng/L  | P435493  |          |
| 2440572   | EPA 8270E   | PBDE-99**                                            | 5.1    | U    | ng/L  | P435493  |          |
|           |             | Azinphos Methyl                                      | 3.1    | U    | ng/L  | P435493  |          |
|           |             | Tri-o-cresyl Phosphate**                             | 6.2    | U    | ng/L  | P435493  |          |
|           |             | Azoxystrobin                                         | 0.41   | U    | ng/L  | P435493  |          |
|           |             | Bromacil                                             | 0.62   | U    | ng/L  | P435493  |          |
|           |             | 2-Ethylhexyl<br>2,3,4,5-tetrabromobenzoate (EHTBB)** | 12     | U    | ng/L  | P435493  | MS       |
|           |             | Butylate                                             | 0.46   | U    | ng/L  | P435493  |          |
|           |             | Dechlorane Plus**                                    | 31     | U    | ng/L  | P435493  |          |
|           |             | Caffeine**                                           | 7.7    | U    | ng/L  | P435493  |          |
|           |             | Dechlorane 602**                                     | 5.1    | U    | ng/L  | P435493  | MS       |
|           |             | Carbophenothion                                      | 0.51   | U    | ng/L  | P435493  |          |
|           |             | Dechlorane 603**                                     | 4.1    | U    | ng/L  | P435493  |          |
|           |             | Carfentrazone Ethyl                                  | 0.15   | U    | ng/L  | P435493  |          |
|           |             | Hexabromobenzene**                                   | 6.2    | U    | ng/L  | P435493  |          |
|           |             | Chlorfenapyr                                         | 0.31   | U    | ng/L  | P435493  |          |
|           |             | PBB-153**                                            | 8.2    | U    | ng/L  | P435493  | MS       |
|           |             | Chlorpyrifos Ethyl                                   | 0.31   | U    | ng/L  | P435493  |          |
|           |             | Pentabromotoluene**                                  | 3.1    | U    | ng/L  | P435493  |          |
|           |             | Chlorpyrifos Methyl                                  | 0.10   | U    | ng/L  | P435493  |          |
|           |             | Tris(2-chloroethyl) phosphate (TCEP)**               | 72     | U    | ng/L  | P435493  |          |
|           |             | Coumaphos                                            | 1.1    | U    | ng/L  | P435493  |          |
|           |             | Tris(1-chloro-2-propyl) phosphate<br>(TCPP)**        | 15     | U    | ng/L  | P435493  |          |
|           |             | Cyanazine                                            | 5.1    | U    | ng/L  | P435493  |          |
|           |             | Tris(1,3-dichloro-2-propyl) phosphate<br>(TDCPP)**   | 2.6    | U    | ng/L  | P435493  |          |
|           |             |                                                      |        |      |       |          |          |

Field ID: G3NW0142

Matrix: W-SURF-FRH

| Sample ID | Ref. Method | Component                                                   | Result | Code | Units | Batch ID | QC Codes |
|-----------|-------------|-------------------------------------------------------------|--------|------|-------|----------|----------|
| 2440572   | EPA 8270E   | Cyprodinil                                                  | 0.21   | U    | ng/L  | P435493  |          |
|           |             | Tetradecachloro-m-terphenyl**                               | 7.7    | U    | ng/L  | P435493  |          |
|           |             | Demeton                                                     | 3.6    | U    | ng/L  | P435493  |          |
|           |             | 2-(2H-benzotriazol-2-yl)-4,6-ditertpentyl phenol (UV-328)** | 62     | U    | ng/L  | P435493  |          |
|           |             | Diazinon                                                    | 0.13   | U    | ng/L  | P435493  |          |
|           |             | Difenoconazole                                              | 0.62   | U    | ng/L  | P435493  |          |
|           |             | Dimethenamid                                                | 0.10   | U    | ng/L  | P435493  |          |
|           |             | Dimethomorph                                                | 0.31   | U    | ng/L  | P435493  | MS       |
|           |             | Disulfoton                                                  | 0.62   | U    | ng/L  | P435493  |          |
|           |             | Dithiopyr                                                   | 1.0    | U    | ng/L  | P435493  |          |
|           |             | EPTC                                                        | 0.51   | U    | ng/L  | P435493  | RPD      |
|           |             | Ethion                                                      | 0.31   | U    | ng/L  | P435493  |          |
|           |             | Ethoprop                                                    | 0.13   | U    | ng/L  | P435493  |          |
|           |             | Etridiazole                                                 | 0.10   | U    | ng/L  | P435493  |          |
|           |             | Fenamiphos                                                  | 0.46   | U    | ng/L  | P435493  |          |
|           |             | Fenbuconazole                                               | 0.51   | U    | ng/L  | P435493  |          |
|           |             | Fipronil                                                    | 1.3    |      | ng/L  | P435493  |          |
|           |             | Fipronil Desulfinyl**                                       | 0.47   | I    | ng/L  | P435493  |          |
|           |             | Fipronil Sulfide                                            | 5.9    |      | ng/L  | P435493  |          |
|           |             | Fipronil Sulfone                                            | 8.9    |      | ng/L  | P435493  |          |
|           |             | Fluazifop-P-butyl                                           | 0.10   | U    | ng/L  | P435493  |          |
|           |             | Fludioxonil                                                 | 0.10   | U    | ng/L  | P435493  |          |
|           |             | Flumioxazin                                                 | 3.1    | U    | ng/L  | P435493  |          |
|           |             | Flutolanil                                                  | 0.10   | U    | ng/L  | P435493  |          |
|           |             | Fluxapyroxad                                                | 0.26   | U    | ng/L  | P435493  |          |
|           |             | Fonofos                                                     | 0.15   | U    | ng/L  | P435493  |          |
|           |             | Hexazinone                                                  | 0.51   | U    | ng/L  | P435493  |          |
|           |             | Imazalil                                                    | 0.67   | U    | ng/L  | P435493  |          |
|           |             | Iprodione                                                   | 0.51   | UJ   | ng/L  | P435493  | CCV      |
|           |             | Loratadine**                                                | 0.31   | U    | ng/L  | P435493  |          |
|           |             | Malathion                                                   | 0.36   | U    | ng/L  | P435493  |          |
|           |             | Metalaxyl                                                   | 0.51   | U    | ng/L  | P435493  |          |
|           |             | Metolachlor                                                 | 0.77   | U    | ng/L  | P435493  |          |
|           |             | Metribuzin                                                  | 0.41   | UJ   | ng/L  | P435493  | LCS      |
|           |             | Mevinphos                                                   | 1.0    | U    | ng/L  | P435493  |          |
|           |             | Molinate                                                    | 0.26   | U    | ng/L  | P435493  |          |
|           |             | Myclobutanil                                                | 0.36   | U    | ng/L  | P435493  |          |
|           |             | Naled                                                       | 2.6    | U    | ng/L  | P435493  |          |
|           |             | Napropamide                                                 | 0.72   | U    | ng/L  | P435493  |          |
|           |             | Norflurazon                                                 | 1.0    | U    | ng/L  | P435493  |          |
|           |             | Oxadiazon                                                   | 0.36   | U    | ng/L  | P435493  |          |
|           |             | Oxyfluorfen                                                 | 0.21   | U    | ng/L  | P435493  |          |
|           |             | Parathion Ethyl                                             | 0.15   | U    | ng/L  | P435493  |          |
|           |             | Parathion Methyl                                            | 0.21   | U    | ng/L  | P435493  |          |

Field ID: G3NW0142

Matrix: W-SURF-FRH

| Sample ID | Ref. Method | Component        | Result | Code | Units | Batch ID | QC Codes |
|-----------|-------------|------------------|--------|------|-------|----------|----------|
| 2440572   | EPA 8270E   | Pendimethalin    | 0.77   | U    | ng/L  | P435493  |          |
|           |             | Phenytain**      | 5.5    | U    | ng/L  | P435493  |          |
|           |             | Phorate          | 0.26   | U    | ng/L  | P435493  |          |
|           |             | Prodiamine       | 0.21   | U    | ng/L  | P435493  |          |
|           |             | Prometon         | 3.1    | U    | ng/L  | P435493  |          |
|           |             | Prometryn        | 0.36   | U    | ng/L  | P435493  |          |
|           |             | Pronamide        | 0.10   | U    | ng/L  | P435493  |          |
|           |             | Propanil         | 0.10   | U    | ng/L  | P435493  |          |
|           |             | Propargite       | 0.82   | U    | ng/L  | P435493  |          |
|           |             | Propiconazole    | 0.62   | U    | ng/L  | P435493  |          |
|           |             | Pyraflufen Ethyl | 0.31   | U    | ng/L  | P435493  |          |
|           |             | Pyridaben        | 1.4    | U    | ng/L  | P435493  |          |
|           |             | Pyriproxyfen     | 0.26   | UJ   | ng/L  | P435493  | CCV      |
|           |             | Simazine         | 0.26   | U    | ng/L  | P435493  |          |
|           |             | Stirophos        | 0.41   | U    | ng/L  | P435493  |          |
|           |             | Sulfentrazone    | 6.6    | I    | ng/L  | P435493  |          |
|           |             | Tebuconazole     | 1.4    | U    | ng/L  | P435493  |          |
|           |             | Terbufos         | 0.21   | U    | ng/L  | P435493  |          |
|           |             | Terbuthylazine   | 0.21   | U    | ng/L  | P435493  |          |
|           |             | Thiobencarb      | 0.51   | U    | ng/L  | P435493  |          |
|           |             | Triadimefon      | 0.15   | U    | ng/L  | P435493  |          |

Ref. Method and Comment:

EPA 8321B: MS accuracy for some analytes could not be assessed due to high concentration of parameter in the spiked sample.

EPA 8270E: MS accuracy for atrazine not assessed due to high content of this parameter in the sample spiked. Refer to the Lab Analysis Report for an explanation of QC Codes.

Sample Location: FB

Collection Date/Time: 09/26/2023 10:05

Field ID: FB\_09262023

Matrix: W-FIELD-BK

| Sample ID | Ref. Method | Component                                                   | Result | Code | Units | Batch ID | QC Codes |
|-----------|-------------|-------------------------------------------------------------|--------|------|-------|----------|----------|
| 2440573   | EPA 8270E   | Oxybenzone**                                                | 54     |      | ng/L  | P435493  |          |
|           |             | Acetochlor                                                  | 0.21   | U    | ng/L  | P435493  |          |
|           |             | Octinoxate**                                                | 160    | U    | ng/L  | P435493  |          |
|           |             | Alachlor                                                    | 0.42   | U    | ng/L  | P435493  |          |
|           |             | Avobenzone**                                                | 110    | U    | ng/L  | P435493  |          |
|           |             | Ametryn                                                     | 1.2    | U    | ng/L  | P435493  |          |
|           |             | Atrazine                                                    | 0.21   | U    | ng/L  | P435493  |          |
|           |             | PBDE-47**                                                   | 4.2    | U    | ng/L  | P435493  |          |
|           |             | Atrazine Desethyl                                           | 1.4    | U    | ng/L  | P435493  |          |
|           |             | PBDE-99**                                                   | 5.3    | U    | ng/L  | P435493  |          |
|           |             | Azinphos Methyl                                             | 3.2    | U    | ng/L  | P435493  |          |
|           |             | Tri-o-cresyl Phosphate**                                    | 6.4    | U    | ng/L  | P435493  |          |
|           |             | Azoxystrobin                                                | 0.42   | U    | ng/L  | P435493  |          |
|           |             | Bromacil                                                    | 0.64   | U    | ng/L  | P435493  |          |
|           |             | 2-Ethylhexyl                                                | 13     | U    | ng/L  | P435493  | MS       |
|           |             | 2,3,4,5-tetrabromobenzoate (EHTBB)**                        |        |      |       |          |          |
|           |             | Butylate                                                    | 0.21   | U    | ng/L  | P435493  |          |
|           |             | Dechlorane Plus**                                           | 32     | U    | ng/L  | P435493  |          |
|           |             | Caffeine**                                                  | 7.9    | U    | ng/L  | P435493  |          |
|           |             | Dechlorane 602**                                            | 5.3    | U    | ng/L  | P435493  | MS       |
|           |             | Carbophenothion                                             | 0.53   | U    | ng/L  | P435493  |          |
|           |             | Dechlorane 603**                                            | 4.2    | U    | ng/L  | P435493  |          |
|           |             | Carfentrazone Ethyl                                         | 0.16   | U    | ng/L  | P435493  |          |
|           |             | Hexabromobenzene**                                          | 6.4    | U    | ng/L  | P435493  |          |
|           |             | Chlorfenapyr                                                | 0.32   | U    | ng/L  | P435493  |          |
|           |             | PBB-153**                                                   | 8.5    | U    | ng/L  | P435493  | MS       |
|           |             | Chlorpyrifos Ethyl                                          | 0.32   | U    | ng/L  | P435493  |          |
|           |             | Pentabromotoluene**                                         | 3.2    | U    | ng/L  | P435493  |          |
|           |             | Chlorpyrifos Methyl                                         | 0.11   | U    | ng/L  | P435493  |          |
|           |             | Tris(2-chloroethyl) phosphate (TCEP)**                      | 74     | U    | ng/L  | P435493  |          |
|           |             | Coumaphos                                                   | 1.1    | U    | ng/L  | P435493  |          |
|           |             | Tris(1-chloro-2-propyl) phosphate (TCPP)**                  | 16     | U    | ng/L  | P435493  |          |
|           |             | Cyanazine                                                   | 5.3    | U    | ng/L  | P435493  |          |
|           |             | Tris(1,3-dichloro-2-propyl) phosphate (TDCPP)**             | 3.5    | I    | ng/L  | P435493  |          |
|           |             | Cyprodinil                                                  | 0.21   | U    | ng/L  | P435493  |          |
|           |             | Tetradecachloro-m-terphenyl**                               | 7.9    | U    | ng/L  | P435493  |          |
|           |             | Demeton                                                     | 3.7    | U    | ng/L  | P435493  |          |
|           |             | 2-(2H-benzotriazol-2-yl)-4,6-ditertpentyl phenol (UV-328)** | 64     | U    | ng/L  | P435493  |          |
|           |             | Diazinon                                                    | 0.13   | U    | ng/L  | P435493  |          |
|           |             | Difenoconazole                                              | 0.64   | U    | ng/L  | P435493  |          |
|           |             | Dimethenamid                                                | 0.11   | U    | ng/L  | P435493  |          |
|           |             | Dimethomorph                                                | 0.32   | U    | ng/L  | P435493  | MS       |
|           |             | Disulfoton                                                  | 0.64   | U    | ng/L  | P435493  |          |

Field ID: FB\_09262023

Matrix: W-FIELD-BK

| Sample ID | Ref. Method | Component             | Result | Code | Units | Batch ID | QC Codes |
|-----------|-------------|-----------------------|--------|------|-------|----------|----------|
| 2440573   | EPA 8270E   | Dithiopyr             | 1.1    | U    | ng/L  | P435493  |          |
|           |             | EPTC                  | 0.53   | U    | ng/L  | P435493  | RPD      |
|           |             | Ethion                | 0.32   | U    | ng/L  | P435493  |          |
|           |             | Ethoprop              | 0.13   | U    | ng/L  | P435493  |          |
|           |             | Etridiazole           | 0.11   | U    | ng/L  | P435493  |          |
|           |             | Fenamiphos            | 0.48   | U    | ng/L  | P435493  |          |
|           |             | Fenbuconazole         | 0.53   | U    | ng/L  | P435493  |          |
|           |             | Fipronil              | 0.21   | U    | ng/L  | P435493  |          |
|           |             | Fipronil Desulfinyl** | 0.11   | U    | ng/L  | P435493  |          |
|           |             | Fipronil Sulfide      | 0.11   | U    | ng/L  | P435493  |          |
|           |             | Fipronil Sulfone      | 0.11   | U    | ng/L  | P435493  |          |
|           |             | Fluazifop-P-butyl     | 0.11   | U    | ng/L  | P435493  |          |
|           |             | Fludioxonil           | 0.11   | U    | ng/L  | P435493  |          |
|           |             | Flumioxazin           | 3.2    | U    | ng/L  | P435493  |          |
|           |             | Flutolanil            | 0.11   | U    | ng/L  | P435493  |          |
|           |             | Fluxapyroxad          | 0.26   | U    | ng/L  | P435493  |          |
|           |             | Fonofos               | 0.16   | U    | ng/L  | P435493  |          |
|           |             | Hexazinone            | 0.53   | U    | ng/L  | P435493  |          |
|           |             | Imazalil              | 0.69   | U    | ng/L  | P435493  |          |
|           |             | Iprodione             | 0.53   | UJ   | ng/L  | P435493  | CCV      |
|           |             | Loratadine**          | 0.32   | U    | ng/L  | P435493  |          |
|           |             | Malathion             | 0.37   | U    | ng/L  | P435493  |          |
|           |             | Metalaxyl             | 0.53   | U    | ng/L  | P435493  |          |
|           |             | Metolachlor           | 0.79   | U    | ng/L  | P435493  |          |
|           |             | Metribuzin            | 0.42   | UJ   | ng/L  | P435493  | LCS      |
|           |             | Mevinphos             | 1.1    | U    | ng/L  | P435493  |          |
|           |             | Molinate              | 0.26   | U    | ng/L  | P435493  |          |
|           |             | Myclobutanil          | 0.37   | U    | ng/L  | P435493  |          |
|           |             | Naled                 | 2.6    | U    | ng/L  | P435493  |          |
|           |             | Napropamide           | 0.74   | U    | ng/L  | P435493  |          |
|           |             | Norflurazon           | 1.1    | U    | ng/L  | P435493  |          |
|           |             | Oxadiazon             | 0.37   | U    | ng/L  | P435493  |          |
|           |             | Oxyfluorfen           | 0.21   | U    | ng/L  | P435493  |          |
|           |             | Parathion Ethyl       | 0.16   | U    | ng/L  | P435493  |          |
|           |             | Parathion Methyl      | 0.21   | U    | ng/L  | P435493  |          |
|           |             | Pendimethalin         | 0.79   | U    | ng/L  | P435493  |          |
|           |             | Phenytol**            | 5.6    | U    | ng/L  | P435493  |          |
|           |             | Phorate               | 0.26   | U    | ng/L  | P435493  |          |
|           |             | Prodiamine            | 0.21   | U    | ng/L  | P435493  |          |
|           |             | Prometon              | 3.2    | U    | ng/L  | P435493  |          |
|           |             | Prometryn             | 0.37   | U    | ng/L  | P435493  |          |
|           |             | Pronamide             | 0.11   | U    | ng/L  | P435493  |          |
|           |             | Propanil              | 0.11   | U    | ng/L  | P435493  |          |
|           |             | Propargite            | 0.85   | U    | ng/L  | P435493  |          |
|           |             | Propiconazole         | 0.64   | U    | ng/L  | P435493  |          |

Field ID: FB\_09262023

Matrix: W-FIELD-BK

| Sample ID | Ref. Method | Component        | Result | Code | Units | Batch ID | QC Codes |
|-----------|-------------|------------------|--------|------|-------|----------|----------|
| 2440573   | EPA 8270E   | Pyraflufen Ethyl | 0.32   | U    | ng/L  | P435493  | CCV      |
|           |             | Pyridaben        | 1.5    | U    | ng/L  | P435493  |          |
|           |             | Pyriproxyfen     | 0.26   | UJ   | ng/L  | P435493  |          |
|           |             | Simazine         | 0.26   | U    | ng/L  | P435493  |          |
|           |             | Stirophos        | 0.42   | U    | ng/L  | P435493  |          |
|           |             | Sulfentrazone    | 1.5    | U    | ng/L  | P435493  |          |
|           |             | Tebuconazole     | 1.5    | U    | ng/L  | P435493  |          |
|           |             | Terbufos         | 0.21   | U    | ng/L  | P435493  |          |
|           |             | Terbuthylazine   | 0.21   | U    | ng/L  | P435493  |          |
|           |             | Thiobencarb      | 0.53   | U    | ng/L  | P435493  |          |
|           |             | Triadimefon      | 0.16   | U    | ng/L  | P435493  |          |

Ref. Method and Comment:  
EPA 8270E: MS accuracy for atrazine not assessed due to high content of this parameter in the sample spiked. Refer to the Lab Analysis Report for an explanation of QC Codes.

## Quality Assurance Report Method Blank Results

Reference Method: DEP SOP: NU-094-1  
Batch ID: P435606

| Component    | Result | Code | Units |
|--------------|--------|------|-------|
| Color (true) | 2.5    | U    | PCU   |

Reference Method: DEP SOP: NU-094-1  
Batch ID: P435608

| Component    | Result | Code | Units |
|--------------|--------|------|-------|
| Color (true) | 2.5    | U    | PCU   |

Reference Method: EPA 180.1 Rev. 2.0  
Batch ID: P435617

| Component | Result | Code | Units |
|-----------|--------|------|-------|
| Turbidity | 0.10   | U    | NTU   |

Reference Method: EPA 200.7 Rev. 4.4  
Batch ID: P435682

| Component | Result | Code | Units |
|-----------|--------|------|-------|
| Calcium   | 0.075  | U    | mg/L  |
| Iron      | 30     | U    | ug/L  |
| Magnesium | 0.040  | U    | mg/L  |
| Potassium | 0.30   | U    | mg/L  |
| Sodium    | 0.50   | U    | mg/L  |
| Strontium | 2.0    | U    | ug/L  |
| Tin       | 3.0    | U    | ug/L  |
| Titanium  | 0.75   | U    | ug/L  |
| Vanadium  | 2.0    | U    | ug/L  |
| Zinc      | 5.0    | U    | ug/L  |

Reference Method: EPA 200.8 Rev. 5.4  
Batch ID: P435682

| Component  | Result | Code | Units |
|------------|--------|------|-------|
| Aluminum   | 5.0    | U    | ug/L  |
| Antimony   | 0.050  | U    | ug/L  |
| Arsenic    | 0.050  | U    | ug/L  |
| Barium     | 0.20   | U    | ug/L  |
| Beryllium  | 0.010  | U    | ug/L  |
| Boron      | 2.0    | U    | ug/L  |
| Cadmium    | 0.020  | U    | ug/L  |
| Chromium   | 0.40   | U    | ug/L  |
| Cobalt     | 0.020  | U    | ug/L  |
| Copper     | 0.40   | U    | ug/L  |
| Lead       | 0.20   | U    | ug/L  |
| Manganese  | 0.12   | I    | ug/L  |
| Molybdenum | 0.15   | U    | ug/L  |
| Nickel     | 0.50   | U    | ug/L  |
| Selenium   | 0.20   | U    | ug/L  |
| Silver     | 0.012  | I    | ug/L  |
| Thallium   | 0.10   | U    | ug/L  |

## Quality Assurance Report Method Blank Results

Reference Method: EPA 300.0 Rev. 2.1  
Batch ID: P436046

| Component | Result | Code | Units   |
|-----------|--------|------|---------|
| Chloride  | 0.20   | U    | mg Cl/L |

Reference Method: EPA 300.0 Rev. 2.1  
Batch ID: P436049

| Component | Result | Code | Units    |
|-----------|--------|------|----------|
| Sulfate   | 0.20   | U    | mg SO4/L |

Reference Method: EPA 350.1 Rev. 2.0  
Batch ID: P435750

| Component | Result | Code | Units  |
|-----------|--------|------|--------|
| Ammonia-N | 0.002  | U    | mg N/L |

Reference Method: EPA 350.1 Rev. 2.0  
Batch ID: P435811

| Component | Result | Code | Units  |
|-----------|--------|------|--------|
| Ammonia-N | 0.002  | U    | mg N/L |

Reference Method: EPA 351.2 Rev. 2.0  
Batch ID: P435772

| Component         | Result | Code | Units  |
|-------------------|--------|------|--------|
| Kjeldahl Nitrogen | 0.080  | U    | mg N/L |

Reference Method: EPA 351.2 Rev. 2.0  
Batch ID: P435773

| Component         | Result | Code | Units  |
|-------------------|--------|------|--------|
| Kjeldahl Nitrogen | 0.080  | U    | mg N/L |

Reference Method: EPA 353.2 Rev. 2.0  
Batch ID: P436140

| Component | Result | Code | Units  |
|-----------|--------|------|--------|
| NO2NO3-N  | 0.004  | U    | mg N/L |

Reference Method: EPA 353.2 Rev. 2.0  
Batch ID: P436205

| Component | Result | Code | Units  |
|-----------|--------|------|--------|
| NO2NO3-N  | 0.004  | U    | mg N/L |

Reference Method: EPA 353.2 Rev. 2.0  
Batch ID: P436261

| Component | Result | Code | Units  |
|-----------|--------|------|--------|
| NO2NO3-N  | 0.004  | U    | mg N/L |

## Quality Assurance Report Method Blank Results

Reference Method: EPA 365.1 Rev. 2.0  
Batch ID: P435709

| Component | Result | Code | Units  |
|-----------|--------|------|--------|
| Total-P   | 0.002  | U    | mg P/L |

Reference Method: EPA 365.1 Rev. 2.0  
Batch ID: P435710

| Component | Result | Code | Units  |
|-----------|--------|------|--------|
| Total-P   | 0.002  | U    | mg P/L |

Reference Method: EPA 8270E  
Batch ID: P435493

| Component                                                | Result | Code | Units |
|----------------------------------------------------------|--------|------|-------|
| 2-(2H-benzotriazol-2-yl)-4,6-ditertpentylphenol (UV-328) | 60     | U    | ng/L  |
| 2-Ethylhexyl 2,3,4,5-tetrabromobenzoate (EHTBB)          | 12     | U    | ng/L  |
| Acetochlor                                               | 0.20   | U    | ng/L  |
| Alachlor                                                 | 0.40   | U    | ng/L  |
| Ametryn                                                  | 1.1    | U    | ng/L  |
| Atrazine                                                 | 0.20   | U    | ng/L  |
| Atrazine Desethyl                                        | 1.3    | U    | ng/L  |
| Avobenzone                                               | 100    | U    | ng/L  |
| Azinphos Methyl                                          | 3.0    | U    | ng/L  |
| Azoxystrobin                                             | 0.40   | U    | ng/L  |
| Bromacil                                                 | 0.60   | U    | ng/L  |
| Butylate                                                 | 0.20   | U    | ng/L  |
| Caffeine                                                 | 7.5    | U    | ng/L  |
| Carbophenothion                                          | 0.50   | U    | ng/L  |
| Carfentrazone Ethyl                                      | 0.15   | U    | ng/L  |
| Chlorfenapyr                                             | 0.30   | U    | ng/L  |
| Chlorpyrifos Ethyl                                       | 0.30   | U    | ng/L  |
| Chlorpyrifos Methyl                                      | 0.10   | U    | ng/L  |
| Coumaphos                                                | 1.0    | U    | ng/L  |
| Cyanazine                                                | 5.0    | U    | ng/L  |
| Cyprodinil                                               | 0.20   | U    | ng/L  |
| Dechlorane 602                                           | 5.0    | U    | ng/L  |
| Dechlorane 603                                           | 4.0    | U    | ng/L  |
| Dechlorane Plus                                          | 30     | U    | ng/L  |
| Demeton                                                  | 3.5    | U    | ng/L  |
| Diazinon                                                 | 0.12   | U    | ng/L  |
| Difenoconazole                                           | 0.60   | U    | ng/L  |
| Dimethenamid                                             | 0.10   | U    | ng/L  |
| Dimethomorph                                             | 0.30   | U    | ng/L  |
| Disulfoton                                               | 0.60   | U    | ng/L  |
| Dithiopyr                                                | 1.0    | U    | ng/L  |
| EPTC                                                     | 0.50   | U    | ng/L  |
| Ethion                                                   | 0.30   | U    | ng/L  |
| Ethoprop                                                 | 0.12   | U    | ng/L  |
| Etridiazole                                              | 0.10   | U    | ng/L  |
| Fenamiphos                                               | 0.45   | U    | ng/L  |
| Fenbuconazole                                            | 0.50   | U    | ng/L  |
| Fipronil                                                 | 0.20   | U    | ng/L  |
| Fipronil Desulfinyl                                      | 0.10   | U    | ng/L  |
| Fipronil Sulfide                                         | 0.10   | U    | ng/L  |

## Quality Assurance Report

### Method Blank Results

Reference Method: EPA 8270E

Batch ID: P435493

| Component                   | Result | Code | Units |
|-----------------------------|--------|------|-------|
| Fipronil Sulfone            | 0.10   | U    | ng/L  |
| Fluazifop-P-butyl           | 0.10   | U    | ng/L  |
| Fludioxonil                 | 0.10   | U    | ng/L  |
| Flumioxazin                 | 3.0    | U    | ng/L  |
| Flutolanil                  | 0.10   | U    | ng/L  |
| Fluxapyroxad                | 0.25   | U    | ng/L  |
| Fonofos                     | 0.15   | U    | ng/L  |
| Hexabromobenzene            | 6.0    | U    | ng/L  |
| Hexazinone                  | 0.50   | U    | ng/L  |
| Imazalil                    | 0.65   | U    | ng/L  |
| Iprodione                   | 0.50   | U    | ng/L  |
| Loratadine                  | 0.30   | U    | ng/L  |
| Malathion                   | 0.35   | U    | ng/L  |
| Metalaxyl                   | 0.50   | U    | ng/L  |
| Metolachlor                 | 0.75   | U    | ng/L  |
| Metribuzin                  | 0.40   | U    | ng/L  |
| Mevinphos                   | 1.0    | U    | ng/L  |
| Molinate                    | 0.25   | U    | ng/L  |
| Myclobutanil                | 0.35   | U    | ng/L  |
| Naled                       | 2.5    | U    | ng/L  |
| Napropamide                 | 0.70   | U    | ng/L  |
| Norflurazon                 | 1.0    | U    | ng/L  |
| Octinoxate                  | 150    | U    | ng/L  |
| Oxadiazon                   | 0.35   | U    | ng/L  |
| Oxybenzone                  | 10     | U    | ng/L  |
| Oxyfluorfen                 | 0.20   | U    | ng/L  |
| Parathion Ethyl             | 0.15   | U    | ng/L  |
| Parathion Methyl            | 0.20   | U    | ng/L  |
| PBB-153                     | 8.0    | U    | ng/L  |
| PBDE-47                     | 4.0    | U    | ng/L  |
| PBDE-99                     | 5.0    | U    | ng/L  |
| Pendimethalin               | 0.75   | U    | ng/L  |
| Pentabromotoluene           | 3.0    | U    | ng/L  |
| Phenytol                    | 5.3    | U    | ng/L  |
| Phorate                     | 0.25   | U    | ng/L  |
| Prodiamine                  | 0.20   | U    | ng/L  |
| Prometon                    | 3.0    | U    | ng/L  |
| Prometryn                   | 0.35   | U    | ng/L  |
| Pronamide                   | 0.10   | U    | ng/L  |
| Propanil                    | 0.10   | U    | ng/L  |
| Propargite                  | 0.80   | U    | ng/L  |
| Propiconazole               | 0.60   | U    | ng/L  |
| Pyraflufen Ethyl            | 0.30   | U    | ng/L  |
| Pyridaben                   | 1.4    | U    | ng/L  |
| Pyriproxyfen                | 0.25   | U    | ng/L  |
| Simazine                    | 0.25   | U    | ng/L  |
| Stirophos                   | 0.40   | U    | ng/L  |
| Sulfentrazone               | 1.4    | U    | ng/L  |
| Tebuconazole                | 1.4    | U    | ng/L  |
| Terbufos                    | 0.20   | U    | ng/L  |
| Terbutylazine               | 0.20   | U    | ng/L  |
| Tetradecachloro-m-terphenyl | 7.5    | U    | ng/L  |

## Quality Assurance Report Method Blank Results

Reference Method: EPA 8270E

Batch ID: P435493

| Component                                     | Result | Code | Units |
|-----------------------------------------------|--------|------|-------|
| Thiobencarb                                   | 0.50   | U    | ng/L  |
| Tri-o-cresyl Phosphate                        | 6.0    | U    | ng/L  |
| Triadimefon                                   | 0.15   | U    | ng/L  |
| Tris(1-chloro-2-propyl) phosphate (TCPP)      | 15     | U    | ng/L  |
| Tris(1,3-dichloro-2-propyl) phosphate (TDCPP) | 2.5    | U    | ng/L  |
| Tris(2-chloroethyl) phosphate (TCEP)          | 70     | U    | ng/L  |

Reference Method: EPA 8270E

Batch ID: P435653

| Component          | Result | Code | Units |
|--------------------|--------|------|-------|
| Aldrin             | 0.65   | U    | ng/L  |
| Alpha-BHC          | 0.10   | U    | ng/L  |
| Alpha-Chlordane    | 0.20   | U    | ng/L  |
| Beta-BHC           | 0.10   | U    | ng/L  |
| Beta-Cyfluthrin    | 1.2    | U    | ng/L  |
| Bifenthrin         | 0.50   | U    | ng/L  |
| Chlorothalonil     | 3.6    | U    | ng/L  |
| Cis-Nonachlor      | 0.20   | U    | ng/L  |
| Cypermethrin       | 1.5    | U    | ng/L  |
| Dacthal            | 0.15   | U    | ng/L  |
| DDD-p,p'           | 0.25   | U    | ng/L  |
| DDE-p,p'           | 0.20   | U    | ng/L  |
| DDT-p,p'           | 0.80   | U    | ng/L  |
| Delta-BHC          | 0.40   | U    | ng/L  |
| Deltamethrin       | 1.2    | U    | ng/L  |
| Dichlobenil        | 0.25   | U    | ng/L  |
| Dicofol            | 1.2    | U    | ng/L  |
| Dieldrin           | 0.40   | U    | ng/L  |
| Endosulfan I       | 0.40   | U    | ng/L  |
| Endosulfan II      | 0.90   | U    | ng/L  |
| Endosulfan Sulfate | 0.30   | U    | ng/L  |
| Endrin             | 0.90   | U    | ng/L  |
| Endrin Aldehyde    | 0.75   | U    | ng/L  |
| Endrin Ketone      | 0.40   | U    | ng/L  |
| Esfenvalerate      | 0.75   | U    | ng/L  |
| Ethalfuralin       | 0.15   | U    | ng/L  |
| Fenpropathrin      | 0.25   | U    | ng/L  |
| Gamma-BHC          | 0.12   | U    | ng/L  |
| Gamma-Chlordane    | 0.20   | U    | ng/L  |
| Heptachlor         | 0.20   | U    | ng/L  |
| Heptachlor Epoxide | 0.25   | U    | ng/L  |
| Hexachlorobenzene  | 1.0    | U    | ng/L  |
| Kepone             | 14     | U    | ng/L  |
| Lambda-Cyhalothrin | 0.75   | U    | ng/L  |
| Methoprene         | 0.75   | U    | ng/L  |
| Methoxychlor       | 0.30   | U    | ng/L  |
| MGK-264            | 0.20   | U    | ng/L  |
| Mirex              | 0.35   | U    | ng/L  |
| Oxychlordane       | 0.30   | U    | ng/L  |
| PCB-1016           | 2.0    | U    | ng/L  |
| PCB-1221           | 2.0    | U    | ng/L  |

## Quality Assurance Report

### Method Blank Results

Reference Method: EPA 8270E

Batch ID: P435653

| Component          | Result | Code | Units |
|--------------------|--------|------|-------|
| PCB-1232           | 2.0    | U    | ng/L  |
| PCB-1242           | 2.0    | U    | ng/L  |
| PCB-1248           | 2.0    | U    | ng/L  |
| PCB-1254           | 2.0    | U    | ng/L  |
| PCB-1260           | 2.0    | U    | ng/L  |
| Permethrin         | 1.6    | U    | ng/L  |
| Phenothrin         | 0.90   | U    | ng/L  |
| Piperonyl Butoxide | 0.15   | U    | ng/L  |
| Prallethrin        | 2.0    | U    | ng/L  |
| Tau-Fluvalinate    | 0.25   | U    | ng/L  |
| Tetramethrin       | 0.75   | U    | ng/L  |
| Trans-Nonachlor    | 0.20   | U    | ng/L  |
| Triclosan Methyl   | 0.15   | U    | ng/L  |
| Trifluralin        | 0.20   | U    | ng/L  |

Reference Method: EPA 8276

Batch ID: P435653

| Component | Result | Code | Units |
|-----------|--------|------|-------|
| Chlordane | 2.0    | U    | ng/L  |
| Toxaphene | 15     | U    | ng/L  |

Reference Method: EPA 8321B

Batch ID: P435381

| Component           | Result | Code | Units |
|---------------------|--------|------|-------|
| 3-Hydroxycarbofuran | 0.0020 | U    | ug/L  |
| Aldicarb            | 0.020  | U    | ug/L  |
| Aldicarb Sulfone    | 0.0020 | U    | ug/L  |
| Aldicarb Sulfoxide  | 0.0020 | U    | ug/L  |
| Carbaryl            | 0.0020 | U    | ug/L  |
| Carbofuran          | 0.0020 | U    | ug/L  |
| Methiocarb          | 0.0020 | U    | ug/L  |
| Methomyl            | 0.0020 | U    | ug/L  |
| Oxamyl              | 0.0020 | U    | ug/L  |
| Propoxur            | 0.0020 | U    | ug/L  |

Reference Method: EPA 8321B

Batch ID: P435496

| Component    | Result | Code | Units |
|--------------|--------|------|-------|
| Acesulfame K | 0.10   | U    | ug/L  |
| AMPA         | 0.10   | U    | ug/L  |
| Endothall    | 0.25   | U    | ug/L  |
| Glufosinate  | 0.10   | U    | ug/L  |
| Glyphosate   | 0.10   | U    | ug/L  |
| Sucralose    | 0.010  | U    | ug/L  |

Reference Method: EPA 8321B

Batch ID: P435567

| Component | Result | Code | Units |
|-----------|--------|------|-------|
|-----------|--------|------|-------|

## Quality Assurance Report Method Blank Results

Reference Method: EPA 8321B  
Batch ID: P435567

| Component        | Result  | Code | Units |
|------------------|---------|------|-------|
| 2,4-D            | 0.020   |      | ug/L  |
| 2,4,5-T          | 0.0040  | U    | ug/L  |
| Acetaminophen    | 0.0080  | U    | ug/L  |
| Acetamiprid      | 0.0020  | U    | ug/L  |
| Afidopyropen     | 0.0020  | U    | ug/L  |
| Bentazon         | 8.0E-04 | U    | ug/L  |
| Benzovindiflupyr | 0.0020  | U    | ug/L  |
| Carbamazepine    | 8.0E-04 | U    | ug/L  |
| Clothianidin     | 0.0020  | U    | ug/L  |
| Dinotefuran      | 0.0020  | U    | ug/L  |
| Diuron           | 0.0020  | U    | ug/L  |
| Fenuron          | 0.032   | U    | ug/L  |
| Fluridone        | 8.0E-04 | U    | ug/L  |
| Hydrocodone      | 0.0020  | U    | ug/L  |
| Ibuprofen        | 0.080   | U    | ug/L  |
| Imazapyr         | 0.0040  | U    | ug/L  |
| Imidacloprid     | 0.0020  | U    | ug/L  |
| Linuron          | 0.0040  | U    | ug/L  |
| Mandestrobin     | 0.0020  | U    | ug/L  |
| MCPP             | 0.0020  | U    | ug/L  |
| Naproxen         | 0.0080  | U    | ug/L  |
| Primidone        | 0.0040  | U    | ug/L  |
| Pyraclostrobin   | 0.0020  | U    | ug/L  |
| Silvex           | 0.0040  | U    | ug/L  |
| Thiamethoxam     | 0.0020  | U    | ug/L  |
| Tolfenpyrad      | 0.0020  | U    | ug/L  |
| Triclopyr        | 0.0040  | U    | ug/L  |

Reference Method: SM 2320 B-2011  
Batch ID: P435768

| Component        | Result | Code | Units      |
|------------------|--------|------|------------|
| Total Alkalinity | 0.65   | U    | mg CaCO3/L |

Reference Method: SM 2320 B-2011  
Batch ID: P435872

| Component        | Result | Code | Units      |
|------------------|--------|------|------------|
| Total Alkalinity | 0.65   | U    | mg CaCO3/L |

Reference Method: SM 2540 C-2015  
Batch ID: P436283

| Component | Result | Code | Units |
|-----------|--------|------|-------|
| TDS       | 15     | U    | mg/L  |

Reference Method: SM 2540 C-2015  
Batch ID: P436285

| Component | Result | Code | Units |
|-----------|--------|------|-------|
| TDS       | 15     | U    | mg/L  |

## Quality Assurance Report

### Method Blank Results

Reference Method: SM 2540 D-2015  
Batch ID: P436015

| Component | Result | Code | Units |
|-----------|--------|------|-------|
| TSS       | 2      | U    | mg/L  |

Reference Method: SM 2540 D-2015  
Batch ID: P436019

| Component | Result | Code | Units |
|-----------|--------|------|-------|
| TSS       | 3      | U    | mg/L  |

Reference Method: SM 4500-F- C-2011  
Batch ID: P435770

| Component | Result | Code | Units  |
|-----------|--------|------|--------|
| Fluoride  | 0.025  | U    | mg F/L |

Reference Method: SM 4500-F- C-2011  
Batch ID: P435874

| Component | Result | Code | Units  |
|-----------|--------|------|--------|
| Fluoride  | 0.025  | U    | mg F/L |

Reference Method: SM 4500-F- C-2011  
Batch ID: P436026

| Component | Result | Code | Units  |
|-----------|--------|------|--------|
| Fluoride  | 0.025  | U    | mg F/L |

Reference Method: SM 5310 B-2011  
Batch ID: P435847

| Component      | Result | Code | Units  |
|----------------|--------|------|--------|
| Organic Carbon | 0.50   | U    | mg C/L |

Reference Method: SM 5310 B-2011  
Batch ID: P436004

| Component      | Result | Code | Units  |
|----------------|--------|------|--------|
| Organic Carbon | 0.50   | U    | mg C/L |

## Quality Assurance Report

### Laboratory Control Sample Accuracy

Reference Method: DEP SOP: NU-094-1  
Batch ID: P435606

| Component    | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|--------------|---------|---------|-----------|----------------|
| Color (true) | 98.8    |         | P         | 90 - 110       |

Reference Method: DEP SOP: NU-094-1  
Batch ID: P435608

| Component    | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|--------------|---------|---------|-----------|----------------|
| Color (true) | 98.9    |         | P         | 90 - 110       |

Reference Method: EPA 180.1 Rev. 2.0  
Batch ID: P435617

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Turbidity | 105     |         | P         | 90 - 110       |

Reference Method: EPA 200.7 Rev. 4.4  
Batch ID: P435682

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Calcium   | 102     |         | P         | 85 - 115       |
| Iron      | 103     |         | P         | 85 - 115       |
| Magnesium | 105     |         | P         | 85 - 115       |
| Potassium | 101     |         | P         | 85 - 115       |
| Sodium    | 100     |         | P         | 85 - 115       |
| Strontium | 99.6    |         | P         | 85 - 115       |
| Tin       | 106     |         | P         | 85 - 115       |
| Titanium  | 102     |         | P         | 85 - 115       |
| Vanadium  | 102     |         | P         | 85 - 115       |
| Zinc      | 104     |         | P         | 85 - 115       |

Reference Method: EPA 200.8 Rev. 5.4  
Batch ID: P435682

| Component  | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|------------|---------|---------|-----------|----------------|
| Aluminum   | 97.9    |         | P         | 85 - 115       |
| Antimony   | 94.0    |         | P         | 85 - 115       |
| Arsenic    | 98.7    |         | P         | 85 - 115       |
| Barium     | 98.3    |         | P         | 85 - 115       |
| Beryllium  | 95.3    |         | P         | 85 - 115       |
| Boron      | 102     |         | P         | 85 - 115       |
| Cadmium    | 96.3    |         | P         | 85 - 115       |
| Chromium   | 94.2    |         | P         | 85 - 115       |
| Cobalt     | 98.4    |         | P         | 85 - 115       |
| Copper     | 96.4    |         | P         | 85 - 115       |
| Lead       | 90.8    |         | P         | 85 - 115       |
| Manganese  | 94.1    |         | P         | 85 - 115       |
| Molybdenum | 96.2    |         | P         | 85 - 115       |
| Nickel     | 97.9    |         | P         | 85 - 115       |
| Selenium   | 95.6    |         | P         | 85 - 115       |
| Silver     | 107     |         | P         | 85 - 115       |
| Thallium   | 99.0    |         | P         | 85 - 115       |

## Quality Assurance Report Laboratory Control Sample Accuracy

Reference Method: EPA 300.0 Rev. 2.1  
Batch ID: P436046

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Chloride  | 105     |         | P         | 90 - 110       |

Reference Method: EPA 300.0 Rev. 2.1  
Batch ID: P436049

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Sulfate   | 107     |         | P         | 90 - 110       |

Reference Method: EPA 350.1 Rev. 2.0  
Batch ID: P435750

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Ammonia-N | 103     |         | P         | 90 - 110       |

Reference Method: EPA 350.1 Rev. 2.0  
Batch ID: P435811

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Ammonia-N | 103     |         | P         | 90 - 110       |

Reference Method: EPA 351.2 Rev. 2.0  
Batch ID: P435772

| Component         | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-------------------|---------|---------|-----------|----------------|
| Kjeldahl Nitrogen | 101     |         | P         | 90 - 110       |

Reference Method: EPA 351.2 Rev. 2.0  
Batch ID: P435773

| Component         | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-------------------|---------|---------|-----------|----------------|
| Kjeldahl Nitrogen | 95.7    |         | P         | 90 - 110       |

Reference Method: EPA 353.2 Rev. 2.0  
Batch ID: P436140

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| NO2NO3-N  | 98.0    |         | P         | 90 - 110       |

Reference Method: EPA 353.2 Rev. 2.0  
Batch ID: P436205

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| NO2NO3-N  | 98.5    |         | P         | 90 - 110       |

Reference Method: EPA 353.2 Rev. 2.0  
Batch ID: P436261

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| NO2NO3-N  | 97.5    |         | P         | 90 - 110       |

## Quality Assurance Report Laboratory Control Sample Accuracy

Reference Method: EPA 365.1 Rev. 2.0

Batch ID: P435709

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Total-P   | 98.9    |         | P         | 90 - 110       |

Reference Method: EPA 365.1 Rev. 2.0

Batch ID: P435710

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Total-P   | 101     |         | P         | 90 - 110       |

Reference Method: EPA 8270E

Batch ID: P435493

| Component                                                | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|----------------------------------------------------------|---------|---------|-----------|----------------|
| 2-(2H-benzotriazol-2-yl)-4,6-ditertpentylphenol (UV-328) | 63.8    |         | P         | 50 - 150       |
| 2-Ethylhexyl 2,3,4,5-tetrabromobenzoate (EHTBB)          | 98.6    |         | P         | 42 - 162       |
| Acetochlor                                               | 89.0    |         | P         | 69 - 123       |
| Alachlor                                                 | 73.8    |         | P         | 65 - 118       |
| Ametryn                                                  | 124     |         | P         | 58 - 141       |
| Atrazine                                                 | 86.0    |         | P         | 73 - 118       |
| Atrazine Desethyl                                        | 81.7    |         | P         | 32 - 125       |
| Avobenzone                                               | 101     |         | P         | 40 - 203       |
| Azinphos Methyl                                          | 95.0    |         | P         | 36 - 197       |
| Azoxystrobin                                             | 94.1    |         | P         | 58 - 226       |
| Bromacil                                                 | 92.9    |         | P         | 48 - 120       |
| Butylate                                                 | 59.5    |         | P         | 27 - 85.0      |
| Caffeine                                                 | 96.9    |         | P         | 40 - 137       |
| Carbophenothion                                          | 93.6    |         | P         | 54 - 132       |
| Carfentrazone Ethyl                                      | 103     |         | P         | 60 - 142       |
| Chlorfenapyr                                             | 55.8    |         | P         | 53 - 117       |
| Chlorpyrifos Ethyl                                       | 99.4    |         | P         | 59 - 116       |
| Chlorpyrifos Methyl                                      | 91.4    |         | P         | 66 - 119       |
| Coumaphos                                                | 83.6    |         | P         | 11 - 234       |
| Cyanazine                                                | 145     |         | P         | 61 - 248       |
| Cyprodinil                                               | 87.6    |         | P         | 50 - 147       |
| Dechlorane 602                                           | 68.4    |         | P         | 50 - 150       |
| Dechlorane 603                                           | 110     |         | P         | 50 - 150       |
| Dechlorane Plus                                          | 109     |         | P         | 47 - 182       |
| Demeton                                                  | 69.5    |         | P         | 30 - 138       |
| Diazinon                                                 | 108     |         | P         | 67 - 126       |
| Difenoconazole                                           | 63.0    |         | P         | 38 - 205       |
| Dimethenamid                                             | 76.2    |         | P         | 57 - 111       |
| Dimethomorph                                             | 183     |         | P         | 16 - 212       |
| Disulfoton                                               | 96.2    |         | P         | 46 - 126       |
| Dithiopyr                                                | 107     |         | P         | 62 - 115       |
| EPTC                                                     | 63.0    |         | P         | 28 - 80.0      |
| Ethion                                                   | 39.1    |         | P         | 24 - 122       |
| Ethoprop                                                 | 83.8    |         | P         | 62 - 113       |
| Etridiazole                                              | 64.1    |         | P         | 28 - 92.0      |
| Fenamiphos                                               | 74.1    |         | P         | 57 - 128       |
| Fenbuconazole                                            | 58.2    |         | P         | 52 - 155       |
| Fipronil                                                 | 92.9    |         | P         | 63 - 130       |
| Fipronil Desulfinyl                                      | 96.2    |         | P         | 61 - 130       |
| Fipronil Sulfide                                         | 79.0    |         | P         | 56 - 117       |

## Quality Assurance Report

### Laboratory Control Sample Accuracy

Reference Method: EPA 8270E

Batch ID: P435493

| Component                   | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------------------------|---------|---------|-----------|----------------|
| Fipronil Sulfone            | 67.1    |         | P         | 52 - 118       |
| Fluazifop-P-butyl           | 68.3    |         | P         | 61 - 128       |
| Fludioxonil                 | 62.9    |         | P         | 59 - 129       |
| Flumioxazin                 | 96.8    |         | P         | 30 - 250       |
| Flutolanil                  | 66.0    |         | P         | 53 - 127       |
| Fluxapyroxad                | 73.2    |         | P         | 42 - 132       |
| Fonofos                     | 89.8    |         | P         | 61 - 110       |
| Hexabromobenzene            | 99.8    |         | P         | 50 - 150       |
| Hexazinone                  | 81.8    |         | P         | 46 - 139       |
| Imazalil                    | 89.0    |         | P         | 40 - 139       |
| Iprodione                   | 54.0    |         | P         | 40 - 146       |
| Loratadine                  | 124     |         | P         | 10 - 224       |
| Malathion                   | 104     |         | P         | 61 - 135       |
| Metalaxyl                   | 88.0    |         | P         | 58 - 121       |
| Metolachlor                 | 99.1    |         | P         | 64 - 118       |
| Metribuzin                  | 41.7    |         | F         | 45 - 245       |
| Mevinphos                   | 72.7    |         | P         | 49 - 118       |
| Molinate                    | 58.8    |         | P         | 42 - 92.0      |
| Myclobutanil                | 67.1    |         | P         | 55 - 127       |
| Naled                       | 43.0    |         | P         | 10 - 114       |
| Napropamide                 | 81.2    |         | P         | 39 - 121       |
| Norflurazon                 | 76.5    |         | P         | 55 - 129       |
| Octinoxate                  | 102     |         | P         | 26 - 166       |
| Oxadiazon                   | 72.4    |         | P         | 54 - 115       |
| Oxybenzone                  | 107     |         | P         | 49 - 135       |
| Oxyfluorfen                 | 77.5    |         | P         | 64 - 139       |
| Parathion Ethyl             | 89.6    |         | P         | 70 - 111       |
| Parathion Methyl            | 99.1    |         | P         | 76 - 136       |
| PBB-153                     | 106     |         | P         | 50 - 150       |
| PBDE-47                     | 89.0    |         | P         | 41 - 148       |
| PBDE-99                     | 76.5    |         | P         | 38 - 147       |
| Pendimethalin               | 74.2    |         | P         | 52 - 118       |
| Pentabromotoluene           | 96.5    |         | P         | 50 - 150       |
| Phenytoin                   | 28.0    |         | P         | 10 - 162       |
| Phorate                     | 97.4    |         | P         | 40 - 122       |
| Prodiamine                  | 48.9    |         | P         | 26 - 141       |
| Prometon                    | 106     |         | P         | 54 - 122       |
| Prometryn                   | 99.6    |         | P         | 61 - 128       |
| Pronamide                   | 101     |         | P         | 72 - 121       |
| Propanil                    | 93.8    |         | P         | 45 - 144       |
| Propargite                  | 59.9    |         | P         | 10 - 199       |
| Propiconazole               | 72.9    |         | P         | 56 - 127       |
| Pyraflufen Ethyl            | 89.9    |         | P         | 56 - 140       |
| Pyridaben                   | 86.9    |         | P         | 26 - 211       |
| Pyriproxyfen                | 125     |         | P         | 33 - 194       |
| Simazine                    | 82.1    |         | P         | 67 - 121       |
| Stirophos                   | 46.6    |         | P         | 20 - 142       |
| Sulfentrazone               | 39.8    |         | P         | 21 - 144       |
| Tebuconazole                | 47.6    |         | P         | 10 - 122       |
| Terbufos                    | 110     |         | P         | 60 - 129       |
| Terbutylazine               | 82.6    |         | P         | 69 - 113       |
| Tetradecachloro-m-terphenyl | 126     |         | P         | 70 - 200       |

## Quality Assurance Report Laboratory Control Sample Accuracy

Reference Method: EPA 8270E

Batch ID: P435493

| Component                                     | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------------------------------------------|---------|---------|-----------|----------------|
| Thiobencarb                                   | 90.2    |         | P         | 51 - 120       |
| Tri-o-cresyl Phosphate                        | 101     |         | P         | 49 - 150       |
| Triadimefon                                   | 85.4    |         | P         | 56 - 114       |
| Tris(1-chloro-2-propyl) phosphate (TCPP)      | 106     |         | P         | 50 - 150       |
| Tris(1,3-dichloro-2-propyl) phosphate (TDCPP) | 97.4    |         | P         | 50 - 150       |
| Tris(2-chloroethyl) phosphate (TCEP)          | 108     |         | P         | 70 - 180       |

Reference Method: EPA 8270E

Batch ID: P435653

| Component          | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|--------------------|---------|---------|-----------|----------------|
| Aldrin             | 52.2    |         | P         | 30 - 96.0      |
| Alpha-BHC          | 77.4    |         | P         | 70 - 109       |
| Alpha-Chlordane    | 88.3    |         | P         | 45 - 107       |
| Beta-BHC           | 73.8    |         | P         | 64 - 138       |
| Beta-Cyfluthrin    | 77.8    |         | P         | 17 - 141       |
| Bifenthrin         | 54.3    |         | P         | 10 - 113       |
| Chlorothalonil     | 107     |         | P         | 26 - 180       |
| Cis-Nonachlor      | 70.4    |         | P         | 37 - 102       |
| Cypermethrin       | 69.5    |         | P         | 20 - 133       |
| Dacthal            | 99.0    |         | P         | 69 - 114       |
| DDD-p,p'           | 61.9    |         | P         | 42 - 105       |
| DDE-p,p'           | 68.2    |         | P         | 42 - 106       |
| DDT-p,p'           | 56.4    |         | P         | 42 - 107       |
| Delta-BHC          | 103     |         | P         | 67 - 144       |
| Deltamethrin       | 76.9    |         | P         | 15 - 149       |
| Dichlobenil        | 74.7    |         | P         | 46 - 117       |
| Dicofol            | 67.4    |         | P         | 34 - 114       |
| Dieldrin           | 74.6    |         | P         | 50 - 108       |
| Endosulfan I       | 76.2    |         | P         | 55 - 104       |
| Endosulfan II      | 93.6    |         | P         | 51 - 111       |
| Endosulfan Sulfate | 83.1    |         | P         | 56 - 121       |
| Endrin             | 77.6    |         | P         | 10 - 106       |
| Endrin Aldehyde    | 62.1    |         | P         | 34 - 114       |
| Endrin Ketone      | 94.7    |         | P         | 63 - 177       |
| Esfenvalerate      | 64.6    |         | P         | 29 - 143       |
| Ethalfuralin       | 73.9    |         | P         | 46 - 96.0      |
| Fenpropathrin      | 71.8    |         | P         | 28 - 115       |
| Gamma-BHC          | 79.0    |         | P         | 65 - 121       |
| Gamma-Chlordane    | 73.4    |         | P         | 39 - 103       |
| Heptachlor         | 56.5    |         | P         | 39 - 94.0      |
| Heptachlor Epoxide | 74.6    |         | P         | 54 - 104       |
| Hexachlorobenzene  | 78.3    |         | P         | 36 - 100       |
| Kepone             | 140     |         | P         | 10 - 225       |
| Lambda-Cyhalothrin | 56.8    |         | P         | 10 - 135       |
| Methoprene         | 48.4    |         | P         | 10 - 109       |
| Methoxychlor       | 74.2    |         | P         | 52 - 112       |
| MGK-264            | 60.6    |         | P         | 44 - 117       |
| Mirex              | 64.9    |         | P         | 20 - 90.0      |
| Oxychlordane       | 70.1    |         | P         | 44 - 102       |
| PCB-1016           | 77.3    |         | P         | 45 - 107       |
| PCB-1260           | 89.1    |         | P         | 40 - 118       |

## Quality Assurance Report Laboratory Control Sample Accuracy

Reference Method: EPA 8270E  
Batch ID: P435653

| Component          | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|--------------------|---------|---------|-----------|----------------|
| Permethrin         | 73.3    |         | P         | 18 - 135       |
| Phenothrin         | 55.1    |         | P         | 10 - 102       |
| Piperonyl Butoxide | 81.5    |         | P         | 28 - 156       |
| Prallethrin        | 71.7    |         | P         | 28 - 113       |
| Tau-Fluvalinate    | 68.8    |         | P         | 10 - 123       |
| Tetramethrin       | 65.5    |         | P         | 18 - 158       |
| Trans-Nonachlor    | 71.0    |         | P         | 39 - 104       |
| Triclosan Methyl   | 66.1    |         | P         | 54 - 108       |
| Trifluralin        | 69.8    |         | P         | 46 - 97.0      |

Reference Method: EPA 8276  
Batch ID: P435653

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Chlordane | 92.2    |         | P         | 52 - 117       |
| Toxaphene | 99.8    |         | P         | 44 - 125       |

Reference Method: EPA 8321B  
Batch ID: P435381

| Component           | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------------|---------|---------|-----------|----------------|
| 3-Hydroxycarbofuran | 82.1    |         | P         | 40 - 150       |
| Aldicarb            | 42.4    |         | P         | 30 - 150       |
| Aldicarb Sulfone    | 100     |         | P         | 40 - 150       |
| Aldicarb Sulfoxide  | 131     |         | P         | 40 - 150       |
| Carbaryl            | 79.5    |         | P         | 40 - 150       |
| Carbofuran          | 85.6    |         | P         | 40 - 150       |
| Methiocarb          | 64.8    |         | P         | 40 - 150       |
| Methomyl            | 89.5    |         | P         | 40 - 150       |
| Oxamyl              | 100     |         | P         | 40 - 150       |
| Propoxur            | 90.0    |         | P         | 40 - 150       |

Reference Method: EPA 8321B  
Batch ID: P435496

| Component    | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|--------------|---------|---------|-----------|----------------|
| Acesulfame K | 95.9    |         | P         | 40 - 150       |
| AMPA         | 76.6    |         | P         | 40 - 150       |
| Endothall    | 99.7    |         | P         | 40 - 150       |
| Glufosinate  | 126     |         | P         | 40 - 150       |
| Glyphosate   | 72.5    |         | P         | 40 - 150       |
| Sucralose    | 99.3    |         | P         | 40 - 150       |

Reference Method: EPA 8321B  
Batch ID: P435567

| Component     | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|---------|---------|-----------|----------------|
| 2,4-D         | 84.3    |         | P         | 40 - 150       |
| 2,4,5-T       | 119     |         | P         | 40 - 150       |
| Acetaminophen | 98.9    |         | P         | 30 - 150       |
| Acetamiprid   | 92.1    |         | P         | 40 - 150       |
| Afidopyropen  | 48.0    |         | P         | 30 - 150       |

## Quality Assurance Report

### Laboratory Control Sample Accuracy

Reference Method: EPA 8321B  
Batch ID: P435567

| Component        | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|------------------|---------|---------|-----------|----------------|
| Bentazon         | 93.0    |         | P         | 30 - 150       |
| Benzovindiflupyr | 91.2    |         | P         | 40 - 150       |
| Carbamazepine    | 95.8    |         | P         | 40 - 150       |
| Clothianidin     | 110     |         | P         | 40 - 150       |
| Dinotefuran      | 116     |         | P         | 40 - 150       |
| Diuron           | 90.0    |         | P         | 40 - 150       |
| Fenuron          | 98.1    |         | P         | 40 - 150       |
| Fluridone        | 79.7    |         | P         | 40 - 150       |
| Hydrocodone      | 97.7    |         | P         | 40 - 150       |
| Ibuprofen        | 74.8    |         | P         | 40 - 150       |
| Imazapyr         | 98.0    |         | P         | 40 - 150       |
| Imidacloprid     | 96.6    |         | P         | 40 - 150       |
| Linuron          | 71.1    |         | P         | 40 - 150       |
| Mandestrobin     | 90.9    |         | P         | 40 - 150       |
| MCPP             | 110     |         | P         | 40 - 150       |
| Naproxen         | 70.8    |         | P         | 40 - 150       |
| Primidone        | 97.3    |         | P         | 40 - 150       |
| Pyraclostrobin   | 88.9    |         | P         | 40 - 150       |
| Silvex           | 85.4    |         | P         | 40 - 150       |
| Thiamethoxam     | 108     |         | P         | 40 - 150       |
| Tolfenpyrad      | 59.2    |         | P         | 30 - 150       |
| Triclopyr        | 114     |         | P         | 40 - 150       |

Reference Method: SM 2320 B-2011  
Batch ID: P435768

| Component        | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|------------------|---------|---------|-----------|----------------|
| Total Alkalinity | 96.4    |         | P         | 92 - 105       |

Reference Method: SM 2320 B-2011  
Batch ID: P435872

| Component        | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|------------------|---------|---------|-----------|----------------|
| Total Alkalinity | 97.1    |         | P         | 92 - 105       |

Reference Method: SM 2540 C-2015  
Batch ID: P436283

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| TDS       | 94.8    |         | P         | 90 - 110       |

Reference Method: SM 2540 C-2015  
Batch ID: P436285

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| TDS       | 94.4    |         | P         | 90 - 110       |

Reference Method: SM 2540 D-2015  
Batch ID: P436015

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| TSS       | 94.6    |         | P         | 85 - 106       |

## Quality Assurance Report

### Laboratory Control Sample Accuracy

Reference Method: SM 2540 D-2015  
Batch ID: P436019

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| TSS       | 97.5    |         | P         | 85 - 106       |

Reference Method: SM 4500-F- C-2011  
Batch ID: P435770

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Fluoride  | 99.3    |         | P         | 94 - 106       |

Reference Method: SM 4500-F- C-2011  
Batch ID: P435874

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Fluoride  | 105     |         | P         | 94 - 106       |

Reference Method: SM 4500-F- C-2011  
Batch ID: P436026

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Fluoride  | 101     |         | P         | 94 - 106       |

Reference Method: SM 5310 B-2011  
Batch ID: P435847

| Component      | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|----------------|---------|---------|-----------|----------------|
| Organic Carbon | 96.0    |         | P         | 85 - 115       |

Reference Method: SM 5310 B-2011  
Batch ID: P436004

| Component      | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|----------------|---------|---------|-----------|----------------|
| Organic Carbon | 98.1    |         | P         | 85 - 115       |

## Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 200.7 Rev. 4.4

Batch ID: P435682

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 2440487       | Calcium   | 98.8    |         | P         | 80 - 120       |
| 2440487       | Iron      | 102     | 101     | P/P       | 80 - 120       |
| 2440487       | Magnesium | 104     | 102     | P/P       | 80 - 120       |
| 2440487       | Potassium | 96.4    | 98.4    | P/P       | 80 - 120       |
| 2440487       | Sodium    | 99.9    |         | P         | 80 - 120       |
| 2440487       | Strontium | 98.1    | 99.1    | P/P       | 80 - 120       |
| 2440487       | Tin       | 101     | 103     | P/P       | 80 - 120       |
| 2440487       | Titanium  | 92.9    | 95.4    | P/P       | 80 - 120       |
| 2440487       | Vanadium  | 98.6    | 101     | P/P       | 80 - 120       |
| 2440487       | Zinc      | 101     | 102     | P/P       | 80 - 120       |
| 2441075       | Calcium   | 102     |         | P         | 80 - 120       |
| 2441075       | Iron      | 99.7    |         | P         | 80 - 120       |
| 2441075       | Magnesium | 104     |         | P         | 80 - 120       |
| 2441075       | Potassium | 97.4    |         | P         | 80 - 120       |
| 2441075       | Sodium    | 99.5    |         | P         | 80 - 120       |
| 2441075       | Strontium | 99.2    |         | P         | 80 - 120       |
| 2441075       | Tin       | 102     |         | P         | 80 - 120       |
| 2441075       | Titanium  | 101     |         | P         | 80 - 120       |
| 2441075       | Vanadium  | 103     |         | P         | 80 - 120       |
| 2441075       | Zinc      | 102     |         | P         | 80 - 120       |

Reference Method: EPA 200.8 Rev. 5.4

Batch ID: P435682

| Spiked Sample | Component  | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|------------|---------|---------|-----------|----------------|
| 2440487       | Aluminum   | 101     | 98.7    | P/P       | 80 - 120       |
| 2440487       | Antimony   | 98.9    | 98.1    | P/P       | 80 - 120       |
| 2440487       | Arsenic    | 99.1    | 99.7    | P/P       | 80 - 120       |
| 2440487       | Barium     | 103     | 102     | P/P       | 80 - 120       |
| 2440487       | Beryllium  | 94.7    | 96.1    | P/P       | 80 - 120       |
| 2440487       | Boron      | 105     | 104     | P/P       | 80 - 120       |
| 2440487       | Cadmium    | 103     | 101     | P/P       | 80 - 120       |
| 2440487       | Chromium   | 95.1    | 94.9    | P/P       | 80 - 120       |
| 2440487       | Cobalt     | 96.9    | 96.6    | P/P       | 80 - 120       |
| 2440487       | Copper     | 93.9    | 94.5    | P/P       | 80 - 120       |
| 2440487       | Lead       | 93.2    | 93.0    | P/P       | 80 - 120       |
| 2440487       | Manganese  | 95.5    | 95.7    | P/P       | 80 - 120       |
| 2440487       | Molybdenum | 101     | 100     | P/P       | 80 - 120       |
| 2440487       | Nickel     | 94.2    | 93.7    | P/P       | 80 - 120       |
| 2440487       | Selenium   | 97.1    | 97.7    | P/P       | 80 - 120       |
| 2440487       | Silver     | 109     | 109     | P/P       | 80 - 120       |
| 2440487       | Thallium   | 104     | 104     | P/P       | 80 - 120       |
| 2441075       | Aluminum   | 87.6    |         | P         | 80 - 120       |
| 2441075       | Antimony   | 93.3    |         | P         | 80 - 120       |
| 2441075       | Arsenic    | 95.2    |         | P         | 80 - 120       |
| 2441075       | Barium     | 97.3    |         | P         | 80 - 120       |
| 2441075       | Beryllium  | 88.9    |         | P         | 80 - 120       |
| 2441075       | Boron      | 97.6    |         | P         | 80 - 120       |
| 2441075       | Cadmium    | 97.5    |         | P         | 80 - 120       |
| 2441075       | Chromium   | 93.5    |         | P         | 80 - 120       |
| 2441075       | Cobalt     | 93.8    |         | P         | 80 - 120       |
| 2441075       | Copper     | 96.7    |         | P         | 80 - 120       |

## Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 200.8 Rev. 5.4  
Batch ID: P435682

| Spiked Sample | Component  | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|------------|---------|---------|-----------|----------------|
| 2441075       | Lead       | 95.5    |         | P         | 80 - 120       |
| 2441075       | Manganese  | 92.7    |         | P         | 80 - 120       |
| 2441075       | Molybdenum | 94.7    |         | P         | 80 - 120       |
| 2441075       | Nickel     | 94.0    |         | P         | 80 - 120       |
| 2441075       | Selenium   | 93.1    |         | P         | 80 - 120       |
| 2441075       | Silver     | 104     |         | P         | 80 - 120       |
| 2441075       | Thallium   | 99.2    |         | P         | 80 - 120       |

Reference Method: EPA 300.0 Rev. 2.1  
Batch ID: P436046

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 2440524       | Chloride  | 105     |         | P         | 90 - 110       |
| 2440730       | Chloride  | 104     |         | P         | 90 - 110       |

Reference Method: EPA 300.0 Rev. 2.1  
Batch ID: P436049

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 2440524       | Sulfate   | 103     |         | P         | 90 - 110       |
| 2440730       | Sulfate   | 103     |         | P         | 90 - 110       |

Reference Method: EPA 350.1 Rev. 2.0  
Batch ID: P435750

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 2440476       | Ammonia-N | 98.4    | 99.6    | P/P       | 90 - 110       |

Reference Method: EPA 350.1 Rev. 2.0  
Batch ID: P435811

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 2440552       | Ammonia-N | 101     | 102     | P/P       | 90 - 110       |

Reference Method: EPA 351.2 Rev. 2.0  
Batch ID: P435772

| Spiked Sample | Component         | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-------------------|---------|---------|-----------|----------------|
| 2440435       | Kjeldahl Nitrogen | 97.5    | 100     | P/P       | 90 - 110       |

Reference Method: EPA 351.2 Rev. 2.0  
Batch ID: P435773

| Spiked Sample | Component         | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-------------------|---------|---------|-----------|----------------|
| 2440516       | Kjeldahl Nitrogen | 100     | 98.2    | P/P       | 90 - 110       |

Reference Method: EPA 353.2 Rev. 2.0  
Batch ID: P436140

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 2437931       | NO2NO3-N  | 98.5    | 100     | P/P       | 90 - 110       |

## Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 353.2 Rev. 2.0  
Batch ID: P436205

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 2440067       | NO2NO3-N  | 101     | 99.0    | P/P       | 90 - 110       |

Reference Method: EPA 353.2 Rev. 2.0  
Batch ID: P436261

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 2438460       | NO2NO3-N  | 98.5    | 100     | P/P       | 90 - 110       |

Reference Method: EPA 365.1 Rev. 2.0  
Batch ID: P435709

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 2440551       | Total-P   | 100     | 101     | P/P       | 90 - 110       |

Reference Method: EPA 365.1 Rev. 2.0  
Batch ID: P435710

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 2440540       | Total-P   | 102     | 104     | P/P       | 90 - 110       |

Reference Method: EPA 8270E  
Batch ID: P435493

| Spiked Sample | Component                                                | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|----------------------------------------------------------|---------|---------|-----------|----------------|
| 2440545       | 2-(2H-benzotriazol-2-yl)-4,6-ditertpentylphenol (UV-328) | 93.3    | 81.7    | P/P       | 50 - 150       |
| 2440545       | 2-Ethylhexyl 2,3,4,5-tetrabromobenzoate (EHTBB)          | 28.5    | 22.9    | P/F       | 26 - 165       |
| 2440545       | Acetochlor                                               | 103     | 85.9    | P/P       | 67 - 124       |
| 2440545       | Alachlor                                                 | 88.1    | 90.2    | P/P       | 60 - 120       |
| 2440545       | Ametryn                                                  | 130     | 115     | P/P       | 54 - 216       |
| 2440545       | Atrazine Desethyl                                        | 85.7    | 70.4    | P/P       | 15 - 122       |
| 2440545       | Avobenzone                                               | 83.2    | 96.1    | P/P       | 37 - 178       |
| 2440545       | Azinphos Methyl                                          | 78.6    | 92.7    | P/P       | 40 - 292       |
| 2440545       | Azoxystrobin                                             | 110     | 94.7    | P/P       | 35 - 220       |
| 2440545       | Bromacil                                                 | 115     | 98.8    | P/P       | 45 - 127       |
| 2440545       | Butylate                                                 | 58.6    | 43.0    | P/P       | 20 - 83.0      |
| 2440545       | Caffeine                                                 | 112     | 92.6    | P/P       | 10 - 194       |
| 2440545       | Carbophenothion                                          | 109     | 92.5    | P/P       | 57 - 127       |
| 2440545       | Carfentrazone Ethyl                                      | 117     | 99.4    | P/P       | 51 - 141       |
| 2440545       | Chlorfenapyr                                             | 62.6    | 54.7    | P/P       | 46 - 111       |
| 2440545       | Chlorpyrifos Ethyl                                       | 97.7    | 82.9    | P/P       | 52 - 120       |
| 2440545       | Chlorpyrifos Methyl                                      | 91.5    | 78.9    | P/P       | 63 - 119       |
| 2440545       | Coumaphos                                                | 61.4    | 56.6    | P/P       | 10 - 228       |
| 2440545       | Cyanazine                                                | 182     | 126     | P/P       | 59 - 241       |
| 2440545       | Cyprodinil                                               | 81.1    | 63.7    | P/P       | 47 - 146       |
| 2440545       | Dechlorane 602                                           | 37.8    | 40.7    | F/F       | 50 - 150       |
| 2440545       | Dechlorane 603                                           | 70.5    | 75.5    | P/P       | 50 - 150       |
| 2440545       | Dechlorane Plus                                          | 67.6    | 73.9    | P/P       | 50 - 150       |
| 2440545       | Demeton                                                  | 78.1    | 67.5    | P/P       | 40 - 136       |
| 2440545       | Diazinon                                                 | 108     | 107     | P/P       | 69 - 132       |
| 2440545       | Difenoconazole                                           | 118     | 137     | P/P       | 57 - 258       |
| 2440545       | Dimethenamid                                             | 80.6    | 69.9    | P/P       | 54 - 110       |
| 2440545       | Dimethomorph                                             | 227     | 241     | F/F       | 28 - 210       |

## Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 8270E  
Batch ID: P435493

| Spiked Sample | Component           | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|---------------------|---------|---------|-----------|----------------|
| 2440545       | Disulfoton          | 101     | 101     | P/P       | 43 - 133       |
| 2440545       | Dithiopyr           | 102     | 88.5    | P/P       | 39 - 116       |
| 2440545       | EPTC                | 51.7    | 32.0    | P/P       | 20 - 78.0      |
| 2440545       | Ethion              | 44.3    | 42.5    | P/P       | 17 - 119       |
| 2440545       | Ethoprop            | 103     | 88.7    | P/P       | 66 - 120       |
| 2440545       | Etridiazole         | 66.3    | 52.5    | P/P       | 28 - 96.0      |
| 2440545       | Fenamiphos          | 63.5    | 58.1    | P/P       | 41 - 126       |
| 2440545       | Fenbuconazole       | 58.8    | 68.2    | P/P       | 42 - 169       |
| 2440545       | Fipronil            | 82.1    | 68.2    | P/P       | 61 - 132       |
| 2440545       | Fipronil Desulfinyl | 99.7    | 88.5    | P/P       | 56 - 132       |
| 2440545       | Fipronil Sulfide    | 105     | 90.9    | P/P       | 48 - 119       |
| 2440545       | Fipronil Sulfone    | 60.2    | 66.0    | P/P       | 42 - 131       |
| 2440545       | Fluazifop-P-butyl   | 63.5    | 63.1    | P/P       | 53 - 131       |
| 2440545       | Fludioxonil         | 73.8    | 63.8    | P/P       | 56 - 127       |
| 2440545       | Flumioxazin         | 136     | 166     | P/P       | 19 - 300       |
| 2440545       | Flutolanil          | 71.4    | 67.7    | P/P       | 41 - 127       |
| 2440545       | Fluxapyroxad        | 88.1    | 74.8    | P/P       | 42 - 172       |
| 2440545       | Fonofos             | 90.8    | 86.5    | P/P       | 59 - 113       |
| 2440545       | Hexabromobenzene    | 83.1    | 82.9    | P/P       | 50 - 150       |
| 2440545       | Hexazinone          | 101     | 79.1    | P/P       | 66 - 122       |
| 2440545       | Imazail             | 121     | 104     | P/P       | 21 - 283       |
| 2440545       | Iprodione           | 75.2    | 61.7    | P/P       | 43 - 150       |
| 2440545       | Loratadine          | 167     | 181     | P/P       | 23 - 201       |
| 2440545       | Malathion           | 120     | 91.0    | P/P       | 58 - 136       |
| 2440545       | Metalaxyl           | 96.4    | 81.5    | P/P       | 55 - 120       |
| 2440545       | Metolachlor         | 105     | 82.3    | P/P       | 57 - 121       |
| 2440545       | Metribuzin          | 68.8    | 62.6    | P/P       | 58 - 294       |
| 2440545       | Mevinphos           | 82.2    | 74.2    | P/P       | 50 - 126       |
| 2440545       | Molinate            | 55.8    | 49.9    | P/P       | 42 - 93.0      |
| 2440545       | Myclobutanil        | 78.7    | 65.3    | P/P       | 55 - 125       |
| 2440545       | Naled               | 33.8    | 33.9    | P/P       | 18 - 200       |
| 2440545       | Napropamide         | 90.8    | 78.5    | P/P       | 39 - 110       |
| 2440545       | Norflurazon         | 75.9    | 74.5    | P/P       | 48 - 128       |
| 2440545       | Octinoxate          | 91.1    | 89.0    | P/P       | 21 - 159       |
| 2440545       | Oxadiazon           | 89.8    | 74.4    | P/P       | 43 - 112       |
| 2440545       | Oxybenzone          | 97.8    | 100     | P/P       | 41 - 142       |
| 2440545       | Oxyfluorfen         | 90.7    | 69.0    | P/P       | 64 - 153       |
| 2440545       | Parathion Ethyl     | 105     | 87.3    | P/P       | 69 - 114       |
| 2440545       | Parathion Methyl    | 108     | 97.9    | P/P       | 79 - 139       |
| 2440545       | PBB-153             | 33.2    | 35.2    | F/F       | 50 - 150       |
| 2440545       | PBDE-47             | 78.0    | 78.6    | P/P       | 27 - 144       |
| 2440545       | PBDE-99             | 22.9    | 25.1    | P/P       | 18 - 150       |
| 2440545       | Pendimethalin       | 85.9    | 75.0    | P/P       | 50 - 139       |
| 2440545       | Pentabromotoluene   | 86.2    | 84.1    | P/P       | 50 - 150       |
| 2440545       | Phenytoin           | 54.4    | 44.5    | P/P       | 10 - 146       |
| 2440545       | Phorate             | 116     | 116     | P/P       | 54 - 161       |
| 2440545       | Prodiamine          | 49.5    | 35.1    | P/P       | 30 - 161       |
| 2440545       | Prometon            | 110     | 96.6    | P/P       | 45 - 134       |
| 2440545       | Prometryn           | 104     | 95.5    | P/P       | 45 - 137       |
| 2440545       | Pronamide           | 118     | 95.6    | P/P       | 65 - 133       |
| 2440545       | Propanil            | 110     | 89.2    | P/P       | 49 - 142       |
| 2440545       | Propargite          | 60.8    | 50.0    | P/P       | 10 - 203       |

## Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 8270E

Batch ID: P435493

| Spiked Sample | Component                                     | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------------------------------------------|---------|---------|-----------|----------------|
| 2440545       | Propiconazole                                 | 73.4    | 80.4    | P/P       | 38 - 146       |
| 2440545       | Pyraflufen Ethyl                              | 73.6    | 81.8    | P/P       | 34 - 153       |
| 2440545       | Pyridaben                                     | 50.8    | 51.4    | P/P       | 12 - 192       |
| 2440545       | Pyriproxyfen                                  | 92.3    | 113     | P/P       | 33 - 180       |
| 2440545       | Simazine                                      | 80.3    | 60.5    | P/P       | 51 - 157       |
| 2440545       | Stiropfos                                     | 47.3    | 44.8    | P/P       | 10 - 128       |
| 2440545       | Sulfentrazone                                 | 77.7    | 62.0    | P/P       | 53 - 186       |
| 2440545       | Tebuconazole                                  | 56.2    | 50.6    | P/P       | 10 - 133       |
| 2440545       | Terbufos                                      | 124     | 115     | P/P       | 65 - 139       |
| 2440545       | Terbuthylazine                                | 91.9    | 84.6    | P/P       | 66 - 117       |
| 2440545       | Tetradecachloro-m-terphenyl                   | 74.0    | 74.2    | P/P       | 70 - 200       |
| 2440545       | Thiobencarb                                   | 95.0    | 79.7    | P/P       | 51 - 119       |
| 2440545       | Tri-o-cresyl Phosphate                        | 94.8    | 94.1    | P/P       | 31 - 144       |
| 2440545       | Triadimefon                                   | 98.5    | 75.8    | P/P       | 48 - 119       |
| 2440545       | Tris(1-chloro-2-propyl) phosphate (TCPP)      | 104     | 103     | P/P       | 50 - 150       |
| 2440545       | Tris(1,3-dichloro-2-propyl) phosphate (TDCPP) | 97.9    | 93.5    | P/P       | 50 - 150       |
| 2440545       | Tris(2-chloroethyl) phosphate (TCEP)          | 106     | 102     | P/P       | 70 - 180       |

Reference Method: EPA 8270E

Batch ID: P435653

| Spiked Sample | Component          | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|--------------------|---------|---------|-----------|----------------|
| 2440340       | PCB-1016           | 78.1    | 85.7    | P/P       | 45 - 107       |
| 2440340       | PCB-1260           | 78.4    | 88.8    | P/P       | 40 - 112       |
| 2441048       | Aldrin             | 63.9    | 65.3    | P/P       | 24 - 81.0      |
| 2441048       | Alpha-BHC          | 96.5    | 83.3    | P/P       | 65 - 110       |
| 2441048       | Alpha-Chlordane    | 91.1    | 76.7    | P/P       | 43 - 119       |
| 2441048       | Beta-BHC           | 83.7    | 89.6    | P/P       | 54 - 165       |
| 2441048       | Beta-Cyfluthrin    | 94.0    | 105     | P/P       | 27 - 165       |
| 2441048       | Bifenthrin         | 71.4    | 60.2    | P/P       | 17 - 117       |
| 2441048       | Chlorothalonil     | 11.8    | 12.1    | P/P       | 10 - 255       |
| 2441048       | Cis-Nonachlor      | 72.0    | 79.4    | P/P       | 34 - 98.0      |
| 2441048       | Cypermethrin       | 94.0    | 101     | P/P       | 25 - 143       |
| 2441048       | Dacthal            | 97.2    | 84.7    | P/P       | 55 - 139       |
| 2441048       | DDD-p,p'           | 59.8    | 64.8    | P/P       | 30 - 109       |
| 2441048       | DDE-p,p'           | 68.4    | 57.5    | P/P       | 35 - 106       |
| 2441048       | DDT-p,p'           | 58.6    | 61.1    | P/P       | 41 - 101       |
| 2441048       | Delta-BHC          | 150     | 117     | P/P       | 58 - 165       |
| 2441048       | Deltamethrin       | 119     | 118     | P/P       | 10 - 194       |
| 2441048       | Dichlobenil        | 50.7    | 52.3    | P/P       | 22 - 114       |
| 2441048       | Dicofol            | 86.9    | 76.9    | P/P       | 17 - 133       |
| 2441048       | Dieldrin           | 85.4    | 72.7    | P/P       | 45 - 129       |
| 2441048       | Endosulfan I       | 99.7    | 86.7    | P/P       | 49 - 104       |
| 2441048       | Endosulfan II      | 90.0    | 88.7    | P/P       | 37 - 117       |
| 2441048       | Endosulfan Sulfate | 83.9    | 77.4    | P/P       | 38 - 128       |
| 2441048       | Endrin             | 89.0    | 76.2    | P/P       | 35 - 116       |
| 2441048       | Endrin Aldehyde    | 54.9    | 55.9    | P/P       | 19 - 108       |
| 2441048       | Endrin Ketone      | 96.9    | 102     | P/P       | 44 - 134       |
| 2441048       | Esfenvalerate      | 106     | 99.0    | P/P       | 27 - 176       |
| 2441048       | Ethalfuralin       | 78.3    | 63.7    | P/P       | 49 - 100       |
| 2441048       | Fenpropathrin      | 82.5    | 75.7    | P/P       | 34 - 117       |
| 2441048       | Gamma-BHC          | 119     | 88.7    | P/P       | 59 - 129       |

## Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 8270E

Batch ID: P435653

| Spiked Sample | Component          | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|--------------------|---------|---------|-----------|----------------|
| 2441048       | Gamma-Chlordane    | 90.6    | 71.9    | P/P       | 33 - 107       |
| 2441048       | Heptachlor         | 85.0    | 67.2    | P/P       | 37 - 94.0      |
| 2441048       | Heptachlor Epoxide | 94.2    | 70.6    | P/P       | 38 - 118       |
| 2441048       | Hexachlorobenzene  | 73.0    | 66.5    | P/P       | 35 - 97.0      |
| 2441048       | Kepone             | 119     | 116     | P/P       | 10 - 221       |
| 2441048       | Lambda-Cyhalothrin | 96.9    | 107     | P/P       | 23 - 190       |
| 2441048       | Methoprene         | 50.1    | 53.5    | P/P       | 21 - 109       |
| 2441048       | Methoxychlor       | 115     | 97.9    | P/P       | 46 - 118       |
| 2441048       | MGK-264            | 64.3    | 63.9    | P/P       | 39 - 122       |
| 2441048       | Mirex              | 73.5    | 71.6    | P/P       | 25 - 90.0      |
| 2441048       | Oxychlordane       | 81.6    | 66.7    | P/P       | 42 - 100       |
| 2441048       | Permethrin         | 80.1    | 99.1    | P/P       | 33 - 181       |
| 2441048       | Phenothrin         | 71.6    | 103     | P/P       | 12 - 125       |
| 2441048       | Piperonyl Butoxide | 86.4    | 78.1    | P/P       | 10 - 178       |
| 2441048       | Prallethrin        | 80.3    | 82.0    | P/P       | 24 - 122       |
| 2441048       | Tau-Fluvalinate    | 103     | 100     | P/P       | 13 - 151       |
| 2441048       | Tetramethrin       | 84.7    | 93.5    | P/P       | 16 - 172       |
| 2441048       | Trans-Nonachlor    | 96.9    | 75.3    | P/P       | 39 - 100       |
| 2441048       | Triclosan Methyl   | 79.0    | 79.6    | P/P       | 43 - 110       |
| 2441048       | Trifluralin        | 74.0    | 70.2    | P/P       | 45 - 94.0      |

Reference Method: EPA 8276

Batch ID: P435653

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 2440340       | Chlordane | 72.0    | 67.8    | P/P       | 43 - 123       |
| 2440340       | Toxaphene | 82.9    | 76.9    | P/P       | 27 - 156       |

Reference Method: EPA 8321B

Batch ID: P435381

| Spiked Sample | Component           | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|---------------------|---------|---------|-----------|----------------|
| 2438839       | 3-Hydroxycarbofuran | 57.3    | 53.6    | P/P       | 40 - 150       |
| 2438839       | Aldicarb            | 35.7    | 33.6    | P/P       | 30 - 150       |
| 2438839       | Aldicarb Sulfone    | 55.7    | 54.4    | P/P       | 40 - 150       |
| 2438839       | Aldicarb Sulfoxide  | 27.5    | 26.1    | F/F       | 40 - 150       |
| 2438839       | Carbaryl            | 57.8    | 54.7    | P/P       | 40 - 150       |
| 2438839       | Carbofuran          | 50.6    | 46.7    | P/P       | 40 - 150       |
| 2438839       | Methiocarb          | 56.3    | 52.7    | P/P       | 40 - 150       |
| 2438839       | Methomyl            | 50.9    | 48.9    | P/P       | 40 - 150       |
| 2438839       | Oxamyl              | 52.0    | 50.6    | P/P       | 40 - 150       |
| 2438839       | Propoxur            | 47.3    | 45.7    | P/P       | 40 - 150       |

Reference Method: EPA 8321B

Batch ID: P435496

| Spiked Sample | Component    | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|--------------|---------|---------|-----------|----------------|
| 2440366       | Acesulfame K | 88.0    | 87.9    | P/P       | 40 - 150       |
| 2440366       | AMPA         | 64.6    | 64.3    | P/P       | 40 - 150       |
| 2440366       | Endothall    | 155     | 156     | F/F       | 40 - 150       |
| 2440366       | Glufosinate  | 119     | 108     | P/P       | 40 - 150       |
| 2440366       | Glyphosate   | 115     | 96.5    | P/P       | 40 - 150       |

## Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 8321B  
Batch ID: P435496

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 2440366       | Sucralose | 96.9    | 108     | P/P       | 40 - 150       |

Reference Method: EPA 8321B  
Batch ID: P435567

| Spiked Sample | Component        | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|------------------|---------|---------|-----------|----------------|
| 2440342       | 2,4,5-T          | 93.3    | 86.5    | P/P       | 40 - 150       |
| 2440342       | Acetaminophen    | 116     | 111     | P/P       | 30 - 150       |
| 2440342       | Acetamiprid      | 65.1    | 66.9    | P/P       | 40 - 150       |
| 2440342       | Afidopyropen     | 51.3    | 57.3    | P/P       | 30 - 150       |
| 2440342       | Bentazon         | 37.7    | 37.6    | P/P       | 30 - 150       |
| 2440342       | Benzovindiflupyr | 83.3    | 80.2    | P/P       | 40 - 150       |
| 2440342       | Carbamazepine    | 67.4    | 65.1    | P/P       | 40 - 150       |
| 2440342       | Clothianidin     | 83.2    | 79.4    | P/P       | 40 - 150       |
| 2440342       | Dinotefuran      | 95.6    | 87.5    | P/P       | 40 - 150       |
| 2440342       | Diuron           | 56.3    | 56.0    | P/P       | 40 - 150       |
| 2440342       | Fenuron          | 57.0    | 55.5    | P/P       | 40 - 150       |
| 2440342       | Fluridone        | 44.9    | 39.9    | P/F       | 40 - 150       |
| 2440342       | Hydrocodone      | 59.4    | 55.5    | P/P       | 40 - 150       |
| 2440342       | Ibuprofen        | 50.8    | 60.8    | P/P       | 40 - 150       |
| 2440342       | Imidacloprid     | 116     | 108     | P/P       | 40 - 150       |
| 2440342       | Linuron          | 50.8    | 46.9    | P/P       | 40 - 150       |
| 2440342       | Mandestrobin     | 69.7    | 66.7    | P/P       | 40 - 150       |
| 2440342       | MCPP             | 91.5    | 85.3    | P/P       | 40 - 150       |
| 2440342       | Naproxen         | 55.5    | 60.3    | P/P       | 40 - 150       |
| 2440342       | Primidone        | 75.1    | 68.6    | P/P       | 40 - 150       |
| 2440342       | Pyraclostrobin   | 81.2    | 77.0    | P/P       | 40 - 150       |
| 2440342       | Silvex           | 83.1    | 72.3    | P/P       | 40 - 150       |
| 2440342       | Thiamethoxam     | 82.7    | 78.2    | P/P       | 40 - 150       |
| 2440342       | Tolfenpyrad      | 60.0    | 61.2    | P/P       | 30 - 150       |
| 2440342       | Triclopyr        | 99.1    | 93.7    | P/P       | 40 - 150       |

Reference Method: SM 4500-F- C-2011  
Batch ID: P435770

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 2441080       | Fluoride  | 104     | 103     | P/P       | 94 - 106       |

Reference Method: SM 4500-F- C-2011  
Batch ID: P435874

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 2440920       | Fluoride  | 103     | 103     | P/P       | 94 - 106       |

Reference Method: SM 4500-F- C-2011  
Batch ID: P436026

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 2442288       | Fluoride  | 101     | 101     | P/P       | 94 - 106       |

---

## Quality Assurance Report

### Matrix Spike Accuracy

Reference Method: SM 5310 B-2011  
Batch ID: P435847

| Spiked Sample | Component      | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|----------------|---------|---------|-----------|----------------|
| 2440525       | Organic Carbon | 97.2    | 97.7    | P/P       | 85 - 115       |

Reference Method: SM 5310 B-2011  
Batch ID: P436004

| Spiked Sample | Component      | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|----------------|---------|---------|-----------|----------------|
| 2440551       | Organic Carbon | 96.5    | 95.7    | P/P       | 85 - 115       |

## Quality Assurance Report Precision

Reference Method: DEP SOP: NU-094-1  
Batch ID: P435606

Replicated

| Lab Sample | Component    | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|------------|--------------|-----------|-------------------|-----------|----------------|
| 2440539    | Color (true) | 0.617     | Sample            | P         | 0 - 20         |

Reference Method: EPA 180.1 Rev. 2.0  
Batch ID: P435617

Replicated

| Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|------------|-----------|-----------|-------------------|-----------|----------------|
| 2440433    | Turbidity | 2.28      | Sample            | P         | 0 - 20         |

Reference Method: EPA 200.7 Rev. 4.4  
Batch ID: P435682

Replicated

| Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|------------|-----------|-----------|-------------------|-----------|----------------|
| 2440487    | Calcium   | 0.768     | Spike             | P         | 0 - 20         |
| 2440487    | Iron      | 1.39      | Spike             | P         | 0 - 20         |
| 2440487    | Magnesium | 1.24      | Spike             | P         | 0 - 20         |
| 2440487    | Potassium | 1.62      | Spike             | P         | 0 - 20         |
| 2440487    | Sodium    | 1.56      | Spike             | P         | 0 - 20         |
| 2440487    | Strontium | 1.03      | Spike             | P         | 0 - 20         |
| 2440487    | Tin       | 1.82      | Spike             | P         | 0 - 20         |
| 2440487    | Titanium  | 2.02      | Spike             | P         | 0 - 20         |
| 2440487    | Vanadium  | 1.97      | Spike             | P         | 0 - 20         |
| 2440487    | Zinc      | 1.47      | Spike             | P         | 0 - 20         |

Reference Method: EPA 200.8 Rev. 5.4  
Batch ID: P435682

Replicated

| Lab Sample | Component  | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|------------|------------|-----------|-------------------|-----------|----------------|
| 2440487    | Aluminum   | 1.14      | Spike             | P         | 0 - 20         |
| 2440487    | Antimony   | 0.837     | Spike             | P         | 0 - 20         |
| 2440487    | Arsenic    | 0.593     | Spike             | P         | 0 - 20         |
| 2440487    | Barium     | 0.694     | Spike             | P         | 0 - 20         |
| 2440487    | Beryllium  | 1.41      | Spike             | P         | 0 - 20         |
| 2440487    | Boron      | 0.927     | Spike             | P         | 0 - 20         |
| 2440487    | Cadmium    | 1.27      | Spike             | P         | 0 - 20         |
| 2440487    | Chromium   | 0.169     | Spike             | P         | 0 - 20         |
| 2440487    | Cobalt     | 0.341     | Spike             | P         | 0 - 20         |
| 2440487    | Copper     | 0.540     | Spike             | P         | 0 - 20         |
| 2440487    | Lead       | 0.281     | Spike             | P         | 0 - 20         |
| 2440487    | Manganese  | 0.273     | Spike             | P         | 0 - 20         |
| 2440487    | Molybdenum | 0.601     | Spike             | P         | 0 - 20         |
| 2440487    | Nickel     | 0.429     | Spike             | P         | 0 - 20         |
| 2440487    | Selenium   | 0.606     | Spike             | P         | 0 - 20         |
| 2440487    | Silver     | 0.0570    | Spike             | P         | 0 - 20         |
| 2440487    | Thallium   | 0.278     | Spike             | P         | 0 - 20         |

## Quality Assurance Report Precision

Reference Method: EPA 300.0 Rev. 2.1  
Batch ID: P436046

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 2440524                  | Chloride  | 0.376     | Sample            | P         | 0 - 20         |

Reference Method: EPA 300.0 Rev. 2.1  
Batch ID: P436049

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 2440524                  | Sulfate   | 0.189     | Sample            | P         | 0 - 20         |

Reference Method: EPA 350.1 Rev. 2.0  
Batch ID: P435750

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 2440476                  | Ammonia-N | 1.15      | Spike             | P         | 0 - 20         |

Reference Method: EPA 350.1 Rev. 2.0  
Batch ID: P435811

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 2440552                  | Ammonia-N | 0.979     | Spike             | P         | 0 - 20         |

Reference Method: EPA 351.2 Rev. 2.0  
Batch ID: P435772

| Replicated<br>Lab Sample | Component         | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-------------------|-----------|-------------------|-----------|----------------|
| 2440435                  | Kjeldahl Nitrogen | 1.44      | Spike             | P         | 0 - 20         |

Reference Method: EPA 351.2 Rev. 2.0  
Batch ID: P435773

| Replicated<br>Lab Sample | Component         | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-------------------|-----------|-------------------|-----------|----------------|
| 2440516                  | Kjeldahl Nitrogen | 1.78      | Spike             | P         | 0 - 20         |

Reference Method: EPA 353.2 Rev. 2.0  
Batch ID: P436140

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 2437931                  | NO2NO3-N  | 1.51      | Spike             | P         | 0 - 20         |

Reference Method: EPA 353.2 Rev. 2.0  
Batch ID: P436205

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 2440067                  | NO2NO3-N  | 1.01      | Spike             | P         | 0 - 20         |

## Quality Assurance Report Precision

Reference Method: EPA 353.2 Rev. 2.0

Batch ID: P436261

Replicated

| Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|------------|-----------|-----------|-------------------|-----------|----------------|
| 2438460    | NO2NO3-N  | 1.51      | Spike             | P         | 0 - 20         |

Reference Method: EPA 365.1 Rev. 2.0

Batch ID: P435709

Replicated

| Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|------------|-----------|-----------|-------------------|-----------|----------------|
| 2440551    | Total-P   | 0.480     | Spike             | P         | 0 - 20         |

Reference Method: EPA 365.1 Rev. 2.0

Batch ID: P435710

Replicated

| Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|------------|-----------|-----------|-------------------|-----------|----------------|
| 2440540    | Total-P   | 2.28      | Spike             | P         | 0 - 20         |

Reference Method: EPA 8270E

Batch ID: P435493

Replicated

| Lab Sample | Component                                                | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|------------|----------------------------------------------------------|-----------|-------------------|-----------|----------------|
| 2440545    | 2-(2H-benzotriazol-2-yl)-4,6-ditertpentylphenol (UV-328) | 13.3      | Spike             | P         | 0 - 30         |
| 2440545    | 2-Ethylhexyl 2,3,4,5-tetrabromobenzoate (EHTBB)          | 21.7      | Spike             | P         | 0 - 37         |
| 2440545    | Acetochlor                                               | 17.6      | Spike             | P         | 0 - 28         |
| 2440545    | Alachlor                                                 | 2.27      | Spike             | P         | 0 - 30         |
| 2440545    | Ametryn                                                  | 12.5      | Spike             | P         | 0 - 32         |
| 2440545    | Atrazine                                                 | 6.84      | Spike             | P         | 0 - 41         |
| 2440545    | Atrazine Desethyl                                        | 15.5      | Spike             | P         | 0 - 36         |
| 2440545    | Avobenzone                                               | 14.4      | Spike             | P         | 0 - 36         |
| 2440545    | Azinphos Methyl                                          | 16.5      | Spike             | P         | 0 - 75         |
| 2440545    | Azoxystrobin                                             | 14.7      | Spike             | P         | 0 - 39         |
| 2440545    | Bromacil                                                 | 14.9      | Spike             | P         | 0 - 33         |
| 2440545    | Butylate                                                 | 30.7      | Spike             | P         | 0 - 44         |
| 2440545    | Caffeine                                                 | 18.6      | Spike             | P         | 0 - 74         |
| 2440545    | Carbophenothion                                          | 16.2      | Spike             | P         | 0 - 25         |
| 2440545    | Carfentrazone Ethyl                                      | 16.0      | Spike             | P         | 0 - 27         |
| 2440545    | Chlorfenapyr                                             | 13.6      | Spike             | P         | 0 - 24         |
| 2440545    | Chlorpyrifos Ethyl                                       | 16.4      | Spike             | P         | 0 - 26         |
| 2440545    | Chlorpyrifos Methyl                                      | 14.7      | Spike             | P         | 0 - 26         |
| 2440545    | Coumaphos                                                | 8.07      | Spike             | P         | 0 - 28         |
| 2440545    | Cyanazine                                                | 36.5      | Spike             | P         | 0 - 48         |
| 2440545    | Cyprodinil                                               | 21.4      | Spike             | P         | 0 - 29         |
| 2440545    | Dechlorane 602                                           | 7.57      | Spike             | P         | 0 - 30         |
| 2440545    | Dechlorane 603                                           | 6.96      | Spike             | P         | 0 - 30         |
| 2440545    | Dechlorane Plus                                          | 8.97      | Spike             | P         | 0 - 30         |
| 2440545    | Demeton                                                  | 14.7      | Spike             | P         | 0 - 33         |
| 2440545    | Diazinon                                                 | 1.39      | Spike             | P         | 0 - 29         |
| 2440545    | Difenoconazole                                           | 15.0      | Spike             | P         | 0 - 34         |
| 2440545    | Dimethenamid                                             | 14.2      | Spike             | P         | 0 - 39         |
| 2440545    | Dimethomorph                                             | 5.97      | Spike             | P         | 0 - 51         |
| 2440545    | Disulfoton                                               | 0.528     | Spike             | P         | 0 - 30         |

## Quality Assurance Report Precision

Reference Method: EPA 8270E  
Batch ID: P435493

| Replicated<br>Lab Sample | Component           | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|---------------------|-----------|-------------------|-----------|----------------|
| 2440545                  | Dithiopyr           | 13.7      | Spike             | P         | 0 - 26         |
| 2440545                  | EPTC                | 47.0      | Spike             | F         | 0 - 43         |
| 2440545                  | Ethion              | 4.13      | Spike             | P         | 0 - 79         |
| 2440545                  | Ethoprop            | 15.3      | Spike             | P         | 0 - 29         |
| 2440545                  | Etridiazole         | 23.3      | Spike             | P         | 0 - 33         |
| 2440545                  | Fenamiphos          | 8.92      | Spike             | P         | 0 - 40         |
| 2440545                  | Fenbuconazole       | 14.7      | Spike             | P         | 0 - 74         |
| 2440545                  | Fipronil            | 18.6      | Spike             | P         | 0 - 29         |
| 2440545                  | Fipronil Desulfanyl | 12.0      | Spike             | P         | 0 - 32         |
| 2440545                  | Fipronil Sulfide    | 14.3      | Spike             | P         | 0 - 30         |
| 2440545                  | Fipronil Sulfone    | 9.19      | Spike             | P         | 0 - 33         |
| 2440545                  | Fluazifop-P-butyl   | 0.649     | Spike             | P         | 0 - 38         |
| 2440545                  | Fludioxonil         | 14.5      | Spike             | P         | 0 - 29         |
| 2440545                  | Flumioxazin         | 19.7      | Spike             | P         | 0 - 51         |
| 2440545                  | Flutolanil          | 5.26      | Spike             | P         | 0 - 25         |
| 2440545                  | Fluxapyroxad        | 16.4      | Spike             | P         | 0 - 45         |
| 2440545                  | Fonofos             | 4.88      | Spike             | P         | 0 - 27         |
| 2440545                  | Hexabromobenzene    | 0.301     | Spike             | P         | 0 - 30         |
| 2440545                  | Hexazinone          | 24.0      | Spike             | P         | 0 - 30         |
| 2440545                  | Imazalil            | 15.2      | Spike             | P         | 0 - 100        |
| 2440545                  | Iprodione           | 19.8      | Spike             | P         | 0 - 33         |
| 2440545                  | Loratadine          | 8.44      | Spike             | P         | 0 - 56         |
| 2440545                  | Malathion           | 27.1      | Spike             | P         | 0 - 37         |
| 2440545                  | Metalaxyl           | 16.7      | Spike             | P         | 0 - 40         |
| 2440545                  | Metolachlor         | 21.1      | Spike             | P         | 0 - 29         |
| 2440545                  | Metribuzin          | 9.46      | Spike             | P         | 0 - 45         |
| 2440545                  | Mevinphos           | 10.3      | Spike             | P         | 0 - 29         |
| 2440545                  | Molinate            | 11.2      | Spike             | P         | 0 - 33         |
| 2440545                  | Myclobutanil        | 18.7      | Spike             | P         | 0 - 26         |
| 2440545                  | Naled               | 0.251     | Spike             | P         | 0 - 37         |
| 2440545                  | Napropamide         | 14.6      | Spike             | P         | 0 - 44         |
| 2440545                  | Norflurazon         | 1.84      | Spike             | P         | 0 - 30         |
| 2440545                  | Octinoxate          | 2.34      | Spike             | P         | 0 - 45         |
| 2440545                  | Oxadiazon           | 18.8      | Spike             | P         | 0 - 28         |
| 2440545                  | Oxybenzone          | 2.69      | Spike             | P         | 0 - 46         |
| 2440545                  | Oxyfluorfen         | 27.2      | Spike             | P         | 0 - 28         |
| 2440545                  | Parathion Ethyl     | 18.3      | Spike             | P         | 0 - 31         |
| 2440545                  | Parathion Methyl    | 9.54      | Spike             | P         | 0 - 29         |
| 2440545                  | PBB-153             | 5.91      | Spike             | P         | 0 - 30         |
| 2440545                  | PBDE-47             | 0.774     | Spike             | P         | 0 - 36         |
| 2440545                  | PBDE-99             | 9.23      | Spike             | P         | 0 - 40         |
| 2440545                  | Pendimethalin       | 13.6      | Spike             | P         | 0 - 33         |
| 2440545                  | Pentabromotoluene   | 2.50      | Spike             | P         | 0 - 30         |
| 2440545                  | Phenytoin           | 20.0      | Spike             | P         | 0 - 100        |
| 2440545                  | Phorate             | 0.602     | Spike             | P         | 0 - 36         |
| 2440545                  | Prodiamine          | 34.2      | Spike             | P         | 0 - 71         |
| 2440545                  | Prometon            | 12.7      | Spike             | P         | 0 - 36         |
| 2440545                  | Prometryn           | 8.18      | Spike             | P         | 0 - 28         |
| 2440545                  | Pronamide           | 21.2      | Spike             | P         | 0 - 24         |
| 2440545                  | Propanil            | 21.1      | Spike             | P         | 0 - 28         |
| 2440545                  | Propargite          | 19.4      | Spike             | P         | 0 - 43         |

## Quality Assurance Report Precision

Reference Method: EPA 8270E

Batch ID: P435493

| Replicated<br>Lab Sample | Component                                     | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------------------------------------------|-----------|-------------------|-----------|----------------|
| 2440545                  | Propiconazole                                 | 9.03      | Spike             | P         | 0 - 33         |
| 2440545                  | Pyraflufen Ethyl                              | 10.5      | Spike             | P         | 0 - 29         |
| 2440545                  | Pyridaben                                     | 1.15      | Spike             | P         | 0 - 30         |
| 2440545                  | Pyriproxyfen                                  | 19.8      | Spike             | P         | 0 - 79         |
| 2440545                  | Simazine                                      | 24.6      | Spike             | P         | 0 - 29         |
| 2440545                  | Stirophos                                     | 5.50      | Spike             | P         | 0 - 61         |
| 2440545                  | Sulfentrazone                                 | 22.6      | Spike             | P         | 0 - 33         |
| 2440545                  | Tebuconazole                                  | 10.6      | Spike             | P         | 0 - 69         |
| 2440545                  | Terbufos                                      | 7.49      | Spike             | P         | 0 - 29         |
| 2440545                  | Terbuthylazine                                | 8.21      | Spike             | P         | 0 - 32         |
| 2440545                  | Tetradecachloro-m-terphenyl                   | 0.349     | Spike             | P         | 0 - 30         |
| 2440545                  | Thiobencarb                                   | 17.6      | Spike             | P         | 0 - 26         |
| 2440545                  | Tri-o-cresyl Phosphate                        | 0.742     | Spike             | P         | 0 - 33         |
| 2440545                  | Triadimefon                                   | 26.0      | Spike             | P         | 0 - 28         |
| 2440545                  | Tris(1-chloro-2-propyl) phosphate (TCPP)      | 1.19      | Spike             | P         | 0 - 30         |
| 2440545                  | Tris(1,3-dichloro-2-propyl) phosphate (TDCPP) | 4.55      | Spike             | P         | 0 - 30         |
| 2440545                  | Tris(2-chloroethyl) phosphate (TCEP)          | 4.23      | Spike             | P         | 0 - 30         |

Reference Method: EPA 8270E

Batch ID: P435653

| Replicated<br>Lab Sample | Component          | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|--------------------|-----------|-------------------|-----------|----------------|
| 2440340                  | PCB-1016           | 9.27      | Spike             | P         | 0 - 25         |
| 2440340                  | PCB-1260           | 12.5      | Spike             | P         | 0 - 30         |
| 2441048                  | Aldrin             | 2.25      | Spike             | P         | 0 - 41         |
| 2441048                  | Alpha-BHC          | 14.6      | Spike             | P         | 0 - 25         |
| 2441048                  | Alpha-Chlordane    | 17.2      | Spike             | P         | 0 - 32         |
| 2441048                  | Beta-BHC           | 6.78      | Spike             | P         | 0 - 33         |
| 2441048                  | Beta-Cyfluthrin    | 11.5      | Spike             | P         | 0 - 43         |
| 2441048                  | Bifenthrin         | 17.0      | Spike             | P         | 0 - 52         |
| 2441048                  | Chlorothalonil     | 2.54      | Spike             | P         | 0 - 82         |
| 2441048                  | Cis-Nonachlor      | 9.80      | Spike             | P         | 0 - 33         |
| 2441048                  | Cypermethrin       | 7.34      | Spike             | P         | 0 - 51         |
| 2441048                  | Dacthal            | 13.7      | Spike             | P         | 0 - 27         |
| 2441048                  | DDD-p,p'           | 7.97      | Spike             | P         | 0 - 39         |
| 2441048                  | DDE-p,p'           | 17.3      | Spike             | P         | 0 - 31         |
| 2441048                  | DDT-p,p'           | 4.24      | Spike             | P         | 0 - 29         |
| 2441048                  | Delta-BHC          | 25.0      | Spike             | P         | 0 - 35         |
| 2441048                  | Deltamethrin       | 0.276     | Spike             | P         | 0 - 100        |
| 2441048                  | Dichlobenil        | 3.01      | Spike             | P         | 0 - 40         |
| 2441048                  | Dicofol            | 12.3      | Spike             | P         | 0 - 37         |
| 2441048                  | Dieldrin           | 16.1      | Spike             | P         | 0 - 27         |
| 2441048                  | Endosulfan I       | 14.0      | Spike             | P         | 0 - 23         |
| 2441048                  | Endosulfan II      | 1.45      | Spike             | P         | 0 - 34         |
| 2441048                  | Endosulfan Sulfate | 7.99      | Spike             | P         | 0 - 36         |
| 2441048                  | Endrin             | 15.5      | Spike             | P         | 0 - 45         |
| 2441048                  | Endrin Aldehyde    | 1.87      | Spike             | P         | 0 - 76         |
| 2441048                  | Endrin Ketone      | 5.33      | Spike             | P         | 0 - 43         |
| 2441048                  | Esfenvalerate      | 7.02      | Spike             | P         | 0 - 51         |
| 2441048                  | Ethalfuralin       | 20.6      | Spike             | P         | 0 - 22         |

## Quality Assurance Report Precision

Reference Method: EPA 8270E

Batch ID: P435653

| Replicated<br>Lab Sample | Component          | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|--------------------|-----------|-------------------|-----------|----------------|
| 2441048                  | Fenpropathrin      | 8.62      | Spike             | P         | 0 - 49         |
| 2441048                  | Gamma-BHC          | 29.3      | Spike             | F         | 0 - 28         |
| 2441048                  | Gamma-Chlordane    | 23.0      | Spike             | P         | 0 - 40         |
| 2441048                  | Heptachlor         | 23.4      | Spike             | P         | 0 - 29         |
| 2441048                  | Heptachlor Epoxide | 28.6      | Spike             | P         | 0 - 33         |
| 2441048                  | Hexachlorobenzene  | 9.29      | Spike             | P         | 0 - 36         |
| 2441048                  | Kepone             | 3.04      | Spike             | P         | 0 - 85         |
| 2441048                  | Lambda-Cyhalothrin | 9.76      | Spike             | P         | 0 - 55         |
| 2441048                  | Methoprene         | 6.67      | Spike             | P         | 0 - 53         |
| 2441048                  | Methoxychlor       | 15.8      | Spike             | P         | 0 - 50         |
| 2441048                  | MGK-264            | 0.739     | Spike             | P         | 0 - 43         |
| 2441048                  | Mirex              | 2.68      | Spike             | P         | 0 - 40         |
| 2441048                  | Oxychlordane       | 20.1      | Spike             | P         | 0 - 31         |
| 2441048                  | Permethrin         | 21.2      | Spike             | P         | 0 - 50         |
| 2441048                  | Phenothrin         | 36.3      | Spike             | P         | 0 - 58         |
| 2441048                  | Piperonyl Butoxide | 10.1      | Spike             | P         | 0 - 100        |
| 2441048                  | Prallethrin        | 2.10      | Spike             | P         | 0 - 39         |
| 2441048                  | Tau-Fluvalinate    | 2.18      | Spike             | P         | 0 - 54         |
| 2441048                  | Tetramethrin       | 9.88      | Spike             | P         | 0 - 51         |
| 2441048                  | Trans-Nonachlor    | 25.1      | Spike             | P         | 0 - 39         |
| 2441048                  | Triclosan Methyl   | 0.814     | Spike             | P         | 0 - 31         |
| 2441048                  | Trifluralin        | 5.26      | Spike             | P         | 0 - 22         |

Reference Method: EPA 8276

Batch ID: P435653

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 2440340                  | Chlordane | 5.59      | Spike             | P         | 0 - 28         |
| 2440340                  | Toxaphene | 7.50      | Spike             | P         | 0 - 27         |

Reference Method: EPA 8321B

Batch ID: P435381

| Replicated<br>Lab Sample | Component           | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|---------------------|-----------|-------------------|-----------|----------------|
| 2438839                  | 3-Hydroxycarbofuran | 6.67      | Spike             | P         | 0 - 30         |
| 2438839                  | Aldicarb            | 6.27      | Spike             | P         | 0 - 30         |
| 2438839                  | Aldicarb Sulfone    | 2.40      | Spike             | P         | 0 - 30         |
| 2438839                  | Aldicarb Sulfoxide  | 5.21      | Spike             | P         | 0 - 30         |
| 2438839                  | Carbaryl            | 5.60      | Spike             | P         | 0 - 30         |
| 2438839                  | Carbofuran          | 7.84      | Spike             | P         | 0 - 30         |
| 2438839                  | Methiocarb          | 6.64      | Spike             | P         | 0 - 30         |
| 2438839                  | Methomyl            | 4.00      | Spike             | P         | 0 - 30         |
| 2438839                  | Oxamyl              | 2.59      | Spike             | P         | 0 - 30         |
| 2438839                  | Propoxur            | 3.36      | Spike             | P         | 0 - 30         |

## Quality Assurance Report Precision

Reference Method: EPA 8321B  
Batch ID: P435496

| Replicated<br>Lab Sample | Component    | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|--------------|-----------|-------------------|-----------|----------------|
| 2440366                  | Acesulfame K | 0.157     | Spike             | P         | 0 - 30         |
| 2440366                  | AMPA         | 0.354     | Spike             | P         | 0 - 30         |
| 2440366                  | Endothall    | 0.668     | Spike             | P         | 0 - 30         |
| 2440366                  | Glufosinate  | 9.58      | Spike             | P         | 0 - 30         |
| 2440366                  | Glyphosate   | 17.4      | Spike             | P         | 0 - 30         |
| 2440366                  | Sucralose    | 10.5      | Spike             | P         | 0 - 30         |

Reference Method: EPA 8321B  
Batch ID: P435567

| Replicated<br>Lab Sample | Component        | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|------------------|-----------|-------------------|-----------|----------------|
| 2440342                  | 2,4-D            | 3.83      | Spike             | P         | 0 - 30         |
| 2440342                  | 2,4,5-T          | 7.48      | Spike             | P         | 0 - 30         |
| 2440342                  | Acetaminophen    | 5.12      | Spike             | P         | 0 - 30         |
| 2440342                  | Acetamiprid      | 2.84      | Spike             | P         | 0 - 30         |
| 2440342                  | Afidopyropen     | 11.1      | Spike             | P         | 0 - 30         |
| 2440342                  | Bentazon         | 0.151     | Spike             | P         | 0 - 30         |
| 2440342                  | Benzovindiflupyr | 3.79      | Spike             | P         | 0 - 30         |
| 2440342                  | Carbamazepine    | 3.44      | Spike             | P         | 0 - 30         |
| 2440342                  | Clothianidin     | 4.66      | Spike             | P         | 0 - 30         |
| 2440342                  | Dinotefuran      | 8.80      | Spike             | P         | 0 - 30         |
| 2440342                  | Diuron           | 0.585     | Spike             | P         | 0 - 30         |
| 2440342                  | Fenuron          | 2.57      | Spike             | P         | 0 - 30         |
| 2440342                  | Fluridone        | 11.8      | Spike             | P         | 0 - 30         |
| 2440342                  | Hydrocodone      | 6.74      | Spike             | P         | 0 - 30         |
| 2440342                  | Ibuprofen        | 17.9      | Spike             | P         | 0 - 30         |
| 2440342                  | Imazapyr         | 0.792     | Spike             | P         | 0 - 30         |
| 2440342                  | Imidacloprid     | 6.34      | Spike             | P         | 0 - 30         |
| 2440342                  | Linuron          | 8.07      | Spike             | P         | 0 - 30         |
| 2440342                  | Mandestrobin     | 4.45      | Spike             | P         | 0 - 30         |
| 2440342                  | MCPP             | 7.06      | Spike             | P         | 0 - 30         |
| 2440342                  | Naproxen         | 8.29      | Spike             | P         | 0 - 30         |
| 2440342                  | Primidone        | 8.95      | Spike             | P         | 0 - 30         |
| 2440342                  | Pyraclostrobin   | 5.32      | Spike             | P         | 0 - 30         |
| 2440342                  | Silvex           | 13.8      | Spike             | P         | 0 - 30         |
| 2440342                  | Thiamethoxam     | 5.57      | Spike             | P         | 0 - 30         |
| 2440342                  | Tolfenpyrad      | 2.01      | Spike             | P         | 0 - 30         |
| 2440342                  | Triclopyr        | 5.61      | Spike             | P         | 0 - 30         |

Reference Method: SM 2320 B-2011  
Batch ID: P435768

| Replicated<br>Lab Sample | Component        | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|------------------|-----------|-------------------|-----------|----------------|
| 2441080                  | Total Alkalinity | 0.815     | Sample            | P         | 0 - 3.9        |

## Quality Assurance Report Precision

Reference Method: SM 2320 B-2011  
Batch ID: P435872

| Replicated<br>Lab Sample | Component        | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|------------------|-----------|-------------------|-----------|----------------|
| 2440920                  | Total Alkalinity | 2.67      | Sample            | P         | 0 - 3.9        |

Reference Method: SM 2540 C-2015  
Batch ID: P436283

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 2440475                  | TDS       | 1.94      | Sample            | P         | 0 - 10         |

Reference Method: SM 2540 C-2015  
Batch ID: P436285

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 2441360                  | TDS       | 5.41      | Sample            | P         | 0 - 10         |

Reference Method: SM 2540 D-2015  
Batch ID: P436019

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 2440550                  | TSS       | 3.28      | Sample            | P         | 0 - 10         |

Reference Method: SM 4500-F- C-2011  
Batch ID: P435770

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 2441080                  | Fluoride  | 0.963     | Spike             | P         | 0 - 1.9        |

Reference Method: SM 4500-F- C-2011  
Batch ID: P435874

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 2440920                  | Fluoride  | 0.0       | Spike             | P         | 0 - 1.9        |

Reference Method: SM 4500-F- C-2011  
Batch ID: P436026

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 2442288                  | Fluoride  | 0.506     | Spike             | P         | 0 - 1.9        |

Reference Method: SM 5310 B-2011  
Batch ID: P435847

| Replicated<br>Lab Sample | Component      | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|----------------|-----------|-------------------|-----------|----------------|
| 2440525                  | Organic Carbon | 0.311     | Spike             | P         | 0 - 20         |

## Quality Assurance Report

### Precision

Reference Method: SM 5310 B-2011  
Batch ID: P436004

| Replicated<br>Lab Sample | Component      | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|----------------|-----------|-------------------|-----------|----------------|
| 2440551                  | Organic Carbon | 0.648     | Spike             | P         | 0 - 20         |

\* Sample, spike and/or laboratory control sample precision (LCS) is reported.

## Quality Assurance Report Surrogates

Lab Sample ID: 2440568  
Field Sample ID: G3NW0142

| Reference Method | Surrogate   | % Rec. | Pass/Fail | Control Limits |
|------------------|-------------|--------|-----------|----------------|
| EPA 8321B        | Carbaryl-d7 | 69.1   | P         | 30 - 160       |

Lab Sample ID: 2440569  
Field Sample ID: G3NW0142

| Reference Method | Surrogate          | % Rec. | Pass/Fail | Control Limits |
|------------------|--------------------|--------|-----------|----------------|
| EPA 8321B        | 2,4-D-d3           | 92.9   | P         | 30 - 160       |
| EPA 8321B        | Acetaminophen-d4   | 98.6   | P         | 30 - 160       |
| EPA 8321B        | Carbamazepine-d10  | 69.8   | P         | 30 - 160       |
| EPA 8321B        | Diuron-d6          | 60.4   | P         | 30 - 160       |
| EPA 8321B        | Endothall-d6       | 127    | P         | 30 - 160       |
| EPA 8321B        | Glyphosate 13C 15N | 68.1   | P         | 30 - 160       |
| EPA 8321B        | Ibuprofen-d3       | 66.6   | P         | 30 - 160       |
| EPA 8321B        | Primidone-d5       | 74.1   | P         | 30 - 160       |
| EPA 8321B        | Sucralose-d6       | 104    | P         | 30 - 160       |

Lab Sample ID: 2440570  
Field Sample ID: G3NW0208

| Reference Method | Surrogate          | % Rec. | Pass/Fail | Control Limits |
|------------------|--------------------|--------|-----------|----------------|
| EPA 8321B        | 2,4-D-d3           | 66.9   | P         | 30 - 160       |
| EPA 8321B        | Acetaminophen-d4   | 74.5   | P         | 30 - 160       |
| EPA 8321B        | Carbamazepine-d10  | 58.7   | P         | 30 - 160       |
| EPA 8321B        | Diuron-d6          | 36.8   | P         | 30 - 160       |
| EPA 8321B        | Endothall-d6       | 144    | P         | 30 - 160       |
| EPA 8321B        | Glyphosate 13C 15N | 77.5   | P         | 30 - 160       |
| EPA 8321B        | Ibuprofen-d3       | 60.9   | P         | 30 - 160       |
| EPA 8321B        | Primidone-d5       | 54.4   | P         | 30 - 160       |
| EPA 8321B        | Sucralose-d6       | 105    | P         | 30 - 160       |

Lab Sample ID: 2440571  
Field Sample ID: G3NW0142

| Reference Method | Surrogate            | % Rec. | Pass/Fail | Control Limits |
|------------------|----------------------|--------|-----------|----------------|
| EPA 8270E        | Decachlorobiphenyl   | 73.7   | P         | 37 - 129       |
| EPA 8270E        | Decachlorobiphenyl   | 80.9   | P         | 26 - 115       |
| EPA 8270E        | Tetrachloro-m-xylene | 54.2   | P         | 30 - 101       |
| EPA 8270E        | Tetrachloro-m-xylene | 50.1   | P         | 29 - 95.0      |
| EPA 8276         | Decachlorobiphenyl   | 54.2   | P         | 28 - 102       |
| EPA 8276         | PCNB                 | 93.6   | P         | 49 - 115       |

Lab Sample ID: 2440572  
Field Sample ID: G3NW0142

| Reference Method | Surrogate     | % Rec. | Pass/Fail | Control Limits |
|------------------|---------------|--------|-----------|----------------|
| EPA 8270E        | Caffeine-d9   | 59.7   | P         | 20 - 200       |
| EPA 8270E        | Simazine-d10  | 79.0   | P         | 62 - 142       |
| EPA 8270E        | Terbufos-d10  | 97.9   | P         | 58 - 132       |
| EPA 8270E        | Terphenyl-d14 | 85.0   | P         | 52 - 137       |

---

## Quality Assurance Report Surrogates

Lab Sample ID: 2440573  
Field Sample ID: FB\_09262023

| Reference Method | Surrogate     | % Rec. | Pass/Fail | Control Limits |
|------------------|---------------|--------|-----------|----------------|
| EPA 8270E        | Caffeine-d9   | 56.6   | P         | 20 - 200       |
| EPA 8270E        | Simazine-d10  | 71.9   | P         | 62 - 142       |
| EPA 8270E        | Terbufos-d10  | 83.9   | P         | 58 - 132       |
| EPA 8270E        | Terphenyl-d14 | 84.9   | P         | 52 - 137       |

## Quality Assurance Report Calibration Verification

Reference Method: EPA 8321B

Run ID: A121765

Included Lab Sample IDs: 2440569, 2440570

| Component   | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-------------|---------|---------|------------|----------------|
| AMPA        | 82.3    | 107     | P/P        | 60 - 160       |
| Endothall   | 112     | 99.0    | P/P        | 60 - 160       |
| Glufosinate | 113     | 111     | P/P        | 60 - 160       |
| Glyphosate  | 86.7    | 99.2    | P/P        | 60 - 160       |

Reference Method: DEP SOP: NU-094-1

Run ID: A121796

Included Lab Sample IDs: 2440547, 2440549, 2440550

| Component    | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|--------------|---------|---------|------------|----------------|
| Color (true) | 101     | 99.4    | P/P        | 90 - 110       |
| Color (true) | 99.0    | 99.3    | P/P        | 90 - 110       |

Reference Method: EPA 180.1 Rev. 2.0

Run ID: A121800

Included Lab Sample IDs: 2440547, 2440549, 2440550

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Turbidity | 100     | 101     | P/P        | 95 - 105       |

Reference Method: EPA 8321B

Run ID: A121824

Included Lab Sample IDs: 2440569, 2440570

| Component    | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|--------------|---------|---------|------------|----------------|
| Acesulfame K | 97.6    | 97.7    | P/P        | 60 - 160       |
| Sucralose    | 107     | 101     | P/P        | 60 - 160       |

Reference Method: EPA 8321B

Run ID: A121846

Included Lab Sample IDs: 2440568

| Component           | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|---------------------|---------|---------|------------|----------------|
| 3-Hydroxycarbofuran | 110     | 112     | P/P        | 60 - 150       |
| Aldicarb            | 103     | 114     | P/P        | 60 - 150       |
| Aldicarb Sulfone    | 116     | 119     | P/P        | 50 - 150       |
| Aldicarb Sulfoxide  | 112     | 113     | P/P        | 50 - 150       |
| Carbaryl            | 109     | 112     | P/P        | 60 - 150       |
| Carbofuran          | 116     | 116     | P/P        | 50 - 150       |
| Methiocarb          | 107     | 111     | P/P        | 50 - 150       |
| Methomyl            | 110     | 108     | P/P        | 50 - 150       |
| Oxamyl              | 117     | 114     | P/P        | 50 - 150       |
| Propoxur            | 120     | 124     | P/P        | 50 - 150       |

Reference Method: EPA 350.1 Rev. 2.0

Run ID: A121852

Included Lab Sample IDs: 2440548

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Ammonia-N | 101     | 101     | P/P        | 90 - 110       |

## Quality Assurance Report Calibration Verification

Reference Method: SM 2320 B-2011

Run ID: A121863

Included Lab Sample IDs: 2440547

| Component        | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|------------------|---------|---------|------------|----------------|
| Total Alkalinity | 94.0    | 97.1    | P/P        | 90 - 110       |

Reference Method: SM 4500-F- C-2011

Run ID: A121863

Included Lab Sample IDs: 2440547

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Fluoride  | 102     | 100     | P/P        | 90 - 110       |

Reference Method: EPA 200.7 Rev. 4.4

Run ID: A121868

Included Lab Sample IDs: 2440574

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Calcium   | 102     | 102     | P/P        | 90 - 110       |
| Iron      | 100     | 100     | P/P        | 90 - 110       |
| Magnesium | 101     | 100     | P/P        | 90 - 110       |
| Potassium | 98.9    | 99.4    | P/P        | 90 - 110       |
| Sodium    | 99.6    | 101     | P/P        | 90 - 110       |
| Strontium | 99.1    | 97.0    | P/P        | 90 - 110       |
| Tin       | 99.5    | 101     | P/P        | 90 - 110       |
| Titanium  | 98.3    | 99.1    | P/P        | 90 - 110       |
| Vanadium  | 97.9    | 98.7    | P/P        | 90 - 110       |
| Zinc      | 99.2    | 99.6    | P/P        | 90 - 110       |

Reference Method: EPA 200.8 Rev. 5.4

Run ID: A121869

Included Lab Sample IDs: 2440574

| Component  | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|------------|---------|---------|------------|----------------|
| Aluminum   | 97.9    | 93.6    | P/P        | 90 - 110       |
| Antimony   | 94.6    | 92.3    | P/P        | 90 - 110       |
| Arsenic    | 98.4    | 95.3    | P/P        | 90 - 110       |
| Barium     | 98.4    | 94.9    | P/P        | 90 - 110       |
| Beryllium  | 97.7    | 93.5    | P/P        | 90 - 110       |
| Boron      | 100     | 95.0    | P/P        | 90 - 110       |
| Cadmium    | 100     | 97.1    | P/P        | 90 - 110       |
| Chromium   | 98.6    | 95.9    | P/P        | 90 - 110       |
| Cobalt     | 97.8    | 94.4    | P/P        | 90 - 110       |
| Copper     | 96.0    | 92.3    | P/P        | 90 - 110       |
| Manganese  | 97.9    | 95.5    | P/P        | 90 - 110       |
| Molybdenum | 97.6    | 94.8    | P/P        | 90 - 110       |
| Nickel     | 96.9    | 93.2    | P/P        | 90 - 110       |
| Selenium   | 98.0    | 95.6    | P/P        | 90 - 110       |
| Silver     | 99.4    | 95.9    | P/P        | 90 - 110       |
| Thallium   | 98.9    | 95.2    | P/P        | 90 - 110       |

## Quality Assurance Report Calibration Verification

Reference Method: EPA 8270E

Run ID: A121870

Included Lab Sample IDs: 2440572, 2440573

| Component                                                | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|----------------------------------------------------------|---------|---------|------------|----------------|
| 2-(2H-benzotriazol-2-yl)-4,6-ditertpentylphenol (UV-328) | 98.9    |         | P          | 80 - 120       |
| 2-Ethylhexyl 2,3,4,5-tetrabromobenzoate (EHTBB)          | 93.1    |         | P          | 80 - 120       |
| Avobenzone                                               | 95.5    |         | P          | 80 - 120       |
| Dechlorane 602                                           | 99.1    |         | P          | 80 - 120       |
| Dechlorane 603                                           | 101     |         | P          | 80 - 120       |
| Dechlorane Plus                                          | 101     |         | P          | 80 - 120       |
| Hexabromobenzene                                         | 91.8    |         | P          | 80 - 120       |
| Octinoxate                                               | 92.1    |         | P          | 80 - 120       |
| Oxybenzone                                               | 97.4    |         | P          | 80 - 120       |
| PBB-153                                                  | 93.4    |         | P          | 80 - 120       |
| PBDE-47                                                  | 94.1    |         | P          | 80 - 120       |
| PBDE-99                                                  | 95.8    |         | P          | 80 - 120       |
| Pentabromotoluene                                        | 102     |         | P          | 80 - 120       |
| Tetradecachloro-m-terphenyl                              | 95.2    |         | P          | 80 - 120       |
| Tri-o-cresyl Phosphate                                   | 96.8    |         | P          | 80 - 120       |
| Tris(1-chloro-2-propyl) phosphate (TCPP)                 | 92.7    |         | P          | 80 - 120       |
| Tris(1,3-dichloro-2-propyl) phosphate (TDCPP)            | 97.9    |         | P          | 80 - 120       |
| Tris(2-chloroethyl) phosphate (TCEP)                     | 94.9    |         | P          | 80 - 120       |

Reference Method: EPA 365.1 Rev. 2.0

Run ID: A121874

Included Lab Sample IDs: 2440548

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Total-P   | 101     | 98.6    | P/P        | 90 - 110       |

Reference Method: EPA 200.8 Rev. 5.4

Run ID: A121884

Included Lab Sample IDs: 2440574

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Lead      | 95.5    | 94.9    | P/P        | 90 - 110       |

Reference Method: EPA 350.1 Rev. 2.0

Run ID: A121885

Included Lab Sample IDs: 2440551, 2440552

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Ammonia-N | 100     | 103     | P/P        | 90 - 110       |

Reference Method: EPA 8321B

Run ID: A121893

Included Lab Sample IDs: 2440569, 2440570

| Component        | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|------------------|---------|---------|------------|----------------|
| 2,4-D            | 70.5    | 79.0    | P/P        | 50 - 150       |
| 2,4,5-T          | 76.4    | 83.6    | P/P        | 50 - 150       |
| Acetaminophen    | 111     | 110     | P/P        | 60 - 160       |
| Acetamiprid      | 114     | 112     | P/P        | 50 - 150       |
| Bentazon         | 121     | 123     | P/P        | 50 - 160       |
| Benzovindiflupyr | 77.6    | 75.9    | P/P        | 50 - 150       |

## Quality Assurance Report Calibration Verification

Reference Method: EPA 8321B

Run ID: A121893

Included Lab Sample IDs: 2440569, 2440570

| Component      | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|----------------|---------|---------|------------|----------------|
| Carbamazepine  | 76.3    | 74.9    | P/P        | 60 - 150       |
| Clothianidin   | 118     | 120     | P/P        | 60 - 150       |
| Dinotefuran    | 117     | 116     | P/P        | 50 - 150       |
| Diuron         | 67.7    | 63.0    | P/P        | 60 - 160       |
| Fenuron        | 105     | 105     | P/P        | 60 - 150       |
| Fluridone      | 76.3    | 73.4    | P/P        | 60 - 160       |
| Hydrocodone    | 117     | 116     | P/P        | 60 - 150       |
| Ibuprofen      | 96.1    | 67.7    | P/P        | 50 - 160       |
| Imazapyr       | 107     | 98.8    | P/P        | 50 - 150       |
| Imidacloprid   | 111     | 107     | P/P        | 60 - 150       |
| Linuron        | 79.1    | 76.1    | P/P        | 60 - 150       |
| Mandestrobin   | 77.5    | 82.8    | P/P        | 50 - 150       |
| MCPP           | 74.0    | 81.3    | P/P        | 50 - 150       |
| Naproxen       | 115     | 80.2    | P/P        | 50 - 160       |
| Primidone      | 106     | 102     | P/P        | 60 - 150       |
| Pyraclostrobin | 82.3    | 86.3    | P/P        | 60 - 150       |
| Silvex         | 67.9    | 70.1    | P/P        | 50 - 150       |
| Thiamethoxam   | 119     | 115     | P/P        | 50 - 150       |
| Tolfenpyrad    | 68.6    | 68.2    | P/P        | 60 - 150       |
| Triclopyr      | 88.7    | 80.6    | P/P        | 50 - 150       |

Reference Method: SM 5310 B-2011

Run ID: A121902

Included Lab Sample IDs: 2440548

| Component      | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|----------------|---------|---------|------------|----------------|
| Organic Carbon | 93.3    | 95.4    | P/P        | 90 - 110       |

Reference Method: EPA 8270E

Run ID: A121906

Included Lab Sample IDs: 2440572, 2440573

| Component           | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|---------------------|---------|---------|------------|----------------|
| Acetochlor          | 94.3    |         | P          | 80 - 120       |
| Alachlor            | 96.7    |         | P          | 80 - 120       |
| Ametryn             | 99.2    |         | P          | 80 - 120       |
| Atrazine            | 96.1    |         | P          | 80 - 120       |
| Atrazine Desethyl   | 114     |         | P          | 80 - 120       |
| Azinphos Methyl     | 106     |         | P          | 80 - 120       |
| Azoxystrobin        | 97.8    |         | P          | 80 - 120       |
| Bromacil            | 93.3    |         | P          | 80 - 120       |
| Butylate            | 98.7    |         | P          | 80 - 120       |
| Caffeine            | 105     |         | P          | 80 - 120       |
| Carbophenothion     | 104     |         | P          | 80 - 120       |
| Carfentrazone Ethyl | 97.5    |         | P          | 80 - 120       |
| Chlorfenapyr        | 85.4    |         | P          | 80 - 120       |
| Chlorpyrifos Ethyl  | 89.1    |         | P          | 80 - 120       |
| Chlorpyrifos Methyl | 99.5    |         | P          | 80 - 120       |
| Coumaphos           | 93.4    |         | P          | 80 - 120       |
| Cyanazine           | 99.1    |         | P          | 80 - 120       |
| Cyprodinil          | 104     |         | P          | 80 - 120       |

## Quality Assurance Report Calibration Verification

Reference Method: EPA 8270E

Run ID: A121906

Included Lab Sample IDs: 2440572, 2440573

| Component           | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|---------------------|---------|---------|------------|----------------|
| Demeton             | 102     |         | P          | 80 - 120       |
| Diazinon            | 104     |         | P          | 80 - 120       |
| Difenoconazole      | 92.0    |         | P          | 80 - 120       |
| Dimethenamid        | 101     |         | P          | 80 - 120       |
| Dimethomorph        | 97.2    |         | P          | 80 - 120       |
| Disulfoton          | 104     |         | P          | 80 - 120       |
| Dithiopyr           | 103     |         | P          | 80 - 120       |
| EPTC                | 99.1    |         | P          | 80 - 120       |
| Ethion              | 89.5    |         | P          | 80 - 120       |
| Ethoprop            | 104     |         | P          | 80 - 120       |
| Etridiazole         | 102     |         | P          | 80 - 120       |
| Fenamiphos          | 97.7    |         | P          | 80 - 120       |
| Fenbuconazole       | 87.2    |         | P          | 80 - 120       |
| Fipronil            | 96.7    |         | P          | 80 - 120       |
| Fipronil Desulfinyl | 100     |         | P          | 80 - 120       |
| Fipronil Sulfide    | 103     |         | P          | 80 - 120       |
| Fipronil Sulfone    | 102     |         | P          | 80 - 120       |
| Fluazifop-P-butyl   | 101     |         | P          | 80 - 120       |
| Fludioxonil         | 87.7    |         | P          | 80 - 120       |
| Flumioxazin         | 94.6    |         | P          | 80 - 120       |
| Flutolanil          | 101     |         | P          | 80 - 120       |
| Fluxapyroxad        | 97.8    |         | P          | 80 - 120       |
| Fonofos             | 96.3    |         | P          | 80 - 120       |
| Hexazinone          | 100     |         | P          | 80 - 120       |
| Imazalil            | 111     |         | P          | 80 - 120       |
| Iprodione           | 78.7*   |         | F          | 80 - 120       |
| Loratadine          | 86.1    |         | P          | 80 - 120       |
| Malathion           | 80.2    |         | P          | 80 - 120       |
| Metaxyl             | 88.5    |         | P          | 80 - 120       |
| Metolachlor         | 104     |         | P          | 80 - 120       |
| Metribuzin          | 97.6    |         | P          | 80 - 120       |
| Mevinphos           | 92.4    |         | P          | 80 - 120       |
| Molinate            | 89.0    |         | P          | 80 - 120       |
| Myclobutanil        | 92.5    |         | P          | 80 - 120       |
| Naled               | 105     |         | P          | 80 - 120       |
| Napropamide         | 98.9    |         | P          | 80 - 120       |
| Norflurazon         | 102     |         | P          | 80 - 120       |
| Oxadiazon           | 103     |         | P          | 80 - 120       |
| Oxyfluorfen         | 99.5    |         | P          | 80 - 120       |
| Parathion Ethyl     | 103     |         | P          | 80 - 120       |
| Parathion Methyl    | 92.0    |         | P          | 80 - 120       |
| Pendimethalin       | 108     |         | P          | 80 - 120       |
| Phenytol            | 95.6    |         | P          | 80 - 120       |
| Phorate             | 99.7    |         | P          | 80 - 120       |
| Prodiamine          | 101     |         | P          | 80 - 120       |
| Prometon            | 105     |         | P          | 80 - 120       |
| Prometryn           | 104     |         | P          | 80 - 120       |
| Pronamide           | 101     |         | P          | 80 - 120       |
| Propanil            | 87.1    |         | P          | 80 - 120       |
| Propargite          | 107     |         | P          | 80 - 120       |
| Propiconazole       | 85.9    |         | P          | 80 - 120       |

## Quality Assurance Report Calibration Verification

Reference Method: EPA 8270E

Run ID: A121906

Included Lab Sample IDs: 2440572, 2440573

| Component        | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|------------------|---------|---------|------------|----------------|
| Pyraflufen Ethyl | 105     |         | P          | 80 - 120       |
| Pyridaben        | 102     |         | P          | 80 - 120       |
| Pyriproxyfen     | 174*    |         | F          | 80 - 120       |
| Simazine         | 101     |         | P          | 80 - 120       |
| Stirophos        | 84.0    |         | P          | 80 - 120       |
| Sulfentrazone    | 87.3    |         | P          | 80 - 120       |
| Tebuconazole     | 97.9    |         | P          | 80 - 120       |
| Terbufos         | 94.9    |         | P          | 80 - 120       |
| Terbuthylazine   | 95.4    |         | P          | 80 - 120       |
| Thiobencarb      | 104     |         | P          | 80 - 120       |
| Triadimefon      | 100     |         | P          | 80 - 120       |

Reference Method: SM 2320 B-2011

Run ID: A121914

Included Lab Sample IDs: 2440549, 2440550

| Component        | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|------------------|---------|---------|------------|----------------|
| Total Alkalinity | 94.7    | 95.6    | P/P        | 90 - 110       |

Reference Method: SM 4500-F- C-2011

Run ID: A121914

Included Lab Sample IDs: 2440550

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Fluoride  | 104     | 105     | P/P        | 90 - 110       |

Reference Method: EPA 8321B

Run ID: A121918

Included Lab Sample IDs: 2440569, 2440570

| Component    | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|--------------|---------|---------|------------|----------------|
| Afidopyropen | 80.5    | 67.8    | P/P        | 50 - 150       |

Reference Method: EPA 351.2 Rev. 2.0

Run ID: A121940

Included Lab Sample IDs: 2440548, 2440551, 2440552

| Component         | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-------------------|---------|---------|------------|----------------|
| Kjeldahl Nitrogen | 95.5    | 96.1    | P/P        | 90 - 110       |
| Kjeldahl Nitrogen | 95.8    | 101     | P/P        | 90 - 110       |

Reference Method: EPA 365.1 Rev. 2.0

Run ID: A121943

Included Lab Sample IDs: 2440551, 2440552

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Total-P   | 100     | 99.5    | P/P        | 90 - 110       |

## Quality Assurance Report Calibration Verification

Reference Method: EPA 300.0 Rev. 2.1

Run ID: A121948

Included Lab Sample IDs: 2440547, 2440549, 2440550

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Chloride  | 103     | 102     | P/P        | 90 - 110       |
| Sulfate   | 104     | 103     | P/P        | 90 - 110       |

Reference Method: SM 5310 B-2011

Run ID: A121969

Included Lab Sample IDs: 2440551, 2440552

| Component      | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|----------------|---------|---------|------------|----------------|
| Organic Carbon | 95.8    | 91.9    | P/P        | 90 - 110       |

Reference Method: EPA 8270E

Run ID: A121970

Included Lab Sample IDs: 2440571

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| PCB-1016  | 93.4    |         | P          | 80 - 120       |
| PCB-1260  | 93.6    |         | P          | 80 - 120       |

Reference Method: SM 4500-F- C-2011

Run ID: A121975

Included Lab Sample IDs: 2440549

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Fluoride  | 102     | 101     | P/P        | 90 - 110       |

Reference Method: EPA 353.2 Rev. 2.0

Run ID: A122012

Included Lab Sample IDs: 2440551

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| NO2NO3-N  | 99.0    | 99.0    | P/P        | 90 - 110       |

Reference Method: EPA 353.2 Rev. 2.0

Run ID: A122029

Included Lab Sample IDs: 2440552

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| NO2NO3-N  | 101     | 99.5    | P/P        | 90 - 110       |

Reference Method: EPA 8270E

Run ID: A122040

Included Lab Sample IDs: 2440571

| Component       | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------------|---------|---------|------------|----------------|
| Aldrin          | 101     |         | P          | 80 - 120       |
| Alpha-BHC       | 96.0    |         | P          | 80 - 120       |
| Alpha-Chlordane | 81.1    |         | P          | 80 - 120       |
| Beta-BHC        | 83.8    |         | P          | 80 - 120       |
| Beta-Cyfluthrin | 93.4    |         | P          | 80 - 120       |
| Bifenthrin      | 108     |         | P          | 80 - 120       |
| Chlorothalonil  | 94.0    |         | P          | 80 - 120       |

## Quality Assurance Report Calibration Verification

Reference Method: EPA 8270E  
Run ID: A122040  
Included Lab Sample IDs: 2440571

| Component          | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|--------------------|---------|---------|------------|----------------|
| Cis-Nonachlor      | 91.2    |         | P          | 80 - 120       |
| Cypermethrin       | 87.6    |         | P          | 80 - 120       |
| Dacthal            | 98.2    |         | P          | 80 - 120       |
| DDD-p,p'           | 109     |         | P          | 80 - 120       |
| DDE-p,p'           | 107     |         | P          | 80 - 120       |
| DDT-p,p'           | 94.3    |         | P          | 80 - 120       |
| Delta-BHC          | 92.9    |         | P          | 80 - 120       |
| Deltamethrin       | 91.1    |         | P          | 80 - 120       |
| Dichlobenil        | 91.6    |         | P          | 80 - 120       |
| Dieldrin           | 113     |         | P          | 80 - 120       |
| Endosulfan I       | 81.7    |         | P          | 80 - 120       |
| Endosulfan II      | 99.2    |         | P          | 80 - 120       |
| Endosulfan Sulfate | 104     |         | P          | 80 - 120       |
| Endrin             | 110     |         | P          | 80 - 120       |
| Endrin Aldehyde    | 104     |         | P          | 80 - 120       |
| Endrin Ketone      | 99.5    |         | P          | 80 - 120       |
| Esfenvalerate      | 89.7    |         | P          | 80 - 120       |
| Ethalfuralin       | 96.7    |         | P          | 80 - 120       |
| Fenpropathrin      | 102     |         | P          | 80 - 120       |
| Gamma-BHC          | 84.0    |         | P          | 80 - 120       |
| Gamma-Chlordane    | 82.2    |         | P          | 80 - 120       |
| Heptachlor         | 110     |         | P          | 80 - 120       |
| Heptachlor Epoxide | 85.8    |         | P          | 80 - 120       |
| Hexachlorobenzene  | 87.2    |         | P          | 80 - 120       |
| Kepone             | 92.9    |         | P          | 80 - 120       |
| Lambda-Cyhalothrin | 93.7    |         | P          | 80 - 120       |
| Methoprene         | 96.2    |         | P          | 80 - 120       |
| MGK-264            | 96.1    |         | P          | 80 - 120       |
| Mirex              | 104     |         | P          | 80 - 120       |
| Oxychlordane       | 84.8    |         | P          | 80 - 120       |
| Permethrin         | 101     |         | P          | 80 - 120       |
| Phenothrin         | 90.2    |         | P          | 80 - 120       |
| Piperonyl Butoxide | 92.5    |         | P          | 80 - 120       |
| Prallethrin        | 92.9    |         | P          | 80 - 120       |
| Tau-Fluvalinate    | 92.6    |         | P          | 80 - 120       |
| Tetramethrin       | 97.6    |         | P          | 80 - 120       |
| Trans-Nonachlor    | 87.9    |         | P          | 80 - 120       |
| Triclosan Methyl   | 107     |         | P          | 80 - 120       |
| Trifluralin        | 103     |         | P          | 80 - 120       |

Reference Method: EPA 8270E  
Run ID: A122041  
Included Lab Sample IDs: 2440571

| Component    | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|--------------|---------|---------|------------|----------------|
| Dicofol      | 93.7    |         | P          | 80 - 120       |
| Methoxychlor | 96.9    |         | P          | 80 - 120       |

## Quality Assurance Report Calibration Verification

Reference Method: EPA 353.2 Rev. 2.0

Run ID: A122043

Included Lab Sample IDs: 2440548

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| NO2NO3-N  | 97.5    | 98.0    | P/P        | 90 - 110       |

Reference Method: EPA 8276

Run ID: A122071

Included Lab Sample IDs: 2440571

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Chlordane | 92.3    |         | P          | 80 - 120       |
| Toxaphene | 95.2    |         | P          | 80 - 120       |

\* Pass/Fail determinations are made for each bracketing calibration verification check.

Control limits for initial calibration checks may be different from those for continuing checks, depending on method requirements.  
Where they are different, both control limits are provided.

## Quality Assurance Report Summary

| Ref. Method        | Analyte                                                      | LCS % Recovery | MS % Recovery |      |      | LCS | Precision<br>SMP | MS     |
|--------------------|--------------------------------------------------------------|----------------|---------------|------|------|-----|------------------|--------|
| DEP SOP: NU-094-1  | Color (true)                                                 | 98.8           |               |      |      |     | 0.617            |        |
|                    | Color (true)                                                 | 98.9           |               |      |      |     |                  |        |
| EPA 180.1 Rev. 2.0 | Turbidity                                                    | 105            |               |      |      |     | 2.28             |        |
| EPA 200.7 Rev. 4.4 | Calcium                                                      | 102            | 98.8          | 102  |      |     |                  | 0.768  |
|                    | Iron                                                         | 103            | 102           | 101  | 99.7 |     |                  | 1.39   |
|                    | Magnesium                                                    | 105            | 104           | 102  | 104  |     |                  | 1.24   |
|                    | Potassium                                                    | 101            | 96.4          | 98.4 | 97.4 |     |                  | 1.62   |
|                    | Sodium                                                       | 100            | 99.9          | 99.5 |      |     |                  | 1.56   |
|                    | Strontium                                                    | 99.6           | 98.1          | 99.1 | 99.2 |     |                  | 1.03   |
|                    | Tin                                                          | 106            | 101           | 103  | 102  |     |                  | 1.82   |
|                    | Titanium                                                     | 102            | 92.9          | 95.4 | 101  |     |                  | 2.02   |
|                    | Vanadium                                                     | 102            | 98.6          | 101  | 103  |     |                  | 1.97   |
|                    | Zinc                                                         | 104            | 101           | 102  | 102  |     |                  | 1.47   |
| EPA 200.8 Rev. 5.4 | Aluminum                                                     | 97.9           | 101           | 98.7 | 87.6 |     |                  | 1.14   |
|                    | Antimony                                                     | 94.0           | 98.9          | 98.1 | 93.3 |     |                  | 0.837  |
|                    | Arsenic                                                      | 98.7           | 99.1          | 99.7 | 95.2 |     |                  | 0.593  |
|                    | Barium                                                       | 98.3           | 103           | 102  | 97.3 |     |                  | 0.694  |
|                    | Beryllium                                                    | 95.3           | 94.7          | 96.1 | 88.9 |     |                  | 1.41   |
|                    | Boron                                                        | 102            | 105           | 104  | 97.6 |     |                  | 0.927  |
|                    | Cadmium                                                      | 96.3           | 103           | 101  | 97.5 |     |                  | 1.27   |
|                    | Chromium                                                     | 94.2           | 95.1          | 94.9 | 93.5 |     |                  | 0.169  |
|                    | Cobalt                                                       | 98.4           | 96.9          | 96.6 | 93.8 |     |                  | 0.341  |
|                    | Copper                                                       | 96.4           | 93.9          | 94.5 | 96.7 |     |                  | 0.540  |
|                    | Lead                                                         | 90.8           | 95.5          | 93.2 | 93.0 |     |                  | 0.281  |
|                    | Manganese                                                    | 94.1           | 95.5          | 95.7 | 92.7 |     |                  | 0.273  |
|                    | Molybdenum                                                   | 96.2           | 101           | 100  | 94.7 |     |                  | 0.601  |
|                    | Nickel                                                       | 97.9           | 94.2          | 93.7 | 94.0 |     |                  | 0.429  |
|                    | Selenium                                                     | 95.6           | 97.1          | 97.7 | 93.1 |     |                  | 0.606  |
|                    | Silver                                                       | 107            | 109           | 109  | 104  |     |                  | 0.0570 |
|                    | Thallium                                                     | 99.0           | 104           | 104  | 99.2 |     |                  | 0.278  |
| EPA 300.0 Rev. 2.1 | Chloride                                                     | 105            | 105           | 104  |      |     | 0.376            |        |
|                    | Sulfate                                                      | 107            | 103           | 103  |      |     | 0.189            |        |
| EPA 350.1 Rev. 2.0 | Ammonia-N                                                    | 103            | 98.4          | 99.6 |      |     |                  | 1.15   |
|                    | Ammonia-N                                                    | 103            | 101           | 102  |      |     |                  | 0.979  |
| EPA 351.2 Rev. 2.0 | Kjeldahl Nitrogen                                            | 101            | 97.5          | 100  |      |     |                  | 1.44   |
|                    | Kjeldahl Nitrogen                                            | 95.7           | 100           | 98.2 |      |     |                  | 1.78   |
| EPA 353.2 Rev. 2.0 | NO2NO3-N                                                     | 98.0           | 98.5          | 100  |      |     |                  | 1.51   |
|                    | NO2NO3-N                                                     | 98.5           | 101           | 99.0 |      |     |                  | 1.01   |
|                    | NO2NO3-N                                                     | 97.5           | 98.5          | 100  |      |     |                  | 1.51   |
| EPA 365.1 Rev. 2.0 | Total-P                                                      | 98.9           | 100           | 101  |      |     |                  | 0.480  |
|                    | Total-P                                                      | 101            | 102           | 104  |      |     |                  | 2.28   |
| EPA 8270E          | 2-(2H-benzotriazol-2-yl)-4,6-ditertpe<br>ntylphenol (UV-328) | 63.8           | 93.3          | 81.7 |      |     |                  | 13.3   |
|                    | 2-Ethylhexyl<br>2,3,4,5-tetrabromobenzoate<br>(EHTBB)        | 98.6           | 28.5          | 22.9 |      |     |                  | 21.7   |
|                    | Acetochlor                                                   | 89.0           | 103           | 85.9 |      |     |                  | 17.6   |
|                    | Alachlor                                                     | 73.8           | 88.1          | 90.2 |      |     |                  | 2.27   |
|                    | Aldrin                                                       | 52.2           | 63.9          | 65.3 |      |     |                  | 2.25   |
|                    | Alpha-BHC                                                    | 77.4           | 96.5          | 83.3 |      |     |                  | 14.6   |
|                    | Alpha-Chlordane                                              | 88.3           | 91.1          | 76.7 |      |     |                  | 17.2   |
|                    | Ametryn                                                      | 124            | 130           | 115  |      |     |                  | 12.5   |
|                    | Atrazine                                                     | 86.0           |               |      |      |     |                  | 6.84   |
|                    | Atrazine Desethyl                                            | 81.7           | 85.7          | 70.4 |      |     |                  | 15.5   |

## Quality Assurance Report Summary

| Ref. Method | Analyte             | LCS % Recovery | MS % Recovery |      | Precision<br>SMP | MS    |
|-------------|---------------------|----------------|---------------|------|------------------|-------|
|             |                     |                | LCS           |      |                  |       |
| EPA 8270E   | Avobenzene          | 101            | 83.2          | 96.1 |                  | 14.4  |
|             | Azinphos Methyl     | 95.0           | 78.6          | 92.7 |                  | 16.5  |
|             | Azoxystrobin        | 94.1           | 110           | 94.7 |                  | 14.7  |
|             | Beta-BHC            | 73.8           | 83.7          | 89.6 |                  | 6.78  |
|             | Beta-Cyfluthrin     | 77.8           | 94.0          | 105  |                  | 11.5  |
|             | Bifenthrin          | 54.3           | 71.4          | 60.2 |                  | 17.0  |
|             | Bromacil            | 92.9           | 115           | 98.8 |                  | 14.9  |
|             | Butylate            | 59.5           | 58.6          | 43.0 |                  | 30.7  |
|             | Caffeine            | 96.9           | 112           | 92.6 |                  | 18.6  |
|             | Carbophenothion     | 93.6           | 109           | 92.5 |                  | 16.2  |
|             | Carfentrazone Ethyl | 103            | 117           | 99.4 |                  | 16.0  |
|             | Chlorfenapyr        | 55.8           | 62.6          | 54.7 |                  | 13.6  |
|             | Chlorothalonil      | 107            | 11.8          | 12.1 |                  | 2.54  |
|             | Chlorpyrifos Ethyl  | 99.4           | 97.7          | 82.9 |                  | 16.4  |
|             | Chlorpyrifos Methyl | 91.4           | 91.5          | 78.9 |                  | 14.7  |
|             | Cis-Nonachlor       | 70.4           | 72.0          | 79.4 |                  | 9.80  |
|             | Coumaphos           | 83.6           | 61.4          | 56.6 |                  | 8.07  |
|             | Cyanazine           | 145            | 182           | 126  |                  | 36.5  |
|             | Cypermethrin        | 69.5           | 94.0          | 101  |                  | 7.34  |
|             | Cyprodinil          | 87.6           | 81.1          | 63.7 |                  | 21.4  |
|             | Dacthal             | 99.0           | 97.2          | 84.7 |                  | 13.7  |
|             | DDD-p,p'            | 61.9           | 59.8          | 64.8 |                  | 7.97  |
|             | DDE-p,p'            | 68.2           | 68.4          | 57.5 |                  | 17.3  |
|             | DDT-p,p'            | 56.4           | 58.6          | 61.1 |                  | 4.24  |
|             | Dechlorane 602      | 68.4           | 37.8          | 40.7 |                  | 7.57  |
|             | Dechlorane 603      | 110            | 70.5          | 75.5 |                  | 6.96  |
|             | Dechlorane Plus     | 109            | 67.6          | 73.9 |                  | 8.97  |
|             | Delta-BHC           | 103            | 150           | 117  |                  | 25.0  |
|             | Deltamethrin        | 76.9           | 119           | 118  |                  | 0.276 |
|             | Demeton             | 69.5           | 78.1          | 67.5 |                  | 14.7  |
|             | Diazinon            | 108            | 108           | 107  |                  | 1.39  |
|             | Dichlobenil         | 74.7           | 50.7          | 52.3 |                  | 3.01  |
|             | Dicofol             | 67.4           | 86.9          | 76.9 |                  | 12.3  |
|             | Dieldrin            | 74.6           | 85.4          | 72.7 |                  | 16.1  |
|             | Difenoconazole      | 63.0           | 118           | 137  |                  | 15.0  |
|             | Dimethenamid        | 76.2           | 80.6          | 69.9 |                  | 14.2  |
|             | Dimethomorph        | 183            | 227           | 241  |                  | 5.97  |
|             | Disulfoton          | 96.2           | 101           | 101  |                  | 0.528 |
|             | Dithiopyr           | 107            | 102           | 88.5 |                  | 13.7  |
|             | Endosulfan I        | 76.2           | 99.7          | 86.7 |                  | 14.0  |
|             | Endosulfan II       | 93.6           | 90.0          | 88.7 |                  | 1.45  |
|             | Endosulfan Sulfate  | 83.1           | 83.9          | 77.4 |                  | 7.99  |
|             | Endrin              | 77.6           | 89.0          | 76.2 |                  | 15.5  |
|             | Endrin Aldehyde     | 62.1           | 54.9          | 55.9 |                  | 1.87  |
|             | Endrin Ketone       | 94.7           | 96.9          | 102  |                  | 5.33  |
|             | EPTC                | 63.0           | 51.7          | 32.0 |                  | 47.0  |
|             | Esfenvalerate       | 64.6           | 106           | 99.0 |                  | 7.02  |
|             | Ethalfuralin        | 73.9           | 78.3          | 63.7 |                  | 20.6  |
|             | Ethion              | 39.1           | 44.3          | 42.5 |                  | 4.13  |
|             | Ethoprop            | 83.8           | 103           | 88.7 |                  | 15.3  |
|             | Etridiazole         | 64.1           | 66.3          | 52.5 |                  | 23.3  |
|             | Fenamiphos          | 74.1           | 63.5          | 58.1 |                  | 8.92  |
|             | Fenbuconazole       | 58.2           | 58.8          | 68.2 |                  | 14.7  |
|             | Fenpropathrin       | 71.8           | 82.5          | 75.7 |                  | 8.62  |

## Quality Assurance Report Summary

| Ref. Method | Analyte             | LCS % Recovery | MS % Recovery |      | LCS | Precision | MS    |
|-------------|---------------------|----------------|---------------|------|-----|-----------|-------|
|             |                     |                |               |      |     | SMP       |       |
| EPA 8270E   | Fipronil            | 92.9           | 82.1          | 68.2 |     |           | 18.6  |
|             | Fipronil Desulfinyl | 96.2           | 99.7          | 88.5 |     |           | 12.0  |
|             | Fipronil Sulfide    | 79.0           | 105           | 90.9 |     |           | 14.3  |
|             | Fipronil Sulfone    | 67.1           | 60.2          | 66.0 |     |           | 9.19  |
|             | Fluazifop-P-butyl   | 68.3           | 63.5          | 63.1 |     |           | 0.649 |
|             | Fludioxonil         | 62.9           | 73.8          | 63.8 |     |           | 14.5  |
|             | Flumioxazin         | 96.8           | 136           | 166  |     |           | 19.7  |
|             | Flutolanil          | 66.0           | 71.4          | 67.7 |     |           | 5.26  |
|             | Fluxapyroxad        | 73.2           | 88.1          | 74.8 |     |           | 16.4  |
|             | Fonofos             | 89.8           | 90.8          | 86.5 |     |           | 4.88  |
|             | Gamma-BHC           | 79.0           | 119           | 88.7 |     |           | 29.3  |
|             | Gamma-Chlordane     | 73.4           | 90.6          | 71.9 |     |           | 23.0  |
|             | Heptachlor          | 56.5           | 85.0          | 67.2 |     |           | 23.4  |
|             | Heptachlor Epoxide  | 74.6           | 94.2          | 70.6 |     |           | 28.6  |
|             | Hexabromobenzene    | 99.8           | 83.1          | 82.9 |     |           | 0.301 |
|             | Hexachlorobenzene   | 78.3           | 73.0          | 66.5 |     |           | 9.29  |
|             | Hexazinone          | 81.8           | 101           | 79.1 |     |           | 24.0  |
|             | Imazalil            | 89.0           | 121           | 104  |     |           | 15.2  |
|             | Iprodione           | 54.0           | 75.2          | 61.7 |     |           | 19.8  |
|             | Kepone              | 140            | 119           | 116  |     |           | 3.04  |
|             | Lambda-Cyhalothrin  | 56.8           | 96.9          | 107  |     |           | 9.76  |
|             | Loratadine          | 124            | 167           | 181  |     |           | 8.44  |
|             | Malathion           | 104            | 120           | 91.0 |     |           | 27.1  |
|             | Metalaxyl           | 88.0           | 96.4          | 81.5 |     |           | 16.7  |
|             | Methoprene          | 48.4           | 50.1          | 53.5 |     |           | 6.67  |
|             | Methoxychlor        | 74.2           | 115           | 97.9 |     |           | 15.8  |
|             | Metolachlor         | 99.1           | 105           | 82.3 |     |           | 21.1  |
|             | Metribuzin          | 41.7           | 68.8          | 62.6 |     |           | 9.46  |
|             | Mevinphos           | 72.7           | 82.2          | 74.2 |     |           | 10.3  |
|             | MGK-264             | 60.6           | 64.3          | 63.9 |     |           | 0.739 |
|             | Mirex               | 64.9           | 73.5          | 71.6 |     |           | 2.68  |
|             | Molinate            | 58.8           | 55.8          | 49.9 |     |           | 11.2  |
|             | Myclobutanil        | 67.1           | 78.7          | 65.3 |     |           | 18.7  |
|             | Naled               | 43.0           | 33.8          | 33.9 |     |           | 0.251 |
|             | Napropamide         | 81.2           | 90.8          | 78.5 |     |           | 14.6  |
|             | Norflurazon         | 76.5           | 75.9          | 74.5 |     |           | 1.84  |
|             | Octinoxate          | 102            | 91.1          | 89.0 |     |           | 2.34  |
|             | Oxadiazon           | 72.4           | 89.8          | 74.4 |     |           | 18.8  |
|             | Oxybenzone          | 107            | 97.8          | 100  |     |           | 2.69  |
|             | Oxychlordane        | 70.1           | 81.6          | 66.7 |     |           | 20.1  |
|             | Oxyfluorfen         | 77.5           | 90.7          | 69.0 |     |           | 27.2  |
|             | Parathion Ethyl     | 89.6           | 105           | 87.3 |     |           | 18.3  |
|             | Parathion Methyl    | 99.1           | 108           | 97.9 |     |           | 9.54  |
|             | PBB-153             | 106            | 33.2          | 35.2 |     |           | 5.91  |
|             | PBDE-47             | 89.0           | 78.0          | 78.6 |     |           | 0.774 |
|             | PBDE-99             | 76.5           | 22.9          | 25.1 |     |           | 9.23  |
|             | PCB-1016            | 77.3           | 78.1          | 85.7 |     |           | 9.27  |
|             | PCB-1260            | 89.1           | 78.4          | 88.8 |     |           | 12.5  |
|             | Pendimethalin       | 74.2           | 85.9          | 75.0 |     |           | 13.6  |
|             | Pentabromotoluene   | 96.5           | 86.2          | 84.1 |     |           | 2.50  |
|             | Permethrin          | 73.3           | 80.1          | 99.1 |     |           | 21.2  |
|             | Phenothrin          | 55.1           | 71.6          | 103  |     |           | 36.3  |
|             | Phenytoln           | 28.0           | 54.4          | 44.5 |     |           | 20.0  |
|             | Phorate             | 97.4           | 116           | 116  |     |           | 0.602 |

## Quality Assurance Report Summary

| Ref. Method | Analyte                                       | LCS % Recovery | MS % Recovery |      | LCS | Precision | MS    |
|-------------|-----------------------------------------------|----------------|---------------|------|-----|-----------|-------|
|             |                                               |                |               |      |     | SMP       |       |
| EPA 8270E   | Piperonyl Butoxide                            | 81.5           | 86.4          | 78.1 |     |           | 10.1  |
|             | Prallethrin                                   | 71.7           | 80.3          | 82.0 |     |           | 2.10  |
|             | Prodiamine                                    | 48.9           | 49.5          | 35.1 |     |           | 34.2  |
|             | Prometon                                      | 106            | 110           | 96.6 |     |           | 12.7  |
|             | Prometryn                                     | 99.6           | 104           | 95.5 |     |           | 8.18  |
|             | Pronamide                                     | 101            | 118           | 95.6 |     |           | 21.2  |
|             | Propanil                                      | 93.8           | 110           | 89.2 |     |           | 21.1  |
|             | Propargite                                    | 59.9           | 60.8          | 50.0 |     |           | 19.4  |
|             | Propiconazole                                 | 72.9           | 73.4          | 80.4 |     |           | 9.03  |
|             | Pyraflufen Ethyl                              | 89.9           | 73.6          | 81.8 |     |           | 10.5  |
|             | Pyridaben                                     | 86.9           | 50.8          | 51.4 |     |           | 1.15  |
|             | Pyriproxyfen                                  | 125            | 92.3          | 113  |     |           | 19.8  |
|             | Simazine                                      | 82.1           | 80.3          | 60.5 |     |           | 24.6  |
|             | Stiropfos                                     | 46.6           | 47.3          | 44.8 |     |           | 5.50  |
|             | Sulfentrazone                                 | 39.8           | 77.7          | 62.0 |     |           | 22.6  |
|             | Tau-Fluvalinate                               | 68.8           | 103           | 100  |     |           | 2.18  |
|             | Tebuconazole                                  | 47.6           | 56.2          | 50.6 |     |           | 10.6  |
|             | Terbufos                                      | 110            | 124           | 115  |     |           | 7.49  |
|             | Terbutylazine                                 | 82.6           | 91.9          | 84.6 |     |           | 8.21  |
|             | Tetradecachloro-m-terphenyl                   | 126            | 74.0          | 74.2 |     |           | 0.349 |
|             | Tetramethrin                                  | 65.5           | 84.7          | 93.5 |     |           | 9.88  |
|             | Thiobencarb                                   | 90.2           | 95.0          | 79.7 |     |           | 17.6  |
|             | Trans-Nonachlor                               | 71.0           | 96.9          | 75.3 |     |           | 25.1  |
|             | Tri-o-cresyl Phosphate                        | 101            | 94.8          | 94.1 |     |           | 0.742 |
|             | Triadimefon                                   | 85.4           | 98.5          | 75.8 |     |           | 26.0  |
|             | Triclosan Methyl                              | 66.1           | 79.0          | 79.6 |     |           | 0.814 |
|             | Trifluralin                                   | 69.8           | 74.0          | 70.2 |     |           | 5.26  |
|             | Tris(1-chloro-2-propyl) phosphate (TCPP)      | 106            | 104           | 103  |     |           | 1.19  |
|             | Tris(1,3-dichloro-2-propyl) phosphate (TDCPP) | 97.4           | 97.9          | 93.5 |     |           | 4.55  |
|             | Tris(2-chloroethyl) phosphate (TCEP)          | 108            | 106           | 102  |     |           | 4.23  |
| EPA 8276    | Chlordane                                     | 92.2           | 72.0          | 67.8 |     |           | 5.59  |
|             | Toxaphene                                     | 99.8           | 82.9          | 76.9 |     |           | 7.50  |
| EPA 8321B   | 2,4-D                                         | 84.3           |               |      |     |           | 3.83  |
|             | 2,4,5-T                                       | 119            | 93.3          | 86.5 |     |           | 7.48  |
|             | 3-Hydroxycarbofuran                           | 82.1           | 57.3          | 53.6 |     |           | 6.67  |
|             | Acesulfame K                                  | 95.9           | 88.0          | 87.9 |     |           | 0.157 |
|             | Acetaminophen                                 | 98.9           | 116           | 111  |     |           | 5.12  |
|             | Acetamiprid                                   | 92.1           | 65.1          | 66.9 |     |           | 2.84  |
|             | Afidopyropen                                  | 48.0           | 51.3          | 57.3 |     |           | 11.1  |
|             | Aldicarb                                      | 42.4           | 35.7          | 33.6 |     |           | 6.27  |
|             | Aldicarb Sulfone                              | 100            | 55.7          | 54.4 |     |           | 2.40  |
|             | Aldicarb Sulfoxide                            | 131            | 27.5          | 26.1 |     |           | 5.21  |
|             | AMPA                                          | 76.6           | 64.6          | 64.3 |     |           | 0.354 |
|             | Bentazon                                      | 93.0           | 37.7          | 37.6 |     |           | 0.151 |
|             | Benzovindiflupyr                              | 91.2           | 83.3          | 80.2 |     |           | 3.79  |
|             | Carbamazepine                                 | 95.8           | 67.4          | 65.1 |     |           | 3.44  |
|             | Carbaryl                                      | 79.5           | 57.8          | 54.7 |     |           | 5.60  |
|             | Carbofuran                                    | 85.6           | 50.6          | 46.7 |     |           | 7.84  |
|             | Clothianidin                                  | 110            | 83.2          | 79.4 |     |           | 4.66  |
|             | Dinotefuran                                   | 116            | 95.6          | 87.5 |     |           | 8.80  |
|             | Diuron                                        | 90.0           | 56.3          | 56.0 |     |           | 0.585 |

## Quality Assurance Report Summary

| Ref. Method       | Analyte          | LCS % Recovery | MS % Recovery |      | Precision |       |
|-------------------|------------------|----------------|---------------|------|-----------|-------|
|                   |                  |                |               |      | LCS       | MS    |
| EPA 8321B         | Endothall        | 99.7           | 155           | 156  |           | 0.668 |
|                   | Fenuron          | 98.1           | 57.0          | 55.5 |           | 2.57  |
|                   | Fluridone        | 79.7           | 44.9          | 39.9 |           | 11.8  |
|                   | Glufosinate      | 126            | 119           | 108  |           | 9.58  |
|                   | Glyphosate       | 72.5           | 115           | 96.5 |           | 17.4  |
|                   | Hydrocodone      | 97.7           | 59.4          | 55.5 |           | 6.74  |
|                   | Ibuprofen        | 74.8           | 50.8          | 60.8 |           | 17.9  |
|                   | Imazapyr         | 98.0           |               |      |           | 0.792 |
|                   | Imidacloprid     | 96.6           | 116           | 108  |           | 6.34  |
|                   | Linuron          | 71.1           | 50.8          | 46.9 |           | 8.07  |
|                   | Mandestrobin     | 90.9           | 69.7          | 66.7 |           | 4.45  |
|                   | MCPP             | 110            | 91.5          | 85.3 |           | 7.06  |
|                   | Methiocarb       | 64.8           | 56.3          | 52.7 |           | 6.64  |
|                   | Methomyl         | 89.5           | 50.9          | 48.9 |           | 4.00  |
|                   | Naproxen         | 70.8           | 55.5          | 60.3 |           | 8.29  |
|                   | Oxamyl           | 100            | 52.0          | 50.6 |           | 2.59  |
|                   | Primidone        | 97.3           | 75.1          | 68.6 |           | 8.95  |
|                   | Propoxur         | 90.0           | 47.3          | 45.7 |           | 3.36  |
|                   | Pyraclostrobin   | 88.9           | 81.2          | 77.0 |           | 5.32  |
|                   | Silvex           | 85.4           | 83.1          | 72.3 |           | 13.8  |
|                   | Sucralose        | 99.3           | 96.9          | 108  |           | 10.5  |
|                   | Thiamethoxam     | 108            | 82.7          | 78.2 |           | 5.57  |
|                   | Tolfenpyrad      | 59.2           | 60.0          | 61.2 |           | 2.01  |
|                   | Triclopyr        | 114            | 99.1          | 93.7 |           | 5.61  |
| SM 2320 B-2011    | Total Alkalinity | 96.4           |               |      | 0.815     |       |
|                   | Total Alkalinity | 97.1           |               |      | 2.67      |       |
| SM 2540 C-2015    | TDS              | 94.8           |               |      | 1.94      |       |
|                   | TDS              | 94.4           |               |      | 5.41      |       |
| SM 2540 D-2015    | TSS              | 94.6           |               |      |           |       |
|                   | TSS              | 97.5           |               |      | 3.28      |       |
| SM 4500-F- C-2011 | Fluoride         | 99.3           | 104           | 103  |           | 0.963 |
|                   | Fluoride         | 105            | 103           | 103  |           | 0.0   |
|                   | Fluoride         | 101            | 101           | 101  |           | 0.506 |
| SM 5310 B-2011    | Organic Carbon   | 96.0           | 97.2          | 97.7 |           | 0.311 |
|                   | Organic Carbon   | 98.1           | 96.5          | 95.7 |           | 0.648 |

## Reference Method Descriptions

| Method             | Description                                                                                                               | Associated Samples        |
|--------------------|---------------------------------------------------------------------------------------------------------------------------|---------------------------|
| DEP SOP: NU-094-1  | True Color measured at 450 nm (not valid for NPDES monitoring)                                                            | 2440547, 2440549, 2440550 |
| EPA 180.1 Rev. 2.0 | Turbidity in aqueous matrices                                                                                             | 2440547, 2440549, 2440550 |
| EPA 200.7 Rev. 4.4 | Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects | 2440574                   |
| EPA 200.8 Rev. 5.4 | Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects                    | 2440574                   |
| EPA 300.0 Rev. 2.1 | Chloride in aqueous matrices                                                                                              | 2440547, 2440549, 2440550 |
| EPA 300.0 Rev. 2.1 | Sulfate in aqueous matrices                                                                                               | 2440547, 2440549, 2440550 |
| EPA 350.1 Rev. 2.0 | Ammonia in aqueous matrices as mg N/L                                                                                     | 2440548, 2440551, 2440552 |
| EPA 351.2 Rev. 2.0 | Total Kjeldahl Nitrogen in aqueous matrices                                                                               | 2440548, 2440551, 2440552 |
| EPA 353.2 Rev. 2.0 | Nitrite/Nitrate in aqueous matrices as mg N/L                                                                             | 2440548, 2440551, 2440552 |
| EPA 365.1 Rev. 2.0 | Total Phosphorus in aqueous matrices as mg P/L                                                                            | 2440548, 2440551, 2440552 |
| EPA 8270E          | Analysis of Sunscreen Compounds and Flame Retardants in Water by GC/MS-SIM                                                | 2440572, 2440573          |
| EPA 8270E          | Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS/MS                                          | 2440571                   |

## Reference Method Descriptions

| Method            | Description                                                                          | Associated Samples        |
|-------------------|--------------------------------------------------------------------------------------|---------------------------|
| EPA 8270E         | Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS               | 2440572, 2440573          |
| EPA 8270E         | PCBs in water matrices by GC/MS/MS                                                   | 2440571                   |
| EPA 8276          | Chlordane and Toxaphene in water matrices by GC/MS with Negative Chemical Ionization | 2440571                   |
| EPA 8321B         | Carbamates in water matrices by HPLC/MS/MS                                           | 2440568                   |
| EPA 8321B         | Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS          | 2440569, 2440570          |
| SM 2320 B-2011    | Alkalinity in aqueous matrices as mg CaCO <sub>3</sub> /L                            | 2440547, 2440549, 2440550 |
| SM 2340 B-2011    | Hardness by calculation, in aqueous matrices, reported as mg/L CaCO <sub>3</sub>     | 2440574                   |
| SM 2540 C-2015    | Total Dissolved Solids in aqueous matrices                                           | 2440547, 2440549, 2440550 |
| SM 2540 D-2015    | Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample       | 2440547, 2440549, 2440550 |
| SM 4500-F- C-2011 | Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)  | 2440547, 2440549, 2440550 |
| SM 5310 B-2011    | Nonpurgeable Organic Carbon in aqueous matrices                                      | 2440548, 2440551, 2440552 |

## Preparation and Analysis Log

| Ref. Method        | Received Date | Prep Date/Time   | Prepared By        | Analysis Date/Time | Analyzed By        | Associated Samples |
|--------------------|---------------|------------------|--------------------|--------------------|--------------------|--------------------|
| DEP SOP: NU-094-1  | 09/27/2023    |                  |                    | 09/27/2023 15:27   | Alexis Price       | 2440547            |
|                    | 09/27/2023    |                  |                    | 09/27/2023 15:28   | Alexis Price       | 2440550            |
|                    | 09/27/2023    |                  |                    | 09/27/2023 15:48   | Alexis Price       | 2440549            |
| EPA 180.1 Rev. 2.0 | 09/27/2023    |                  |                    | 09/27/2023 13:47   | Alexis Price       | 2440547            |
|                    | 09/27/2023    |                  |                    | 09/27/2023 13:48   | Alexis Price       | 2440549, 2440550   |
| EPA 200.7 Rev. 4.4 | 09/27/2023    | 09/28/2023 13:30 | George D Taylor    | 09/29/2023 15:05   | McKinley C Carter  | 2440574            |
| EPA 200.8 Rev. 5.4 | 09/27/2023    | 09/28/2023 13:30 | George D Taylor    | 09/29/2023 17:43   | Conrad Hartmann    | 2440574            |
|                    | 09/27/2023    | 09/28/2023 13:30 | George D Taylor    | 10/02/2023 14:29   | Conrad Hartmann    | 2440574            |
| EPA 300.0 Rev. 2.1 | 09/27/2023    |                  |                    | 10/05/2023 00:02   | James L Waggeberby | 2440547            |
|                    | 09/27/2023    |                  |                    | 10/05/2023 00:17   | James L Waggeberby | 2440549            |
|                    | 09/27/2023    |                  |                    | 10/05/2023 00:32   | James L Waggeberby | 2440550            |
| EPA 350.1 Rev. 2.0 | 09/27/2023    |                  |                    | 09/29/2023 11:54   | Khloe J Berg       | 2440548            |
|                    | 09/27/2023    |                  |                    | 10/02/2023 13:53   | Ping Hua           | 2440551            |
|                    | 09/27/2023    |                  |                    | 10/02/2023 13:55   | Ping Hua           | 2440552            |
| EPA 351.2 Rev. 2.0 | 09/27/2023    | 10/03/2023 09:32 | Samantha L Bates   | 10/04/2023 09:45   | Samantha L Bates   | 2440548            |
|                    | 09/27/2023    | 10/03/2023 09:32 | Samantha L Bates   | 10/04/2023 10:08   | Samantha L Bates   | 2440551            |
|                    | 09/27/2023    | 10/03/2023 09:32 | Samantha L Bates   | 10/04/2023 10:09   | Samantha L Bates   | 2440552            |
| EPA 353.2 Rev. 2.0 | 09/27/2023    |                  |                    | 10/06/2023 12:23   | Fadila Guebre      | 2440551            |
|                    | 09/27/2023    |                  |                    | 10/09/2023 13:22   | Fadila Guebre      | 2440552            |
|                    | 09/27/2023    |                  |                    | 10/09/2023 14:22   | Anna M. Plaviak    | 2440548            |
| EPA 365.1 Rev. 2.0 | 09/27/2023    | 09/29/2023 10:00 | Simonne.V. Calhoun | 09/29/2023 14:31   | Chandler E Cox     | 2440548            |
|                    | 09/27/2023    | 09/29/2023 10:00 | Simonne.V. Calhoun | 10/04/2023 10:32   | Chandler E Cox     | 2440551            |
|                    | 09/27/2023    | 09/29/2023 10:00 | Simonne.V. Calhoun | 10/04/2023 10:38   | Chandler E Cox     | 2440552            |
| EPA 8270E          | 09/27/2023    | 09/28/2023 08:00 | Fe-Val Siddell     | 09/29/2023 20:19   | Vandana T. Nagar   | 2440572            |
|                    | 09/27/2023    | 09/28/2023 08:00 | Fe-Val Siddell     | 09/29/2023 20:46   | Vandana T. Nagar   | 2440573            |
|                    | 09/27/2023    | 09/28/2023 08:00 | Fe-Val Siddell     | 09/30/2023 23:41   | Arthur Maknenko    | 2440572            |
|                    | 09/27/2023    | 09/28/2023 08:00 | Fe-Val Siddell     | 10/01/2023 00:07   | Arthur Maknenko    | 2440573            |
|                    | 09/27/2023    | 10/02/2023 08:00 | Fe-Val Siddell     | 10/04/2023 02:04   | Julie Wi           | 2440571            |
|                    | 09/27/2023    | 10/02/2023 08:00 | Fe-Val Siddell     | 10/04/2023 03:19   | Julie Wi           | 2440571            |
|                    | 09/27/2023    | 10/02/2023 08:00 | Fe-Val Siddell     | 10/05/2023 05:03   | Julie Wi           | 2440571            |
|                    | 09/27/2023    | 10/02/2023 08:00 | Fe-Val Siddell     | 10/06/2023 10:33   | Arthur Maknenko    | 2440571            |
| EPA 8276           | 09/27/2023    | 10/02/2023 08:00 | Fe-Val Siddell     | 10/06/2023 10:33   | Arthur Maknenko    | 2440571            |
| EPA 8321B          | 09/27/2023    | 09/27/2023 12:00 | Hana Lee           | 09/27/2023 17:03   | Tae K Lee          | 2440569            |
|                    | 09/27/2023    | 09/27/2023 12:00 | Hana Lee           | 09/27/2023 17:17   | Tae K Lee          | 2440570            |
|                    | 09/27/2023    | 09/27/2023 12:00 | Hana Lee           | 09/28/2023 01:46   | Tae K Lee          | 2440569            |
|                    | 09/27/2023    | 09/27/2023 12:00 | Hana Lee           | 09/28/2023 01:59   | Tae K Lee          | 2440570            |
|                    | 09/27/2023    | 09/27/2023 14:00 | Hoor Shaik         | 09/29/2023 00:53   | Juyoung Kim        | 2440568            |
|                    | 09/27/2023    | 09/29/2023 09:00 | Hoor Shaik         | 09/29/2023 22:55   | Juyoung Kim        | 2440569            |
|                    | 09/27/2023    | 09/29/2023 09:00 | Hoor Shaik         | 09/29/2023 23:13   | Juyoung Kim        | 2440570            |
|                    | 09/27/2023    | 09/29/2023 09:00 | Hoor Shaik         | 10/03/2023 01:37   | Juyoung Kim        | 2440569            |
|                    | 09/27/2023    | 09/29/2023 09:00 | Hoor Shaik         | 10/03/2023 01:54   | Juyoung Kim        | 2440570            |
|                    | 09/27/2023    | 09/29/2023 09:00 | Hoor Shaik         | 10/03/2023 01:54   | Juyoung Kim        | 2440570            |

## Preparation and Analysis Log

| Ref. Method       | Received Date | Prep Date/Time | Prepared By | Analysis Date/Time | Analyzed By       | Associated Samples        |
|-------------------|---------------|----------------|-------------|--------------------|-------------------|---------------------------|
| SM 2320 B-2011    | 09/27/2023    |                |             | 09/29/2023 21:57   | Adam P Silver     | 2440547                   |
|                   | 09/27/2023    |                |             | 10/03/2023 02:01   | Adam P Silver     | 2440549                   |
|                   | 09/27/2023    |                |             | 10/03/2023 02:14   | Adam P Silver     | 2440550                   |
| SM 2340 B-2011    | 09/27/2023    |                |             | 09/29/2023 15:05   | McKinley C Carter | 2440574                   |
| SM 2540 C-2015    | 09/27/2023    |                |             | 10/02/2023 15:37   | Yijie Li          | 2440547, 2440549, 2440550 |
| SM 2540 D-2015    | 09/27/2023    |                |             | 10/02/2023 15:27   | Yijie Li          | 2440547, 2440549, 2440550 |
| SM 4500-F- C-2011 | 09/27/2023    |                |             | 09/29/2023 21:57   | Adam P Silver     | 2440547                   |
|                   | 09/27/2023    |                |             | 10/03/2023 00:18   | Adam P Silver     | 2440550                   |
|                   | 09/27/2023    |                |             | 10/05/2023 02:10   | Adam P Silver     | 2440549                   |
| SM 5310 B-2011    | 09/27/2023    |                |             | 10/02/2023 21:46   | Elise M. Gillis   | 2440548                   |
|                   | 09/27/2023    |                |             | 10/04/2023 23:09   | Elise M. Gillis   | 2440551                   |
|                   | 09/27/2023    |                |             | 10/04/2023 23:48   | Elise M. Gillis   | 2440552                   |