

Login Checklist

RQ-_____

Login Station ID: _____

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: _____

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
		YES	HNO ₃		Formalin	Present?		*Intact?	
	Yes					No	Yes	No	

COOLER CHECK

***All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.**

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. **NCR#** _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. **NCR#** _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. **NCR#** _____
- If coolers or samples are received late; identify the affected samples in an NCR. **NCR#** _____

Chain of Custody/ Field Sheet(s) Included?

Yes _____ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No _____

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA _____

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____

Containers intact? Yes _____ No _____

Caps on tight?

Yes _____ No _____

Sufficient Sample Volume:

Yes _____ No _____

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. **NCR#** _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes _____ No _____ Init: _____

Chlorine detected? (One container checked per Field ID)

Yes _____ No _____ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . **NCR#** _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

****Acid Preserved Samples:** pH < 2.0?

Yes _____ No _____ NA _____ Init: _____

****W-1-4-DIOX (Green dot on container)** preserved to pH < 4.0?

Yes _____ No _____ NA _____ Init: _____

If samples were not preserved correctly, generate an NCR listing affected sample IDs . **NCR#** _____

Coolers Unpacked/Checked by: _____

Date: _____ Event contains NCRs (Y/N)? _____

Event ID: _____

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	
pH Test Strips 0 – 6	
pH Paper 0 – 3	
pH Paper 0 – 13	
Chlorine Test Strips	

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Benchmark EnviroAnalytical, Inc
1711 12th Street East
Palmetto, FL 34221
941-723-9986
941-723-6061 Fax

PO# C00EF5

Client Information: DEP: SW-DIST

Address: 13051 N. Telecom Parkway

Tampa FL 33604

Phone # 815-470-5878

Report to: benjamin.paswater@dep.state.fl.us
DEP-Overflomicro@dep.state.fl.us

Invoice to: FDEP Micro Overflow

Project Name: RQ-2023-04-03 30

Laboratory Submission #

23030881

Sample Name	Sample Type ¹ / Sample Matrix ²	Collection		Container			Preservative ⁴	Parameters for Analysis	Laboratory Sample #
		Date	Time	Qty	Capacity	Type ³			
<u>G2SW0039</u>									
<u>G2SW0039</u>	SW	<u>3/16/23</u>	<u>10:15</u>	<u>1</u>	250mL	P	Plain (on Ice)	<u>E. coli</u>	<u>1</u>
	SW				250mL	P	Plain (on Ice)		
	SW				250mL	P	Plain (on Ice)		
	SW				250mL	P	Plain (on Ice)		
	SW				250mL	P	Plain (on Ice)		
	SW				250mL	P	Plain (on Ice)		
	SW				250mL	P	Plain (on Ice)		

1 "Sample Type" is used to indicate whether the sample was a grab (G) or whether it was a composite (C).
2 "Sample Matrix" is used to indicate whether the sample is being discharged to drinking water (DW), groundwater (GW), surface water (SW), fresh surface water (FSW), saline surface water (SSW), soil, sediment (SDMNT), or sludge (SLDG).
3 "Container Type" is used to indicate whether the container is plastic (P) or glass (G).
4 Sample must be refrigerated or stored in wet ice after collection. The temperature during storage should be less than or equal to 6°C (42.8°F).
Under "Preservative," list any preservatives that were added to the sample container.

Instructions:
1. Each bottle has a label identifying sample ID, premeasured preservative contained in the bottle, sample type, client ID, and parameters for analysis.
2. The following information should be added to each bottle label after collection with permanent black ink: date and time of collection, sampler's name or initials, and any field number or ID.
3. All bottles not containing preservative may be rinsed with appropriate sample prior to collection.
4. The client is responsible for documentation of the sampling event. Please note special sampling events on the sample custody form.

Laboratory Sample Acceptability:

Temperature: 0.9°C

1	Collected / Relinquished By: <u>Megan Maloney</u>	Date: <u>3/16/23</u>	Time: <u>11:05</u>	Received By: <u>Nathan Hadsell</u>	Date: <u>3-16-23</u>	Time: <u>1103</u>
2	Relinquished By:	Date:	Time:	Received By:	Date:	Time:

Date of Request: 09-MAR-2023
 Created By: PASWATER_B On: 09-MAR-2023
 Modified By: JASROTIA_P On: 13-MAR-2023
 Customer: SW-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Southwest District
 Event Description: Run 1

Send Coolers To:

Phone: 813-632-7600
 FL Dept. of Environmental Protection
 13051 N. Telecom Parkway
 Temple Terrace, FL 33637-0926
 Attn: Ben Paswater
 Cooler Ship EMail: benjamin.paswater@dep.state.fl.us

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 10-MAR-2023
 Biology Request Reviewed By: JASROTIA_P On: 13-MAR-2023
 Sampling Kit Required: YES Ship on: 17-MAR-2023
 Sampling Kit Shipped: YES On: 14-MAR-2023
 Sampling Kit Packed By: PENDLETO_C
 Preservatives Needed: YES
 Date to Receive Samples: 03-APR-2023
 Logged In By: SASNETT_L On: 05-APR-2023

Send Final Report To:

FL Dept. of Environmental Protection
 13051 N. Telecom Parkway
 Temple Terrace, FL 33637-0926
 Attn: Ben Paswater
 Report Notification EMail:
 benjamin.paswater@dep.state.fl.us;sarah.meyer@dep.state.fl.us
 ;Devin.Mathias@Floridadep.gov

Comments: #####

Buffer Solution for W-CARB-AA Bottle
 1 vial per bottle

#####

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
Total Alkalinity		
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
Turbidity		
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
Chloride		
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
Fluoride		
W-TDS	Template: DEFAULT	(SM 2540 C-2015) Total Dissolved Solids in aqueous matrices
TDS		
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
TSS		
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10150 B) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Chlorophyll-a, Corrected		
Chlorophyll-a, Uncorrected		
Phaeophytin-a		
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: CH ₂ CICOOH and Ice
W-CARB-AA	Template: DEFAULT	(EPA 8321B) Carbamates in water matrices by HPLC/MS/MS
3-Hydroxycarbofuran		

Bottle Group A (Water) With 1 Samples:

Bottle Type: BG-500ML Number of Bottles: 1 Preserved With: CH₂ClCOOH and Ice
 W-CARB-AA Template: DEFAULT (EPA 8321B) Carbamates in water matrices by HPLC/MS/MS

Aldicarb
 Aldicarb Sulfone
 Aldicarb Sulfoxide
 Carbaryl
 Carbofuran
 Methiocarb
 Methomyl
 Oxamyl
 Propoxur

Bottle Type: BG-500ML FILL TO Number of Bottles: 4 Preserved With: ICE
 W-CT-CI-R Template: DEFAULT (EPA 8276) Chlordane and Toxaphene in water matrices by GC/MS with Negative Chemical Ionization

Chlordane
 Toxaphene

W-PCB-TQ-R Template: DEFAULT (EPA 8270E) PCBs in water matrices by GC/MS/MS

PCB-1016
 PCB-1221
 PCB-1232
 PCB-1242
 PCB-1248
 PCB-1254
 PCB-1260

W-PCL-TQ-R Template: (EPA 8270E) Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS/MS

*Hexachlorobenzene
 Aldrin
 Alpha-BHC
 Alpha-Chlordane
 Beta-BHC
 Beta-Cyfluthrin
 Bifenthrin
 Carbophenothion
 Chlorothalonil
 Cis-Nonachlor
 Cypermethrin
 Dacthal
 DDD-p,p'
 DDE-p,p'
 DDT-p,p'
 Delta-BHC
 Deltamethrin
 Dichlobenil
 Dicofol
 Dieldrin
 Endosulfan I
 Endosulfan II
 Endosulfan Sulfate
 Endrin
 Endrin Aldehyde
 Endrin Ketone
 Esfenvalerate
 Ethalfuralin
 Fenpropathrin
 Gamma-BHC
 Gamma-Chlordane
 Heptachlor
 Heptachlor Epoxide
 Kepone
 Lambda-Cyhalothrin
 Methoprene

Bottle Group A (Water) With 1 Samples:

Bottle Type: BG-500ML FILL TO Number of Bottles: 4 Preserved With: ICE
 W-PCL-TQ-R Template: (EPA 8270E) Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS/MS
 Methoxychlor
 MGK-264
 Mirex
 Oxychlordane
 Permethrin
 Phenothrin
 Piperonyl Butoxide
 Prallethrin
 Tau-Fluvalinate
 Tetramethrin
 Trans-Nonachlor
 Triclosan Methyl
 Trifluralin

Bottle Type: BG-500ML Number of Bottles: 1 Preserved With: ICE
 W-E8321-DI Template: DEFAULT (EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
 Acesulfame K
 AMPA
 Endothall
 Glufosinate
 Glyphosate
 Sucralose

W-E8321-MS Template: SMP (EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
 2,4-D
 2,4,5-T
 Acetaminophen
 Acetamiprid
 Afidopyropen
 Bentazon
 Benzovindiflupyr
 Carbamazepine
 Clothianidin
 Dinotefuran
 Diuron
 Fenuron
 Fluridone
 Hydrocodone
 Ibuprofen
 Imazapyr
 Imidacloprid
 Linuron
 Mandestrobin
 MCPP
 Naproxen
 Primidone
 Pyraclostrobin
 Silvex
 Thiamethoxam
 Tolfenpyrad
 Triclopyr

Bottle Type: P-500ML Number of Bottles: 1 Preserved With: ICE And H2SO4
 W-NH3 Template: DEFAULT (EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
 Ammonia-N
 W-NO2NO3 Template: DEFAULT (EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
 NO2NO3-N
 W-S-A-TP Template: DEFAULT (EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
 Total-P
 W-TKN Template: DEFAULT (EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
 Kjeldahl Nitrogen
 W-TOC Template: DEFAULT (SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Organic Carbon		
Bottle Type: BG-500ML	Number of Bottles: 4	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS

*Caffeine
 *Fipronil Desulfinyl
 *Loratadine
 *Phenytoin
 Acetochlor
 Alachlor
 Ametryn
 Atrazine
 Atrazine Desethyl
 Azinphos Methyl
 Azoxystrobin
 Bromacil
 Butylate
 Carbophenothion
 Carfentrazone Ethyl
 Chlorfenapyr
 Chlorpyrifos Ethyl
 Chlorpyrifos Methyl
 Coumaphos
 Cyanazine
 Cyprodinil
 Demeton
 Diazinon
 Difenconazole
 Dimethenamid
 Dimethomorph
 Disulfoton
 Dithiopyr
 EPTC
 Ethion
 Ethoprop
 Etridiazole
 Fenamiphos
 Fenbuconazole
 Fipronil
 Fipronil Sulfide
 Fipronil Sulfone
 Fluzifop-P-butyl
 Fludioxonil
 Flumioxazin
 Flutolanil
 Fluxapyroxad
 Fonofos
 Hexazinone
 Imazalil
 Iprodione
 Malathion
 Metalaxyl
 Metolachlor
 Metribuzin
 Mevinphos
 Molinate
 Myclobutanil
 Naled
 Napropamide
 Norflurazon

Bottle Group A (Water) With 1 Samples:

Bottle Type: BG-500ML	Number of Bottles: 4	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS
Oxadiazon Oxyfluorfen Parathion Ethyl Parathion Methyl Pendimethalin Phorate Prodiamine Prometon Prometryn Pronamide Propanil Propargite Propiconazole Pyraflufen Ethyl Pyridaben Pyriproxyfen Simazine Stirophos Sulfentrazone Tebuconazole Terbufos Terbutylazine Thiobencarb Triadimefon		
W-TR-SQ-R	Template: DEFAULT	(EPA 8270E) Analysis of Sunscreen Compounds and Flame Retardants in Water by GC/MS-SIM
*2-Ethylhexyl 2,3,4,5-tetrabromobenzoate (EHTBB) *Avobenzene *Dechlorane 602 *Dechlorane 603 *Dechlorane Plus *Hexabromobenzene *Octinoxate *Oxybenzone *PBB-153 *PBDE-47 *PBDE-99 *Pentabromotoluene *Tetradecachloro-m-terphenyl *Tri-o-cresyl Phosphate *Tris(1-chloro-2-propyl) phosphate (TCPP) *Tris(1,3-dichloro-2-propyl) phosphate (TDCPP) *Tris(2-chloroethyl) phosphate (TCEP)		
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-SO4-IC-F	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate, dissolved, in filtered, aqueous matrices
Sulfate		

Bottle Group B (Water) With 1 Samples:

Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10150 B) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Chlorophyll-a, Corrected Chlorophyll-a, Uncorrected Phaeophytin-a		
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems
Enterococci-Quanti-Tray		
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
FCOLI-MF	Template: DEFAULT	(SM 9222 D) Fecal coliforms by membrane filter method - non-chlorinated water systems
Fecal Coliforms-Membrane Filter		
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
Ammonia-N		
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
NO2NO3-N		
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
Total-P		
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
Kjeldahl Nitrogen		
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Organic Carbon		
Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
Total Alkalinity		
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
Turbidity		
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
Chloride		
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
Fluoride		
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
Sulfate		
W-TDS	Template: DEFAULT	(SM 2540 C-2015) Total Dissolved Solids in aqueous matrices
TDS		
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
TSS		

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
Total Alkalinity		
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
Turbidity		
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
Chloride		
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
Fluoride		
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
Sulfate		
W-TDS	Template: DEFAULT	(SM 2540 C-2015) Total Dissolved Solids in aqueous matrices
TDS		
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
TSS		
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10150 B) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Chlorophyll-a, Corrected		
Chlorophyll-a, Uncorrected		
Phaeophytin-a		
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems
Enterococci-Quanti-Tray		
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
Ammonia-N		
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
NO2NO3-N		
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
Total-P		
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
Kjeldahl Nitrogen		
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Organic Carbon		

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.