

Login Checklist

RQ- 2023-07-24-34

Login Station ID: #3

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 08/8/23 @ 1600

*Cooler Temperature	Samples Frozen? YES	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
		HNO ₃	Formalin		Present?		*Intact?		
					Yes	No	Yes	No	
<u>1.1</u>				<u>8</u>		<u>x</u>			<u>585947374256</u>

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes X No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No X

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA X Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____ Containers intact? Yes X No _____

Caps on tight?

Yes X No _____

Sufficient Sample Volume:

Yes X No _____

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes X No _____ Init: BKK

Chlorine detected? (One container checked per Field ID)

Yes _____ No X Init: BKK

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes X No _____ NA _____ Init: BKK

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes _____ No _____ NA X Init: BKK

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: BKK

Date: 08/8/23

Event contains NCRs (Y/N)? N

EventID: SMP - Melbourne
SE-DIST-2023-08-08-01 (SMP)

- Date Received: 08-AUG-2023 10:00

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #3 Exp:10/17/2023
pH Test Strips 0 – 6	Lot#223819AV Exp:8/30/23
pH Paper 0 – 3	
pH Paper 0 – 13	Lot#207621 Exp:3/15/24
Chlorine Test Strips	Lot#1196 Exp:2/24

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 8/7/2023 **Collected By:** Jordan Skaggs, Tirzah Chichester
Customer: SE-DIST **Sampling Agency:** FDEP
RQ: RQ-2023-07-24-34 **Project ID:** SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1

Delivery Method: FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
CRANE CREEK EAST OF RR BRIDGE	 G3SE0071
KID CREEK AT OLD DIXIE HIGHWAY	 G5SE0050

RELINQUISHED BY(SIGNATURE):

Tirzah Chichester

DATE/TIME: 8/7/2023 1600
EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By:

Brian H. H. H.

Rec'd/Inspected

Date: 8/8/23 1000



RQ-2023-07-24-34

Customer: FDEP

Project ID: SMP

Collected By: Jordan Skaggs, Tirzah Chichester

Field Report Prepared by: Jordan Skaggs, Tirzah Chichester

Sampling Agency: FDEP

Comments:

 WIN ID/Field ID: 
 WIN ID/Field ID: G3SE0071

Location: CRANE CREEK EAST OF RR BRIDGE

Matrix: Marine

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT)
8/7/2023 1115	2.34	34.7	32	8	0.3	0.8	0.8	24100	14.46

Parameter Suite	Parameter Methods	Preservation	pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP	Ice H2SO4*	<2		
	Lot # Exp:				
Metals (P-500ML)	W-ICPMS W-ICP W-HARD	Ice HNO3*	<2		
	Lot # Exp:				
Filtered Nutrients (P125ML)	W-PO4-F Field Filtered 0.45 µm Filter	Ice			
	Filter Lot # Syringe Lot #				
BOD (BP-1L)	OV-BODUNIN	Ice			
Chlorophyll (BP-1L)	CHLSUITE-W	Ice			
Physical/Aggregate (Fresh) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY / W-C-IC / W-COLOR / W-SO4-IC / W-TDS	Ice			
Physical/Aggregate (Marine) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY	Ice			
Macroinvertebrates (PJ-2L)	MI-FW-QLDC Formalin Lot #	Formalin			
Periphyton (PT-50ML)	ALGAE-ID	Ice			
Microbiology (Contract Lab Bottle)	E Coli F Coli X Enterococci Contract Lab	x Ice		1	C
Molecular (QPCR-P-500ML)	PCR-HF183 PCR-BacR PCR-DG3 PCR-GULL2 PCR-GFD	Ice			
Tracers (BG-500ML)	W-E8321-DI W-E8321-MS	Ice			
Pesticides (BG-500ML) (BG-1L)	W-E8321-DI W-E8321-MS W-PSNP-TQ X W-PCL-TQ-R W-CARB-AA (5 ml of MCAA Buffer Solution) X W-CT-CL-R W-TR-SQ-R X W-PCB-TQ-R	x Ice MCAA Exp.	MCAA Lot#	4	C
Phytoplankton (BP-1L)	DTY-QN-C PKD-QN-BV	Ice			
DOC (P-500ML)	W-DOC Field Filtered 0.45 µm Filter	Ice H2SO4*	<2		
	Acid Preservative Expiration Date				
	Acid Preservative Lot Number				



RQ-2023-07-24-34

Customer: FDEP

Project ID: SMP

Collected By: Jordan Skaggs, Tirzah Chichester

Field Report Prepared by: Jordan Skaggs, Tirzah Chichester

Sampling Agency: FDEP

Comments:

WIN ID/Field ID:



WIN ID/Field ID: G5SE0050

Location: KID CREEK AT OLD DIXIE HIGHWAY

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT)
8/7/2023 1145	3.33	43.2	28.8	5.79	0.1	0.2	0.2	160	0.07

Parameter Suite	Parameter Methods				Preservation	pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP				Ice	H2SO4*	<2	
	Lot #		Exp:					
Metals (P-500ML)	W-ICPMS				Ice	HNO3*	<2	
	Lot #		Exp:					
Filtered Nutrients (P125ML)	W-PO4-F				Ice			
	Filter Lot #	Syringe Lot #						
BOD (BP-1L)	OV-BODUNIN				Ice			
Chlorophyll (BP-1L)	CHLSUITE-W				Ice			
Physical/Aggregate (Fresh) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY / W-CL-IC / W-COLOR / W-SO4-IC / W- TDS				Ice			
Physical/Aggregate (Marine) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY				Ice			
Macroinvertebrates (PJ-2L)	MI-FW-QLDC	Formalin Lot #			Formalin			
Periphyton (PT-50ML)	ALGAE-ID				Ice			
Microbiology (Contract Lab Bottle)	X E Coli		F Coli	Enterococci	x Ice		1	B
	Contract Lab							
Molecular (QPCR-P-500ML)	X PCR-HF183	X	PCR-BacR	X PCR-DG3	x Ice		1	B
	PCR-GULL2		PCR-GFD					
Tracers (BG-500ML)	X W-E8321-DI	X	W-E8321-MS		x Ice		1	B
Pesticides (BG-500ML) (BG-1L)	W-E8321-DI	W-E8321-MS	W-PSNP-TQ		Ice	MCAA Exp.	MCAA Lot#	
	W-PCl-TQ-R	W-CARB-AA (5 ml of MCAA Buffer Solution)	W-CT-CL-R					
	W-TR-SQ-R	W-PCB-TQ-R						
Phytoplankton (BP-1L)	DTY-QN-C	PKD-QN-BV			Ice			
DOC (P-500ML)	W-DOC	Field Filtered 0.45 um Filter			Ice	H2SO 4*	<2	
		Acid Preservative Expiration Date						
		Acid Preservative Lot Number						

Date of Request: 29-JUN-2023
 Created By: SKAGGS_J On: 29-JUN-2023
 Modified By: JASROTIA_P On: 06-JUL-2023
 Customer: SE-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Southeast District
 Event Description: SMP - Melbourne

Send Coolers To:

Phone: (772) 448-5884
 FL Dept. of Environmental Protection
 2199 South Rock Road
 Fort Pierce, FL 34945
 Attn: Jordan Skaggs
 Cooler Ship EMail: jordan.skaggs@FloridaDEP.gov

Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 06-JUL-2023
 Biology Request Reviewed By: JASROTIA_P On: 06-JUL-2023
 Sampling Kit Required: YES Ship on: 14-JUL-2023
 Sampling Kit Shipped: YES On: 13-JUL-2023
 Sampling Kit Packed By: KREUCH_B
 Preservatives Needed: NO
 Date to Receive Samples: 01-AUG-2023
 Logged In By:

Send Final Report To:

FL Dept. of Environmental Protection
 2199 South Rock Road
 Fort Pierce, FL 34945
 Attn: Andrew Luering
 Report Notification EMail:
 jordan.skaggs@floridadep.gov;andrew.luering@floridadep.gov

Comments:
 Sampler Comments:

A
 G3SE0068
 -Nutrients

B
 G5SE0050
 -E. coli, PCR, Tracer

C
 G3SE0070
 -Enter, W-CT-CI-R/W-PCL-TQ-R/W-PCB-TQ-R

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2015) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10150 B) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 B Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: SMP	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems
Bottle Type: BG-500ML FILL TO	Number of Bottles: 4	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Chlordane and Toxaphene in water matrices by GC/MS with Negative Chemical Ionization
W-PCB-TQ-R	Template: DEFAULT	(EPA 8270E) PCBs in water matrices by GC/MS/MS
W-PCL-TQ-R	Template: DEFAULT	(EPA 8270E) Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS/MS

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.