

Login Checklist

RQ- 2024-04-22-10

Login Station ID: #3

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 4/26/2024 @ 9:14

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
2.1 0.6				2 4 MB		X			5859 4729 1521 6484 8457 1652

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No ☐

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes ☐ No ☒

CONTAINER CHECK

Evidence Tape on Bottles?

Yes ☐ No ☐ NA ☒

Evidence Tape intact? Yes ☐ No ☐

If Criminal, photographs taken?

Yes ☐ No ☐

Containers intact? Yes ☒ No ☐

Caps on tight?

Yes ☒ No ☐

Sufficient Sample Volume:

Yes ☒ No ☐

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ☒ No ☐ Init: MB

Chlorine detected? (One container checked per Field ID)

Yes ☐ No ☒ Init: MB

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH< 2.0?

Yes ☒ No ☐ NA ☐ Init: MB

**W-1-4-DIOX (Green dot on container) preserved to pH< 4.0?

Yes ☐ No ☐ NA ☒ Init: MB

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: MB

Date: 4/26/2024

Event contains NCRs (Y/N)? N

EventID: SCI SMP
NE-DIST-2024-04-26-01 (SMP)

- Date Received: 26-APR-2024 09:14

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Infrared Thermometer ID:	IR TEMP GUN #3 Exp. 10/16/2024
pH Test Strips 0 – 6	Lot# 223819BV Exp. 8/15/2024
pH Paper 0 – 3	
pH Paper 0 – 13	Lot# 228323 Exp. 10/1/2026
Chlorine Test Strips	Lot# 3180A Exp. 4/30/2024

Additional Comments:

017

1.5

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 4/25/2024
Customer: NE-DIST
RQ: RQ-2024-04-22-10
Collected By: Jeremy Parrish, Katherine Halbert
Sampling Agency: FDEP
Project ID: SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 2

Delivery Method: FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
JONES CREEK ABOVE I 295	 G2NE1233

RELINQUISHED BY(SIGNATURE):



DATE/TIME: 4/25/2024
1630 EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By:



Rec'd/Inspected

Date:

4/26/24



RQ-2024-04-22-10

Customer: FDEP

Project ID: SMP

Collected By: Jeremy Parrish, Katherine Halbert

Field Report Prepared by: Jeremy Parrish,
Katherine Halbert

Sampling Agency: FDEP

WIN ID/Field ID:



WIN ID/Field ID: G2NE1233

Comments:

Location: JONES CREEK ABOVE I 295

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPTH)
4/25/2024 1025	7.73	84.1	19.4	7.19	0.1	0.2	0.2	267.9	0.13

Parameter Suite	Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group			
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	X	<2	1	A	
		Lot #	SA3340020		Exp:	12/11/2024							
Metals (P-500ML)	X	W-ICPMS	X	W-ICP	X	W-HARD	Ice	X	HNO3*	X	<2	1	A
		Lot #	NA3340030		Exp:	12/13/2024							
Filtered Nutrients (P125ML)	X	W-PO4-F	X	Field Filtered 0.45 µm Filter		x	Ice				1	A	
		Filter Lot #		Syringe Lot #									
BOD (BP-1L)		OV-BODUNIN					Ice						
Chlorophyll (BP-1L)	X	CHLSUITE-W				x	Ice				1	A	
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W-TDS				x	Ice				1	A	
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY					Ice						
Macroinvertebrates (PJ-2L)	X	MI-FW-QLDC		Formalin Lot #	9.70623WB	x	Formalin				2	B	
Periphyton (PT-50ML)		ALGAE-ID					Ice						
Microbiology (Contract Lab Bottle)		E Coli		F Coli		Enterococci				Ice			
		Contract Lab											
Molecular (QPCR-P-500ML)		PCR-HF183		PCR-BacR		PCR-DG3				Ice			
		PCR-GULL2		PCR-GFD									
Tracers (BG-500ML)		W-E8321-DI		W-E8321-MS			Ice						
Pesticides (BG-500ML) (BG-1L)	X	W-E8321-DI	X	W-E8321-MS	X	W-P5NP-TQ	x	Ice	MCAA Exp.	MCAA Lot#	5	A	
		W-PCL-TQ-R		W-CARB-AA (5 ml of MCAA Buffer Solution)		W-CT-CL-R							
		W-TR-SQ-R		W-PCB-TQ-R									
Phytoplankton (BP-1L)		DTY-QN-C		PKD-QN-BV			Ice						
DOC (P-500ML)		W-DOC		Field Filtered 0.45 µm Filter			Ice		H2SO4*		<2		
			Acid Preservative Expiration Date										
			Acid Preservative Lot Number										

Date of Request: 11-MAR-2024
Created By: PARRISH_J On: 11-MAR-2024
Modified By: JASROTIA_P On: 03-APR-2024
Customer: NE-DIST
Project: SMP
Division: Division of Environmental Assessment and Restoration
District: Northeast District
Event Description: SCI SMP

Send Coolers To:

Phone: 904-256-1700
8800 Baymeadows Way West
Suite 100
Jacksonville, FL 32256
Attn: Jeremy Parrish
Cooler Ship EMail: Jeremy.M.Parrish@floridadep.gov

Priority: 3
Event Status: S
Criminal Investigation: NO
Chemistry Request Reviewed By: AYRES_J On: 03-APR-2024
Biology Request Reviewed By: JASROTIA_P On: 03-APR-2024
Sampling Kit Required: YES Ship on: 12-APR-2024
Sampling Kit Shipped: YES On: 08-APR-2024
Sampling Kit Packed By: PENDLETO_C
Preservatives Needed: NO
Date to Receive Samples: 22-APR-2024
Logged In By:

Send Final Report To:

8800 Baymeadows Way West
Suite 100
Jacksonville, FL 32256
Attn: Jeremy Parrish
Report Notification EMail: Jeremy.M.Parrish@floridadep.gov

Comments: Group A: Nutrients, Metals, Tracers, markers, Q-PSNP-TQ, W-TR-SQ-R, Bacteria
Group B: SCI, Algae_ID

NE-DIV-ECQ

Packing Notes:
none

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2015) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10150 B) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
NE-DIV-ECQ	Template: DEFAULT	(SM 9223 B Quanti-Tray) E. coli by Colilert/QT by Diversified Environmental Laboratories in Jacksonville
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction

Bottle Group A (Water) With 1 Samples:

Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: SMP	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-HARD	Template: DEFAULT	(SM 2340 B-2011) Hardness by calculation, in aqueous matrices, reported as mg/L CaCO3
Hardness		
W-ICP	Template: SMP-FRESH	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Calcium		
Iron		
Magnesium		
Potassium		
Sodium		
Strontium		
Tin		
Titanium		
Vanadium		
Zinc		
W-ICPMS	Template: DEFAULT	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
Aluminum		
Antimony		
Arsenic		
Barium		
Beryllium		
Boron		
Cadmium		
Chromium		
Cobalt		
Copper		
Lead		
Manganese		
Molybdenum		
Nickel		
Selenium		
Silver		
Thallium		

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2014) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
Bottle Type: BG-500ML	Number of Bottles: 4	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS
W-TR-SQ-R	Template: DEFAULT	(EPA 8270E) Analysis of Sunscreen Compounds and Flame Retardants in Water by GC/MS-SIM

Bottle Group B (Biological) With 1 Samples:

Bottle Type: PT-50ML	Number of Bottles: 1	Preserved With: ICE
ALGAL_ID	Template: DEFAULT	(SOP-AB18) Qualitative assessment of algal taxa present without counts
Bottle Type: PJ-2L	Number of Bottles: 2	Preserved With: Formalin
MI-FW-QLDC	Template: DEFAULT	(SOP-IZ06) No. Taxa of FW macroinverts, qual samp, 20 dipnets.

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.