

Login Checklist

RQ- 2024-03-18-41

Login Station ID: #3

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 5/ 1 /2024 @ 13:00

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
1.9				4		X			6484 8459 3500

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ✓ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No ✓

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA ✓

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____

Containers intact? Yes ✓ No _____

Caps on tight?

Yes ✓ No _____

Sufficient Sample Volume:

Yes ✓ No _____

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes _____ No ✓ Init: MB

Chlorine detected? (One container checked per Field ID)

Yes _____ No _____ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

** Acid Preserved Samples: pH< 2.0?

Yes ✓ No _____ NA _____ Init: MB

**W-1-4-DIOX (Green dot on container) preserved to pH< 4.0?

Yes _____ No _____ NA ✓ Init: MB

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: MB

Date: 5/ 1 /2024

Event contains NCRs (Y/N)? N

SMP - 2024 Deployments

EventID: SE-DIST-2024-05-01-01 (SMP)

- Date Received: 01-MAY-2024 13:00

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #3 Exp. 10/16/2024
pH Test Strips 0 – 6	Lot# 223819BV Exp. 8/15/2024
pH Paper 0 – 3	
pH Paper 0 – 13	Lot# 228323 Exp. 10/1/2026
Chlorine Test Strips	Lot# 3180A Exp. 4/30/2024

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 4/30/2024 **Collected By:** Andrew Luering, Natalie Howard
Customer: SE-DIST **Sampling Agency:** FDEP
RQ: RQ-2024-03-18-41 **Project ID:** SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1

Delivery Method: FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
ARCH CREEK AT ENCHANTED FOREST	 G4SE0120

RELINQUISHED BY(SIGNATURE):



DATE/TIME: 4/30/2024
1600 EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By:

MB

Rec'd/Inspected

Date:

5/1/24

Project ID: SMP

Sampling Agency: FDEP

Comments:

WIN ID/Field ID: 
WIN ID/Field ID: G4SE0120

Location: ARCH CREEK AT ENCHANTED FOREST

Matrix: Marine

(Check One)

✓ Grab

☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT _h)							
4/30/2024 1115	3.86	57.3	26.9	7.44	0.3	1.4	1.4	47532	30.89							
Parameter Suite		Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group					
Preserved Nutrients (P-500ML)		X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	X	<2	1	B			
		Lot #		SA3340020		Exp:		12/11/2024								
Metals (P-500ML)			W-ICPMS		W-ICP		W-HARD			Ice		HN03*		<2		
		Lot #				Exp:										
Filtered Nutrients (P125ML)			W-PO4-F		Field Filtered 0.45 µm Filter				Ice		<2					
		Filter Lot #				Syringe Lot #										
BOD (BP-1L)			OV-BODUNIN					Ice								
Chlorophyll (BP-1L)		X	CHLSUITE-W				X	Ice						1	B	
Physical/Aggregate (Fresh) (P-1L)		X	Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-Cl / W-COLOR / W-SO4-Cl / W- TDS				X	Ice						1	B	
Physical/Aggregate (Marine) (P-1L)			Alkalinity / W-F / W-TSS / TURBIDITY					Ice								
Macroinvertebrates (PJ-2L)			MI-FW-QLDC		Formalin Lot #				Formalin							
Periphyton (PT-50ML)			ALGAE-ID					Ice								
Microbiology (Contract Lab Bottle)		E Coli		F Coli		X	Enterococci	X	Ice					1	B	
		Contract Lab														
Molecular (QPCR-P-500ML)		PCR-HF183		PCR-BacR			PCR-DG3		Ice							
		PCR-GULL2		PCR-GFD												
Tracers (BG-500ML)		W-E8321-DI		W-E8321-M5				Ice								
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI		W-E8321-M5		W-PSNP-TQ		Ice	MCAA Exp.	MCAA Lot#						
		W-PCL-TQ-R		W-CARB-AA (5 ml of MCAA Buffer Solution)		W-CT-CL-R										
		W-TR-SQ-R		W-PCB-TQ-R												
Phytoplankton (BP-1L)		DTY-QN-C		PKD-QN-BV				Ice								
DOC (P-500ML)		W-DOC		Field Filtered 0.45 µm Filter			Ice		H2SO 4*		<2					
				Acid Preservative Expiration Date												
				Acid Preservative Lot Number												

Date of Request: 20-FEB-2024
Created By: SKAGGS_J On: 20-FEB-2024
Modified By: JASROTIA_P On: 27-FEB-2024
Customer: SE-DIST
Project: SMP
Division: Division of Environmental Assessment and Restoration
District: Southeast District
Event Description: SMP - 2024 Deployments

Send Coolers To:

Phone: (772) 448-5884
FL Dept. of Environmental Protection
2199 South Rock Road
Fort Pierce, FL 34945
Attn: Jordan Skaggs
Cooler Ship EMail: jordan.skaggs@FloridaDEP.gov

Priority: 3
Event Status: S
Criminal Investigation: NO
Chemistry Request Reviewed By: AYRES_J On: 27-FEB-2024
Biology Request Reviewed By: JASROTIA_P On: 27-FEB-2024
Sampling Kit Required: YES Ship on: 08-MAR-2024
Sampling Kit Shipped: YES On: 06-MAR-2024
Sampling Kit Packed By: SHAIK_A
Preservatives Needed: NO
Date to Receive Samples: 28-MAR-2024
Logged In By:

Send Final Report To:

FL Dept. of Environmental Protection
2199 South Rock Road
Fort Pierce, FL 34945
Attn: Andrew Luering
Report Notification EMail:
jordan.skaggs@floridadep.gov;andrew.luering@floridadep.gov

Comments:**Sampler Comments:**

A - 3226M2 Entero only (deploy)
B - 3226M2 Entero/Nutrients (pickup)

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2015) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10150 B) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2014) Nonpurgeable Organic Carbon in aqueous matrices