

Login Checklist

RQ- 2024-05-20-17

Login Station ID: #4

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 06/04/2024@ 9:07

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
-1.3				12					7281 6631 2158
-0.3				12					7281 6631 3143
2.4				10					7281 6631 3132
-0.6				11					7281 6631 3157

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No ☐

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes ☐ No ☒

CONTAINER CHECK

Evidence Tape on Bottles?

Yes ☐ No ☐ NA ☒ Evidence Tape intact? Yes ☐ No ☐

If Criminal, photographs taken?

Yes ☐ No ☐ Containers intact? Yes ☒ No ☐

Caps on tight?

Yes ☒ No ☐

Sufficient Sample Volume:

Yes ☒ No ☐

If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ☒ No ☐ Init: BD

Chlorine detected? (One container checked per Field ID)

Yes ☐ No ☒ Init: BD

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes ☒ No ☐ NA ☐ Init: BD

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes ☐ No ☒ NA ☐ Init: BD

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: BD

Date: 06/04/2024

Event contains NCRs (Y/N)? N

SMP - Vero Beach (w Boat sites)

EventID: SE-DIST-2024-06-04-01 (SMP)

- Date Received: 04-JUN-2024 09:07

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #4 Exp:10/17/2024
pH Test Strips 0 – 6	LOT# 223819AV Exp: AUG 30, 2024
pH Paper 0 – 3	N/A
pH Paper 0 – 13	LOT# 228323 Exp: Oct 1, 2026
Chlorine Test Strips	LOT# 3032 Exp: Aug. 2025

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 6/3/2024 **Collected By:** Jordan Skaggs, Drew Liddick
Customer: SE-DIST **Sampling Agency:** FDEP
RQ: RQ-2024-05-20-17 **Project ID:** SMP

EDD file path: https://floridadep.sharepoint.com/dear/Sample%20Receiving/2024/2024-05-20-17_SE-DIST_COC_EDD_2024_06_03.txt

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 4

Delivery Method: FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
LATERAL C CANAL NEAR 85TH ST	 G5SE0143
UNNAMED CANAL NEAR 85TH ST	 G5SE0144
LATERAL C CANAL NEAR 69TH ST	 G5SE0141
VERO NORTH CANAL AT 66TH AVE	 G5SE0069
MAIN CANAL AT KINGS HIGHWAY	 G5SE0115
SOUTH CANAL AT 20TH AVE	 G5SE0086

RELINQUISHED BY(SIGNATURE):



DATE/TIME: 6/3/2024 1600
EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By:



Rec'd/Inspected

Date: 06/04/2024 9:07



RQ-2024-05-20-17

Collected By: Jordan Skaggs, Drew Liddick

Customer: FDEP

Field Report Prepared by: Jordan Skaggs, Drew Liddick

Project ID: SMP

Sampling Agency: FDEP

 WIN ID/Field ID: 
 WIN ID/Field ID: G5SE0143

Comments:

Location: LATERAL C CANAL NEAR 85TH ST

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT)
6/3/2024 1030	7.49	96.1	27.7	7.91	0.3	0.8	1.9	3208	1.67

Parameter Suite	Parameter Methods			Preservation	pH Check	# Bottles sent to Lab	Bottle Group	
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP	X	Ice	X	H2SO4*		
		Lot # SA3340020	Exp:	12/11/2024	X	<2	1	
Metals (P-500ML)		W-ICPMS	W-ICP	W-HARD	Ice	HNO3*		
		Lot #	Exp:			<2		
Filtered Nutrients (P125ML)		W-PO4-F	Field Filtered 0.45 um Filter		Ice			
		Filter Lot #	Syringe Lot #					
BOD (BP-1L)		OV-BODUNIN		Ice				
Chlorophyll (BP-1L)	X	CHLSUITE-W		X	Ice		1	
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-D-IC / W-COLOR / W-SO4-IC / W- TDS		X	Ice		1	
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY		Ice				
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #	Formalin				
Periphyton (PT-50ML)		ALGAE-ID		Ice				
Microbiology (Contract Lab Bottle)	X	E Coli	F Coli	Enterococci	X	Ice	1	
		Contract Lab						
Molecular (QPCR-P-500ML)	X	PCR-HF183	X	PCR-BacR	X	PCR-DG3	X	Ice
		PCR-GULL2		PCR-GFD				
Tracers (BG-500ML)	X	W-E8321-DI	X	W-E8321-MS	X	Ice	1	
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI	W-E8321-MS	W-PSNP-TQ		MCAA Exp.	MCAA Lot#	
		W-PCL-TQ-R	W-CARB-AA (5 ml of MCAA Buffer Solution)	W-CT-CL-R	Ice			
		W-TR-SQ-R	W-PCB-TQ-R					
Phytoplankton (BP-1L)		DTY-QN-C	PKD-QN-BV	Ice				
DOC (P-500ML)		W-DOC	Field Filtered 0.45 um Filter	Ice		H2SO4*		
			Add Preservative Expiration Date				<2	
			Add Preservative Lot Number					

WIN ID/Field ID: 
WIN ID/Field ID: G5SE0144

Location: UNNAMED CANAL NEAR 85TH ST

Matrix: Fresh

(Check One)

✓ Grab

☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT _h)									
6/3/2024 1100	6.06	76.6	26.9	7.36	0.2	0.3	0.3	2502	1.28									
Parameter Suite		Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group							
Preserved Nutrients (P-500ML)		X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	X	<2	1	E					
		Lot #		SA3340020		Exp:		12/11/2024										
Metals (P-500ML)			W-ICPMS			W-ICP			W-HARD			Ice		HNO3*		<2		
		Lot #				Exp:												
Filtered Nutrients (P125ML)			W-PO4-F			Field Filtered 0.45 µm Filter				Ice		<2						
		Filter Lot #				Syringe Lot #												
BOD (BP-1L)			OV-BODUNIN					Ice										
Chlorophyll (BP-1L)		X	CHLSUITE-W				X	Ice		1					E			
Physical/Aggregate (Fresh) (P-1L)		X	Alkalinity / W-F / W-TSS / TURBIDITY / W-CL-IC / W-COLOR / W-SO4-IC / W- TDS				X	Ice		1					E			
Physical/Aggregate (Marine) (P-1L)			Alkalinity / W-F / W-TSS / TURBIDITY					Ice										
Macroinvertebrates (PJ-2L)			MI-FW-QLDC		Formalin Lot #			Formalin										
Periphyton (PT-50ML)			ALGAE-ID					Ice										
Microbiology (Contract Lab Bottle)		X	E Coli			F Coli			Enterococci	X					Ice		1	E
		Contract Lab																
Molecular (QPCR-P-500ML)		X	PCR-HF183		X	PCR-BacR		X	PCR-DG3	X	Ice		1	E				
		PCR-GULL2			PCR-GFD													
Tracers (BG-500ML)		X	W-E8321-DI		X	W-E8321-MS				X	Ice		1	E				
Pesticides (BG-500ML) (BG-1L)			W-E8321-DI			W-E8321-MS			W-PSNP-TQ		Ice	MCAA Exp.	MCAA Lot#					
			W-PCL-TQ-R			W-CARB-AA (5 ml of MCAA Buffer Solution)			W-CT-CL-R									
		W-TR-SQ-R			W-PCB-TQ-R													
Phytoplankton (BP-1L)			DTY-QN-C			PKD-QN-BV				Ice								
DOC (P-500ML)			W-DOC		Field Filtered 0.45 µm Filter				Ice		H2SO4*		<2					
		Acid Preservative Expiration Date																
		Acid Preservative Lot Number																



RQ-2024-05-20-17

Collected By: Jordan Skaggs, Drew Liddick

Customer: FDEP

Field Report Prepared by: Jordan Skaggs, Drew Liddick

Project ID: SMP

Sampling Agency: FDEP

 WIN ID/Field ID: 
 WIN ID/Field ID: G5SE0141

Comments:

Location: LATERAL C CANAL NEAR 69TH ST

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT)
6/3/2024 1130	5.02	63.5	27.4	7.39	0.3	1.3	1.3	3229	1.68

Parameter Suite	Parameter Methods			Preservation		pH Check		# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	
		Lot #	SA3340020		Exp:	12/11/2024		X	<2
Metals (P-500ML)		W-ICPMS		W-ICP	W-HARD	Ice	HNO3*		<2
		Lot #			Exp:				
Filtered Nutrients (P125ML)		W-PO4-F	Field Filtered 0.45 um Filter			Ice			
		Filter Lot #		Syringe Lot #					
BOD (BP-1L)		OV-BODUNIN				Ice			
Chlorophyll (BP-1L)	X	CHLSUITE-W			X	Ice		1	F
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W- TDS			X	Ice		1	F
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY				Ice			
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #			Formalin			
Periphyton (PT-50ML)		ALGAE-ID				Ice			
Microbiology (Contract Lab Bottle)	X	E Coli	F Coli	Enterococci	X	Ice		1	F
		Contract Lab							
Molecular (QPCR-P-500ML)	X	PCR-HF183	X	PCR-BacR	X	PCR-DG3	X	Ice	1
		PCR-GULL2		PCR-GFD					
Tracers (BG-500ML)	X	W-E8321-DI	X	W-E8321-MS	X	Ice		1	F
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI	W-E8321-MS	W-PSNP-TQ		Ice	MCAA Exp.	MCAA Lot#	
		W-PCL-TQ-R	W-CARB-AA (5 ml of MCAA Buffer Solution)	W-CT-CL-R					
		W-TR-SQ-R	W-PCB-TQ-R						
Phytoplankton (BP-1L)		DTY-QN-C	PKD-QN-BV			Ice			
DOC (P-500ML)		W DOC	Field Filtered 0.45 um Filter			Ice	H2SO 4*		<2
			Acid Preservative Expiration Date						
			Acid Preservative Lot Number						



RQ-2024-05-20-17

Customer: FDEP

Project ID: SMP

Collected By: Jordan Skaggs, Drew Liddick

Field Report Prepared by: Jordan Skaggs, Drew Liddick

Sampling Agency: FDEP

Comments:

 WIN ID/Field ID: 
 WIN ID/Field ID: G5SE0069

Location: VERO NORTH CANAL AT 66TH AVE

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPTH)
6/3/2024 1200	4.32	54.6	26.9	7.55	0.3	0.7	0.7	1494	0.75

Parameter Suite	Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group					
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	X	<2	1	A			
	Lot #		SA3340020		Exp:		12/11/2024								
Metals (P-500ML)		W-ICPMS		W-ICP	W-HARD		Ice	HNO3*		<2					
	Lot #		Exp:												
Filtered Nutrients (P125ML)		W-PO4-F		Field Filtered 0.45 µm Filter			Ice								
	Filter Lot #			Syringe Lot #											
BOD (BP-1L)		OV-BODUNIN					Ice								
Chlorophyll (BP-1L)	X	CHLSUITE-W				X	Ice						1	A	
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W-TDS				X	Ice						1	A	
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY					Ice								
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #			Formalin									
Periphyton (PT-50ML)		ALGAE-ID					Ice								
Microbiology (Contract Lab Bottle)	X	E Coli		F Coli		Enterococci	X	Ice						1	A
	Contract Lab														
Molecular (QPCR-P-500ML)	X	PCR-HF183		X	PCR-BacR	X	PCR-DG3	X	Ice		1	A			
	PCR-GULL2		PCR-GFD												
Tracers (BG-500ML)		W-E8321-DI		W-E8321-MS			Ice								
Pesticides (BG-500ML) (BG-1L)	X	W-E8321-DI	X	W-E8321-MS		X	W-PSNP-TQ	X	Ice	MCAA Exp.	MCAA Lot#	10	A		
	X	W-PCL-TQ-R	X	W-CARB-AA (5 ml of MCAA Buffer Solution)		X	W-CT-CL-R								
	X	W-TR-SQ-R	X	W-PCB-TQ-R											
Phytoplankton (BP-1L)		DTY-QN-C		PKD-QN-BV			Ice								
DOC (P-500ML)		W-DOC	Field Filtered 0.45 µm Filter			Ice		H2SO4*		<2					
	Add Preservative Expiration Date														
	Add Preservative Lot Number														

WIN ID/Field ID:  WIN ID/Field ID: G5SE0115	Comments:
---	-----------

Matrix: Fresh

(Check One) ☒ **Grab** ☐ **Composite**

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPTH)							
6/3/2024 1320	9.45	122.5	29.1	8.11	0.3	0.6	2.3	2266	1.15							
Parameter Suite		Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group					
Preserved Nutrients (P-500ML)		X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	X	<2	1	C			
		Lot #		SA3340020		Exp:		12/11/2024								
Metals (P-500ML)			W-ICPMS			W-ICP		W-HARD		Ice		HNO3*		<2		
		Lot #				Exp:										
Filtered Nutrients (P125ML)			W-PO4-F		Field Filtered 0.45 um Filter				Ice							
		Filter Lot #				Syringe Lot #										
BOD (BP-1L)			OV-BODUNIN						Ice							
Chlorophyll (BP-1L)		X	CHLSUITE-W					X	Ice			1	C			
Physical/Aggregate (Fresh) (P-1L)		X	Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W- TD5					X	Ice			1	C			
Physical/Aggregate (Marine) (P-1L)			Alkalinity / W-F / W-TSS / TURBIDITY						Ice							
Macroinvertebrates (PJ-2L)			MI-FW-QLDC	Formalin Lot #				Formalin								
Periphyton (PT-50ML)			ALGAE-ID						Ice							
Microbiology (Contract Lab Bottle)		X	E Coli			F Coli		Enterococci	X			Ice	1	C		
		Contract Lab														
Molecular (QPCR-P-500ML)		X	PCR-HF183		X	PCR-BacR	X	PCR-DG3	X	Ice	1	C				
		PCR-GULL2		PCR-GFD												
Tracers (BG-500ML)		X	W-E8321-DI		X	W-E8321-MS			X	Ice	1	C				
Pesticides (BG-500ML) (BG-1L)			W-E8321-DI	W-E8321-MS				W-PSNP-TQ	Ice	MCAA Exp.	MCAA Lot#					
			W-PCL-TQ-R	W-CARB-AA (5 ml of MCAA Buffer Solution)				W-CT-CL-R								
		W-TR-SQ-R			W-PCB-TQ-R											
Phytoplankton (BP-1L)			DTY-QN-C		PKD-QN-BV				Ice							
DOC (P-500ML)			W-DOC	Field Filtered 0.45 um Filter				Ice		H2SO 4*		<2				
				Acid Preservative Expiration Date												
				Acid Preservative Lot Number												



RQ-2024-05-20-17

Collected By: Jordan Skaggs, Drew Liddick

Customer: FDEP

Field Report Prepared by: Jordan Skaggs, Drew Liddick

Project ID: SMP

Sampling Agency: FDEP

 WIN ID/Field ID: 
 WIN ID/Field ID: G5SE0086

Comments:

Location: SOUTH CANAL AT 20TH AVE

Matrix: Fresh

(Check One) ☒ Grab ☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT)
6/3/2024 1350	6.67	93.4	33.2	7.06	0.1	0.2	0.2	1045	0.51

Parameter Suite	Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group		
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	X	<2	1	B
		Lot #	SA3340020		Exp:	12/11/2024						
Metals (P-500ML)		W-ICPMS		W-ICP	W-HARD	Ice		HNO3*		<2		
		Lot #			Exp:							
Filtered Nutrients (P125ML)		W-PO4-F	Field Filtered 0.45 µm Filter			Ice						
		Filter Lot #	Syringe Lot #									
BOD (BP-1L)		OV-BODUNIN				Ice						
Chlorophyll (BP-1L)	X	CHLSUITE-W				X	Ice			1	B	
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-Q-IC / W-COLOR / W-SO4-IC / W-TDS				X	Ice			1	B	
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY					Ice					
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #				Formalin					
Periphyton (PT-50ML)		ALGAE-ID					Ice					
Microbiology (Contract Lab Bottle)	X	E Coli	F Coli	Enterococci		X	Ice			1	B	
		Contract Lab										
Molecular (QPCR-P-500ML)	X	PCR-HF183	X	PCR-BacR	X	PCR-DG3	X	Ice		1	B	
		PCR-GULL2	PCR-GFD									
Tracers (BG-500ML)	X	W-E8321-DI	X	W-E8321-MS		X	Ice			1	B	
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI	W-E8321-MS		W-PSNP-TQ		Ice	MCAA Exp.	MCAA Lot#			
		W-PCL-TQ-R	W-CARB-AA (5 ml of MCAA Buffer Solution)		W-CT-CL-R							
		W-TR-SQ-R	W-PCB-TQ-R									
Phytoplankton (BP-1L)		DTY-QN-C		PKD-QN-BV		Ice						
DOC (P-500ML)		W-DOC	Field Filtered 0.45 µm Filter			Ice		H2SO4*	<2			
	Acid Preservative Expiration Date											
	Acid Preservative Lot Number											

Date of Request: 09-APR-2024
Created By: SKAGGS_J On: 09-APR-2024
Modified By: JASROTIA_P On: 30-APR-2024
Customer: SE-DIST
Project: SMP
Division: Division of Environmental Assessment and Restoration
District: Southeast District
Event Description: SMP - Vero Beach (w Boat sites)

Send Coolers To:

Phone: (772) 448-5884
FL Dept. of Environmental Protection
2199 South Rock Road
Fort Pierce, FL 34945
Attn: Jordan Skaggs
Cooler Ship EMail: jordan.skaggs@FloridaDEP.gov

Priority: 3
Event Status: S
Criminal Investigation: NO
Chemistry Request Reviewed By: AYRES_J On: 30-APR-2024
Biology Request Reviewed By: JASROTIA_P On: 30-APR-2024
Sampling Kit Required: YES Ship on: 10-MAY-2024
Sampling Kit Shipped: YES On: 06-MAY-2024
Sampling Kit Packed By: BARNHART_M
Preservatives Needed: NO
Date to Receive Samples: 30-MAY-2024
Logged In By:

Send Final Report To:

FL Dept. of Environmental Protection
2199 South Rock Road
Fort Pierce, FL 34945
Attn: Andrew Luering
Report Notification EMail:
jordan.skaggs@floridadep.gov;andrew.luering@floridadep.gov

Comments: #####

Buffer Solution for W-CARB-AA Bottle
1 vial per bottle

#####

Please send 4 coolers for return

Sampler Comments:

A - G5SE0069 - nut, ecoli, markers, pest
B - G5SE0086 - nut, ecoli, markers, tracers
C - G5SE0115 - nut, ecoli, markers, tracers
D - G5SE0143 - nut, ecoli, markers, tracers
E - G5SE0144 - nut, ecoli, markers, tracers
F - G5SE0141 - nut, ecoli, markers, tracers - site was moved South of original kmz point

Boat/Canoe Sites - dog park launch
G - G5SE0088 - entero, fecal, tracers
H - G5SE0089 - entero, fecal

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
W-TDS	Template: DEFAULT	(SM 2540 C-2015) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10150 B) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 B Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: CH ₂ ClCOOH and Ice
W-CARB-AA	Template: DEFAULT	(EPA 8321B) Carbamates in water matrices by HPLC/MS/MS
Bottle Type: BG-500ML FILL TO	Number of Bottles: 4	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Chlordane and Toxaphene in water matrices by GC/MS with Negative Chemical Ionization
W-PCB-TQ-R	Template: DEFAULT	(EPA 8270E) PCBs in water matrices by GC/MS/MS
W-PCL-TQ-R	Template: DEFAULT	(EPA 8270E) Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS/MS
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: SMP	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2014) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: BG-500ML	Number of Bottles: 4	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS
W-TR-SQ-R	Template: DEFAULT	(EPA 8270E) Analysis of Sunscreen Compounds and Flame Retardants in Water by GC/MS-SIM

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2015) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10150 B) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 B Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction

Bottle Group B (Water) With 1 Samples:

Bottle Type: BG-500ML		Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B)	Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: SMP	(EPA 8321B)	Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML		Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0)	Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0)	Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0)	Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0)	Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2014)	Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-1L		Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011)	Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0)	Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1)	Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1)	True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)			
W-F	Template: DEFAULT	(SM 4500-F- C-2011)	Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1)	Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2015)	Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2015)	Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L		Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10150 B)	Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI		Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 B Quanti-Tray)	Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: QPCR-P-500ML		Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4)	Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5)	Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0)	Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: BG-500ML		Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B)	Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: SMP	(EPA 8321B)	Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML		Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0)	Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0)	Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0)	Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0)	Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2014)	Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group D (Water) With 1 Samples:

Bottle Type: P-1L		Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011)	Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0)	Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1)	Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1)	True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)			
W-F	Template: DEFAULT	(SM 4500-F- C-2011)	Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1)	Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2015)	Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2015)	Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L		Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10150 B)	Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI		Number of Bottles: 1	Preserved With: ICE

Bottle Group D (Water) With 1 Samples:

Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 B Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: SMP	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2014) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group E (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2015) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10150 B) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 B Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: SMP	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2014) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group F (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		

Bottle Group F (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2015) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10150 B) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 B Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: SMP	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2014) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group G (Water) With 1 Samples:

Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
FCOLI-MF	Template: DEFAULT	(SM 9222 D) Fecal coliforms by membrane filter method - non-chlorinated water systems
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: SMP	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Bottle Group H (Water) With 1 Samples:

Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
FCOLI-MF	Template: DEFAULT	(SM 9222 D) Fecal coliforms by membrane filter method - non-chlorinated water systems

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.