

Chemical Analysis Report

WQAP-2021-05-28-01

Florida Department of Environmental Protection
Central Laboratory
2600 Blair Stone Road
Tallahassee, FL 32399-2400
DOH Accreditation E31780


Event Description: **Algal Bloom Response -SOROC**
Request ID: **RQ-2021-05-31-65**
Customer: **WQAP**
Project ID: **BLOOM-RESP**

Send Reports to:
FL Dept. of Environmental Protection
2295 Victoria AVE
Suite 364
Fort Myers, FL 33901
Attn: Kirby Wolfe

For additional information please contact
Colin Wright, Ph.D.
Liang-Tsair Lin, Ph.D.
Kerry Tate, Ph.D.
Dr. rer. nat. Bettina Steinbock
Thekkekalathil Chandrasekhar, Ph.D, QA Officer
Phone (850) 245-8085

Certified by: Dr. rer. nat. Bettina Steinbock, Environmental Administrator

Date Certified: 21-JUN-2021 18:38



Case Narrative

Unless otherwise noted, all samples included in this report were received in accordance with protocols referenced in Chapter 62-160, Florida Administrative Code (F.A.C.). Results published in this report pertain only to the samples as submitted to, and received by the laboratory. All times in this report are adjusted to the applicable Eastern Time Zone (EST or EDT).

Results for the following analytical groups are included in this report: Nutrients and Pesticides.

Scientific notation may be used in reporting very large or small values. Values reported using scientific notation will take the form of the following example: 1.3E+03, which is equivalent to 1.3×10^3 or 1300.

Unless otherwise noted, analytical values for soil and sediment samples are reported on a dry weight basis, and analytical values for waste and tissue samples are reported on a wet weight basis.

Results for TNI accredited tests met requirements established by The NELAC Institute. A double asterisk (**) is used to indicate an analyte/matrix/method for which the laboratory is not TNI accredited by the Florida Department of Health Environmental Laboratory Certification Program or where accreditation for that field of testing is not applicable.

Any significant anomalies or deviations from established protocols are documented in Non-Conformance Reports, which, where appropriate, are included within this analytical report. Additional comments related to specific analytical tests may be included as remarks following the analytical results for each sample. Such comments and remarks are for informational purposes only and are not intended to convey judgement about the usability of the reported data.

A quality control report on the performance of the test method for the submitted samples is included. Uncertainty associated with the analytical results contained in this report can be estimated from the reported quality assurance results and from published quality control acceptance limits for each analytical test. Matrix quality control results (matrix spike recoveries and matrix sample precision) pertain only to the matrix sample tested and do not necessarily reflect test method performance for other samples.

Typical matrix quality control (QC) measurements may include matrix spike recovery, matrix spike duplicate recovery, matrix spike precision and matrix sample precision. Not all matrix QC results may be available or reportable; where they are not an explanation is provided. Typical reasons for unavailable QC results include, but are not limited to, a) insufficient matrix sample to perform some or all QC measurements; b) analyte concentration in the sample replicated was too low for a meaningful measurement of precision and c) analyte concentration in the matrix sample spiked was too high (relative to the amount of analyte spiked) for a meaningful measurement of recovery. Where matrix QC results are unavailable, other method performance metrics (e.g., LCS recovery, LCS precision, surrogate recovery) may be used to assess performance of the method. Comments explaining any missing QC measurements are not intended to convey any adverse conclusions about the quality of the reported data.

Precision is reported as relative percent difference unless otherwise noted.

Quality Control codes as defined below may be used in this report to indicate results that are associated with one or more quality control elements which did not fall within established test method criteria. Such results may be qualified as estimates using a J qualifier as required by 62-160 F.A.C. Explanations are included in the report for any results that were reported as estimates for other reasons.

QC Codes used in this report may include:

- LCS – Recovery for the batch Laboratory Control Sample (LCS) was outside existing control limits;
- MS – Recovery for the batch matrix spike (MS) was outside existing control limits;
- CCV – Recovery for a continuing calibration verification (CCV) standard was outside existing control limits;
- SUR – Recovery of a surrogate (SUR) for associated analytes was outside existing control limits;
- RPD – The precision, measured as relative percent difference (RPD), of batch replicate measurements was outside existing control limits;
- RSD – The precision, measured as relative standard deviation (RSD), of batch replicate measurements was outside existing control limits;
- SMP – Sample - used precision derived from replicate analyses of a sample;

The following data qualifiers are used, where applicable, in this report as specified in 62-160 F.A.C.

- A - Value reported is the mean of two or more determinations.
- B - Results based on colony counts outside the acceptable range.
- I - The reported value is between the laboratory method detection limit and the laboratory practical quantitation limit.
- J - Estimated value and/or the analysis did not meet established quality control criteria.
- K - Actual value is known to be less than value given.
- L - Actual value is known to be greater than value given.
- N - Presumptive evidence of presence of material.
- O - Sampled, but analysis lost or not performed.
- Q - Sample held beyond normal holding time.
- T - Value reported is less than the criterion of detection.
- U - Material was analyzed for but not detected. The reported value is the method detection limit for the sample analyzed.
- V - Analyte was detected in both sample and method blank.
- X - Too few individuals to calculate SCI value.
- Y - The laboratory analysis was from an unpreserved or improperly preserved sample. The data may not be accurate.
- Z - Colonies were too numerous to count (TNTC).

Quality control information from overflow laboratories may not be included in this report. Please refer to the associated report from the overflow laboratory for additional information.

Sample Location: Orange River- at Orange Harbor RV Resort

Collection Date/Time: 05/27/2021 12:30

Field ID: HAB-SD-052721-002

Matrix: W-SURF-FRH

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2250862	EPA 8321B	Anatoxin-a	0.25	U	ug/L	P398958	
		Cylindrospermopsin	0.10	U	ug/L	P398958	
		Desmethyl microcystin LR	0.25	U	ug/L	P398958	
		Microcystin HIR**	0.25	U	ug/L	P398958	
		Microcystin HtyR**	0.25	U	ug/L	P398958	
		Microcystin LA	0.10	U	ug/L	P398958	
		Microcystin LF	0.10	U	ug/L	P398958	
		Microcystin LR	0.33	I	ug/L	P398958	
		Microcystin LW	0.25	U	ug/L	P398958	
		Microcystin LY	0.10	U	ug/L	P398958	
		Microcystin RR	0.10	U	ug/L	P398958	
		Microcystin WR	0.50	U	ug/L	P398958	
		Microcystin YR	0.25	U	ug/L	P398958	
		Nodularin-R**	0.10	U	ug/L	P398958	
2250874	EPA 350.1 Rev. 2.0	Ammonia-N	0.012		mg N/L	P399371	
	EPA 351.2 Rev. 2.0	Kjeldahl Nitrogen	1.2		mg N/L	P399037	
	EPA 353.2 Rev. 2.0	NO2NO3-N	0.004	U	mg N/L	P399030	
	EPA 365.1 Rev. 2.0	Total-P	0.097		mg P/L	P399032	
2250876	EPA 365.1 Rev. 2.0 dissolved	O-Phosphate-P	0.034		mg P/L	P398987	

Sample Location: Orange River - Manatee Park

Collection Date/Time: 05/27/2021 12:00

Field ID: HAB-SD-052721-001

Matrix: W-SURF-FRH

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2250863	EPA 8321B	Anatoxin-a	0.25	U	ug/L	P398958	
		Cylindrospermopsin	0.10	U	ug/L	P398958	
		Desmethyl microcystin LR	0.25	U	ug/L	P398958	
		Microcystin HIR**	0.25	U	ug/L	P398958	
		Microcystin HtyR**	0.25	U	ug/L	P398958	
		Microcystin LA	0.10	U	ug/L	P398958	
		Microcystin LF	0.10	U	ug/L	P398958	
		Microcystin LR	6.2		ug/L	P398958	
		Microcystin LW	0.25	U	ug/L	P398958	
		Microcystin LY	0.10	U	ug/L	P398958	
		Microcystin RR	0.10	U	ug/L	P398958	
		Microcystin WR	0.50	U	ug/L	P398958	
		Microcystin YR	0.25	U	ug/L	P398958	
		Nodularin-R**	0.10	U	ug/L	P398958	
2250875	EPA 350.1 Rev. 2.0	Ammonia-N	0.011		mg N/L	P399372	
	EPA 351.2 Rev. 2.0	Kjeldahl Nitrogen	1.5		mg N/L	P399039	
	EPA 353.2 Rev. 2.0	NO2NO3-N	0.004	U	mg N/L	P399030	
	EPA 365.1 Rev. 2.0	Total-P	0.13		mg P/L	P399034	
2250877	EPA 365.1 Rev. 2.0 dissolved	O-Phosphate-P	0.037		mg P/L	P398987	

Ref. Method and Comment:

EPA 351.2 Rev. 2.0: Batch matrix spike recoveries are unavailable because of high analyte concentration in the QC sample.

Quality Assurance Report Method Blank Results

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P399371

Component	Result	Code	Units
Ammonia-N	0.002	U	mg N/L

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P399372

Component	Result	Code	Units
Ammonia-N	0.002	U	mg N/L

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P399037

Component	Result	Code	Units
Kjeldahl Nitrogen	0.080	U	mg N/L

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P399039

Component	Result	Code	Units
Kjeldahl Nitrogen	0.080	U	mg N/L

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P399030

Component	Result	Code	Units
NO2NO3-N	0.004	U	mg N/L

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P399032

Component	Result	Code	Units
Total-P	0.002	U	mg P/L

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P399034

Component	Result	Code	Units
Total-P	0.002	U	mg P/L

Reference Method: EPA 365.1 Rev. 2.0 dissolved
Batch ID: P398987

Component	Result	Code	Units
O-Phosphate-P	0.004	U	mg P/L

Reference Method: EPA 8321B
Batch ID: P398958

Component	Result	Code	Units
Anatoxin-a	0.25	U	ug/L
Cylindrospermopsin	0.10	U	ug/L
Desmethyl microcystin LR	0.25	U	ug/L
Microcystin HiLR	0.25	U	ug/L

Quality Assurance Report

Method Blank Results

Reference Method: EPA 8321B
Batch ID: P398958

Component	Result	Code	Units
Microcystin HtyR	0.25	U	ug/L
Microcystin LA	0.10	U	ug/L
Microcystin LF	0.10	U	ug/L
Microcystin LR	0.25	U	ug/L
Microcystin LW	0.25	U	ug/L
Microcystin LY	0.10	U	ug/L
Microcystin RR	0.10	U	ug/L
Microcystin WR	0.50	U	ug/L
Microcystin YR	0.25	U	ug/L
Nodularin-R	0.10	U	ug/L

Quality Assurance Report

Laboratory Control Sample Accuracy

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P399371

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Ammonia-N	98.8		P	90 - 110

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P399372

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Ammonia-N	99.6		P	90 - 110

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P399037

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Kjeldahl Nitrogen	106		P	90 - 110

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P399039

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Kjeldahl Nitrogen	104		P	90 - 110

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P399030

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
NO2NO3-N	100		P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P399032

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Total-P	106		P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P399034

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Total-P	109		P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0 dissolved
Batch ID: P398987

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
O-Phosphate-P	100		P	90 - 110

Reference Method: EPA 8321B
Batch ID: P398958

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Anatoxin-a	93.7		P	40 - 150
Cylindrospermopsin	91.4		P	40 - 150
Desmethyl microcystin LR	89.3		P	40 - 150
Microcystin HiLR	99.9		P	40 - 150

Quality Assurance Report

Laboratory Control Sample Accuracy

Reference Method: EPA 8321B
Batch ID: P398958

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Microcystin HtyR	97.0		P	40 - 150
Microcystin LA	99.4		P	40 - 150
Microcystin LF	95.5		P	40 - 150
Microcystin LR	95.8		P	40 - 150
Microcystin LW	94.2		P	40 - 150
Microcystin LY	97.6		P	40 - 150
Microcystin RR	98.4		P	40 - 150
Microcystin WR	99.1		P	40 - 150
Microcystin YR	96.7		P	40 - 150
Nodularin-R	96.3		P	40 - 150

Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P399371

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2250594	Ammonia-N	96.2	99.4	P/P	90 - 110

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P399372

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2250908	Ammonia-N	99.2	101	P/P	90 - 110

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P399037

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2250597	Kjeldahl Nitrogen	94.4	108	P/P	90 - 110

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P399030

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2250581	NO2NO3-N	98.5	99.0	P/P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P399032

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2249753	Total-P	102	104	P/P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P399034

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2250875	Total-P	105	104	P/P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0 dissolved
Batch ID: P398987

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2250906	O-Phosphate-P	98.0	99.3	P/P	90 - 110

Reference Method: EPA 8321B
Batch ID: P398958

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2250884	Anatoxin-a	103	101	P/P	40 - 150
2250884	Cylindrospermopsin	94.5	98.0	P/P	40 - 150
2250884	Desmethyl microcystin LR	97.5	99.5	P/P	40 - 150
2250884	Microcystin HilR	98.1	110	P/P	40 - 150
2250884	Microcystin HtyR	104	104	P/P	40 - 150
2250884	Microcystin LA	104	103	P/P	40 - 150
2250884	Microcystin LF	99.6	104	P/P	40 - 150
2250884	Microcystin LR	89.8	99.3	P/P	40 - 150
2250884	Microcystin LW	95.5	92.3	P/P	40 - 150
2250884	Microcystin LY	101	110	P/P	40 - 150

Quality Assurance Report

Matrix Spike Accuracy

Reference Method: EPA 8321B
Batch ID: P398958

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2250884	Microcystin RR	95.6	96.8	P/P	40 - 150
2250884	Microcystin WR	92.8	96.0	P/P	40 - 150
2250884	Microcystin YR	115	109	P/P	40 - 150
2250884	Nodularin-R	105	102	P/P	40 - 150

Quality Assurance Report Precision

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P399371

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2250594	Ammonia-N	2.77	Spike	P	0 - 20

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P399372

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2250908	Ammonia-N	1.77	Spike	P	0 - 20

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P399037

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2250597	Kjeldahl Nitrogen	8.25	Spike	P	0 - 20

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P399039

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2250905	Kjeldahl Nitrogen	6.29	Spike	P	0 - 20

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P399030

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2250581	NO2NO3-N	0.506	Spike	P	0 - 20

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P399032

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2249753	Total-P	1.16	Spike	P	0 - 20

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P399034

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2250875	Total-P	1.17	Spike	P	0 - 20

Reference Method: EPA 365.1 Rev. 2.0 dissolved
Batch ID: P398987

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2250906	O-Phosphate-P	1.32	Spike	P	0 - 20

Quality Assurance Report Precision

Reference Method: EPA 8321B

Batch ID: P398958

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2250884	Anatoxin-a	2.38	Spike	P	0 - 30
2250884	Cylindrospermopsin	3.56	Spike	P	0 - 30
2250884	Desmethyl microcystin LR	1.98	Spike	P	0 - 30
2250884	Microcystin HlIR	11.2	Spike	P	0 - 30
2250884	Microcystin HtyR	0.530	Spike	P	0 - 30
2250884	Microcystin LA	1.45	Spike	P	0 - 30
2250884	Microcystin LF	3.91	Spike	P	0 - 30
2250884	Microcystin LR	9.63	Spike	P	0 - 30
2250884	Microcystin LW	3.41	Spike	P	0 - 30
2250884	Microcystin LY	8.95	Spike	P	0 - 30
2250884	Microcystin RR	1.17	Spike	P	0 - 30
2250884	Microcystin WR	3.38	Spike	P	0 - 30
2250884	Microcystin YR	4.73	Spike	P	0 - 30
2250884	Nodularin-R	2.96	Spike	P	0 - 30

* Sample, spike and/or laboratory control sample precision (LCS) is reported.

Quality Assurance Report Surrogates

Lab Sample ID: 2250862

Field Sample ID: HAB-SD-052721-002

Reference Method	Surrogate	% Rec.	Pass/Fail	Control Limits
EPA 8321B	Microcystin LR-d7	111	P	30 - 160
EPA 8321B	Microcystin LR ethyl-d5	126	P	30 - 160

Lab Sample ID: 2250863

Field Sample ID: HAB-SD-052721-001

Reference Method	Surrogate	% Rec.	Pass/Fail	Control Limits
EPA 8321B	Microcystin LR-d7	111	P	30 - 160
EPA 8321B	Microcystin LR ethyl-d5	129	P	30 - 160

Quality Assurance Report Calibration Verification

Reference Method: EPA 365.1 Rev. 2.0 dissolved

Run ID: A105764

Included Lab Sample IDs: 2250876, 2250877

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
O-Phosphate-P	98.8	99.3	P/P	90 - 110
O-Phosphate-P	99.3	99.2	P/P	90 - 110

Reference Method: EPA 8321B

Run ID: A105770

Included Lab Sample IDs: 2250862, 2250863

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Anatoxin-a	96.5	103	P/P	50 - 160
Cylindrospermopsin	106	103	P/P	50 - 160
Desmethyl microcystin LR	103	114	P/P	50 - 160
Microcystin H1R	114	120	P/P	50 - 160
Microcystin HtyR	112	115	P/P	50 - 160
Microcystin LA	115	115	P/P	50 - 160
Microcystin LF	107	113	P/P	50 - 160
Microcystin LR	101	112	P/P	50 - 160
Microcystin LW	98.9	101	P/P	50 - 160
Microcystin LY	105	116	P/P	50 - 160
Microcystin RR	106	108	P/P	50 - 160
Microcystin WR	108	108	P/P	50 - 160
Microcystin YR	121	121	P/P	50 - 160
Nodularin-R	106	114	P/P	50 - 160

Reference Method: EPA 353.2 Rev. 2.0

Run ID: A105788

Included Lab Sample IDs: 2250874, 2250875

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
NO2NO3-N	101	102	P/P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0

Run ID: A105810

Included Lab Sample IDs: 2250874, 2250875

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Total-P	102	102	P/P	85 - 115
Total-P	104	103	P/P	85 - 115

Reference Method: EPA 351.2 Rev. 2.0

Run ID: A105840

Included Lab Sample IDs: 2250874, 2250875

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Kjeldahl Nitrogen	99.2	104	P/P	90 - 110
Kjeldahl Nitrogen	99.6	105	P/P	90 - 110

Reference Method: EPA 350.1 Rev. 2.0

Run ID: A105942

Included Lab Sample IDs: 2250874, 2250875

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
-----------	---------	---------	------------	----------------

Quality Assurance Report Calibration Verification

Reference Method: EPA 350.1 Rev. 2.0

Run ID: A105942

Included Lab Sample IDs: 2250874, 2250875

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Ammonia-N	100	99.0	P/P	90 - 110
Ammonia-N	99.0	100	P/P	90 - 110

* Pass/Fail determinations are made for each bracketing calibration verification check.

Control limits for initial calibration checks may be different from those for continuing checks, depending on method requirements.

Where they are different, both control limits are provided.

Quality Assurance Report Summary

Ref. Method	Analyte	LCS % Recovery	MS % Recovery		LCS	Precision	MS
						SMP	
EPA 350.1 Rev. 2.0	Ammonia-N	98.8	96.2	99.4			2.77
	Ammonia-N	99.6	99.2	101			1.77
EPA 351.2 Rev. 2.0	Kjeldahl Nitrogen	106	94.4	108			8.25
	Kjeldahl Nitrogen	104					6.29
EPA 353.2 Rev. 2.0	NO ₂ NO ₃ -N	100	98.5	99.0			0.506
EPA 365.1 Rev. 2.0	Total-P	106	102	104			1.16
	Total-P	109	105	104			1.17
EPA 365.1 Rev. 2.0 dissolved	O-Phosphate-P	100	98.0	99.3			1.32
EPA 8321B	Anatoxin-a	93.7	103	101			2.38
	Cylindrospermopsin	91.4	94.5	98.0			3.56
	Desmethyl microcystin LR	89.3	97.5	99.5			1.98
	Microcystin HiLR	99.9	98.1	110			11.2
	Microcystin HtyR	97.0	104	104			0.530
	Microcystin LA	99.4	104	103			1.45
	Microcystin LF	95.5	99.6	104			3.91
	Microcystin LR	95.8	89.8	99.3			9.63
	Microcystin LW	94.2	95.5	92.3			3.41
	Microcystin LY	97.6	101	110			8.95
	Microcystin RR	98.4	95.6	96.8			1.17
	Microcystin WR	99.1	92.8	96.0			3.38
	Microcystin YR	96.7	115	109			4.73
	Nodularin-R	96.3	105	102			2.96

Reference Method Descriptions

Method	Description	Associated Samples
EPA 350.1 Rev. 2.0	Ammonia in aqueous matrices as mg N/L	2250874, 2250875
EPA 351.2 Rev. 2.0	Total Kjeldahl Nitrogen in aqueous matrices	2250874, 2250875
EPA 353.2 Rev. 2.0	Nitrite/Nitrate in aqueous matrices as mg N/L	2250874, 2250875
EPA 365.1 Rev. 2.0	Total Phosphorus in aqueous matrices as mg P/L	2250874, 2250875
EPA 365.1 Rev. 2.0 dissolved	Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L	2250876, 2250877
EPA 8321B	Microcystins in water matrices by HPLC/MS/MS	2250862, 2250863

Preparation and Analysis Log

Ref. Method	Received Date	Prep Date/Time	Prepared By	Analysis Date/Time	Analyzed By	Associated Samples
EPA 350.1 Rev. 2.0	05/28/2021			06/08/2021 13:44	Roberta Tatti	2250874
	05/28/2021			06/08/2021 13:58	Roberta Tatti	2250875
EPA 351.2 Rev. 2.0	05/28/2021	06/01/2021 13:29	Benjamin T. Nordmann	06/02/2021 16:43	Virginia P. Brown	2250874
	05/28/2021	06/01/2021 13:33	Benjamin T. Nordmann	06/02/2021 17:21	Virginia P. Brown	2250875
EPA 353.2 Rev. 2.0	05/28/2021			06/01/2021 11:44	Beverly Y. Sanders	2250874
	05/28/2021			06/01/2021 11:45	Beverly Y. Sanders	2250875
EPA 365.1 Rev. 2.0	05/28/2021	06/01/2021 13:09	Yen Ta	06/02/2021 10:45	Shengyu Ding	2250874
	05/28/2021	06/01/2021 13:09	Yen Ta	06/02/2021 11:08	Shengyu Ding	2250875
EPA 365.1 Rev. 2.0 dissolved	05/28/2021			05/28/2021 13:05	Lipi Saha	2250876
	05/28/2021			05/28/2021 13:10	Lipi Saha	2250877
EPA 8321B	05/28/2021	05/28/2021 12:30	Juyoung Kim	05/28/2021 22:49	Juyoung Kim	2250862
	05/28/2021	05/28/2021 12:30	Juyoung Kim	05/28/2021 23:06	Juyoung Kim	2250863