

# Chemical Analysis Report

**SE-DIST-2016-04-26-01**

Florida Department of Environmental Protection  
Central Laboratory  
2600 Blair Stone Road  
Tallahassee, FL 32399-2400  
DOH Accreditation E31780

Event Description: **SMP\_2016 Purple A/B**

Request ID: **RQ-2016-04-25-10**

Customer: **SE-DIST**

Project ID: **SMP**

Send Reports to:

FL Dept. of Environmental Protection  
FL Dept. of Environmental Protection  
2199 South Rock Road  
Fort Pierce, FL 34945  
Attn: Jordan Skaggs

For additional information please contact

Timothy W. Fitzpatrick  
Liang-Tsair Lin, Ph.D.  
Colin Wright, Ph.D.  
Thekkekalathil Chandrasekhar, PhD, QA Officer  
Phone (850) 245-8085

Certified by: Thekkekalathil Chandrasekhar, Chemist Administrator

Date Certified: 20-MAY-2016 10:55



## Case Narrative

Unless otherwise noted, all samples included in this report were received in accordance with protocols referenced in Chapter 62-160, Florida Administrative Code (F.A.C.). Results published in this report pertain only to the samples as submitted to, and received by the laboratory. All times in this report are adjusted to the applicable Eastern Time Zone (EST or EDT).

Results for the following analytical groups are included in this report: Metals, Nutrients and Pesticides.

Scientific notation may be used in reporting very large or small values. Values reported using scientific notation will take the form of the following example: 1.3E+03, which is equivalent to  $1.3 \times 10^3$  or 1300.

Unless otherwise noted, analytical values for soil and sediment samples are reported on a dry weight basis, and analytical values for waste and tissue samples are reported on a wet weight basis.

Results for TNI accredited tests met requirements established by The NELAC Institute. A double asterisk (\*\*) is used to indicate an analyte/matrix/method for which the laboratory is not TNI accredited or where accreditation for that field of testing is not applicable.

Any significant anomalies or deviations from established protocols are documented in Non-Conformance Reports, which, where appropriate, are included within this analytical report. Additional comments related to specific analytical tests may be included as remarks following the analytical results for each sample. Such comments and remarks are for informational purposes only and are not intended to convey judgement about the usability of the reported data.

A quality control report on the performance of the test method for the submitted samples is included. Uncertainty associated with the analytical results contained in this report can be estimated from the reported quality assurance results and from published quality control acceptance limits for each analytical test. Matrix quality control results (matrix spike recoveries and matrix sample precision) pertain only to the matrix sample tested and do not necessarily reflect test method performance for other samples.

Typical matrix quality control (QC) measurements may include matrix spike recovery, matrix spike duplicate recovery, matrix spike precision and matrix sample precision. Not all matrix QC results may be available or reportable; where they are not an explanation is provided. Typical reasons for unavailable QC results include, but are not limited to, a) insufficient matrix sample to perform some or all QC measurements; b) analyte concentration in the sample replicated was too low for a meaningful measurement of precision and c) analyte concentration in the matrix sample spiked was too high (relative to the amount of analyte spiked) for a meaningful measurement of recovery. Where matrix QC results are unavailable, other method performance metrics (e.g., LCS recovery, LCS precision, surrogate recovery) may be used to assess performance of the method. Comments explaining any missing QC measurements are not intended to convey any adverse conclusions about the quality of the reported data.

Precision is reported as relative percent difference unless otherwise noted.

Quality Control codes as defined below may be used in this report to indicate results that are associated with one or more quality control elements which did not fall within established test method criteria. Such results may be qualified as estimates using a J qualifier as required by 62-160 F.A.C. Explanations are included in the report for any results that were reported as estimates for other reasons.

QC Codes used in this report may include:

- LCS – Recovery for the batch Laboratory Control Sample (LCS) was outside existing control limits;
- MS – Recovery for the batch matrix spike (MS) was outside existing control limits;
- CCV – Recovery for a continuing calibration verification (CCV) standard was outside existing control limits;
- SUR – Recovery of a surrogate (SUR) for associated analytes was outside existing control limits;
- RPD – The precision, measured as relative percent difference (RPD), of batch replicate measurements was outside existing control limits;
- RSD – The precision, measured as relative standard deviation (RSD), of batch replicate measurements was outside existing control limits;
- SMP – Sample - used precision derived from replicate analyses of a sample;

The following data qualifiers are used, where applicable, in this report as specified in 62-160 F.A.C.

- A - Value reported is the mean of two or more determinations.
- B - Results based on colony counts outside the acceptable range.
- I - The reported value is between the laboratory method detection limit and the laboratory practical quantitation limit.
- J - Estimated value and/or the analysis did not meet established quality control criteria.
- K - Actual value is known to be less than value given.
- L - Actual value is known to be greater than value given.
- N - Presumptive evidence of presence of material.
- O - Sampled, but analysis lost or not performed.
- Q - Sample held beyond normal holding time.
- T - Value reported is less than the criterion of detection.
- U - Material was analyzed for but not detected. The reported value is the method detection limit for the sample analyzed.
- V - Analyte was detected in both sample and method blank.
- X - Too few individuals to calculate SCI value.
- Y - The laboratory analysis was from an unpreserved or improperly preserved sample. The data may not be accurate.
- Z - Colonies were too numerous to count (TNTC).

Quality control information from overflow laboratories may not be included in this report. Please refer to the associated report from the overflow laboratory for additional information.

**Sample Location: New River (North Fork) @ NW 6th St**

**Collection Date/Time: 04/25/2016 10:15**

**Field ID: G4SEB064**

**Matrix: W-SURF-FRH**

| Sample ID | Ref. Method                     | Component         | Result | Code | Units      | Batch ID | QC Codes |
|-----------|---------------------------------|-------------------|--------|------|------------|----------|----------|
| 1792851   | EPA 180.1 Rev. 2.0              | Turbidity         | 5.6    | A    | NTU        | P303008  |          |
|           | EPA 300.0 Rev. 2.1              | Sulfate           | 180    |      | mg SO4/L   | P303582  |          |
|           | SM 2320 B-97                    | Total Alkalinity  | 213    |      | mg CaCO3/L | P303463  |          |
|           | SM 2540 D-97                    | TSS               | 11     | A    | mg/L       | P303314  |          |
|           | SM 4500 F-C-97                  | Fluoride          | 0.29   |      | mg F/L     | P303279  |          |
| 1792852   | EPA 350.1 Rev. 2.0              | Ammonia-N         | 0.065  |      | mg N/L     | P303691  |          |
|           | EPA 351.2 Rev. 2.0              | Kjeldahl Nitrogen | 1.2    |      | mg N/L     | P304112  |          |
|           | EPA 353.2 Rev. 2.0              | NO2NO3-N          | 0.050  |      | mg N/L     | P303636  |          |
|           | EPA 365.1 Rev. 2.0              | Total-P           | 0.11   |      | mg P/L     | P303806  | MS       |
|           | SM 5310 B-00                    | Organic Carbon    | 11     |      | mg C/L     | P304298  |          |
| 1792853   | EPA 365.1 Rev. 2.0<br>dissolved | O-Phosphate-P     | 0.041  |      | mg P/L     | P302987  |          |
| 1792867   | EPA 200.7 Rev. 4.4              | Iron              | 260    |      | ug/L       | P303173  |          |
|           |                                 | Zinc              | 9.4    | I    | ug/L       | P303173  |          |
|           | EPA 200.8 Rev. 5.4              | Arsenic           | 2.54   |      | ug/L       | P303173  |          |
|           |                                 | Cadmium           | 0.042  | I    | ug/L       | P303173  |          |
|           |                                 | Chromium          | 0.70   |      | ug/L       | P303173  |          |
|           |                                 | Copper            | 4.78   |      | ug/L       | P303173  |          |
|           |                                 | Lead              | 2.23   |      | ug/L       | P303173  |          |
|           |                                 | Nickel            | 0.69   |      | ug/L       | P303173  |          |
|           |                                 | Silver            | 0.040  |      | ug/L       | P303173  |          |

Ref. Method and Comment:

EPA 350.1 Rev. 2.0: Matrix spike recovery data is unavailable due to high analyte concentration in the QC sample.

**Sample Location: C-12 Canal @ Sunrise & 441**

**Collection Date/Time: 04/25/2016 10:40**

**Field ID: G4SEB121**

**Matrix: W-SURF-FRH**

| Sample ID | Ref. Method                     | Component         | Result | Code | Units      | Batch ID | QC Codes |
|-----------|---------------------------------|-------------------|--------|------|------------|----------|----------|
| 1792836   | EPA 180.1 Rev. 2.0              | Turbidity         | 0.55   |      | NTU        | P303007  |          |
|           | EPA 300.0 Rev. 2.1              | Chloride          | 37     |      | mg Cl/L    | P303578  |          |
|           |                                 | Sulfate           | 11     |      | mg SO4/L   | P303582  |          |
|           | SM 2120 B                       | Color (true)      | 24     | A    | PCU        | P303015  |          |
|           | SM 2320 B-97                    | Total Alkalinity  | 77     |      | mg CaCO3/L | P303462  |          |
|           | SM 2540 C-97                    | TDS               | 171    |      | mg/L       | P303446  |          |
|           | SM 2540 D-97                    | TSS               | 2      | U    | mg/L       | P303313  |          |
|           | SM 4500 F-C-97                  | Fluoride          | 0.18   |      | mg F/L     | P303278  |          |
| 1792841   | EPA 350.1 Rev. 2.0              | Ammonia-N         | 0.013  |      | mg N/L     | P303685  |          |
|           | EPA 351.2 Rev. 2.0              | Kjeldahl Nitrogen | 0.57   |      | mg N/L     | P303931  |          |
|           | EPA 353.2 Rev. 2.0              | NO2NO3-N          | 0.007  | I    | mg N/L     | P303852  |          |
|           | EPA 365.1 Rev. 2.0              | Total-P           | 0.015  |      | mg P/L     | P304059  |          |
|           | SM 5310 B-00                    | Organic Carbon    | 8.8    |      | mg C/L     | P304298  |          |
| 1792846   | EPA 365.1 Rev. 2.0<br>dissolved | O-Phosphate-P     | 0.004  | U    | mg P/L     | P302985  |          |
| 1792862   | EPA 200.7 Rev. 4.4              | Calcium           | 29.7   |      | mg/L       | P303173  |          |
|           |                                 | Iron              | 30     | U    | ug/L       | P303173  |          |
|           |                                 | Magnesium         | 4.94   |      | mg/L       | P303173  |          |

**Field ID: G4SEB121**

Matrix: W-SURF-FRH

| Sample ID | Ref. Method        | Component | Result | Code | Units | Batch ID | QC Codes |
|-----------|--------------------|-----------|--------|------|-------|----------|----------|
| 1792862   | EPA 200.7 Rev. 4.4 | Potassium | 1.3    |      | mg/L  | P303173  |          |
|           |                    | Sodium    | 24.7   |      | mg/L  | P303173  |          |
|           |                    | Zinc      | 5.0    | U    | ug/L  | P303173  |          |
|           | EPA 200.8 Rev. 5.4 | Arsenic   | 0.92   |      | ug/L  | P303173  |          |
|           |                    | Cadmium   | 0.020  | U    | ug/L  | P303173  |          |
|           |                    | Chromium  | 0.14   | I    | ug/L  | P303173  |          |
|           |                    | Copper    | 2.20   |      | ug/L  | P303173  |          |
|           |                    | Lead      | 0.15   | I    | ug/L  | P303173  |          |
|           |                    | Nickel    | 0.35   |      | ug/L  | P303173  |          |
|           |                    | Silver    | 0.0050 | U    | ug/L  | P303173  |          |

Ref. Method and Comment:

SM 2540 D-97: The precision data is unavailable due to the low analyte concentration in the QC sample.

**Sample Location: C-12 @ Sunrise & 9th Drive**

**Collection Date/Time: 04/25/2016 11:10**

**Field ID: G4SEB128**

Matrix: W-SURF-FRH

| Sample ID | Ref. Method                  | Component         | Result | Code | Units      | Batch ID | QC Codes |
|-----------|------------------------------|-------------------|--------|------|------------|----------|----------|
| 1792837   | EPA 180.1 Rev. 2.0           | Turbidity         | 1.0    |      | NTU        | P303007  |          |
|           | EPA 300.0 Rev. 2.1           | Chloride          | 43     |      | mg Cl/L    | P303578  |          |
|           |                              | Sulfate           | 13     |      | mg SO4/L   | P303582  |          |
|           |                              | Color (true)      | 26     |      | PCU        | P303015  |          |
|           | SM 2320 B-97                 | Total Alkalinity  | 113    |      | mg CaCO3/L | P303462  |          |
|           | SM 2540 C-97                 | TDS               | 219    |      | mg/L       | P303446  |          |
|           | SM 2540 D-97                 | TSS               | 2      | U    | mg/L       | P303313  |          |
|           | SM 4500 F-C-97               | Fluoride          | 0.20   |      | mg F/L     | P303278  |          |
|           | EPA 350.1 Rev. 2.0           | Ammonia-N         | 0.009  |      | mg N/L     | P303685  |          |
|           |                              | Kjeldahl Nitrogen | 0.73   |      | mg N/L     | P303931  |          |
| 1792842   | EPA 353.2 Rev. 2.0           | NO2NO3-N          | 0.004  | U    | mg N/L     | P303852  |          |
|           | EPA 365.1 Rev. 2.0           | Total-P           | 0.015  |      | mg P/L     | P304059  |          |
|           | SM 5310 B-00                 | Organic Carbon    | 9.8    |      | mg C/L     | P304298  |          |
| 1792847   | EPA 365.1 Rev. 2.0 dissolved | O-Phosphate-P     | 0.004  | U    | mg P/L     | P302985  |          |
| 1792863   | EPA 200.7 Rev. 4.4           | Calcium           | 45.9   |      | mg/L       | P303173  |          |
|           |                              | Iron              | 30     | U    | ug/L       | P303173  |          |
|           |                              | Magnesium         | 5.64   |      | mg/L       | P303173  |          |
|           |                              | Potassium         | 1.9    |      | mg/L       | P303173  |          |
|           |                              | Sodium            | 29.1   |      | mg/L       | P303173  |          |
|           |                              | Zinc              | 5.0    | U    | ug/L       | P303173  |          |
|           | EPA 200.8 Rev. 5.4           | Arsenic           | 1.06   |      | ug/L       | P303173  |          |
|           |                              | Cadmium           | 0.020  | U    | ug/L       | P303173  |          |
|           |                              | Chromium          | 0.16   | I    | ug/L       | P303173  |          |
|           |                              | Copper            | 4.04   |      | ug/L       | P303173  |          |
|           |                              | Lead              | 0.16   | I    | ug/L       | P303173  |          |
|           |                              | Nickel            | 0.35   |      | ug/L       | P303173  |          |
|           |                              | Silver            | 0.0050 | U    | ug/L       | P303173  |          |

Ref. Method and Comment:

SM 2540 D-97: The precision data is unavailable due to the low analyte concentration in the QC sample.

Sample Location: New River Canal (North) @ University Drive

Collection Date/Time: 04/25/2016 11:30

Field ID: G4SENNR3

Matrix: W-SURF-FRH

| Sample ID | Ref. Method                  | Component         | Result | Code | Units      | Batch ID | QC Codes |
|-----------|------------------------------|-------------------|--------|------|------------|----------|----------|
| 1792838   | EPA 180.1 Rev. 2.0           | Turbidity         | 0.80   |      | NTU        | P303007  |          |
|           | EPA 300.0 Rev. 2.1           | Chloride          | 95     |      | mg Cl/L    | P303578  |          |
|           |                              | Sulfate           | 22     |      | mg SO4/L   | P303582  |          |
|           |                              | Color (true)      | 92     |      | PCU        | P303015  |          |
|           | SM 2320 B-97                 | Total Alkalinity  | 213    |      | mg CaCO3/L | P303462  |          |
|           | SM 2540 C-97                 | TDS               | 452    |      | mg/L       | P303446  |          |
|           | SM 2540 D-97                 | TSS               | 2      | U    | mg/L       | P303313  |          |
|           | SM 4500 F-C-97               | Fluoride          | 0.42   |      | mg F/L     | P303278  |          |
| 1792843   | EPA 350.1 Rev. 2.0           | Ammonia-N         | 0.084  |      | mg N/L     | P303685  |          |
|           | EPA 351.2 Rev. 2.0           | Kjeldahl Nitrogen | 1.6    |      | mg N/L     | P303931  |          |
|           | EPA 353.2 Rev. 2.0           | NO2NO3-N          | 0.075  |      | mg N/L     | P303852  |          |
|           | EPA 365.1 Rev. 2.0           | Total-P           | 0.01   |      | mg P/L     | P304059  |          |
|           | SM 5310 B-00                 | Organic Carbon    | 27     |      | mg C/L     | P304298  |          |
| 1792848   | EPA 365.1 Rev. 2.0 dissolved | O-Phosphate-P     | 0.004  | U    | mg P/L     | P302986  |          |
| 1792864   | EPA 200.7 Rev. 4.4           | Calcium           | 72.8   |      | mg/L       | P303173  |          |
|           |                              | Iron              | 64     | I    | ug/L       | P303173  |          |
|           |                              | Magnesium         | 18.7   |      | mg/L       | P303173  |          |
|           |                              | Potassium         | 5.6    |      | mg/L       | P303173  |          |
|           |                              | Sodium            | 61.1   |      | mg/L       | P303173  |          |
|           | EPA 200.8 Rev. 5.4           | Zinc              | 5.0    | U    | ug/L       | P303173  |          |
|           |                              | Arsenic           | 1.33   |      | ug/L       | P303173  |          |
|           |                              | Cadmium           | 0.020  | U    | ug/L       | P303173  |          |
|           |                              | Chromium          | 0.13   | I    | ug/L       | P303173  |          |
|           |                              | Copper            | 0.33   | I    | ug/L       | P303173  |          |
|           |                              | Lead              | 0.19   | I    | ug/L       | P303173  |          |
|           |                              | Nickel            | 0.15   | I    | ug/L       | P303173  |          |
|           |                              | Silver            | 0.0050 | U    | ug/L       | P303173  |          |

Ref. Method and Comment:

SM 2540 D-97: The precision data is unavailable due to the low analyte concentration in the QC sample.

Sample Location: New River Canal (North) @ University Drive

Collection Date/Time: 04/25/2016 11:30

Field ID: G4SENNR3

Matrix: W-SURF-FRH

| Sample ID | Ref. Method    | Component    | Result | Code | Units | Batch ID | QC Codes |
|-----------|----------------|--------------|--------|------|-------|----------|----------|
| 1792860   | USGS O-2060-01 | 2,4-D        | 0.0020 | UJ   | ug/L  | P302924  | MS       |
|           |                | Diuron       | 0.0020 | U    | ug/L  | P302924  |          |
|           |                | 2,4-DB       | 0.0020 | U    | ug/L  | P302924  |          |
|           |                | Fenuron      | 0.0080 | U    | ug/L  | P302924  |          |
|           |                | 2,4,5-T      | 0.0020 | U    | ug/L  | P302924  |          |
|           |                | Acifluorfen  | 0.0020 | U    | ug/L  | P302924  |          |
|           |                | Imidacloprid | 0.0040 | UJ   | ug/L  | P302924  | MS       |
|           |                | Bentazon     | 0.21   |      | ug/L  | P302924  |          |
|           |                | Linuron      | 0.0040 | U    | ug/L  | P302924  |          |
|           |                | Dichlorprop  | 0.0020 | U    | ug/L  | P302924  |          |

Field ID: G4SENNR3

Matrix: W-SURF-FRH

| Sample ID | Ref. Method                                     | Component             | Result  | Code | Units | Batch ID | QC Codes |
|-----------|-------------------------------------------------|-----------------------|---------|------|-------|----------|----------|
| 1792860   | USGS O-2060-01                                  | Dinoseb               | 0.020   | U    | ug/L  | P302924  |          |
|           |                                                 | MCPA                  | 0.0040  | U    | ug/L  | P302924  |          |
|           |                                                 | Acetaminophen**       | 0.0040  | UJ   | ug/L  | P302924  | LCS, RPD |
|           |                                                 | MCPD                  | 0.0040  | U    | ug/L  | P302924  |          |
|           |                                                 | Carbamazepine**       | 4.0E-04 | U    | ug/L  | P302924  |          |
|           |                                                 | Silvex                | 0.0020  | UJ   | ug/L  | P302924  | MS       |
|           |                                                 | Primidone**           | 0.0080  | U    | ug/L  | P302924  |          |
|           |                                                 | Fluridone**           | 8.9E-04 | I    | ug/L  | P302924  |          |
| 1792868   | DEP SOP: GC-011-5<br>(based on EPA 608 and 617) | Aldrin                | 0.0020  | U    | ug/L  | P302942  |          |
|           |                                                 | Alpha-BHC             | 0.0020  | U    | ug/L  | P302942  |          |
|           |                                                 | Beta-BHC              | 0.0020  | U    | ug/L  | P302942  |          |
|           |                                                 | Delta-BHC             | 0.0020  | U    | ug/L  | P302942  |          |
|           |                                                 | Gamma-BHC             | 0.0020  | U    | ug/L  | P302942  |          |
|           |                                                 | Carbophenothion       | 0.0059  | UJ   | ug/L  | P302942  | CCV      |
|           |                                                 | Chlorothalonil        | 0.0078  | UJ   | ug/L  | P302942  | CCV      |
|           |                                                 | Cypermethrin          | 0.012   | UJ   | ug/L  | P302942  | CCV      |
|           |                                                 | DDD-p,p'              | 0.0039  | U    | ug/L  | P302942  |          |
|           |                                                 | DDE-p,p'              | 0.0039  | U    | ug/L  | P302942  |          |
|           |                                                 | DDT-p,p'              | 0.0039  | U    | ug/L  | P302942  | MS, RPD  |
|           |                                                 | Dicofol               | 0.024   | U    | ug/L  | P302942  |          |
|           |                                                 | Dieldrin              | 0.0020  | U    | ug/L  | P302942  |          |
|           |                                                 | Endosulfan I          | 0.0020  | U    | ug/L  | P302942  | MS, RPD  |
|           |                                                 | Endosulfan II         | 0.0020  | U    | ug/L  | P302942  |          |
|           |                                                 | Endosulfan Sulfate    | 0.0039  | U    | ug/L  | P302942  |          |
|           |                                                 | Endrin                | 0.0039  | U    | ug/L  | P302942  |          |
|           |                                                 | Endrin Aldehyde       | 0.0039  | U    | ug/L  | P302942  |          |
|           |                                                 | Heptachlor            | 0.0020  | U    | ug/L  | P302942  |          |
|           |                                                 | Heptachlor Epoxide    | 0.0020  | U    | ug/L  | P302942  |          |
|           |                                                 | Methoxychlor          | 0.0098  | U    | ug/L  | P302942  |          |
|           |                                                 | Mirex                 | 0.0039  | U    | ug/L  | P302942  |          |
|           |                                                 | Permethrin            | 0.0098  | U    | ug/L  | P302942  |          |
| 1792870   | EPA 8270D                                       | Ametryn**             | 14      |      | ng/L  | P303196  |          |
|           |                                                 | Atrazine**            | 120     |      | ng/L  | P303196  |          |
|           |                                                 | Chlorpyrifos Ethyl**  | 0.10    | U    | ng/L  | P303196  |          |
|           |                                                 | Chlorpyrifos Methyl** | 0.10    | U    | ng/L  | P303196  |          |
|           |                                                 | Disulfoton**          | 0.32    | U    | ng/L  | P303196  |          |
|           |                                                 | Ethion**              | 0.15    | U    | ng/L  | P303196  |          |
|           |                                                 | Ethoprop**            | 0.10    | U    | ng/L  | P303196  |          |
|           |                                                 | Hexazinone**          | 2.8     |      | ng/L  | P303196  |          |
|           |                                                 | Malathion**           | 0.35    | U    | ng/L  | P303196  |          |
|           |                                                 | Metribuzin**          | 15      |      | ng/L  | P303196  |          |
|           |                                                 | Mevinphos**           | 0.50    | U    | ng/L  | P303196  |          |
|           |                                                 | Norflurazon**         | 0.50    | I    | ng/L  | P303196  |          |
|           |                                                 | Phorate**             | 0.25    | U    | ng/L  | P303196  |          |

**Field ID: G4SENNR3**

Matrix: W-SURF-FRH

| Sample ID | Ref. Method | Component           | Result | Code | Units | Batch ID | QC Codes |
|-----------|-------------|---------------------|--------|------|-------|----------|----------|
| 1792870   | EPA 8270D   | Prometryn**         | 0.68   | I    | ng/L  | P303196  |          |
|           |             | Simazine**          | 0.50   | U    | ng/L  | P303196  |          |
|           |             | Atrazine Desethyl** | 12     |      | ng/L  | P303196  |          |
|           |             | Prometon**          | 0.90   | U    | ng/L  | P303196  |          |
|           |             | Fipronil**          | 0.25   | U    | ng/L  | P303196  |          |
|           |             | Molinate**          | 0.30   | UJ   | ng/L  | P303196  | MS       |
|           |             | Pendimethalin**     | 1.5    | U    | ng/L  | P303196  |          |
|           |             | Terbufos**          | 0.10   | U    | ng/L  | P303196  |          |
|           |             | EPTC**              | 1.2    | UJ   | ng/L  | P303196  | MS       |
|           |             | Terbutylazine**     | 0.42   | U    | ng/L  | P303196  |          |
|           |             | Bromacil**          | 0.50   | U    | ng/L  | P303196  |          |
|           |             | Fipronil Sulfide**  | 0.15   | U    | ng/L  | P303196  |          |
|           |             | Fipronil Sulfone**  | 0.15   | U    | ng/L  | P303196  |          |
|           |             | Alachlor**          | 0.25   | U    | ng/L  | P303196  |          |
|           |             | Azinphos Methyl**   | 2.2    | U    | ng/L  | P303196  |          |
|           |             | Butylate**          | 0.40   | U    | ng/L  | P303196  |          |
|           |             | Demeton**           | 1.0    | U    | ng/L  | P303196  |          |
|           |             | Diazinon**          | 0.12   | U    | ng/L  | P303196  |          |
|           |             | Fenamiphos**        | 0.25   | U    | ng/L  | P303196  |          |
|           |             | Fonofos**           | 0.20   | U    | ng/L  | P303196  |          |
|           |             | Metalaxyl**         | 0.25   | IJ   | ng/L  | P303196  | MS       |
|           |             | Metolachlor**       | 0.61   | I    | ng/L  | P303196  |          |
|           |             | Acetochlor**        | 0.25   | U    | ng/L  | P303196  |          |
|           |             | Cyanazine**         | 0.50   | UJ   | ng/L  | P303196  | CCV, LCS |
|           |             | Parathion Ethyl**   | 0.25   | U    | ng/L  | P303196  |          |
|           |             | Parathion Methyl**  | 0.25   | U    | ng/L  | P303196  |          |

Ref. Method and Comment:

USGS O-2060-01: Triclopyr = 0.013 I ug/L. MS accuracy for bentazon could not be assessed due to high concentration of parameter in the spiked sample. Refer to the narrative for an explanation of QC Codes.

USGS O-2060-01: Refer to the narrative for an explanation of QC Codes.

DEP SOP: GC-011-5 (based on EPA 608 and 617): Refer to the narrative for an explanation of QC Codes.

EPA 8270D: MS accuracy for Atrazine, Ametryn and Metribuzin not assessed due to high content of these parameters in the sample spiked. Refer to the narrative for an explanation of QC Codes.

**Sample Location: New River Canal (North) @ Flamingo Rd**

**Collection Date/Time: 04/25/2016 12:00**

**Field ID: G4SENNR2**

Matrix: W-SURF-FRH

| Sample ID | Ref. Method    | Component    | Result | Code | Units | Batch ID | QC Codes |
|-----------|----------------|--------------|--------|------|-------|----------|----------|
| 1792861   | USGS O-2060-01 | 2,4-D        | 0.0020 | U    | ug/L  | P302924  | MS       |
|           |                | Diuron       | 0.0020 | U    | ug/L  | P302924  |          |
|           |                | 2,4-DB       | 0.0020 | U    | ug/L  | P302924  |          |
|           |                | Fenuron      | 0.0080 | U    | ug/L  | P302924  |          |
|           |                | 2,4,5-T      | 0.0020 | U    | ug/L  | P302924  |          |
|           |                | Acifluorfen  | 0.0020 | U    | ug/L  | P302924  |          |
|           |                | Imidacloprid | 0.0040 | U    | ug/L  | P302924  | MS       |
|           |                | Bentazon     | 0.22   |      | ug/L  | P302924  |          |
|           |                | Linuron      | 0.0040 | U    | ug/L  | P302924  |          |

Field ID: G4SENNR2

Matrix: W-SURF-FRH

| Sample ID | Ref. Method                                     | Component             | Result  | Code | Units | Batch ID | QC Codes |
|-----------|-------------------------------------------------|-----------------------|---------|------|-------|----------|----------|
| 1792861   | USGS O-2060-01                                  | Dichlorprop           | 0.0020  | U    | ug/L  | P302924  |          |
|           |                                                 | Dinoseb               | 0.020   | U    | ug/L  | P302924  |          |
|           |                                                 | MCPA                  | 0.0040  | U    | ug/L  | P302924  |          |
|           |                                                 | Acetaminophen**       | 0.0040  | UJ   | ug/L  | P302924  | LCS, RPD |
|           |                                                 | MCPD                  | 0.0040  | U    | ug/L  | P302924  |          |
|           |                                                 | Carbamazepine**       | 4.0E-04 | U    | ug/L  | P302924  |          |
|           |                                                 | Silvex                | 0.0020  | U    | ug/L  | P302924  | MS       |
|           |                                                 | Primidone**           | 0.0080  | U    | ug/L  | P302924  |          |
|           |                                                 | Fluridone**           | 6.8E-04 | I    | ug/L  | P302924  |          |
| 1792869   | DEP SOP: GC-011-5<br>(based on EPA 608 and 617) | Aldrin                | 0.0020  | U    | ug/L  | P302942  |          |
|           |                                                 | Alpha-BHC             | 0.0020  | U    | ug/L  | P302942  |          |
|           |                                                 | Beta-BHC              | 0.0020  | U    | ug/L  | P302942  |          |
|           |                                                 | Delta-BHC             | 0.0020  | U    | ug/L  | P302942  |          |
|           |                                                 | Gamma-BHC             | 0.0020  | U    | ug/L  | P302942  |          |
|           |                                                 | Carbophenothion       | 0.0059  | UJ   | ug/L  | P302942  | CCV      |
|           |                                                 | Chlorothalonil        | 0.0079  | UJ   | ug/L  | P302942  | CCV      |
|           |                                                 | Cypermethrin          | 0.012   | UJ   | ug/L  | P302942  | CCV      |
|           |                                                 | DDD-p,p'              | 0.0040  | U    | ug/L  | P302942  |          |
|           |                                                 | DDE-p,p'              | 0.0040  | U    | ug/L  | P302942  |          |
|           |                                                 | DDT-p,p'              | 0.0040  | U    | ug/L  | P302942  | MS, RPD  |
|           |                                                 | Dicofol               | 0.024   | U    | ug/L  | P302942  |          |
|           |                                                 | Dieldrin              | 0.0020  | U    | ug/L  | P302942  |          |
|           |                                                 | Endosulfan I          | 0.0020  | U    | ug/L  | P302942  | MS, RPD  |
|           |                                                 | Endosulfan II         | 0.0020  | U    | ug/L  | P302942  |          |
|           |                                                 | Endosulfan Sulfate    | 0.0040  | U    | ug/L  | P302942  |          |
|           |                                                 | Endrin                | 0.0040  | U    | ug/L  | P302942  |          |
|           |                                                 | Endrin Aldehyde       | 0.0040  | U    | ug/L  | P302942  |          |
|           |                                                 | Heptachlor            | 0.0020  | U    | ug/L  | P302942  |          |
|           |                                                 | Heptachlor Epoxide    | 0.0020  | U    | ug/L  | P302942  |          |
|           |                                                 | Methoxychlor          | 0.0099  | U    | ug/L  | P302942  |          |
|           |                                                 | Mirex                 | 0.0040  | U    | ug/L  | P302942  |          |
|           |                                                 | Permethrin            | 0.0099  | U    | ug/L  | P302942  |          |
| 1792871   | EPA 8270D                                       | Ametryn**             | 16      |      | ng/L  | P303196  |          |
|           |                                                 | Atrazine**            | 140     |      | ng/L  | P303196  |          |
|           |                                                 | Chlorpyrifos Ethyl**  | 0.099   | U    | ng/L  | P303196  |          |
|           |                                                 | Chlorpyrifos Methyl** | 0.099   | U    | ng/L  | P303196  |          |
|           |                                                 | Disulfoton**          | 0.32    | U    | ng/L  | P303196  |          |
|           |                                                 | Ethion**              | 0.15    | U    | ng/L  | P303196  |          |
|           |                                                 | Ethoprop**            | 0.099   | U    | ng/L  | P303196  |          |
|           |                                                 | Hexazinone**          | 3.0     |      | ng/L  | P303196  |          |
|           |                                                 | Malathion**           | 0.35    | U    | ng/L  | P303196  |          |
|           |                                                 | Metribuzin**          | 12      |      | ng/L  | P303196  |          |
|           |                                                 | Mevinphos**           | 0.49    | U    | ng/L  | P303196  |          |
|           |                                                 | Norflurazon**         | 0.49    | U    | ng/L  | P303196  |          |

Field ID: G4SENNR2

Matrix: W-SURF-FRH

| Sample ID | Ref. Method | Component           | Result | Code | Units | Batch ID | QC Codes |
|-----------|-------------|---------------------|--------|------|-------|----------|----------|
| 1792871   | EPA 8270D   | Phorate**           | 0.25   | U    | ng/L  | P303196  |          |
|           |             | Prometryn**         | 0.20   | U    | ng/L  | P303196  |          |
|           |             | Simazine**          | 0.49   | U    | ng/L  | P303196  |          |
|           |             | Atrazine Desethyl** | 13     |      | ng/L  | P303196  |          |
|           |             | Prometon**          | 0.89   | U    | ng/L  | P303196  |          |
|           |             | Fipronil**          | 0.25   | U    | ng/L  | P303196  |          |
|           |             | Molinate**          | 0.30   | U    | ng/L  | P303196  | MS       |
|           |             | Pendimethalin**     | 1.5    | U    | ng/L  | P303196  |          |
|           |             | Terbufos**          | 0.099  | U    | ng/L  | P303196  |          |
|           |             | EPTC**              | 1.2    | U    | ng/L  | P303196  | MS       |
|           |             | Terbuthylazine**    | 0.42   | U    | ng/L  | P303196  |          |
|           |             | Bromacil**          | 0.49   | U    | ng/L  | P303196  |          |
|           |             | Fipronil Sulfide**  | 0.15   | U    | ng/L  | P303196  |          |
|           |             | Fipronil Sulfone**  | 0.15   | U    | ng/L  | P303196  |          |
|           |             | Alachlor**          | 0.25   | U    | ng/L  | P303196  |          |
|           |             | Azinphos Methyl**   | 2.2    | U    | ng/L  | P303196  |          |
|           |             | Butylate**          | 0.40   | U    | ng/L  | P303196  |          |
|           |             | Demeton**           | 0.99   | U    | ng/L  | P303196  |          |
|           |             | Diazinon**          | 0.12   | U    | ng/L  | P303196  |          |
|           |             | Fenamiphos**        | 0.25   | U    | ng/L  | P303196  |          |
|           |             | Fonofos**           | 0.20   | U    | ng/L  | P303196  |          |
|           |             | Metalaxyl**         | 0.20   | U    | ng/L  | P303196  | MS       |
|           |             | Metolachlor**       | 0.44   | I    | ng/L  | P303196  |          |
|           |             | Acetochlor**        | 0.25   | U    | ng/L  | P303196  |          |
|           |             | Cyanazine**         | 0.49   | UJ   | ng/L  | P303196  | CCV, LCS |
|           |             | Parathion Ethyl**   | 0.25   | U    | ng/L  | P303196  |          |
|           |             | Parathion Methyl**  | 0.25   | U    | ng/L  | P303196  |          |

Ref. Method and Comment:

USGS O-2060-01: Triclopyr = 0.014 I ug/L. MS accuracy for bentazon could not be assessed due to high concentration of parameter in the spiked sample.

USGS O-2060-01: Refer to the narrative for an explanation of QC Codes.

DEP SOP: GC-011-5 (based on EPA 608 and 617): Refer to the narrative for an explanation of QC Codes.

EPA 8270D: MS accuracy for Atrazine, Ametryn and Metribuzin not assessed due to high content of these parameters in the sample spiked. Refer to the narrative for an explanation of QC Codes.

Sample Location: New River Canal (North) @ Flamingo Rd

Collection Date/Time: 04/25/2016 12:00

Field ID: G4SENNR2

Matrix: W-SURF-FRH

| Sample ID | Ref. Method        | Component        | Result | Code | Units      | Batch ID | QC Codes |
|-----------|--------------------|------------------|--------|------|------------|----------|----------|
| 1792839   | EPA 180.1 Rev. 2.0 | Turbidity        | 0.95   |      | NTU        | P303008  |          |
|           | EPA 300.0 Rev. 2.1 | Chloride         | 98     |      | mg Cl/L    | P303578  |          |
|           |                    | Sulfate          | 24     |      | mg SO4/L   | P303582  |          |
|           |                    | Color (true)     | 93     |      | PCU        | P303015  |          |
|           | SM 2320 B-97       | Total Alkalinity | 207    |      | mg CaCO3/L | P303462  |          |
|           | SM 2540 C-97       | TDS              | 444    |      | mg/L       | P303446  |          |
|           | SM 2540 D-97       | TSS              | 2      | I    | mg/L       | P303313  |          |
|           | SM 4500 F-C-97     | Fluoride         | 0.43   |      | mg F/L     | P303278  |          |

**Field ID: G4SENNR2**

Matrix: W-SURF-FRH

| Sample ID | Ref. Method                  | Component         | Result | Code | Units  | Batch ID | QC Codes |
|-----------|------------------------------|-------------------|--------|------|--------|----------|----------|
| 1792844   | EPA 350.1 Rev. 2.0           | Ammonia-N         | 0.12   |      | mg N/L | P303685  |          |
|           | EPA 351.2 Rev. 2.0           | Kjeldahl Nitrogen | 1.8    |      | mg N/L | P303931  |          |
|           | EPA 353.2 Rev. 2.0           | NO2NO3-N          | 0.041  |      | mg N/L | P303852  |          |
|           | EPA 365.1 Rev. 2.0           | Total-P           | 0.015  |      | mg P/L | P303744  |          |
|           | SM 5310 B-00                 | Organic Carbon    | 28     |      | mg C/L | P304298  |          |
| 1792849   | EPA 365.1 Rev. 2.0 dissolved | O-Phosphate-P     | 0.004  | U    | mg P/L | P302986  |          |
| 1792865   | EPA 200.7 Rev. 4.4           | Calcium           | 70.3   |      | mg/L   | P303173  |          |
|           |                              | Iron              | 60     | I    | ug/L   | P303173  |          |
|           |                              | Magnesium         | 18.7   |      | mg/L   | P303173  |          |
|           |                              | Potassium         | 5.7    |      | mg/L   | P303173  |          |
|           |                              | Sodium            | 61.3   |      | mg/L   | P303173  |          |
|           |                              | Zinc              | 5.0    | U    | ug/L   | P303173  |          |
|           | EPA 200.8 Rev. 5.4           | Arsenic           | 1.35   |      | ug/L   | P303173  |          |
|           |                              | Cadmium           | 0.020  | U    | ug/L   | P303173  |          |
|           |                              | Chromium          | 0.12   | I    | ug/L   | P303173  |          |
|           |                              | Copper            | 0.16   | I    | ug/L   | P303173  |          |
|           |                              | Lead              | 0.050  | U    | ug/L   | P303173  |          |
|           |                              | Nickel            | 0.15   | I    | ug/L   | P303173  |          |
|           |                              | Silver            | 0.0050 | U    | ug/L   | P303173  |          |
|           |                              |                   |        |      |        |          |          |
|           |                              |                   |        |      |        |          |          |
|           |                              |                   |        |      |        |          |          |

Ref. Method and Comment:

SM 2540 D-97: The precision data is unavailable due to the low analyte concentration in the QC sample.

**Sample Location: Tamiami Canal L-67 @ SR41**

**Collection Date/Time: 04/25/2016 13:10**

**Field ID: G4SE0087**

Matrix: W-SURF-FRH

| Sample ID | Ref. Method                  | Component         | Result | Code | Units      | Batch ID | QC Codes |
|-----------|------------------------------|-------------------|--------|------|------------|----------|----------|
| 1792840   | EPA 180.1 Rev. 2.0           | Turbidity         | 0.80   |      | NTU        | P303008  |          |
|           | EPA 300.0 Rev. 2.1           | Chloride          | 57     |      | mg Cl/L    | P303578  |          |
|           |                              | Sulfate           | 6.5    |      | mg SO4/L   | P303582  |          |
|           |                              | Color (true)      | 53     |      | PCU        | P303015  |          |
|           | SM 2320 B-97                 | Total Alkalinity  | 160    |      | mg CaCO3/L | P303462  |          |
|           | SM 2540 C-97                 | TDS               | 288    |      | mg/L       | P303446  |          |
|           | SM 2540 D-97                 | TSS               | 2      | U    | mg/L       | P303313  |          |
| 1792845   | SM 4500 F-C-97               | Fluoride          | 0.23   |      | mg F/L     | P303278  |          |
|           | EPA 350.1 Rev. 2.0           | Ammonia-N         | 0.080  |      | mg N/L     | P303685  |          |
|           | EPA 351.2 Rev. 2.0           | Kjeldahl Nitrogen | 1.2    |      | mg N/L     | P303931  |          |
|           | EPA 353.2 Rev. 2.0           | NO2NO3-N          | 0.015  |      | mg N/L     | P303852  |          |
|           | EPA 365.1 Rev. 2.0           | Total-P           | 0.009  |      | mg P/L     | P303744  |          |
| 1792850   | SM 5310 B-00                 | Organic Carbon    | 19     |      | mg C/L     | P304298  |          |
|           | EPA 365.1 Rev. 2.0 dissolved | O-Phosphate-P     | 0.004  | U    | mg P/L     | P302986  |          |
|           |                              |                   |        |      |            |          |          |
| 1792866   | EPA 200.7 Rev. 4.4           | Calcium           | 56.3   |      | mg/L       | P303173  |          |
|           |                              | Iron              | 120    | I    | ug/L       | P303173  |          |
|           |                              | Magnesium         | 10.2   |      | mg/L       | P303173  |          |
|           |                              | Potassium         | 3.4    |      | mg/L       | P303173  |          |
|           |                              | Sodium            | 34.8   |      | mg/L       | P303173  |          |

Field ID: G4SE0087

Matrix: W-SURF-FRH

| Sample ID | Ref. Method        | Component | Result | Code | Units | Batch ID | QC Codes |
|-----------|--------------------|-----------|--------|------|-------|----------|----------|
| 1792866   | EPA 200.7 Rev. 4.4 | Zinc      | 5.0    | U    | ug/L  | P303173  |          |
|           | EPA 200.8 Rev. 5.4 | Arsenic   | 0.89   |      | ug/L  | P303173  |          |
|           |                    | Cadmium   | 0.020  | U    | ug/L  | P303173  |          |
|           |                    | Chromium  | 0.050  | U    | ug/L  | P303173  |          |
|           |                    | Copper    | 0.10   | U    | ug/L  | P303173  |          |
|           |                    | Lead      | 0.050  | U    | ug/L  | P303173  |          |
|           |                    | Nickel    | 0.062  | I    | ug/L  | P303173  |          |
|           |                    | Silver    | 0.0050 | U    | ug/L  | P303173  |          |

Ref. Method and Comment:

SM 2540 D-97: The precision data is unavailable due to the low analyte concentration in the QC sample.

## Quality Assurance Report

### Method Blank Results

Reference Method: DEP SOP: GC-011-5 (based on EPA 608 and 617)

Batch ID: P302942

| Component          | Result | Code | Units |
|--------------------|--------|------|-------|
| Aldrin             | 0.0020 | U    | ug/L  |
| Alpha-BHC          | 0.0020 | U    | ug/L  |
| Beta-BHC           | 0.0020 | U    | ug/L  |
| Carbophenothion    | 0.0060 | U    | ug/L  |
| Chlorothalonil     | 0.0080 | U    | ug/L  |
| Cypermethrin       | 0.012  | U    | ug/L  |
| DDD-p,p'           | 0.0040 | U    | ug/L  |
| DDE-p,p'           | 0.0040 | U    | ug/L  |
| DDT-p,p'           | 0.0040 | U    | ug/L  |
| Delta-BHC          | 0.0020 | U    | ug/L  |
| Dicofol            | 0.024  | U    | ug/L  |
| Dieldrin           | 0.0020 | U    | ug/L  |
| Endosulfan I       | 0.0020 | U    | ug/L  |
| Endosulfan II      | 0.0020 | U    | ug/L  |
| Endosulfan Sulfate | 0.0040 | U    | ug/L  |
| Endrin             | 0.0040 | U    | ug/L  |
| Endrin Aldehyde    | 0.0040 | U    | ug/L  |
| Gamma-BHC          | 0.0020 | U    | ug/L  |
| Heptachlor         | 0.0020 | U    | ug/L  |
| Heptachlor Epoxide | 0.0020 | U    | ug/L  |
| Methoxychlor       | 0.010  | U    | ug/L  |
| Mirex              | 0.0040 | U    | ug/L  |
| Permethrin         | 0.010  | U    | ug/L  |

Reference Method: EPA 180.1 Rev. 2.0

Batch ID: P303007

| Component | Result | Code | Units |
|-----------|--------|------|-------|
| Turbidity | 0.10   | U    | NTU   |

Reference Method: EPA 180.1 Rev. 2.0

Batch ID: P303008

| Component | Result | Code | Units |
|-----------|--------|------|-------|
| Turbidity | 0.10   | U    | NTU   |

## Quality Assurance Report Method Blank Results

Reference Method: EPA 200.7 Rev. 4.4  
Batch ID: P303173

| Component | Result | Code | Units |
|-----------|--------|------|-------|
| Calcium   | 0.075  | U    | mg/L  |
| Iron      | 30     | U    | ug/L  |
| Magnesium | 0.040  | U    | mg/L  |
| Potassium | 0.30   | U    | mg/L  |
| Sodium    | 0.50   | U    | mg/L  |
| Zinc      | 5.0    | U    | ug/L  |

Reference Method: EPA 200.8 Rev. 5.4  
Batch ID: P303173

| Component | Result | Code | Units |
|-----------|--------|------|-------|
| Arsenic   | 0.050  | U    | ug/L  |
| Cadmium   | 0.020  | U    | ug/L  |
| Chromium  | 0.050  | U    | ug/L  |
| Copper    | 0.10   | U    | ug/L  |
| Lead      | 0.050  | U    | ug/L  |
| Nickel    | 0.050  | U    | ug/L  |
| Silver    | 0.0050 | U    | ug/L  |

Reference Method: EPA 300.0 Rev. 2.1  
Batch ID: P303578

| Component | Result | Code | Units   |
|-----------|--------|------|---------|
| Chloride  | 0.20   | U    | mg Cl/L |

Reference Method: EPA 300.0 Rev. 2.1  
Batch ID: P303582

| Component | Result | Code | Units    |
|-----------|--------|------|----------|
| Sulfate   | 0.20   | U    | mg SO4/L |

Reference Method: EPA 350.1 Rev. 2.0  
Batch ID: P303685

| Component | Result | Code | Units  |
|-----------|--------|------|--------|
| Ammonia-N | 0.002  | U    | mg N/L |

Reference Method: EPA 350.1 Rev. 2.0  
Batch ID: P303691

| Component | Result | Code | Units  |
|-----------|--------|------|--------|
| Ammonia-N | 0.002  | U    | mg N/L |

Reference Method: EPA 351.2 Rev. 2.0  
Batch ID: P303931

| Component         | Result | Code | Units  |
|-------------------|--------|------|--------|
| Kjeldahl Nitrogen | 0.080  | U    | mg N/L |

## Quality Assurance Report Method Blank Results

Reference Method: EPA 351.2 Rev. 2.0  
Batch ID: P304112

| Component         | Result | Code | Units  |
|-------------------|--------|------|--------|
| Kjeldahl Nitrogen | 0.080  | U    | mg N/L |

Reference Method: EPA 353.2 Rev. 2.0  
Batch ID: P303636

| Component | Result | Code | Units  |
|-----------|--------|------|--------|
| NO2NO3-N  | 0.004  | U    | mg N/L |

Reference Method: EPA 353.2 Rev. 2.0  
Batch ID: P303852

| Component | Result | Code | Units  |
|-----------|--------|------|--------|
| NO2NO3-N  | 0.004  | U    | mg N/L |

Reference Method: EPA 365.1 Rev. 2.0  
Batch ID: P303744

| Component | Result | Code | Units  |
|-----------|--------|------|--------|
| Total-P   | 0.002  | U    | mg P/L |

Reference Method: EPA 365.1 Rev. 2.0  
Batch ID: P303806

| Component | Result | Code | Units  |
|-----------|--------|------|--------|
| Total-P   | 0.002  | U    | mg P/L |

Reference Method: EPA 365.1 Rev. 2.0  
Batch ID: P304059

| Component | Result | Code | Units  |
|-----------|--------|------|--------|
| Total-P   | 0.002  | U    | mg P/L |

Reference Method: EPA 365.1 Rev. 2.0 dissolved  
Batch ID: P302985

| Component     | Result | Code | Units  |
|---------------|--------|------|--------|
| O-Phosphate-P | 0.004  | U    | mg P/L |

Reference Method: EPA 365.1 Rev. 2.0 dissolved  
Batch ID: P302986

| Component     | Result | Code | Units  |
|---------------|--------|------|--------|
| O-Phosphate-P | 0.004  | U    | mg P/L |

Reference Method: EPA 365.1 Rev. 2.0 dissolved  
Batch ID: P302987

| Component     | Result | Code | Units  |
|---------------|--------|------|--------|
| O-Phosphate-P | 0.004  | U    | mg P/L |

## Quality Assurance Report Method Blank Results

Reference Method: EPA 8270D  
Batch ID: P303196

| Component           | Result | Code | Units |
|---------------------|--------|------|-------|
| Acetochlor          | 0.25   | U    | ng/L  |
| Alachlor            | 0.25   | U    | ng/L  |
| Ametryn             | 0.32   | U    | ng/L  |
| Atrazine            | 0.25   | U    | ng/L  |
| Atrazine Desethyl   | 1.5    | U    | ng/L  |
| Azinphos Methyl     | 2.2    | U    | ng/L  |
| Bromacil            | 0.50   | U    | ng/L  |
| Butylate            | 0.40   | U    | ng/L  |
| Chlorpyrifos Ethyl  | 0.10   | U    | ng/L  |
| Chlorpyrifos Methyl | 0.10   | U    | ng/L  |
| Cyanazine           | 0.50   | U    | ng/L  |
| Demeton             | 1.0    | U    | ng/L  |
| Diazinon            | 0.12   | U    | ng/L  |
| Disulfoton          | 0.32   | U    | ng/L  |
| EPTC                | 1.2    | U    | ng/L  |
| Ethion              | 0.15   | U    | ng/L  |
| Ethoprop            | 0.10   | U    | ng/L  |
| Fenamiphos          | 0.25   | U    | ng/L  |
| Fipronil            | 0.25   | U    | ng/L  |
| Fipronil Sulfide    | 0.15   | U    | ng/L  |
| Fipronil Sulfone    | 0.15   | U    | ng/L  |
| Fonofos             | 0.20   | U    | ng/L  |
| Hexazinone          | 0.50   | U    | ng/L  |
| Malathion           | 0.35   | U    | ng/L  |
| Metaxyl             | 0.20   | U    | ng/L  |
| Metolachlor         | 0.25   | U    | ng/L  |
| Metribuzin          | 0.20   | U    | ng/L  |
| Mevinphos           | 0.50   | U    | ng/L  |
| Molinate            | 0.30   | U    | ng/L  |
| Norflurazon         | 0.50   | U    | ng/L  |
| Parathion Ethyl     | 0.25   | U    | ng/L  |
| Parathion Methyl    | 0.25   | U    | ng/L  |
| Pendimethalin       | 1.5    | U    | ng/L  |
| Phorate             | 0.25   | U    | ng/L  |
| Prometon            | 0.90   | U    | ng/L  |
| Prometryn           | 0.20   | U    | ng/L  |
| Simazine            | 0.50   | U    | ng/L  |
| Terbufos            | 0.10   | U    | ng/L  |
| Terbuthylazine      | 0.42   | U    | ng/L  |

Reference Method: SM 2120 B  
Batch ID: P303015

| Component    | Result | Code | Units |
|--------------|--------|------|-------|
| Color (true) | 2.5    | U    | PCU   |

Reference Method: SM 2320 B-97  
Batch ID: P303462

| Component        | Result | Code | Units                   |
|------------------|--------|------|-------------------------|
| Total Alkalinity | 0.65   | U    | mg CaCO <sub>3</sub> /L |

## Quality Assurance Report Method Blank Results

Reference Method: SM 2320 B-97  
Batch ID: P303463

| Component        | Result | Code | Units                   |
|------------------|--------|------|-------------------------|
| Total Alkalinity | 0.65   | U    | mg CaCO <sub>3</sub> /L |

Reference Method: SM 2540 C-97  
Batch ID: P303446

| Component | Result | Code | Units |
|-----------|--------|------|-------|
| TDS       | 15     | U    | mg/L  |

Reference Method: SM 2540 D-97  
Batch ID: P303313

| Component | Result | Code | Units |
|-----------|--------|------|-------|
| TSS       | 2      | U    | mg/L  |

Reference Method: SM 2540 D-97  
Batch ID: P303314

| Component | Result | Code | Units |
|-----------|--------|------|-------|
| TSS       | 2      | U    | mg/L  |

Reference Method: SM 4500 F-C-97  
Batch ID: P303278

| Component | Result | Code | Units  |
|-----------|--------|------|--------|
| Fluoride  | 0.035  | U    | mg F/L |

Reference Method: SM 4500 F-C-97  
Batch ID: P303279

| Component | Result | Code | Units  |
|-----------|--------|------|--------|
| Fluoride  | 0.035  | U    | mg F/L |

Reference Method: SM 5310 B-00  
Batch ID: P304298

| Component      | Result | Code | Units  |
|----------------|--------|------|--------|
| Organic Carbon | 0.50   | U    | mg C/L |

Reference Method: USGS O-2060-01  
Batch ID: P302924

| Component     | Result  | Code | Units |
|---------------|---------|------|-------|
| 2,4,5-T       | 0.0020  | U    | ug/L  |
| 2,4-D         | 0.0020  | U    | ug/L  |
| 2,4-DB        | 0.0020  | U    | ug/L  |
| Acetaminophen | 0.0040  | U    | ug/L  |
| Acifluorfen   | 0.0020  | U    | ug/L  |
| Bentazon      | 0.0020  | U    | ug/L  |
| Carbamazepine | 4.0E-04 | U    | ug/L  |
| Dichlorprop   | 0.0020  | U    | ug/L  |
| Dinoseb       | 0.020   | U    | ug/L  |
| Diuron        | 0.0020  | U    | ug/L  |

## Quality Assurance Report Method Blank Results

Reference Method: USGS O-2060-01  
Batch ID: P302924

| Component    | Result  | Code | Units |
|--------------|---------|------|-------|
| Fenuron      | 0.0080  | U    | ug/L  |
| Fluridone    | 4.0E-04 | U    | ug/L  |
| Imidacloprid | 0.0040  | U    | ug/L  |
| Linuron      | 0.0040  | U    | ug/L  |
| MCPA         | 0.0040  | U    | ug/L  |
| MCPP         | 0.0040  | U    | ug/L  |
| Primidone    | 0.0080  | U    | ug/L  |
| Silvex       | 0.0020  | U    | ug/L  |

## Quality Assurance Report Laboratory Control Sample Accuracy

Reference Method: DEP SOP: GC-011-5 (based on EPA 608 and 617)  
Batch ID: P302942

| Component          | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|--------------------|---------|---------|-----------|----------------|
| Aldrin             | 109     | 116     | P/P       | 70 - 130       |
| Alpha-BHC          | 86.8    | 100     | P/P       | 70 - 130       |
| Beta-BHC           | 99.8    | 115     | P/P       | 70 - 130       |
| DDD-p,p'           | 110     | 115     | P/P       | 70 - 130       |
| DDE-p,p'           | 105     | 110     | P/P       | 70 - 130       |
| DDT-p,p'           | 128     | 129     | P/P       | 70 - 130       |
| Delta-BHC          | 111     | 116     | P/P       | 70 - 130       |
| Dieldrin           | 102     | 106     | P/P       | 70 - 130       |
| Endosulfan I       | 86.7    | 89.5    | P/P       | 70 - 130       |
| Endosulfan II      | 106     | 111     | P/P       | 70 - 130       |
| Endosulfan Sulfate | 129     | 128     | P/P       | 70 - 130       |
| Endrin             | 125     | 129     | P/P       | 81 - 147       |
| Endrin Aldehyde    | 94.7    | 101     | P/P       | 70 - 130       |
| Gamma-BHC          | 94.5    | 104     | P/P       | 70 - 130       |
| Heptachlor         | 114     | 128     | P/P       | 70 - 130       |
| Heptachlor Epoxide | 111     | 118     | P/P       | 70 - 130       |
| Methoxychlor       | 121     | 130     | P/P       | 86 - 145       |

Reference Method: EPA 200.7 Rev. 4.4  
Batch ID: P303173

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Calcium   | 109     |         | P         | 85 - 115       |
| Iron      | 105     |         | P         | 85 - 115       |
| Magnesium | 112     |         | P         | 85 - 115       |
| Potassium | 103     |         | P         | 85 - 115       |
| Sodium    | 108     |         | P         | 85 - 115       |
| Zinc      | 101     |         | P         | 85 - 115       |

Reference Method: EPA 200.8 Rev. 5.4  
Batch ID: P303173

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Arsenic   | 100     |         | P         | 85 - 115       |
| Cadmium   | 98.3    |         | P         | 85 - 115       |

## Quality Assurance Report Laboratory Control Sample Accuracy

Reference Method: EPA 200.8 Rev. 5.4  
Batch ID: P303173

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Chromium  | 100     |         | P         | 85 - 115       |
| Copper    | 99.6    |         | P         | 85 - 115       |
| Lead      | 100     |         | P         | 85 - 115       |
| Nickel    | 102     |         | P         | 85 - 115       |
| Silver    | 96.3    |         | P         | 85 - 115       |

Reference Method: EPA 300.0 Rev. 2.1  
Batch ID: P303578

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Chloride  | 95.2    |         | P         | 90 - 110       |

Reference Method: EPA 300.0 Rev. 2.1  
Batch ID: P303582

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Sulfate   | 93.3    |         | P         | 90 - 110       |

Reference Method: EPA 350.1 Rev. 2.0  
Batch ID: P303685

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Ammonia-N | 97.2    |         | P         | 90 - 110       |

Reference Method: EPA 350.1 Rev. 2.0  
Batch ID: P303691

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Ammonia-N | 98.9    |         | P         | 90 - 110       |

Reference Method: EPA 351.2 Rev. 2.0  
Batch ID: P303931

| Component         | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-------------------|---------|---------|-----------|----------------|
| Kjeldahl Nitrogen | 103     |         | P         | 90 - 110       |

Reference Method: EPA 351.2 Rev. 2.0  
Batch ID: P304112

| Component         | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-------------------|---------|---------|-----------|----------------|
| Kjeldahl Nitrogen | 98.8    |         | P         | 90 - 110       |

Reference Method: EPA 353.2 Rev. 2.0  
Batch ID: P303636

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| NO2NO3-N  | 104     |         | P         | 90 - 110       |

Reference Method: EPA 353.2 Rev. 2.0  
Batch ID: P303852

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
|-----------|---------|---------|-----------|----------------|

## Quality Assurance Report Laboratory Control Sample Accuracy

Reference Method: EPA 353.2 Rev. 2.0  
 Batch ID: P303852

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| NO2NO3-N  | 100     |         | P         | 90 - 110       |

Reference Method: EPA 365.1 Rev. 2.0  
 Batch ID: P303744

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Total-P   | 97.2    |         | P         | 90 - 110       |

Reference Method: EPA 365.1 Rev. 2.0  
 Batch ID: P303806

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Total-P   | 93.7    |         | P         | 90 - 110       |

Reference Method: EPA 365.1 Rev. 2.0  
 Batch ID: P304059

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Total-P   | 100     |         | P         | 90 - 110       |

Reference Method: EPA 365.1 Rev. 2.0 dissolved  
 Batch ID: P302985

| Component     | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|---------|---------|-----------|----------------|
| O-Phosphate-P | 101     |         | P         | 90 - 110       |

Reference Method: EPA 365.1 Rev. 2.0 dissolved  
 Batch ID: P302986

| Component     | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|---------|---------|-----------|----------------|
| O-Phosphate-P | 105     |         | P         | 90 - 110       |

Reference Method: EPA 365.1 Rev. 2.0 dissolved  
 Batch ID: P302987

| Component     | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|---------|---------|-----------|----------------|
| O-Phosphate-P | 104     |         | P         | 90 - 110       |

Reference Method: EPA 8270D  
 Batch ID: P303196

| Component           | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------------|---------|---------|-----------|----------------|
| Acetochlor          | 101     | 89.8    | P/P       | 84 - 119       |
| Alachlor            | 101     | 91.1    | P/P       | 84 - 121       |
| Ametryn             | 108     | 104     | P/P       | 66 - 127       |
| Atrazine            | 104     | 93.5    | P/P       | 72 - 119       |
| Atrazine Desethyl   | 73.6    | 58.4    | P/P       | 21 - 111       |
| Azinphos Methyl     | 144     | 126     | P/P       | 79 - 185       |
| Bromacil            | 73.8    | 62.1    | P/P       | 39 - 122       |
| Butylate            | 57.9    | 55.8    | P/P       | 36 - 94.0      |
| Chlorpyrifos Ethyl  | 92.0    | 83.1    | P/P       | 54 - 101       |
| Chlorpyrifos Methyl | 86.9    | 77.6    | P/P       | 28 - 114       |

## Quality Assurance Report Laboratory Control Sample Accuracy

Reference Method: EPA 8270D

Batch ID: P303196

| Component        | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|------------------|---------|---------|-----------|----------------|
| Cyanazine        | 214     | 183     | F/P       | 58 - 201       |
| Demeton          | 69.0    | 63.1    | P/P       | 57 - 130       |
| Diazinon         | 96.7    | 90.9    | P/P       | 79 - 124       |
| Disulfoton       | 95.0    | 78.9    | P/P       | 45 - 140       |
| EPTC             | 55.5    | 55.1    | P/P       | 43 - 95.0      |
| Ethion           | 95.8    | 87.7    | P/P       | 65 - 125       |
| Ethoprop         | 82.1    | 75.9    | P/P       | 69 - 107       |
| Fenamiphos       | 104     | 95.8    | P/P       | 78 - 129       |
| Fipronil         | 86.6    | 77.4    | P/P       | 62 - 125       |
| Fipronil Sulfide | 75.6    | 69.2    | P/P       | 65 - 119       |
| Fipronil Sulfone | 72.1    | 66.9    | P/P       | 64 - 122       |
| Fonofos          | 83.0    | 76.3    | P/P       | 70 - 112       |
| Hexazinone       | 105     | 90.1    | P/P       | 44 - 147       |
| Malathion        | 104     | 85.9    | P/P       | 72 - 125       |
| Metaxyl          | 93.0    | 85.1    | P/P       | 83 - 113       |
| Metolachlor      | 100     | 89.8    | P/P       | 85 - 120       |
| Metribuzin       | 109     | 91.7    | P/P       | 68 - 129       |
| Mevinphos        | 73.8    | 71.1    | P/P       | 35 - 125       |
| Molinate         | 66.4    | 64.3    | P/P       | 51 - 100       |
| Norflurazon      | 90.3    | 84.4    | P/P       | 66 - 127       |
| Parathion Ethyl  | 94.5    | 89.2    | P/P       | 86 - 108       |
| Parathion Methyl | 103     | 98.3    | P/P       | 87 - 125       |
| Pendimethalin    | 81.0    | 75.8    | P/P       | 53 - 136       |
| Phorate          | 83.3    | 80.4    | P/P       | 52 - 113       |
| Prometon         | 96.3    | 87.2    | P/P       | 67 - 125       |
| Prometryn        | 99.2    | 85.5    | P/P       | 73 - 114       |
| Simazine         | 101     | 94.3    | P/P       | 66 - 123       |
| Terbufos         | 87.8    | 78.0    | P/P       | 58 - 116       |
| Terbutylazine    | 96.2    | 84.8    | P/P       | 77 - 113       |

Reference Method: SM 2320 B-97

Batch ID: P303462

| Component        | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|------------------|---------|---------|-----------|----------------|
| Total Alkalinity | 101     |         | P         | 95 - 105       |

Reference Method: SM 2320 B-97

Batch ID: P303463

| Component        | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|------------------|---------|---------|-----------|----------------|
| Total Alkalinity | 100     |         | P         | 95 - 105       |

Reference Method: SM 4500 F-C-97

Batch ID: P303278

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Fluoride  | 98.3    |         | P         | 92 - 103       |

Reference Method: SM 4500 F-C-97

Batch ID: P303279

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
|-----------|---------|---------|-----------|----------------|

## Quality Assurance Report Laboratory Control Sample Accuracy

Reference Method: SM 4500 F-C-97  
 Batch ID: P303279

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Fluoride  | 98.8    |         | P         | 92 - 103       |

Reference Method: SM 5310 B-00  
 Batch ID: P304298

| Component      | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|----------------|---------|---------|-----------|----------------|
| Organic Carbon | 100     |         | P         | 85 - 115       |

Reference Method: USGS O-2060-01  
 Batch ID: P302924

| Component     | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|---------|---------|-----------|----------------|
| 2,4,5-T       | 102     | 89.6    | P/P       | 40 - 140       |
| 2,4-D         | 107     | 108     | P/P       | 40 - 140       |
| 2,4-DB        | 81.6    | 74.4    | P/P       | 40 - 140       |
| Acetaminophen | 43.6    | 18.1    | P/F       | 40 - 140       |
| Acifluorfen   | 98.8    | 105     | P/P       | 40 - 140       |
| Bentazon      | 86.4    | 85.2    | P/P       | 40 - 140       |
| Carbamazepine | 138     | 136     | P/P       | 40 - 140       |
| Dichlorprop   | 106     | 99.6    | P/P       | 40 - 140       |
| Dinoseb       | 102     | 102     | P/P       | 40 - 140       |
| Diuron        | 112     | 131     | P/P       | 40 - 140       |
| Fenuron       | 114     | 120     | P/P       | 40 - 140       |
| Fluridone     | 105     | 108     | P/P       | 40 - 140       |
| Imidacloprid  | 129     | 125     | P/P       | 40 - 160       |
| Linuron       | 110     | 112     | P/P       | 40 - 140       |
| MCPA          | 98.0    | 95.2    | P/P       | 40 - 140       |
| MCPP          | 105     | 96.4    | P/P       | 40 - 140       |
| Primidone     | 120     | 117     | P/P       | 40 - 140       |
| Silvex        | 116     | 114     | P/P       | 40 - 140       |

## Quality Assurance Report Matrix Spike Accuracy

Reference Method: DEP SOP: GC-011-5 (based on EPA 608 and 617)  
 Batch ID: P302942

| Spiked Sample | Component          | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|--------------------|---------|---------|-----------|----------------|
| 1792377       | Aldrin             | 94.8    | 120     | P/P       | 70 - 130       |
| 1792377       | Alpha-BHC          | 99.3    | 116     | P/P       | 70 - 130       |
| 1792377       | Beta-BHC           | 115     | 110     | P/P       | 70 - 130       |
| 1792377       | DDD-p,p'           | 97.4    | 118     | P/P       | 70 - 130       |
| 1792377       | DDE-p,p'           | 91.2    | 111     | P/P       | 70 - 130       |
| 1792377       | DDT-p,p'           | 99.3    | 184     | P/F       | 70 - 130       |
| 1792377       | Delta-BHC          | 96.5    | 112     | P/P       | 70 - 130       |
| 1792377       | Dieldrin           | 90.8    | 114     | P/P       | 70 - 130       |
| 1792377       | Endosulfan I       | 94.4    | 135     | P/F       | 70 - 130       |
| 1792377       | Endosulfan II      | 96.8    | 117     | P/P       | 70 - 130       |
| 1792377       | Endosulfan Sulfate | 95.7    | 118     | P/P       | 70 - 130       |
| 1792377       | Endrin             | 106     | 135     | P/P       | 81 - 147       |
| 1792377       | Endrin Aldehyde    | 80.2    | 102     | P/P       | 70 - 130       |

## Quality Assurance Report Matrix Spike Accuracy

Reference Method: DEP SOP: GC-011-5 (based on EPA 608 and 617)  
Batch ID: P302942

| Spiked Sample | Component          | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|--------------------|---------|---------|-----------|----------------|
| 1792377       | Gamma-BHC          | 93.1    | 112     | P/P       | 70 - 130       |
| 1792377       | Heptachlor         | 110     | 116     | P/P       | 70 - 130       |
| 1792377       | Heptachlor Epoxide | 99.1    | 127     | P/P       | 70 - 130       |
| 1792377       | Methoxychlor       | 105     | 124     | P/P       | 86 - 145       |
| 1792392       | Aldrin             | 119     |         | P         | 70 - 130       |
| 1792392       | Alpha-BHC          | 112     |         | P         | 70 - 130       |
| 1792392       | Beta-BHC           | 123     |         | P         | 70 - 130       |
| 1792392       | DDD-p,p'           | 106     |         | P         | 70 - 130       |
| 1792392       | DDE-p,p'           | 102     |         | P         | 70 - 130       |
| 1792392       | DDT-p,p'           | 143     |         | F         | 70 - 130       |
| 1792392       | Delta-BHC          | 109     |         | P         | 70 - 130       |
| 1792392       | Dieldrin           | 99.0    |         | P         | 70 - 130       |
| 1792392       | Endosulfan I       | 113     |         | P         | 70 - 130       |
| 1792392       | Endosulfan II      | 108     |         | P         | 70 - 130       |
| 1792392       | Endosulfan Sulfate | 105     |         | P         | 70 - 130       |
| 1792392       | Endrin             | 122     |         | P         | 81 - 147       |
| 1792392       | Endrin Aldehyde    | 97.2    |         | P         | 70 - 130       |
| 1792392       | Gamma-BHC          | 108     |         | P         | 70 - 130       |
| 1792392       | Heptachlor         | 119     |         | P         | 70 - 130       |
| 1792392       | Heptachlor Epoxide | 113     |         | P         | 70 - 130       |
| 1792392       | Methoxychlor       | 110     |         | P         | 86 - 145       |

Reference Method: EPA 200.7 Rev. 4.4  
Batch ID: P303173

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 1792559       | Calcium   | 106     | 108     | P/P       | 80 - 120       |
| 1792559       | Iron      | 105     | 106     | P/P       | 80 - 120       |
| 1792559       | Magnesium | 109     | 110     | P/P       | 80 - 120       |
| 1792559       | Potassium | 101     | 101     | P/P       | 80 - 120       |
| 1792559       | Sodium    | 100     | 99.5    | P/P       | 80 - 120       |
| 1792559       | Zinc      | 101     | 101     | P/P       | 80 - 120       |
| 1792863       | Calcium   | 106     |         | P         | 80 - 120       |
| 1792863       | Iron      | 104     |         | P         | 80 - 120       |
| 1792863       | Magnesium | 106     |         | P         | 80 - 120       |
| 1792863       | Potassium | 98.7    |         | P         | 80 - 120       |
| 1792863       | Sodium    | 98.1    |         | P         | 80 - 120       |
| 1792863       | Zinc      | 101     |         | P         | 80 - 120       |

Reference Method: EPA 200.8 Rev. 5.4  
Batch ID: P303173

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 1792559       | Arsenic   | 96.4    | 99.0    | P/P       | 80 - 120       |
| 1792559       | Cadmium   | 98.5    | 97.8    | P/P       | 80 - 120       |
| 1792559       | Chromium  | 119     | 99.6    | P/P       | 80 - 120       |
| 1792559       | Copper    | 96.1    | 97.1    | P/P       | 80 - 120       |
| 1792559       | Lead      | 98.8    | 99.7    | P/P       | 80 - 120       |
| 1792559       | Nickel    | 98.2    | 99.0    | P/P       | 80 - 120       |
| 1792559       | Silver    | 95.5    | 96.1    | P/P       | 80 - 120       |
| 1792863       | Arsenic   | 102     |         | P         | 80 - 120       |
| 1792863       | Cadmium   | 101     |         | P         | 80 - 120       |

## Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 200.8 Rev. 5.4  
Batch ID: P303173

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 1792863       | Chromium  | 100     |         | P         | 80 - 120       |
| 1792863       | Copper    | 97.3    |         | P         | 80 - 120       |
| 1792863       | Lead      | 101     |         | P         | 80 - 120       |
| 1792863       | Nickel    | 99.3    |         | P         | 80 - 120       |
| 1792863       | Silver    | 94.7    |         | P         | 80 - 120       |

Reference Method: EPA 300.0 Rev. 2.1  
Batch ID: P303578

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 1792908       | Chloride  | 97.9    |         | P         | 90 - 110       |
| 1792961       | Chloride  | 92.6    |         | P         | 90 - 110       |

Reference Method: EPA 300.0 Rev. 2.1  
Batch ID: P303582

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 1792908       | Sulfate   | 94.9    |         | P         | 90 - 110       |
| 1792961       | Sulfate   | 91.5    |         | P         | 90 - 110       |

Reference Method: EPA 350.1 Rev. 2.0  
Batch ID: P303685

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 1792762       | Ammonia-N | 101     | 101     | P/P       | 90 - 110       |

Reference Method: EPA 351.2 Rev. 2.0  
Batch ID: P303931

| Spiked Sample | Component         | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-------------------|---------|---------|-----------|----------------|
| 1792790       | Kjeldahl Nitrogen | 105     | 102     | P/P       | 90 - 110       |

Reference Method: EPA 351.2 Rev. 2.0  
Batch ID: P304112

| Spiked Sample | Component         | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-------------------|---------|---------|-----------|----------------|
| 1792618       | Kjeldahl Nitrogen | 95.5    | 98.2    | P/P       | 90 - 110       |

Reference Method: EPA 353.2 Rev. 2.0  
Batch ID: P303636

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 1793257       | NO2NO3-N  | 101     | 103     | P/P       | 90 - 110       |

Reference Method: EPA 353.2 Rev. 2.0  
Batch ID: P303852

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 1792790       | NO2NO3-N  | 100     | 102     | P/P       | 90 - 110       |

## Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 365.1 Rev. 2.0  
Batch ID: P303744

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 1792844       | Total-P   | 95.9    | 96.7    | P/P       | 90 - 110       |

Reference Method: EPA 365.1 Rev. 2.0  
Batch ID: P303806

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 1793244       | Total-P   | 92.4    | 88.0    | P/F       | 90 - 110       |

Reference Method: EPA 365.1 Rev. 2.0  
Batch ID: P304059

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 1792790       | Total-P   | 99.3    | 102     | P/P       | 90 - 110       |

Reference Method: EPA 365.1 Rev. 2.0 dissolved  
Batch ID: P302985

| Spiked Sample | Component     | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|---------------|---------|---------|-----------|----------------|
| 1792672       | O-Phosphate-P | 100     | 102     | P/P       | 90 - 110       |

Reference Method: EPA 365.1 Rev. 2.0 dissolved  
Batch ID: P302986

| Spiked Sample | Component     | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|---------------|---------|---------|-----------|----------------|
| 1792848       | O-Phosphate-P | 99.7    | 100     | P/P       | 90 - 110       |

Reference Method: EPA 365.1 Rev. 2.0 dissolved  
Batch ID: P302987

| Spiked Sample | Component     | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|---------------|---------|---------|-----------|----------------|
| 1792853       | O-Phosphate-P | 100     | 100     | P/P       | 90 - 110       |

Reference Method: EPA 8270D  
Batch ID: P303196

| Spiked Sample | Component           | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|---------------------|---------|---------|-----------|----------------|
| 1792870       | Acetochlor          | 90.9    | 96.5    | P/P       | 84 - 119       |
| 1792870       | Alachlor            | 89.5    | 99.8    | P/P       | 84 - 121       |
| 1792870       | Atrazine Desethyl   | 46.5    | 46.1    | P/P       | 21 - 111       |
| 1792870       | Azinphos Methyl     | 131     | 130     | P/P       | 79 - 185       |
| 1792870       | Bromacil            | 87.1    | 85.2    | P/P       | 39 - 122       |
| 1792870       | Butylate            | 42.1    | 36.8    | P/P       | 36 - 94.0      |
| 1792870       | Chlorpyrifos Ethyl  | 78.4    | 92.8    | P/P       | 54 - 101       |
| 1792870       | Chlorpyrifos Methyl | 78.6    | 81.6    | P/P       | 28 - 114       |
| 1792870       | Cyanazine           | 163     | 172     | P/P       | 58 - 201       |
| 1792870       | Demeton             | 63.0    | 72.1    | P/P       | 57 - 130       |
| 1792870       | Diazinon            | 88.4    | 90.5    | P/P       | 79 - 124       |
| 1792870       | Disulfoton          | 83.7    | 79.5    | P/P       | 45 - 140       |
| 1792870       | EPTC                | 37.5    | 30.8    | F/F       | 43 - 95.0      |
| 1792870       | Ethion              | 100     | 104     | P/P       | 65 - 125       |
| 1792870       | Ethoprop            | 71.4    | 74.7    | P/P       | 69 - 107       |
| 1792870       | Fenamiphos          | 93.7    | 95.3    | P/P       | 78 - 129       |

## Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 8270D  
Batch ID: P303196

| Spiked Sample | Component        | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|------------------|---------|---------|-----------|----------------|
| 1792870       | Fipronil         | 80.4    | 81.5    | P/P       | 62 - 125       |
| 1792870       | Fipronil Sulfide | 73.0    | 73.1    | P/P       | 65 - 119       |
| 1792870       | Fipronil Sulfone | 66.2    | 65.8    | P/P       | 64 - 122       |
| 1792870       | Fonofos          | 75.5    | 77.2    | P/P       | 70 - 112       |
| 1792870       | Hexazinone       | 98.4    | 101     | P/P       | 44 - 147       |
| 1792870       | Malathion        | 95.2    | 99.5    | P/P       | 72 - 125       |
| 1792870       | Metalaxyl        | 82.5    | 89.8    | F/P       | 83 - 113       |
| 1792870       | Metolachlor      | 90.4    | 98.1    | P/P       | 85 - 120       |
| 1792870       | Mevinphos        | 61.7    | 63.8    | P/P       | 35 - 125       |
| 1792870       | Molinate         | 47.1    | 43.9    | F/F       | 51 - 100       |
| 1792870       | Norflurazon      | 74.9    | 77.2    | P/P       | 66 - 127       |
| 1792870       | Parathion Ethyl  | 88.4    | 89.2    | P/P       | 86 - 108       |
| 1792870       | Parathion Methyl | 104     | 99.9    | P/P       | 87 - 125       |
| 1792870       | Pendimethalin    | 80.2    | 81.4    | P/P       | 53 - 136       |
| 1792870       | Phorate          | 64.4    | 72.3    | P/P       | 52 - 113       |
| 1792870       | Prometon         | 101     | 91.6    | P/P       | 67 - 125       |
| 1792870       | Prometryn        | 90.5    | 95.9    | P/P       | 73 - 114       |
| 1792870       | Simazine         | 106     | 104     | P/P       | 66 - 123       |
| 1792870       | Terbufos         | 74.3    | 78.2    | P/P       | 58 - 116       |
| 1792870       | Terbuthylazine   | 87.5    | 94.6    | P/P       | 77 - 113       |

Reference Method: SM 4500 F-C-97  
Batch ID: P303278

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 1793381       | Fluoride  | 97.9    | 98.6    | P/P       | 91 - 105       |

Reference Method: SM 4500 F-C-97  
Batch ID: P303279

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 1793064       | Fluoride  | 97.4    | 97.9    | P/P       | 91 - 105       |

Reference Method: SM 5310 B-00  
Batch ID: P304298

| Spiked Sample | Component      | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|----------------|---------|---------|-----------|----------------|
| 1792841       | Organic Carbon | 95.7    | 95.7    | P/P       | 85 - 115       |

Reference Method: USGS O-2060-01  
Batch ID: P302924

| Spiked Sample | Component     | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|---------------|---------|---------|-----------|----------------|
| 1792860       | 2,4,5-T       | 106     | 107     | P/P       | 40 - 140       |
| 1792860       | 2,4-D         | 154     | 154     | F/F       | 40 - 140       |
| 1792860       | 2,4-DB        | 72.0    | 71.2    | P/P       | 40 - 140       |
| 1792860       | Acetaminophen | 70.8    | 71.2    | P/P       | 40 - 140       |
| 1792860       | Acifluorfen   | 93.6    | 93.6    | P/P       | 40 - 140       |
| 1792860       | Carbamazepine | 101     | 96.4    | P/P       | 40 - 140       |
| 1792860       | Dichlorprop   | 139     | 136     | P/P       | 40 - 140       |
| 1792860       | Dinoseb       | 101     | 105     | P/P       | 40 - 140       |
| 1792860       | Diuron        | 67.2    | 64.4    | P/P       | 40 - 140       |

## Quality Assurance Report Matrix Spike Accuracy

Reference Method: USGS O-2060-01  
Batch ID: P302924

| Spiked Sample | Component    | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|--------------|---------|---------|-----------|----------------|
| 1792860       | Fenuron      | 62.8    | 61.2    | P/P       | 40 - 140       |
| 1792860       | Fluridone    | 85.5    | 84.3    | P/P       | 40 - 140       |
| 1792860       | Imidacloprid | 232     | 222     | F/F       | 40 - 160       |
| 1792860       | Linuron      | 86.8    | 81.2    | P/P       | 40 - 140       |
| 1792860       | MCPA         | 118     | 116     | P/P       | 40 - 140       |
| 1792860       | MCPP         | 122     | 124     | P/P       | 40 - 140       |
| 1792860       | Primidone    | 106     | 103     | P/P       | 40 - 140       |
| 1792860       | Silvex       | 139     | 146     | P/F       | 40 - 140       |

## Quality Assurance Report Precision

Reference Method: DEP SOP: GC-011-5 (based on EPA 608 and 617)  
Batch ID: P302942

| Replicated<br>Lab Sample | Component          | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|--------------------|-----------|-------------------|-----------|----------------|
| 1792377                  | Aldrin             | 23.5      | Spike             | P         | 0 - 30         |
| 1792377                  | Alpha-BHC          | 15.1      | Spike             | P         | 0 - 30         |
| 1792377                  | Beta-BHC           | 4.59      | Spike             | P         | 0 - 30         |
| 1792377                  | DDD-p,p'           | 19.5      | Spike             | P         | 0 - 30         |
| 1792377                  | DDE-p,p'           | 19.1      | Spike             | P         | 0 - 30         |
| 1792377                  | DDT-p,p'           | 59.8      | Spike             | F         | 0 - 30         |
| 1792377                  | Delta-BHC          | 14.7      | Spike             | P         | 0 - 30         |
| 1792377                  | Dieldrin           | 19.0      | Spike             | P         | 0 - 30         |
| 1792377                  | Endosulfan I       | 35.3      | Spike             | F         | 0 - 30         |
| 1792377                  | Endosulfan II      | 19.1      | Spike             | P         | 0 - 30         |
| 1792377                  | Endosulfan Sulfate | 20.7      | Spike             | P         | 0 - 30         |
| 1792377                  | Endrin             | 23.9      | Spike             | P         | 0 - 30         |
| 1792377                  | Endrin Aldehyde    | 23.5      | Spike             | P         | 0 - 30         |
| 1792377                  | Gamma-BHC          | 18.2      | Spike             | P         | 0 - 30         |
| 1792377                  | Heptachlor         | 4.75      | Spike             | P         | 0 - 30         |
| 1792377                  | Heptachlor Epoxide | 24.5      | Spike             | P         | 0 - 30         |
| 1792377                  | Methoxychlor       | 16.6      | Spike             | P         | 0 - 30         |
| LFB                      | Aldrin             | 6.08      | LCS               | P         | 0 - 30         |
| LFB                      | Alpha-BHC          | 14.4      | LCS               | P         | 0 - 30         |
| LFB                      | Beta-BHC           | 14.2      | LCS               | P         | 0 - 30         |
| LFB                      | DDD-p,p'           | 3.71      | LCS               | P         | 0 - 30         |
| LFB                      | DDE-p,p'           | 4.50      | LCS               | P         | 0 - 30         |
| LFB                      | DDT-p,p'           | 0.693     | LCS               | P         | 0 - 30         |
| LFB                      | Delta-BHC          | 3.97      | LCS               | P         | 0 - 30         |
| LFB                      | Dieldrin           | 4.12      | LCS               | P         | 0 - 30         |
| LFB                      | Endosulfan I       | 3.16      | LCS               | P         | 0 - 30         |
| LFB                      | Endosulfan II      | 4.82      | LCS               | P         | 0 - 30         |
| LFB                      | Endosulfan Sulfate | 1.26      | LCS               | P         | 0 - 30         |
| LFB                      | Endrin             | 3.23      | LCS               | P         | 0 - 30         |
| LFB                      | Endrin Aldehyde    | 6.57      | LCS               | P         | 0 - 30         |
| LFB                      | Gamma-BHC          | 9.11      | LCS               | P         | 0 - 30         |
| LFB                      | Heptachlor         | 12.0      | LCS               | P         | 0 - 30         |
| LFB                      | Heptachlor Epoxide | 6.41      | LCS               | P         | 0 - 30         |
| LFB                      | Methoxychlor       | 7.61      | LCS               | P         | 0 - 30         |

## Quality Assurance Report Precision

Reference Method: EPA 180.1 Rev. 2.0  
Batch ID: P303007

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 1792755                  | Turbidity | 2.72      | Sample            | P         | 0 - 20         |

Reference Method: EPA 180.1 Rev. 2.0  
Batch ID: P303008

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 1792851                  | Turbidity | 1.43      | Sample            | P         | 0 - 20         |

Reference Method: EPA 200.7 Rev. 4.4  
Batch ID: P303173

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 1792559                  | Calcium   | 1.01      | Spike             | P         | 0 - 20         |
| 1792559                  | Iron      | 0.466     | Spike             | P         | 0 - 20         |
| 1792559                  | Magnesium | 0.997     | Spike             | P         | 0 - 20         |
| 1792559                  | Potassium | 0.0699    | Spike             | P         | 0 - 20         |
| 1792559                  | Sodium    | 0.320     | Spike             | P         | 0 - 20         |
| 1792559                  | Zinc      | 0.194     | Spike             | P         | 0 - 20         |

Reference Method: EPA 200.8 Rev. 5.4  
Batch ID: P303173

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 1792559                  | Arsenic   | 2.62      | Spike             | P         | 0 - 20         |
| 1792559                  | Cadmium   | 0.737     | Spike             | P         | 0 - 20         |
| 1792559                  | Chromium  | 17.7      | Spike             | P         | 0 - 20         |
| 1792559                  | Copper    | 1.08      | Spike             | P         | 0 - 20         |
| 1792559                  | Lead      | 0.966     | Spike             | P         | 0 - 20         |
| 1792559                  | Nickel    | 0.824     | Spike             | P         | 0 - 20         |
| 1792559                  | Silver    | 0.613     | Spike             | P         | 0 - 20         |

Reference Method: EPA 300.0 Rev. 2.1  
Batch ID: P303578

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 1792961                  | Chloride  | 0.0388    | Sample            | P         | 0 - 20         |

Reference Method: EPA 300.0 Rev. 2.1  
Batch ID: P303582

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 1792961                  | Sulfate   | 0.0984    | Sample            | P         | 0 - 20         |

## Quality Assurance Report Precision

Reference Method: EPA 350.1 Rev. 2.0  
Batch ID: P303685

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 1792762                  | Ammonia-N | 0.157     | Spike             | P         | 0 - 20         |

Reference Method: EPA 350.1 Rev. 2.0  
Batch ID: P303691

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 1792852                  | Ammonia-N | 0.507     | Spike             | P         | 0 - 20         |

Reference Method: EPA 351.2 Rev. 2.0  
Batch ID: P303931

| Replicated<br>Lab Sample | Component         | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-------------------|-----------|-------------------|-----------|----------------|
| 1792790                  | Kjeldahl Nitrogen | 1.47      | Spike             | P         | 0 - 20         |

Reference Method: EPA 351.2 Rev. 2.0  
Batch ID: P304112

| Replicated<br>Lab Sample | Component         | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-------------------|-----------|-------------------|-----------|----------------|
| 1792618                  | Kjeldahl Nitrogen | 2.38      | Spike             | P         | 0 - 20         |

Reference Method: EPA 353.2 Rev. 2.0  
Batch ID: P303636

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 1793257                  | NO2NO3-N  | 2.36      | Spike             | P         | 0 - 20         |

Reference Method: EPA 353.2 Rev. 2.0  
Batch ID: P303852

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 1792790                  | NO2NO3-N  | 1.48      | Spike             | P         | 0 - 20         |

Reference Method: EPA 365.1 Rev. 2.0  
Batch ID: P303744

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 1792844                  | Total-P   | 0.851     | Spike             | P         | 0 - 20         |

Reference Method: EPA 365.1 Rev. 2.0  
Batch ID: P303806

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 1793244                  | Total-P   | 4.70      | Spike             | P         | 0 - 20         |

## Quality Assurance Report Precision

Reference Method: EPA 365.1 Rev. 2.0

Batch ID: P304059

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 1792790                  | Total-P   | 2.24      | Spike             | P         | 0 - 20         |

Reference Method: EPA 365.1 Rev. 2.0 dissolved

Batch ID: P302985

| Replicated<br>Lab Sample | Component     | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|---------------|-----------|-------------------|-----------|----------------|
| 1792672                  | O-Phosphate-P | 1.39      | Spike             | P         | 0 - 20         |

Reference Method: EPA 365.1 Rev. 2.0 dissolved

Batch ID: P302986

| Replicated<br>Lab Sample | Component     | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|---------------|-----------|-------------------|-----------|----------------|
| 1792848                  | O-Phosphate-P | 0.600     | Spike             | P         | 0 - 20         |

Reference Method: EPA 365.1 Rev. 2.0 dissolved

Batch ID: P302987

| Replicated<br>Lab Sample | Component     | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|---------------|-----------|-------------------|-----------|----------------|
| 1792853                  | O-Phosphate-P | 0.142     | Spike             | P         | 0 - 20         |

Reference Method: EPA 8270D

Batch ID: P303196

| Replicated<br>Lab Sample | Component           | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|---------------------|-----------|-------------------|-----------|----------------|
| 1792870                  | Acetochlor          | 5.94      | Spike             | P         | 0 - 30         |
| 1792870                  | Alachlor            | 10.9      | Spike             | P         | 0 - 30         |
| 1792870                  | Ametryn             | 3.37      | Spike             | P         | 0 - 30         |
| 1792870                  | Atrazine            | 8.90      | Spike             | P         | 0 - 30         |
| 1792870                  | Atrazine Desethyl   | 0.450     | Spike             | P         | 0 - 30         |
| 1792870                  | Azinphos Methyl     | 1.17      | Spike             | P         | 0 - 30         |
| 1792870                  | Bromacil            | 2.28      | Spike             | P         | 0 - 30         |
| 1792870                  | Butylate            | 13.3      | Spike             | P         | 0 - 30         |
| 1792870                  | Chlorpyrifos Ethyl  | 16.8      | Spike             | P         | 0 - 30         |
| 1792870                  | Chlorpyrifos Methyl | 3.75      | Spike             | P         | 0 - 30         |
| 1792870                  | Cyanazine           | 5.75      | Spike             | P         | 0 - 30         |
| 1792870                  | Demeton             | 13.4      | Spike             | P         | 0 - 30         |
| 1792870                  | Diazinon            | 2.29      | Spike             | P         | 0 - 30         |
| 1792870                  | Disulfoton          | 5.15      | Spike             | P         | 0 - 30         |
| 1792870                  | EPTC                | 19.6      | Spike             | P         | 0 - 30         |
| 1792870                  | Ethion              | 3.40      | Spike             | P         | 0 - 30         |
| 1792870                  | Ethoprop            | 4.57      | Spike             | P         | 0 - 30         |
| 1792870                  | Fenamiphos          | 1.64      | Spike             | P         | 0 - 30         |
| 1792870                  | Fipronil            | 1.43      | Spike             | P         | 0 - 30         |
| 1792870                  | Fipronil Sulfide    | 0.0541    | Spike             | P         | 0 - 30         |
| 1792870                  | Fipronil Sulfone    | 0.664     | Spike             | P         | 0 - 30         |
| 1792870                  | Fonofos             | 2.24      | Spike             | P         | 0 - 30         |
| 1792870                  | Hexazinone          | 2.32      | Spike             | P         | 0 - 30         |

## Quality Assurance Report Precision

Reference Method: EPA 8270D  
Batch ID: P303196

| Replicated<br>Lab Sample | Component           | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|---------------------|-----------|-------------------|-----------|----------------|
| 1792870                  | Malathion           | 4.51      | Spike             | P         | 0 - 30         |
| 1792870                  | Metalaxyl           | 8.22      | Spike             | P         | 0 - 30         |
| 1792870                  | Metolachlor         | 7.81      | Spike             | P         | 0 - 30         |
| 1792870                  | Metribuzin          | 5.95      | Spike             | P         | 0 - 30         |
| 1792870                  | Mevinphos           | 3.38      | Spike             | P         | 0 - 30         |
| 1792870                  | Molinate            | 6.95      | Spike             | P         | 0 - 30         |
| 1792870                  | Norflurazon         | 2.94      | Spike             | P         | 0 - 30         |
| 1792870                  | Parathion Ethyl     | 0.848     | Spike             | P         | 0 - 30         |
| 1792870                  | Parathion Methyl    | 4.45      | Spike             | P         | 0 - 30         |
| 1792870                  | Pendimethalin       | 1.56      | Spike             | P         | 0 - 30         |
| 1792870                  | Phorate             | 11.5      | Spike             | P         | 0 - 30         |
| 1792870                  | Prometon            | 9.59      | Spike             | P         | 0 - 30         |
| 1792870                  | Prometryn           | 5.32      | Spike             | P         | 0 - 30         |
| 1792870                  | Simazine            | 2.21      | Spike             | P         | 0 - 30         |
| 1792870                  | Terbufos            | 5.14      | Spike             | P         | 0 - 30         |
| 1792870                  | Terbutylazine       | 7.73      | Spike             | P         | 0 - 30         |
| LFB                      | Acetochlor          | 12.0      | LCS               | P         | 0 - 30         |
| LFB                      | Alachlor            | 10.6      | LCS               | P         | 0 - 30         |
| LFB                      | Ametryn             | 3.40      | LCS               | P         | 0 - 30         |
| LFB                      | Atrazine            | 10.8      | LCS               | P         | 0 - 30         |
| LFB                      | Atrazine Desethyl   | 23.1      | LCS               | P         | 0 - 30         |
| LFB                      | Azinphos Methyl     | 13.5      | LCS               | P         | 0 - 30         |
| LFB                      | Bromacil            | 17.1      | LCS               | P         | 0 - 30         |
| LFB                      | Butylate            | 3.76      | LCS               | P         | 0 - 30         |
| LFB                      | Chlorpyrifos Ethyl  | 10.2      | LCS               | P         | 0 - 30         |
| LFB                      | Chlorpyrifos Methyl | 11.3      | LCS               | P         | 0 - 30         |
| LFB                      | Cyanazine           | 15.5      | LCS               | P         | 0 - 30         |
| LFB                      | Demeton             | 8.95      | LCS               | P         | 0 - 30         |
| LFB                      | Diazinon            | 6.14      | LCS               | P         | 0 - 30         |
| LFB                      | Disulfoton          | 18.5      | LCS               | P         | 0 - 30         |
| LFB                      | EPTC                | 0.745     | LCS               | P         | 0 - 30         |
| LFB                      | Ethion              | 8.85      | LCS               | P         | 0 - 30         |
| LFB                      | Ethoprop            | 7.78      | LCS               | P         | 0 - 30         |
| LFB                      | Fenamiphos          | 8.16      | LCS               | P         | 0 - 30         |
| LFB                      | Fipronil            | 11.1      | LCS               | P         | 0 - 30         |
| LFB                      | Fipronil Sulfide    | 8.96      | LCS               | P         | 0 - 30         |
| LFB                      | Fipronil Sulfone    | 7.52      | LCS               | P         | 0 - 30         |
| LFB                      | Fonofos             | 8.34      | LCS               | P         | 0 - 30         |
| LFB                      | Hexazinone          | 14.9      | LCS               | P         | 0 - 30         |
| LFB                      | Malathion           | 19.0      | LCS               | P         | 0 - 30         |
| LFB                      | Metalaxyl           | 8.93      | LCS               | P         | 0 - 30         |
| LFB                      | Metolachlor         | 11.3      | LCS               | P         | 0 - 30         |
| LFB                      | Metribuzin          | 17.3      | LCS               | P         | 0 - 30         |
| LFB                      | Mevinphos           | 3.74      | LCS               | P         | 0 - 30         |
| LFB                      | Molinate            | 3.12      | LCS               | P         | 0 - 30         |
| LFB                      | Norflurazon         | 6.79      | LCS               | P         | 0 - 30         |
| LFB                      | Parathion Ethyl     | 5.79      | LCS               | P         | 0 - 30         |
| LFB                      | Parathion Methyl    | 4.88      | LCS               | P         | 0 - 30         |
| LFB                      | Pendimethalin       | 6.60      | LCS               | P         | 0 - 30         |
| LFB                      | Phorate             | 3.57      | LCS               | P         | 0 - 30         |
| LFB                      | Prometon            | 9.89      | LCS               | P         | 0 - 30         |

## Quality Assurance Report Precision

Reference Method: EPA 8270D  
Batch ID: P303196

| Replicated<br>Lab Sample | Component     | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|---------------|-----------|-------------------|-----------|----------------|
| LFB                      | Prometryn     | 14.8      | LCS               | P         | 0 - 30         |
| LFB                      | Simazine      | 6.96      | LCS               | P         | 0 - 30         |
| LFB                      | Terbufos      | 11.7      | LCS               | P         | 0 - 30         |
| LFB                      | Terbutylazine | 12.6      | LCS               | P         | 0 - 30         |

Reference Method: SM 2120 B  
Batch ID: P303015

| Replicated<br>Lab Sample | Component    | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|--------------|-----------|-------------------|-----------|----------------|
| 1792836                  | Color (true) | 1.99      | Sample            | P         | 0 - 20         |

Reference Method: SM 2320 B-97  
Batch ID: P303462

| Replicated<br>Lab Sample | Component        | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|------------------|-----------|-------------------|-----------|----------------|
| 1793381                  | Total Alkalinity | 0.380     | Sample            | P         | 0 - 4.8        |

Reference Method: SM 2320 B-97  
Batch ID: P303463

| Replicated<br>Lab Sample | Component        | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|------------------|-----------|-------------------|-----------|----------------|
| 1793064                  | Total Alkalinity | 0.435     | Sample            | P         | 0 - 4.8        |

Reference Method: SM 2540 C-97  
Batch ID: P303446

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 1792800                  | TDS       | 5.52      | Sample            | P         | 0 - 10         |

Reference Method: SM 2540 D-97  
Batch ID: P303314

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 1792851                  | TSS       | 7.41      | Sample            | P         | 0 - 10         |

Reference Method: SM 4500 F-C-97  
Batch ID: P303278

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 1793381                  | Fluoride  | 0.509     | Spike             | P         | 0 - 3.0        |

## Quality Assurance Report Precision

Reference Method: SM 4500 F-C-97  
Batch ID: P303279

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 1793064                  | Fluoride  | 0.492     | Spike             | P         | 0 - 3.0        |

Reference Method: SM 5310 B-00  
Batch ID: P304298

| Replicated<br>Lab Sample | Component      | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|----------------|-----------|-------------------|-----------|----------------|
| 1792841                  | Organic Carbon | 0.0357    | Spike             | P         | 0 - 20         |

Reference Method: USGS O-2060-01  
Batch ID: P302924

| Replicated<br>Lab Sample | Component     | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|---------------|-----------|-------------------|-----------|----------------|
| 1792860                  | 2,4,5-T       | 0.375     | Spike             | P         | 0 - 30         |
| 1792860                  | 2,4-D         | 0.519     | Spike             | P         | 0 - 30         |
| 1792860                  | 2,4-DB        | 1.12      | Spike             | P         | 0 - 30         |
| 1792860                  | Acetaminophen | 0.563     | Spike             | P         | 0 - 30         |
| 1792860                  | Acifluorfen   | 0.0       | Spike             | P         | 0 - 30         |
| 1792860                  | Bentazon      | 7.69      | Spike             | P         | 0 - 30         |
| 1792860                  | Carbamazepine | 4.46      | Spike             | P         | 0 - 30         |
| 1792860                  | Dichlorprop   | 2.04      | Spike             | P         | 0 - 30         |
| 1792860                  | Dinoseb       | 3.88      | Spike             | P         | 0 - 30         |
| 1792860                  | Diuron        | 4.26      | Spike             | P         | 0 - 30         |
| 1792860                  | Fenuron       | 2.58      | Spike             | P         | 0 - 30         |
| 1792860                  | Fluridone     | 1.40      | Spike             | P         | 0 - 30         |
| 1792860                  | Imidacloprid  | 4.59      | Spike             | P         | 0 - 30         |
| 1792860                  | Linuron       | 6.67      | Spike             | P         | 0 - 30         |
| 1792860                  | MCPA          | 1.71      | Spike             | P         | 0 - 30         |
| 1792860                  | MCP           | 1.95      | Spike             | P         | 0 - 30         |
| 1792860                  | Primidone     | 3.05      | Spike             | P         | 0 - 30         |
| 1792860                  | Silvex        | 5.06      | Spike             | P         | 0 - 30         |
| LFB                      | 2,4,5-T       | 12.6      | LCS               | P         | 0 - 30         |
| LFB                      | 2,4-D         | 1.11      | LCS               | P         | 0 - 30         |
| LFB                      | 2,4-DB        | 9.23      | LCS               | P         | 0 - 30         |
| LFB                      | Acetaminophen | 82.6      | LCS               | F         | 0 - 30         |
| LFB                      | Acifluorfen   | 6.27      | LCS               | P         | 0 - 30         |
| LFB                      | Bentazon      | 1.40      | LCS               | P         | 0 - 30         |
| LFB                      | Carbamazepine | 1.75      | LCS               | P         | 0 - 30         |
| LFB                      | Dichlorprop   | 5.85      | LCS               | P         | 0 - 30         |
| LFB                      | Dinoseb       | 0.0       | LCS               | P         | 0 - 30         |
| LFB                      | Diuron        | 16.1      | LCS               | P         | 0 - 30         |
| LFB                      | Fenuron       | 5.48      | LCS               | P         | 0 - 30         |
| LFB                      | Fluridone     | 3.01      | LCS               | P         | 0 - 30         |
| LFB                      | Imidacloprid  | 2.83      | LCS               | P         | 0 - 30         |
| LFB                      | Linuron       | 1.08      | LCS               | P         | 0 - 30         |
| LFB                      | MCPA          | 2.90      | LCS               | P         | 0 - 30         |
| LFB                      | MCP           | 8.73      | LCS               | P         | 0 - 30         |
| LFB                      | Primidone     | 2.03      | LCS               | P         | 0 - 30         |
| LFB                      | Silvex        | 1.73      | LCS               | P         | 0 - 30         |

## Quality Assurance Report Precision

\* Sample, spike and/or laboratory control sample precision (LCS) is reported.  
Replicate spike precision may be reported when sample results are below quantifiable levels.

## Quality Assurance Report Surrogates

Lab Sample ID: 1792860  
Field Sample ID: G4SENNR3

| Reference Method | Surrogate         | % Rec. | Pass/Fail | Control Limits |
|------------------|-------------------|--------|-----------|----------------|
| USGS O-2060-01   | 2,4-D-d3          | 113    | P         | 40 - 150       |
| USGS O-2060-01   | Acetaminophen-d4  | 65.2   | P         | 30 - 150       |
| USGS O-2060-01   | Carbamazepine-d10 | 115    | P         | 40 - 160       |
| USGS O-2060-01   | Diuron-d6         | 63.0   | P         | 40 - 150       |
| USGS O-2060-01   | Primidone-d5      | 78.0   | P         | 40 - 150       |

Lab Sample ID: 1792861  
Field Sample ID: G4SENNR2

| Reference Method | Surrogate         | % Rec. | Pass/Fail | Control Limits |
|------------------|-------------------|--------|-----------|----------------|
| USGS O-2060-01   | 2,4-D-d3          | 119    | P         | 40 - 150       |
| USGS O-2060-01   | Acetaminophen-d4  | 72.0   | P         | 30 - 150       |
| USGS O-2060-01   | Carbamazepine-d10 | 126    | P         | 40 - 160       |
| USGS O-2060-01   | Diuron-d6         | 72.8   | P         | 40 - 150       |
| USGS O-2060-01   | Primidone-d5      | 89.4   | P         | 40 - 150       |

Lab Sample ID: 1792868  
Field Sample ID: G4SENNR3

| Reference Method                             | Surrogate          | % Rec. | Pass/Fail | Control Limits |
|----------------------------------------------|--------------------|--------|-----------|----------------|
| DEP SOP: GC-011-5 (based on EPA 608 and 617) | Decachlorobiphenyl | 73.1   | P         | 44 - 128       |

Lab Sample ID: 1792869  
Field Sample ID: G4SENNR2

| Reference Method                             | Surrogate          | % Rec. | Pass/Fail | Control Limits |
|----------------------------------------------|--------------------|--------|-----------|----------------|
| DEP SOP: GC-011-5 (based on EPA 608 and 617) | Decachlorobiphenyl | 80.1   | P         | 44 - 128       |

Lab Sample ID: 1792870  
Field Sample ID: G4SENNR3

| Reference Method | Surrogate    | % Rec. | Pass/Fail | Control Limits |
|------------------|--------------|--------|-----------|----------------|
| EPA 8270D        | Malathion-d7 | 92.0   | P         | 67 - 131       |
| EPA 8270D        | Simazine-d10 | 102    | P         | 75 - 130       |

Lab Sample ID: 1792871  
Field Sample ID: G4SENNR2

| Reference Method | Surrogate    | % Rec. | Pass/Fail | Control Limits |
|------------------|--------------|--------|-----------|----------------|
| EPA 8270D        | Malathion-d7 | 67.7   | P         | 67 - 131       |
| EPA 8270D        | Simazine-d10 | 96.7   | P         | 75 - 130       |

## Quality Assurance Report Calibration Verification

Reference Method: EPA 365.1 Rev. 2.0 dissolved

Run ID: A69106

Included Lab Sample IDs: 1792846, 1792847, 1792848, 1792849, 1792850, 1792853

| Component     | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|---------------|---------|---------|------------|----------------|
| O-Phosphate-P | 100     | 102     | P/P        | 90 - 110       |
| O-Phosphate-P | 101     | 99.3    | P/P        | 90 - 110       |
| O-Phosphate-P | 102     | 100     | P/P        | 90 - 110       |

Reference Method: EPA 180.1 Rev. 2.0

Run ID: A69112

Included Lab Sample IDs: 1792836, 1792837, 1792838, 1792839, 1792840, 1792851

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Turbidity | 101     | 100     | P/P        | 95 - 105       |
| Turbidity | 101     | 101     | P/P        | 95 - 105       |

Reference Method: SM 2120 B

Run ID: A69115

Included Lab Sample IDs: 1792836, 1792837, 1792838, 1792839, 1792840

| Component    | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|--------------|---------|---------|------------|----------------|
| Color (true) | 102     | 103     | P/P        | 90 - 115       |

Reference Method: SM 4500 F-C-97

Run ID: A69187

Included Lab Sample IDs: 1792836, 1792837, 1792838, 1792839, 1792840, 1792851

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Fluoride  | 101     | 99.5    | P/P        | 90 - 110       |
| Fluoride  | 99.5    | 101     | P/P        | 90 - 110       |

Reference Method: EPA 200.7 Rev. 4.4

Run ID: A69210

Included Lab Sample IDs: 1792862, 1792863, 1792864, 1792865, 1792866, 1792867

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Calcium   | 101     | 102     | P/P        | 90 - 110       |
| Calcium   | 102     | 101     | P/P        | 90 - 110       |
| Iron      | 100     | 99.1    | P/P        | 90 - 110       |
| Iron      | 99.6    | 100     | P/P        | 90 - 110       |
| Magnesium | 101     | 102     | P/P        | 90 - 110       |
| Magnesium | 102     | 101     | P/P        | 90 - 110       |
| Potassium | 100     | 101     | P/P        | 90 - 110       |
| Potassium | 101     | 98.1    | P/P        | 90 - 110       |
| Sodium    | 100     | 101     | P/P        | 90 - 110       |
| Sodium    | 101     | 94.0    | P/P        | 90 - 110       |
| Zinc      | 100     | 100     | P/P        | 90 - 110       |
| Zinc      | 100     | 101     | P/P        | 90 - 110       |

Reference Method: EPA 200.8 Rev. 5.4

Run ID: A69214

Included Lab Sample IDs: 1792862, 1792863, 1792864, 1792865, 1792866, 1792867

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Arsenic   | 99.6    | 99.3    | P/P        | 90 - 110       |

## Quality Assurance Report Calibration Verification

Reference Method: EPA 200.8 Rev. 5.4

Run ID: A69214

Included Lab Sample IDs: 1792862, 1792863, 1792864, 1792865, 1792866, 1792867

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Cadmium   | 97.8    | 97.9    | P/P        | 90 - 110       |
| Chromium  | 99.7    | 99.0    | P/P        | 90 - 110       |
| Copper    | 99.1    | 98.7    | P/P        | 90 - 110       |
| Lead      | 96.2    | 96.3    | P/P        | 90 - 110       |
| Nickel    | 99.5    | 99.4    | P/P        | 90 - 110       |
| Silver    | 95.7    | 96.7    | P/P        | 90 - 110       |

Reference Method: USGS O-2060-01

Run ID: A69216

Included Lab Sample IDs: 1792860, 1792861

| Component     | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|---------------|---------|---------|------------|----------------|
| Acetaminophen | 115     | 125     | P/P        | 60 - 150       |
| Acetaminophen | 122     | 115     | P/P        | 60 - 150       |
| Carbamazepine | 124     | 136     | P/P        | 60 - 150       |
| Carbamazepine | 136     | 136     | P/P        | 60 - 150       |
| Diuron        | 117     | 93.6    | P/P        | 60 - 150       |
| Diuron        | 93.6    | 104     | P/P        | 60 - 150       |
| Fenuron       | 110     | 114     | P/P        | 60 - 150       |
| Fenuron       | 114     | 116     | P/P        | 60 - 150       |
| Fluridone     | 91.6    | 94.0    | P/P        | 60 - 150       |
| Fluridone     | 94.0    | 93.6    | P/P        | 60 - 150       |
| Imidacloprid  | 120     | 130     | P/P        | 60 - 150       |
| Imidacloprid  | 130     | 128     | P/P        | 60 - 150       |
| Linuron       | 112     | 115     | P/P        | 60 - 150       |
| Linuron       | 115     | 118     | P/P        | 60 - 150       |
| Primidone     | 103     | 125     | P/P        | 60 - 150       |
| Primidone     | 125     | 111     | P/P        | 60 - 150       |

Reference Method: EPA 300.0 Rev. 2.1

Run ID: A69217

Included Lab Sample IDs: 1792836, 1792837, 1792838, 1792839, 1792840

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Chloride  | 100     | 99.8    | P/P        | 90 - 110       |
| Chloride  | 100     | 100     | P/P        | 90 - 110       |
| Sulfate   | 97.9    | 99.3    | P/P        | 90 - 110       |
| Sulfate   | 99.9    | 97.9    | P/P        | 90 - 110       |

Reference Method: USGS O-2060-01

Run ID: A69227

Included Lab Sample IDs: 1792860, 1792861

| Component   | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-------------|---------|---------|------------|----------------|
| 2,4,5-T     | 92.2    | 92.4    | P/P        | 50 - 150       |
| 2,4,5-T     | 92.4    | 92.0    | P/P        | 50 - 150       |
| 2,4-D       | 103     | 102     | P/P        | 50 - 150       |
| 2,4-D       | 89.8    | 103     | P/P        | 50 - 150       |
| 2,4-DB      | 100     | 88.4    | P/P        | 50 - 150       |
| 2,4-DB      | 88.4    | 88.8    | P/P        | 50 - 150       |
| Acifluorfen | 102     | 109     | P/P        | 50 - 150       |

## Quality Assurance Report Calibration Verification

Reference Method: USGS O-2060-01

Run ID: A69227

Included Lab Sample IDs: 1792860, 1792861

| Component   | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-------------|---------|---------|------------|----------------|
| Acifluorfen | 109     | 111     | P/P        | 50 - 150       |
| Bentazon    | 85.4    | 85.2    | P/P        | 50 - 150       |
| Bentazon    | 94.4    | 85.4    | P/P        | 50 - 150       |
| Dichlorprop | 95.8    | 98.4    | P/P        | 50 - 150       |
| Dichlorprop | 97.4    | 95.8    | P/P        | 50 - 150       |
| Dinoseb     | 97.0    | 95.4    | P/P        | 50 - 150       |
| Dinoseb     | 99.0    | 97.0    | P/P        | 50 - 150       |
| MCPA        | 109     | 97.2    | P/P        | 50 - 150       |
| MCPA        | 97.2    | 104     | P/P        | 50 - 150       |
| MCPP        | 109     | 99.2    | P/P        | 50 - 150       |
| MCPP        | 99.2    | 105     | P/P        | 50 - 150       |
| Silvex      | 110     | 114     | P/P        | 50 - 150       |
| Silvex      | 110     | 110     | P/P        | 50 - 150       |

Reference Method: SM 2320 B-97

Run ID: A69249

Included Lab Sample IDs: 1792836, 1792837, 1792838, 1792839, 1792840, 1792851

| Component        | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|------------------|---------|---------|------------|----------------|
| Total Alkalinity | 100     | 98.0    | P/P        | 90 - 110       |
| Total Alkalinity | 98.0    | 100     | P/P        | 90 - 110       |

Reference Method: DEP SOP: GC-011-5 (based on EPA 608 and 617)

Run ID: A69288

Included Lab Sample IDs: 1792868, 1792869

| Component          | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|--------------------|---------|---------|------------|----------------|
| Aldrin             | 94.7    | 89.9    | P/P        | 85 - 115       |
| Alpha-BHC          | 93.8    | 89.5    | P/P        | 85 - 115       |
| Beta-BHC           | 98.0    | 93.4    | P/P        | 85 - 115       |
| Carbophenothion    | 108     | 124*    | P/F        | 90 - 110       |
| Chlorothalonil     | 111*    | 118*    | F/F        | 90 - 110       |
| Cypermethrin       | 108     | 123*    | P/F        | 85 - 115       |
| DDD-p,p'           | 96.1    | 93.9    | P/P        | 85 - 115       |
| DDE-p,p'           | 95.5    | 91.4    | P/P        | 85 - 115       |
| DDT-p,p'           | 94.6    | 93.3    | P/P        | 85 - 115       |
| Delta-BHC          | 95.5    | 91.5    | P/P        | 85 - 115       |
| Dicofol            | 100     | 104     | P/P        | 90 - 110       |
| Dieldrin           | 95.9    | 90.9    | P/P        | 85 - 115       |
| Endosulfan I       | 95.4    | 91.0    | P/P        | 85 - 115       |
| Endosulfan II      | 95.8    | 90.9    | P/P        | 85 - 115       |
| Endosulfan Sulfate | 95.2    | 93.4    | P/P        | 85 - 115       |
| Endrin             | 98.0    | 92.1    | P/P        | 85 - 115       |
| Endrin Aldehyde    | 95.4    | 91.2    | P/P        | 85 - 115       |
| Gamma-BHC          | 95.1    | 91.1    | P/P        | 85 - 115       |
| Heptachlor         | 96.1    | 97.9    | P/P        | 85 - 115       |
| Heptachlor Epoxide | 95.6    | 91.2    | P/P        | 85 - 115       |
| Methoxychlor       | 97.2    | 98.1    | P/P        | 90 - 110       |
| Mirex              | 105     | 108     | P/P        | 90 - 110       |
| Permethrin         | 106     | 110     | P/P        | 90 - 110       |

## Quality Assurance Report Calibration Verification

Reference Method: EPA 353.2 Rev. 2.0

Run ID: A69298

Included Lab Sample IDs: 1792852

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| NO2NO3-N  | 102     | 102     | P/P        | 90 - 110       |

Reference Method: EPA 350.1 Rev. 2.0

Run ID: A69311

Included Lab Sample IDs: 1792841, 1792842, 1792843, 1792844, 1792845, 1792852

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Ammonia-N | 100     | 101     | P/P        | 90 - 110       |
| Ammonia-N | 101     | 102     | P/P        | 90 - 110       |

Reference Method: EPA 353.2 Rev. 2.0

Run ID: A69340

Included Lab Sample IDs: 1792841, 1792842, 1792843, 1792844, 1792845

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| NO2NO3-N  | 100     | 100     | P/P        | 90 - 110       |

Reference Method: EPA 365.1 Rev. 2.0

Run ID: A69372

Included Lab Sample IDs: 1792852

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Total-P   | 99.8    | 101     | P/P        | 90 - 110       |

Reference Method: EPA 8270D

Run ID: A69390

Included Lab Sample IDs: 1792870, 1792871

| Component           | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|---------------------|---------|---------|------------|----------------|
| Acetochlor          | 98.2    |         | P          | 80 - 120       |
| Alachlor            | 98.3    |         | P          | 80 - 120       |
| Ametryn             | 95.3    |         | P          | 80 - 120       |
| Atrazine Desethyl   | 92.9    |         | P          | 80 - 120       |
| Azinphos Methyl     | 94.7    |         | P          | 80 - 120       |
| Bromacil            | 99.0    |         | P          | 80 - 120       |
| Butylate            | 102     |         | P          | 80 - 120       |
| Chlorpyrifos Ethyl  | 98.4    |         | P          | 80 - 120       |
| Chlorpyrifos Methyl | 97.1    |         | P          | 80 - 120       |
| Cyanazine           | 120*    |         | F          | 80 - 120       |
| Demeton             | 96.3    |         | P          | 80 - 120       |
| Diazinon            | 93.4    |         | P          | 80 - 120       |
| Disulfoton          | 95.9    |         | P          | 80 - 120       |
| EPTC                | 100     |         | P          | 80 - 120       |
| Ethion              | 97.8    |         | P          | 80 - 120       |
| Ethoprop            | 98.4    |         | P          | 80 - 120       |
| Fenamiphos          | 101     |         | P          | 80 - 120       |
| Fipronil            | 91.2    |         | P          | 80 - 120       |
| Fipronil Sulfide    | 95.3    |         | P          | 80 - 120       |
| Fipronil Sulfone    | 95.1    |         | P          | 80 - 120       |
| Fonofos             | 94.1    |         | P          | 80 - 120       |
| Hexazinone          | 99.1    |         | P          | 80 - 120       |

## Quality Assurance Report Calibration Verification

Reference Method: EPA 8270D

Run ID: A69390

Included Lab Sample IDs: 1792870, 1792871

| Component        | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|------------------|---------|---------|------------|----------------|
| Malathion        | 94.7    |         | P          | 80 - 120       |
| Metalaxyl        | 95.5    |         | P          | 80 - 120       |
| Metolachlor      | 98.9    |         | P          | 80 - 120       |
| Metribuzin       | 92.9    |         | P          | 80 - 120       |
| Mevinphos        | 94.9    |         | P          | 80 - 120       |
| Molinate         | 98.9    |         | P          | 80 - 120       |
| Norflurazon      | 94.8    |         | P          | 80 - 120       |
| Parathion Ethyl  | 98.1    |         | P          | 80 - 120       |
| Parathion Methyl | 97.9    |         | P          | 80 - 120       |
| Pendimethalin    | 92.5    |         | P          | 80 - 120       |
| Phorate          | 97.8    |         | P          | 80 - 120       |
| Prometon         | 102     |         | P          | 80 - 120       |
| Prometryn        | 97.4    |         | P          | 80 - 120       |
| Simazine         | 95.0    |         | P          | 80 - 120       |
| Terbufos         | 97.5    |         | P          | 80 - 120       |
| Terbuthylazine   | 97.3    |         | P          | 80 - 120       |

Reference Method: EPA 8270D

Run ID: A69397

Included Lab Sample IDs: 1792870, 1792871

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Atrazine  | 105     |         | P          | 80 - 120       |

Reference Method: EPA 365.1 Rev. 2.0

Run ID: A69412

Included Lab Sample IDs: 1792844, 1792845

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Total-P   | 99.2    | 100     | P/P        | 90 - 110       |

Reference Method: EPA 351.2 Rev. 2.0

Run ID: A69428

Included Lab Sample IDs: 1792841, 1792842, 1792843, 1792844, 1792845

| Component         | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-------------------|---------|---------|------------|----------------|
| Kjeldahl Nitrogen | 96.8    | 94.3    | P/P        | 90 - 110       |

Reference Method: EPA 365.1 Rev. 2.0

Run ID: A69459

Included Lab Sample IDs: 1792841, 1792842, 1792843

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Total-P   | 99.2    | 101     | P/P        | 90 - 110       |

Reference Method: SM 5310 B-00

Run ID: A69474

Included Lab Sample IDs: 1792841, 1792842, 1792843, 1792844, 1792845, 1792852

| Component      | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|----------------|---------|---------|------------|----------------|
| Organic Carbon | 98.6    | 101     | P/P        | 90 - 110       |

## Quality Assurance Report Calibration Verification

Reference Method: EPA 351.2 Rev. 2.0

Run ID: A69479

Included Lab Sample IDs: 1792852

| Component         | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-------------------|---------|---------|------------|----------------|
| Kjeldahl Nitrogen | 93.9    | 95.8    | P/P        | 90 - 110       |

\* Pass/Fail determinations are made for each bracketing calibration verification check.  
Control limits for initial calibration checks may be different from those for continuing checks, depending on method requirements.  
Where they are different, both control limits are provided.

## Quality Assurance Report Summary

| Ref. Method                                  | Analyte            | LCS % Recovery |      | MS % Recovery |      |      |       | LCS | Precision<br>SMP | MS     |
|----------------------------------------------|--------------------|----------------|------|---------------|------|------|-------|-----|------------------|--------|
| DEP SOP: GC-011-5 (based on EPA 608 and 617) | Aldrin             | 109            | 116  | 119           | 94.8 | 120  | 6.08  |     |                  | 23.5   |
|                                              | Alpha-BHC          | 86.8           | 100  | 112           | 99.3 | 116  | 14.4  |     |                  | 15.1   |
|                                              | Beta-BHC           | 99.8           | 115  | 123           | 115  | 110  | 14.2  |     |                  | 4.59   |
|                                              | DDD-p,p'           | 110            | 115  | 106           | 97.4 | 118  | 3.71  |     |                  | 19.5   |
|                                              | DDE-p,p'           | 105            | 110  | 102           | 91.2 | 111  | 4.50  |     |                  | 19.1   |
|                                              | DDT-p,p'           | 129            | 128  | 143           | 99.3 | 184  | 0.693 |     |                  | 59.8   |
|                                              | Delta-BHC          | 111            | 116  | 109           | 96.5 | 112  | 3.97  |     |                  | 14.7   |
|                                              | Dieldrin           | 106            | 102  | 99.0          | 90.8 | 114  | 4.12  |     |                  | 19.0   |
|                                              | Endosulfan I       | 89.5           | 86.7 | 113           | 94.4 | 135  | 3.16  |     |                  | 35.3   |
|                                              | Endosulfan II      | 111            | 106  | 108           | 96.8 | 117  | 4.82  |     |                  | 19.1   |
|                                              | Endosulfan Sulfate | 129            | 128  | 105           | 95.7 | 118  | 1.26  |     |                  | 20.7   |
|                                              | Endrin             | 129            | 125  | 122           | 106  | 135  | 3.23  |     |                  | 23.9   |
|                                              | Endrin Aldehyde    | 94.7           | 101  | 97.2          | 80.2 | 102  | 6.57  |     |                  | 23.5   |
|                                              | Gamma-BHC          | 94.5           | 104  | 108           | 93.1 | 112  | 9.11  |     |                  | 18.2   |
|                                              | Heptachlor         | 114            | 128  | 119           | 110  | 116  | 12.0  |     |                  | 4.75   |
|                                              | Heptachlor Epoxide | 111            | 118  | 113           | 99.1 | 127  | 6.41  |     |                  | 24.5   |
|                                              | Methoxychlor       | 121            | 130  | 110           | 105  | 124  | 7.61  |     |                  | 16.6   |
| EPA 180.1 Rev. 2.0                           | Turbidity          |                |      |               |      |      |       |     | 2.72             |        |
|                                              | Turbidity          |                |      |               |      |      |       |     | 1.43             |        |
| EPA 200.7 Rev. 4.4                           | Calcium            | 109            |      | 106           | 108  | 106  |       |     |                  | 1.01   |
|                                              | Iron               | 105            |      | 105           | 106  | 104  |       |     |                  | 0.466  |
|                                              | Magnesium          | 112            |      | 109           | 110  | 106  |       |     |                  | 0.997  |
|                                              | Potassium          | 103            |      | 101           | 101  | 98.7 |       |     |                  | 0.0699 |
|                                              | Sodium             | 108            |      | 100           | 99.5 | 98.1 |       |     |                  | 0.320  |
|                                              | Zinc               | 101            |      | 101           | 101  | 101  |       |     |                  | 0.194  |
| EPA 200.8 Rev. 5.4                           | Arsenic            | 100            |      | 96.4          | 99.0 | 102  |       |     |                  | 2.62   |
|                                              | Cadmium            | 98.3           |      | 98.5          | 97.8 | 101  |       |     |                  | 0.737  |
|                                              | Chromium           | 100            |      | 119           | 99.6 | 100  |       |     |                  | 17.7   |
|                                              | Copper             | 99.6           |      | 96.1          | 97.1 | 97.3 |       |     |                  | 1.08   |
|                                              | Lead               | 100            |      | 98.8          | 99.7 | 101  |       |     |                  | 0.966  |
|                                              | Nickel             | 102            |      | 98.2          | 99.0 | 99.3 |       |     |                  | 0.824  |
|                                              | Silver             | 96.3           |      | 95.5          | 96.1 | 94.7 |       |     |                  | 0.613  |
|                                              | Chloride           | 95.2           |      | 92.6          | 97.9 |      |       |     | 0.0388           |        |
| EPA 300.0 Rev. 2.1                           | Sulfate            | 93.3           |      | 91.5          | 94.9 |      |       |     | 0.0984           |        |
|                                              | Ammonia-N          | 97.2           |      | 101           | 101  |      |       |     |                  | 0.157  |
| EPA 350.1 Rev. 2.0                           | Ammonia-N          | 98.9           |      |               |      |      |       |     |                  | 0.507  |
|                                              | Kjeldahl Nitrogen  | 103            |      | 105           | 102  |      |       |     |                  | 1.47   |
| EPA 351.2 Rev. 2.0                           | Kjeldahl Nitrogen  | 98.8           |      | 95.5          | 98.2 |      |       |     |                  | 2.38   |

## Quality Assurance Report Summary

| Ref. Method                  | Analyte             | LCS % Recovery |      | MS % Recovery |      | LCS   | Precision | MS     |
|------------------------------|---------------------|----------------|------|---------------|------|-------|-----------|--------|
|                              |                     |                |      |               |      |       | SMP       |        |
| EPA 353.2 Rev. 2.0           | NO2NO3-N            | 104            |      | 101           | 103  |       |           | 2.36   |
|                              | NO2NO3-N            | 100            |      | 100           | 102  |       |           | 1.48   |
| EPA 365.1 Rev. 2.0           | Total-P             | 97.2           |      | 95.9          | 96.7 |       |           | 0.851  |
|                              | Total-P             | 93.7           |      | 92.4          | 88.0 |       |           | 4.70   |
|                              | Total-P             | 100            |      | 99.3          | 102  |       |           | 2.24   |
| EPA 365.1 Rev. 2.0 dissolved | O-Phosphate-P       | 101            |      | 100           | 102  |       |           | 1.39   |
|                              | O-Phosphate-P       | 105            |      | 99.7          | 100  |       |           | 0.600  |
|                              | O-Phosphate-P       | 104            |      | 100           | 100  |       |           | 0.142  |
| EPA 8270D                    | Acetochlor          | 101            | 89.8 | 90.9          | 96.5 | 12.0  |           | 5.94   |
|                              | Alachlor            | 101            | 91.1 | 89.5          | 99.8 | 10.6  |           | 10.9   |
|                              | Ametryn             | 108            | 104  |               |      | 3.40  |           | 3.37   |
|                              | Atrazine            | 104            | 93.5 |               |      | 10.8  |           | 8.90   |
|                              | Atrazine Desethyl   | 73.6           | 58.4 | 46.5          | 46.1 | 23.1  |           | 0.450  |
|                              | Azinphos Methyl     | 144            | 126  | 131           | 130  | 13.5  |           | 1.17   |
|                              | Bromacil            | 73.8           | 62.1 | 87.1          | 85.2 | 17.1  |           | 2.28   |
|                              | Butylate            | 57.9           | 55.8 | 42.1          | 36.8 | 3.76  |           | 13.3   |
|                              | Chlorpyrifos Ethyl  | 92.0           | 83.1 | 78.4          | 92.8 | 10.2  |           | 16.8   |
|                              | Chlorpyrifos Methyl | 86.9           | 77.6 | 78.6          | 81.6 | 11.3  |           | 3.75   |
|                              | Cyanazine           | 214            | 183  | 163           | 172  | 15.5  |           | 5.75   |
|                              | Demeton             | 69.0           | 63.1 | 63.0          | 72.1 | 8.95  |           | 13.4   |
|                              | Diazinon            | 96.7           | 90.9 | 88.4          | 90.5 | 6.14  |           | 2.29   |
|                              | Disulfoton          | 95.0           | 78.9 | 83.7          | 79.5 | 18.5  |           | 5.15   |
|                              | EPTC                | 55.5           | 55.1 | 37.5          | 30.8 | 0.745 |           | 19.6   |
|                              | Ethion              | 95.8           | 87.7 | 100           | 104  | 8.85  |           | 3.40   |
|                              | Ethoprop            | 82.1           | 75.9 | 71.4          | 74.7 | 7.78  |           | 4.57   |
|                              | Fenamiphos          | 104            | 95.8 | 93.7          | 95.3 | 8.16  |           | 1.64   |
|                              | Fipronil            | 86.6           | 77.4 | 80.4          | 81.5 | 11.1  |           | 1.43   |
|                              | Fipronil Sulfide    | 75.6           | 69.2 | 73.0          | 73.1 | 8.96  |           | 0.0541 |
|                              | Fipronil Sulfone    | 72.1           | 66.9 | 66.2          | 65.8 | 7.52  |           | 0.664  |
|                              | Fonofos             | 83.0           | 76.3 | 75.5          | 77.2 | 8.34  |           | 2.24   |
|                              | Hexazinone          | 105            | 90.1 | 98.4          | 101  | 14.9  |           | 2.32   |
|                              | Malathion           | 104            | 85.9 | 95.2          | 99.5 | 19.0  |           | 4.51   |
|                              | Metalaxyl           | 93.0           | 85.1 | 82.5          | 89.8 | 8.93  |           | 8.22   |
|                              | Metolachlor         | 100            | 89.8 | 90.4          | 98.1 | 11.3  |           | 7.81   |
|                              | Metribuzin          | 109            | 91.7 |               |      | 17.3  |           | 5.95   |
|                              | Mevinphos           | 73.8           | 71.1 | 61.7          | 63.8 | 3.74  |           | 3.38   |
|                              | Molinate            | 66.4           | 64.3 | 47.1          | 43.9 | 3.12  |           | 6.95   |
|                              | Norflurazon         | 90.3           | 84.4 | 74.9          | 77.2 | 6.79  |           | 2.94   |
|                              | Parathion Ethyl     | 94.5           | 89.2 | 88.4          | 89.2 | 5.79  |           | 0.848  |
|                              | Parathion Methyl    | 103            | 98.3 | 104           | 99.9 | 4.88  |           | 4.45   |
|                              | Pendimethalin       | 81.0           | 75.8 | 80.2          | 81.4 | 6.60  |           | 1.56   |
|                              | Phorate             | 83.3           | 80.4 | 64.4          | 72.3 | 3.57  |           | 11.5   |
|                              | Prometon            | 96.3           | 87.2 | 101           | 91.6 | 9.89  |           | 9.59   |
|                              | Prometryn           | 99.2           | 85.5 | 90.5          | 95.9 | 14.8  |           | 5.32   |
|                              | Simazine            | 101            | 94.3 | 106           | 104  | 6.96  |           | 2.21   |
|                              | Terbufos            | 87.8           | 78.0 | 74.3          | 78.2 | 11.7  |           | 5.14   |
|                              | Terbutylazine       | 96.2           | 84.8 | 87.5          | 94.6 | 12.6  |           | 7.73   |
| SM 2120 B                    | Color (true)        |                |      |               |      |       | 1.99      |        |
| SM 2320 B-97                 | Total Alkalinity    | 101            |      |               |      |       | 0.380     |        |
|                              | Total Alkalinity    | 100            |      |               |      |       | 0.435     |        |
| SM 2540 C-97                 | TDS                 |                |      |               |      |       | 5.52      |        |
| SM 2540 D-97                 | TSS                 |                |      |               |      |       | 7.41      |        |
| SM 4500 F-C-97               | Fluoride            | 98.3           |      | 97.9          | 98.6 |       |           | 0.509  |
|                              | Fluoride            | 98.8           |      | 97.4          | 97.9 |       |           | 0.492  |

## Quality Assurance Report Summary

| Ref. Method    | Analyte        | LCS % Recovery |      | MS % Recovery |      | Precision |        |
|----------------|----------------|----------------|------|---------------|------|-----------|--------|
|                |                |                |      |               |      | LCS       | MS     |
| SM 5310 B-00   | Organic Carbon | 100            |      | 95.7          | 95.7 |           | 0.0357 |
| USGS O-2060-01 | 2,4,5-T        | 102            | 89.6 | 107           | 106  | 12.6      | 0.375  |
|                | 2,4-D          | 107            | 108  | 154           | 154  | 1.11      | 0.519  |
|                | 2,4-DB         | 81.6           | 74.4 | 71.2          | 72.0 | 9.23      | 1.12   |
|                | Acetaminophen  | 43.6           | 18.1 | 70.8          | 71.2 | 82.6      | 0.563  |
|                | Acifluorfen    | 98.8           | 105  | 93.6          | 93.6 | 6.27      | 0.0    |
|                | Bentazon       | 86.4           | 85.2 |               |      | 1.40      | 7.69   |
|                | Carbamazepine  | 138            | 136  | 101           | 96.4 | 1.75      | 4.46   |
|                | Dichlorprop    | 106            | 99.6 | 136           | 139  | 5.85      | 2.04   |
|                | Dinoseb        | 102            | 102  | 105           | 101  | 0.0       | 3.88   |
|                | Diuron         | 112            | 131  | 67.2          | 64.4 | 16.1      | 4.26   |
|                | Fenuron        | 114            | 120  | 62.8          | 61.2 | 5.48      | 2.58   |
|                | Fluridone      | 108            | 105  | 85.5          | 84.3 | 3.01      | 1.40   |
|                | Imidacloprid   | 129            | 125  | 232           | 222  | 2.83      | 4.59   |
|                | Linuron        | 110            | 112  | 86.8          | 81.2 | 1.08      | 6.67   |
|                | MCPA           | 98.0           | 95.2 | 116           | 118  | 2.90      | 1.71   |
|                | MCPP           | 105            | 96.4 | 124           | 122  | 8.73      | 1.95   |
|                | Primidone      | 120            | 117  | 106           | 103  | 2.03      | 3.05   |
|                | Silvex         | 116            | 114  | 146           | 139  | 1.73      | 5.06   |

## Reference Method Descriptions

| Method / DoH Cert #                                      | Description                                                                                                               | Associated Samples                                   |
|----------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------|
| DEP SOP: GC-011-5<br>(based on EPA 608 and 617) / E31780 | Organochlorine pesticides (low levels) in water matrices by GC/ECD.                                                       | 1792868, 1792869                                     |
| EPA 180.1 Rev. 2.0 / E31780                              | Turbidity in aqueous matrices                                                                                             | 1792836, 1792837, 1792838, 1792839, 1792840, 1792851 |
| EPA 200.7 Rev. 4.4 / E31780                              | Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects | 1792862, 1792863, 1792864, 1792865, 1792866, 1792867 |
| EPA 200.8 Rev. 5.4 / E31780                              | Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects                    | 1792862, 1792863, 1792864, 1792865, 1792866, 1792867 |
| EPA 300.0 Rev. 2.1 / E31780                              | Chloride in aqueous matrices                                                                                              | 1792836, 1792837, 1792838, 1792839, 1792840          |
| EPA 300.0 Rev. 2.1 / E31780                              | Sulfate in aqueous matrices                                                                                               | 1792836, 1792837, 1792838, 1792839, 1792840, 1792851 |
| EPA 350.1 Rev. 2.0 / E31780                              | Ammonia in aqueous matrices as mg N/L                                                                                     | 1792841, 1792842, 1792843, 1792844, 1792845, 1792852 |
| EPA 351.2 Rev. 2.0 / E31780                              | Total Kjeldahl Nitrogen in aqueous matrices                                                                               | 1792841, 1792842, 1792843, 1792844, 1792845, 1792852 |
| EPA 353.2 Rev. 2.0 / E31780                              | Nitrite/Nitrate in aqueous matrices as mg N/L                                                                             | 1792841, 1792842, 1792843, 1792844, 1792845, 1792852 |
| EPA 365.1 Rev. 2.0 / E31780                              | Total Phosphorus in aqueous matrices as mg P/L                                                                            | 1792841, 1792842, 1792843, 1792844, 1792845, 1792852 |
| EPA 365.1 Rev. 2.0 dissolved / E31780                    | Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L                                                       | 1792846, 1792847, 1792848, 1792849, 1792850, 1792853 |
| EPA 8270D / E31780                                       | Organonitrogen and phosphorus pesticides (ultra trace level) in water matrices by GC/MS/MS                                | 1792870, 1792871                                     |
| SM 2120 B / E31780                                       | True Color measured at 450 nm                                                                                             | 1792836, 1792837, 1792838, 1792839, 1792840          |
| SM 2320 B-97 / E31780                                    | Alkalinity in aqueous matrices as mg CaCO3/L                                                                              | 1792836, 1792837, 1792838, 1792839, 1792840, 1792851 |
| SM 2540 C-97 / E31780                                    | Total Dissolved Solids in aqueous matrices                                                                                | 1792836, 1792837, 1792838, 1792839, 1792840          |
| SM 2540 D-97 / E31780                                    | Total Suspended Solids in aqueous matrices                                                                                | 1792836, 1792837, 1792838, 1792839, 1792840, 1792851 |

## Reference Method Descriptions

| Method / DoH Cert #     | Description                                                                         | Associated Samples                                   |
|-------------------------|-------------------------------------------------------------------------------------|------------------------------------------------------|
| SM 4500 F-C-97 / E31780 | Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring) | 1792836, 1792837, 1792838, 1792839, 1792840, 1792851 |
| SM 5310 B-00 / E31780   | Nonpurgeable Organic Carbon in aqueous matrices                                     | 1792841, 1792842, 1792843, 1792844, 1792845, 1792852 |
| USGS O-2060-01 / E31780 | Chlorinated (phenoxy acid) herbicides in water matrices by HPLC/MS/MS               | 1792860, 1792861                                     |
| USGS O-2060-01 / E31780 | Urea herbicides and other chemicals in water matrices by HPLC/MS/MS                 | 1792860, 1792861                                     |

## Preparation and Analysis Log

| Ref. Method                                  | Received Date | Prep Date/Time | Prepared By         | Analysis Date/Time | Analyzed By         | Associated Samples                                   |
|----------------------------------------------|---------------|----------------|---------------------|--------------------|---------------------|------------------------------------------------------|
| DEP SOP: GC-011-5 (based on EPA 608 and 617) | 04/26/2016    | 04/27/2016     | Fe-Val Siddell      | 05/03/2016         | Vandana T. Nagar    | 1792868, 1792869                                     |
| EPA 180.1 Rev. 2.0                           | 04/26/2016    |                |                     | 04/26/2016 16:05   | Blanca Fach         | 1792836, 1792837, 1792838, 1792839, 1792840, 1792851 |
| EPA 200.7 Rev. 4.4                           | 04/26/2016    | 04/28/2016     | Elliott D. Healy    | 05/02/2016         | Joshua Ayres        | 1792862, 1792863, 1792864, 1792865, 1792866, 1792867 |
| EPA 200.8 Rev. 5.4                           | 04/26/2016    | 04/28/2016     | Elliott D. Healy    | 05/02/2016         | Charles J. Peterson | 1792862, 1792863, 1792864, 1792865, 1792866, 1792867 |
| EPA 300.0 Rev. 2.1                           | 04/26/2016    |                |                     | 05/03/2016         | Elisa J Lutz        | 1792836, 1792837, 1792838, 1792839, 1792840, 1792851 |
| EPA 350.1 Rev. 2.0                           | 04/26/2016    |                |                     | 05/05/2016         | Diana M. Turner     | 1792841, 1792842, 1792843, 1792844, 1792845, 1792852 |
| EPA 351.2 Rev. 2.0                           | 04/26/2016    | 05/10/2016     | Sofia Elnemr        | 05/11/2016         | Christopher Armour  | 1792841, 1792842, 1792843, 1792844, 1792845          |
|                                              | 04/26/2016    | 05/12/2016     | Christopher Armour  | 05/15/2016         | Virginia P. Brown   | 1792852                                              |
| EPA 353.2 Rev. 2.0                           | 04/26/2016    |                |                     | 05/05/2016         | Peter D. Kaus       | 1792852                                              |
|                                              | 04/26/2016    |                |                     | 05/06/2016         | Virginia P. Brown   | 1792841, 1792842, 1792843, 1792844, 1792845          |
| EPA 365.1 Rev. 2.0                           | 04/26/2016    | 05/09/2016     | Vijayalakshmi Reddy | 05/10/2016         | Lipi Saha           | 1792844, 1792845, 1792852                            |
|                                              | 04/26/2016    | 05/11/2016     | Vijayalakshmi Reddy | 05/12/2016         | Rochelle Y Jackson  | 1792841, 1792842, 1792843                            |
| EPA 365.1 Rev. 2.0 dissolved                 | 04/26/2016    |                |                     | 04/26/2016 14:59   | Julia Storbeck      | 1792848                                              |
|                                              | 04/26/2016    |                |                     | 04/26/2016 15:08   | Julia Storbeck      | 1792853                                              |
|                                              | 04/26/2016    |                |                     | 04/26/2016 15:45   | Julia Storbeck      | 1792846, 1792847                                     |
|                                              | 04/26/2016    |                |                     | 04/26/2016 15:46   | Julia Storbeck      | 1792849                                              |
|                                              | 04/26/2016    |                |                     | 04/26/2016 15:47   | Julia Storbeck      | 1792850                                              |
| EPA 8270D                                    | 04/26/2016    | 04/29/2016     | John Kaba           | 05/04/2016         | Irina Carbone       | 1792870, 1792871                                     |
|                                              | 04/26/2016    | 04/29/2016     | John Kaba           | 05/09/2016         | Irina Carbone       | 1792870, 1792871                                     |
| SM 2120 B                                    | 04/26/2016    |                |                     | 04/26/2016 16:53   | Chrisoulla Rakowski | 1792836                                              |
|                                              | 04/26/2016    |                |                     | 04/26/2016 16:54   | Chrisoulla Rakowski | 1792837                                              |
|                                              | 04/26/2016    |                |                     | 04/26/2016 16:55   | Chrisoulla Rakowski | 1792838, 1792839                                     |
|                                              | 04/26/2016    |                |                     | 04/26/2016 16:56   | Chrisoulla Rakowski | 1792840                                              |
| SM 2320 B-97                                 | 04/26/2016    |                |                     | 05/03/2016         | Dale L. Simmons     | 1792836, 1792837, 1792838, 1792839, 1792840, 1792851 |
| SM 2540 C-97                                 | 04/26/2016    |                |                     | 04/27/2016         | Yijie Li            | 1792836, 1792837, 1792838, 1792839, 1792840          |
| SM 2540 D-97                                 | 04/26/2016    |                |                     | 04/27/2016         | Yijie Li            | 1792836, 1792837, 1792838, 1792839, 1792840, 1792851 |
| SM 4500 F-C-97                               | 04/26/2016    |                |                     | 04/30/2016         | Dale L. Simmons     | 1792836, 1792837, 1792838, 1792839, 1792840, 1792851 |
| SM 5310 B-00                                 | 04/26/2016    |                |                     | 05/13/2016         | Diana M. Turner     | 1792841, 1792842, 1792843, 1792844, 1792845, 1792852 |
| USGS O-2060-01                               | 04/26/2016    | 04/28/2016     | Hoor Shaik          | 04/30/2016         | Juyoung Kim         | 1792860, 1792861                                     |
|                                              | 04/26/2016    | 04/28/2016     | Hoor Shaik          | 05/01/2016         | Juyoung Kim         | 1792860, 1792861                                     |