

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
Central Lab Sample Submittal Form

Request Number: RQ-2017-04-17-20

Page ____ of ____

SMP Requester: Curtis Musson

Field Report Prepared By: Diana Turner

Customer: WQ-ASSESS

Sampling Agency: FDEP

Project ID: SMP

Collected By: Ben Balys, Robert Wiwi, Diana Turner

Location	☐ Comp ☒ Grab	Collection (comp begin or grab) Date Time	☒ Eastern ☐ Central	Collection (comp begin or grab) Date Time	Bottle Group(s)
Field ID →  Black Creek upstream of Bloxham Cu off April 19, 2017 Black Creek upstream of Bloxham Cutoff STORET ↓  G1WA0023		Date 9:45 AM Time 4/19/17 Matrix (Salt, Fresh) <u>Fresh</u> Temp (C) <u>19.48</u> Salinity (ppt) Latitude (Decimal Degrees) <u>30.27792</u>	Eastern Central	Date Time Diss. Oxygen (mg/L) <u>7.13</u> pH <u>4.40</u> Sample Depts (m) <u>0.2</u> Sp. Conductance (umho/cm) <u>42</u> Comments Longitude (Decimal Degrees) <u>-84.3858</u>	<u>A3</u>
Field ID →  Big Branch 50 meters upstream of CR 67 April 19, 2017 Big Branch 50 meters upstream of CR 67 STORET ↓  G1WA0001		Date 4/19/17 Time 11:40 AM Matrix (Salt, Fresh) <u>Fresh</u> Temp (C) <u>18.50</u> Salinity (ppt) Latitude (Decimal Degrees) <u>30.3110</u>	Eastern Central	Date Time Diss. Oxygen (mg/L) <u>8.41</u> pH <u>6.34</u> Sample Depts (m) <u>0.15</u> Sp. Conductance (umho/cm) <u>44</u> Comments Longitude (Decimal Degrees) <u>-84.7651</u>	<u>A3</u>
Location Field ID STORET #	☐ Comp ☐ Grab	Collection (comp begin or grab) Date Time Matrix (Salt, Fresh) Temp (C) Salinity (ppt) Latitude (Decimal Degrees)	☐ Eastern ☐ Central	Collection (comp begin or grab) Date Time Diss. Oxygen (mg/L) pH Sample Depts (m) Sp. Conductance (umho/cm) Comments Longitude (Decimal Degrees)	Bottle Group(s)

Relinquished By:

Diana Turner

Date/Time

4/19/17 1:05 pm

Number of Coolers

1

Received By:

[Signature]

Date/Time

4-19-17 1:05

Group: A	Bottle Type:	P-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2
	ALKALINITY						
	TURBIDITY						
	W-CL-IC						
	W-COLOR						
	W-F						
	W-SO4-IC						
	W-TDS						
	W-TSS						
Group: A	Bottle Type:	BP-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2
	CHLSUITE-W						
Group: A	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	2
	W-NH3						
	W-NO2NO3						
	W-S-A-TP						
	W-TKN						
	W-TOC						
Group: A	Bottle Type:	P-125ML	# of Bottles: 2	Preservative:	ICE-FLTR	Enter Number of Bottles Sent to Lab	2
	W-PO4-F						
Group: B	Bottle Type:	PJ-2L	# of Bottles: 4	Preservative:	Formalin	Enter Number of Bottles Sent to Lab	2
	MI-FW-QLDC						

Date of Request: 20-MAR-2017
 Created By: MUSSON_C On: 20-MAR-2017
 Modified By: MATTHEWS_D On: 03-APR-2017
 Customer: WQ-ASSESS
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District:
 Sampling Event: Black Creek, Soapstone

Send Coolers To:

Phone: 850-245-8453
 Division Of Water Facilities, FL DEP
 2600 Blair Stone Rd.
 Tallahassee, FL 32399-2400
 Attn: curtis musson

Program Module Number:
 Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 27-MAR-2017
 Biology Request Reviewed By: MATTHEWS_D On: 03-APR-2017
 Sampling Kit Required: YES Ship on: 13-APR-2017
 Sampling Kit Shipped: YES On: 13-APR-2017
 Sampling Kit Packed By: REYNOLDS_T
 Preservatives Needed: YES
 Date to Receive Samples: 19-APR-2017
 Received By:

Send Final Report To:

Division Of Water Facilities, FL DEP
 2600 Blair Stone Rd.
 Tallahassee, FL 32399-2400
 Attn: curtis musson

Report Type: Final Only
 FTP Data: NO
 QC Report: YES
 Date Log: NO
 Authorization Log: NO

Comments: Group A: Freshwater Nutrient Kit
 Group B: SCI

 2 - case of sulfuric acid

 No FedEx Shippers Needed

Bottle Group A (Water) With 2 Samples:

Bottle Type: P-1L	Number of Bottles: 2	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices
Bottle Type: BP-1L	Number of Bottles: 2	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, phaeophytin and ratio by spectrophotometry
Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 2	Preserved With: ICE-FLTR
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Biological) With 2 Samples:

Bottle Type: PJ-2L Number of Bottles: 4 Preserved With: Formalin

Bottle Group B (Biological) With 2 Samples:

Bottle Type: PJ-2L Number of Bottles: 4 Preserved With: Formalin
MI-FW-QLDC Template: DEFAULT (SOP-IZ06) No. Taxa of FW macroinverts, qual samp, 20 dipnets.

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.

Log-in Checklist

RQ- 2017-04-17-20

Shipping Method: 17D

Date/Time of Receipt: 4-19-17/1:05

Cooler ID	Cooler Temperature*	No. Sample Containers in Cooler	Evidence Tape		Tracking # (fill out only if waybill copy is damaged)	
			Present? Yes	*Intact? No	Yes	No
<u>Blue</u>	<u>2.3</u>	<u>10</u>		☒		

*If the temperature of a cooler is above 6.0 °C (or above 10.0 °C for W-1-4-DIOX), or if Evidence Seal is damaged, identify the containers in the affected cooler(s) on back of this form.

**Note: If "No" is checked in any of the fields below, fill out the back of this form with additional details (Field ID, Test IDs, etc.) and generate an NCR.

**Chain of Custody/ Field Sheet(s) Included? Yes ☒ No ☐

CONTAINER CHECK

**Evidence Tape on Bottles? Yes ☒ No ☒ If yes, is it intact? Yes ☒ No ☐

**Caps on tight? Yes ☒ No ☐ **Containers intact? Yes ☒ No ☐

**Sufficient Sample Volume: Yes ☒ No ☐

CHLORINE CHECK (Blue dot on container)

Check the Box marked "Yes" or "No" for the Presence of Chlorine. If Cl detected, an NCR is required.					
Analysis	Yes	No	Analysis	Yes	No
W-1,4 DIOX			W-PC-AA-SF		
W-AHERB-AA (-AHB-AA-R)			W-PCL-SQ (-R)		
W-BNA (-625, -R)			W-PDQUAT		
W-CARB-AA (-CAB-AA-R)			W-PESTNP-R		
W-ENDO-AA			W-PSCL-TQ		
W-GLYPH			W-PSNP-TQ		
W-NP-AA-SF			W-PST-CL-R		
W-PAH (-R)			W-TR-TQ		
W-PCB-R			W-CT-CI-R		

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH ≤ 2.0? Yes ☒ No ☐ NA ☐ Init: SR

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes ☐ No ☒ NA ☒ Init: SR

Coolers Unpacked/Checked by: SR Date: 4-19-17

NCRs (Y/N)? N

Event ID: WQ-ASSESS-2017-04-19-01

NCR #

Log-in Checklist

Samples with Incorrect pH Preservation or presence of Chlorine

Field ID	Bottle Test ID(s)	pH / Cl	Action Taken

Samples in Coolers with Incorrect Preservation or Damaged Evidence Tape

Cooler ID	Field ID	Bottle Test ID(s)

Bottles Not Intact

Field ID	Bottle Test ID(s)	Loose Cap	Damaged Cap		Damaged Container		Evidence Tape Not Intact
			CK	BR	CK	BR	

Samples with Insufficient Volume for Analyses

Field ID	Bottle Test ID(s)	Action Taken

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ No ✓

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF; W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Additional Comments: