

Log-in Checklist

RQ- 2019-08-05-43

Login Station ID: #5

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 8/ 8 /19 @ 10:00

Cooler Temperature*	Samples Frozen	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Tracking # Damaged waybills only
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
2.9				9		✓			4751 8781 5548

* HNO₃ and Formalin persevered samples do **NOT** have a temperature requirement. For all others, if the temperature of a cooler is above 6.0 °C (or above 10.0 °C for W-1-4-DIOX and microbiology), or if Evidence Seal is damaged. Identify the containers in the affected cooler(s) on back of this form. **DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C) without login confirmation from customer for samples requiring ice preservation. An NCR still is required.**

**Chain of Custody/ Field Sheet(s) Included? Yes ☒ No ☐

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes ☒ No ☐

****Note:** If "No" is checked below, fill out the back of this form (Field ID, Test IDs, etc.) and generate an NCR.

CONTAINER CHECK

**Evidence Tape on Bottles? Yes ☐ No ☒ If yes, is it intact? Yes ☐ No ☐
 **Caps on tight? Yes ☒ No ☐ **Containers intact? Yes ☒ No ☐
 **Sufficient Sample Volume: Yes ☒ No ☐

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ☒ No ☐ Init: KK
 Chlorine detected? (One container checked per Field ID) Yes ☐ No ☒ Init: KK

If "YES", list affected Field IDs and Test IDs below.

Field ID	List TestID(s) where Chlorine was Detected, an NCR is required.

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH ≤ 2.0? Yes ☒ No ☐ NA ☐ Init: KK
 **W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes ☐ No ☐ NA ☒ Init: KK
 Coolers Unpacked/Checked by: KK Date: 8/ 8 /19 NCRs (Y/N)? N

Event ID: SCI Nassau and Bigfish
NE-DIST-2019-08-08-02 (SMP) NCR #
 Date Received: 08-AUG-2019 10:00

Log-in Checklist

Samples with Incorrect pH Preservation

Field ID	Bottle Test ID(s)	pH	Action Taken

Samples in Coolers with Incorrect Preservation or Damaged Evidence Tape

Cooler ID	Field ID	Bottle Test ID(s)

Bottles Not Intact

Field ID	Bottle Test ID(s)	Loose Cap	Damaged Cap		Damaged Container		Evidence Tape Not Intact
			CK	BR	CK	BR	

Samples with Insufficient Volume for Analyses

Field ID	Bottle Test ID(s)	Action Taken

Additional Comments:

Infrared Thermometer ID:	REC_07_2018 EXP:12/28/19
pH Test Strips 0 – 6 Lot #	
pH Paper 0 – 3 Lot #	220416A EXP:7/30/20
pH Paper 0 – 13 Lot #	222516 EXP:9/15/19
Chlorine Test Strips Lot #	091417V EXP:9/2021

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes_____ No_____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes_____If No_____

no, were samples shipped on dry ice? Yes_____No_____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF; W-HG-AF-F):

Samples preserved within 48 hours? Yes_____ No_____

Date and time samples preserved: _____

SCI Nassau and Bigfish

Central Laboratory Submittal Form

last revised Jan 25, 2018

Customer: NE-DIST

Requester: Jeremy M. Parrish

Field Report Prepared By:

Project ID: SMP

Collected By:

Sampling Agency:

Location	WIN ID/Field ID:  G4NE0288	Matrix (type, e.g., Salt, Fresh, etc) <u>Fresh</u>	Collection (comp begin or grab) ☒ Comp ☒ Grab Date <u>8/7/19</u> Time <u>955</u>	Eastern Central	Composite end Date Time	Bottle Group(s) (See pg 2) <u>A</u>
Field ID	WIN/S	Temp (C) <u>25.7</u>	pH <u>6.71</u>	Diss. Oxygen <u>3.5</u>	☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L)
Latitude ☐ dd ☐ dms	Longitude ☐ dd ☐ dms	Salinity (ppt) <u>0.1</u>	Comments	Sample Depth <u>0.3</u>	☐ ft ☒ m	Sp. Conductance (umho/cm) <u>204</u>
Location	Field ID	WIN/STORET #	Temp (C)	pH	Sample Depth	Sp. Conductance (umho/cm)
Latitude ☐ dd ☐ dms	Longitude ☐ dd ☐ dms	Salinity (ppt)	Comments			
Location	Field ID	WIN/STORET #	Temp (C)	pH	Sample Depth	Sp. Conductance (umho/cm)
Latitude ☐ dd ☐ dms	Longitude ☐ dd ☐ dms	Salinity (ppt)	Comments			
Location	Field ID	WIN/STORET #	Temp (C)	pH	Sample Depth	Sp. Conductance (umho/cm)
Latitude ☐ dd ☐ dms	Longitude ☐ dd ☐ dms	Salinity (ppt)	Comments			
Location	Field ID	WIN/STORET #	Temp (C)	pH	Sample Depth	Sp. Conductance (umho/cm)
Latitude ☐ dd ☐ dms	Longitude ☐ dd ☐ dms	Salinity (ppt)	Comments			

Relinquished By: <u>Jeremy Parrish</u>	Date/Time <u>8/7/19</u>	Shipping Method <u>Fedex 1500</u>	Number of Coolers Shipped: <u>1</u>	Received By: <u>KK</u>	Date/Time <u>8-8-19 / 10:00</u>
---	----------------------------	--------------------------------------	--	---------------------------	------------------------------------

Group: A	Bottle Type:	P-1L	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	ALKALINITY TURBIDITY W-CL-IC W-COLOR W-F W-SO4-IC W-TDS W-TSS						
Group: A	Bottle Type:	BP-1L	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	CHLSUITE-W						
Group: A	Bottle Type:	P-250ML-WI-THI	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab	0 1 to ALS
	NE-ALS-ECQ						
Group: A	Bottle Type:	BG-500ML	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	W-E8321-DI W-E8321-MS						
Group: A	Bottle Type:	P-500ML	# of Bottles: 3	Preservative:	HNO3	Enter Number of Bottles Sent to Lab	1
	W-ICP W-ICPMS						
Group: A	Bottle Type:	P-500ML	# of Bottles: 3	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	1
	W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC						
Group: A	Bottle Type:	P-125ML	# of Bottles: 3	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab	1
	W-PO4-F						
Group: A	Bottle Type:	BG-1L	# of Bottles: 8	Preservative:	ICE	Enter Number of Bottles Sent to Lab	3
	W-PSNP-TQ						
Group: B	Bottle Type:	PT-50ML	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab	0
	ALGAL_ID						
Group: B	Bottle Type:	PJ-2L	# of Bottles: 6	Preservative:	Formalin	Enter Number of Bottles Sent to Lab	0

Group: B

Bottle Type:
MI-FW-QLDC

PJ-2L

of Bottles: 6

Preservative: Formalin

Enter Number of Bottles Sent to Lab 0



CHAIN OF CUSTODY / LABORATORY ANALYSIS REQUEST FORM

9143 Philips Highway, Suite 200. Jacksonville, FL 32256
Phone (904) 739-2277 / 800-695-7222 x06 / FAX (904) 739-2011

www.alsglobal.com

SR #
ALS Contact

Page _____ of _____

Project Name SCI Nassau		Project Number 2019-08-05-43		ANALYSIS REQUESTED (Include Method Number and Container Preservative)																			
Report To		Report CC		Preservative																			
Company/Address FDEP		NUMBER OF CONTAINERS 40																		Preservative Key 0. None 1. HCL 2. HNO3 3. H2SO4 4. NaOH 5. Zn. Acetate 6. MeOH 7. NaHSO4 8. Other REMARKS			
8800 Baymeadows Way West																							
Phone # 904 256-1700 FAX # 322 56																							
Sampler's Signature Jerry Pansh		Sampler's Printed Name Jerry Pansh																					
CLIENT SAMPLE ID 64NE0288	LAB ID	SAMPLING DATE TIME		Matrix																			
		8/7/19	955	SW	1	X																	
Special Instructions/Comments:				TURNAROUND REQUIREMENTS RUSH (SURCHARGES APPLY) STANDARD REQUESTED FAX DATE REQUESTED REPORT DATE				REPORT REQUIREMENTS I. Results Only II. Results + QC Summaries (LCS, DUP, MS/MSD as required) III. Results + QC and Calibration Summaries IV. Data Validation Report with Raw Data Edata Yes No				INVOICE INFORMATION P.O. # Bill to:											
SAMPLE RECEIPT: CONDITION/COOLER TEMP: 32°C				CUSTODY SEALS: Y N																			
Relinquished By Signature Jerry Pansh		Received By Signature		Relinquished By Signature		Received By Signature		Relinquished By Signature		Received By Signature		Relinquished By Signature		Received By Signature									
Printed Name Jerry Pansh		Printed Name		Printed Name		Printed Name		Printed Name		Printed Name		Printed Name		Printed Name									
Firm FDEP		Firm		Firm		Firm		Firm		Firm		Firm		Firm									
Date/Time 8/7/19 1429		Date/Time		Date/Time		Date/Time		Date/Time		Date/Time		Date/Time		Date/Time 8/7/19 1429									

Chain of Custody

SMF-9

3/14/2016

Date of Request: 12-JUL-2019
 Created By: PARRISH_J On: 12-JUL-2019
 Modified By: JASROTIA_P On: 18-JUL-2019
 Customer: NE-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Northeast District
 Sampling Event: SCI Nassau and Bigfish

Send Coolers To:

Phone: 904-256-1700
 8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: Jeremy Parrish

Send Final Report To:

8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: Jeremy Parrish

Program Module Number:

Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 18-JUL-2019
 Biology Request Reviewed By: JASROTIA_P On: 18-JUL-2019
 Sampling Kit Required: YES Ship on: 26-JUL-2019
 Sampling Kit Shipped: YES On: 24-JUL-2019
 Sampling Kit Packed By: REYNOLDS_T
 Preservatives Needed: NO
 Date to Receive Samples: 05-AUG-2019
 Received By:

Report Type: Final Only
 FTP Data: NO
 QC Report: YES
 Date Log: NO
 Authorization Log: NO

Comments: Group A: Nutrients, Metals, Tracers, Q-PSNP-TQ, Bacteria
 Group B: SCI, Algae_ID

NE-ALS-ECQ

Packing Notes:
 none

Bottle Group A (Water) With 3 Samples:

Bottle Type: P-1L	Number of Bottles: 3	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 3	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WI-THI	Number of Bottles: 3	Preserved With: ICE
NE-ALS-ECQ	Template: DEFAULT	(SM 9223 B Quanti-Tray) E. coli by Colilert/QT by ALS in Jacksonville
Bottle Type: BG-500ML	Number of Bottles: 3	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 3	Preserved With: HNO3
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Barium		

Bottle Group A (Water) With 3 Samples:

Bottle Type: P-500ML	Number of Bottles: 3	Preserved With: HNO3
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects

Calcium
Iron
Magnesium
Potassium
Sodium
Zinc

W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
---------	-----------	---

*Boron
Aluminum
Antimony
Arsenic
Cadmium
Chromium
Copper
Lead
Nickel
Selenium
Silver
Thallium

Bottle Type: P-500ML	Number of Bottles: 3	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Type: P-125ML	Number of Bottles: 3	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Type: BG-1L	Number of Bottles: 8	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS

Bottle Group B (Biological) With 3 Samples:

Bottle Type: PJ-2L	Number of Bottles: 6	Preserved With: Formalin
MI-FW-QLDC	Template: DEFAULT	(SOP-IZ06) No. Taxa of FW macroinverts, qual samp, 20 dipnets.

Bottle Type: PT-50ML	Number of Bottles: 3	Preserved With: ICE
ALGAL_ID	Template: DEFAULT	(SOP-AB05) Qualitative assessment of algal taxa present without counts

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.