

RQ-2019-05-06-53

Log-in Checklist

Login Station ID: #4

Shipping Method: FedEx UPS | HD | Greyhound

Date/Time of Receipt: 05/10/2019 @ 10:30

Cooler Temperature*	Samples Frozen YES	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Tracking # Damaged waybills only
		HNO ₃	Formalin		Present?		*Intact?		
					Yes	No	Yes	No	
0.2°C				12		X			4751 8779 0674

* HNO₃ and Formalin persevered samples do **NOT** have a temperature requirement. For all others, if the temperature of a cooler is above 6.0 °C (or above 10.0 °C for W-1-4-DIOX and microbiology), or if Evidence Seal is damaged. Identify the containers in the affected cooler(s) on back of this form. **DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C) without login confirmation from customer for samples requiring ice preservation. An NCR still is required.**

**Chain of Custody/ Field Sheet(s) Included? Yes ☒ No ☐Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes ☐ No ☒

****Note:** If "No" is checked below, fill out the back of this form (Field ID, Test IDs, etc.) and generate an NCR.

CONTAINER CHECK

Evidence Tape on Bottles? Yes ☐ No ☒ If yes, is it intact? Yes ☐ No ☐Caps on tight? Yes ☒ No ☐ **Containers intact? Yes ☒ No ☐**Sufficient Sample Volume: Yes ☒ No ☐

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ☐ No ☒ Init: TR

Chlorine detected? (One container checked per Field ID)

Yes ☐ No ☐ Init:

If "YES", list affected Field IDs and Test IDs below.

Field ID	List TestID(s) where Chlorine was Detected, an NCR is required.

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

Acid Preserved Samples: pH ≤ 2.0? Yes ☒ No ☐ NA ☐ Init: TRW-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes ☐ No ☐ NA ☒ Init: TR

Coolers Unpacked/Checked by: Tyler Reynolds Date: 05/10/2019

NCRs (Y/N)? N

Event ID: Lk Ann + LVI
CEN-DIST-2019-05-10-02 (SMP)
Date Received: 10-MAY-2019 10:30
Federal Express REF-4-3-3NCR #

Log-in Checklist

Samples with Incorrect pH Preservation

Field ID	Bottle TestID(s)	pH	Action Taken

Samples in Coolers with Incorrect Preservation or Damaged Evidence Tape

Cooler ID	Field ID	Bottle TestID(s)

Bottles Not Intact

Field ID	Bottle TestID(s)	Loose Cap	Damaged Cap		Damaged Container		Evidence Tape Not Intact
			CK	BR	CK	BR	

Samples with Insufficient Volume for Analyses

Field ID	Bottle TestID(s)	Action Taken

Additional Comments:

Infrared Thermometer ID:	REC_04_2018 EXP:04/29/2020
pH Test Strips 0 – 6 Lot #	213316AV EXP:05/15/2020
pH Paper 0 – 3 Lot #	
pH Paper 0 – 13 Lot #	215517 EXP: 06/01/2020
Chlorine Test Strips Lot #	8261 EXP: 07/30/2021

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes ☒ No ☒

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ If No _____

no, were samples shipped on dry ice? Yes _____ No _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Lk Ann + LVI

Central Laboratory Submittal Form

last revised Jan 25, 2018

Customer: CEN-DIST

Requester: Michael Linger

Field Report Prepared By:

Mike Linger

Project ID: SMP

Collected By:

Mike Linger / Lawrence Drannan

Sampling Agency:

FDEP

CE-Roc

Location WIN ID / Field ID → Lake Ann @ Center	 G2CE0097	☐ Comp ☒ Grab	Collection (comp begin or grab) Date 5/9/19 Time 956	Eastern Central	Composite end Date Time	Bottle Group(s) (See pg 2) A
Field ID		Matrix (type, e.g., Salt, Fresh, etc)	Diss. Oxygen 9.39	☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	
WIN/ST		Temp (C) 28.2	pH 7.43	Sample Depth 0.3	Sp. Conductance (umho/cm) 164.6	
Latitude ☐ dd ☐ dms	Longitude ☐ dd ☐ dms	Salinity (ppt) ☐ dd ☐ dms	Comments			
Location WIN ID / Field ID → Lake Ellen @ Center	 G2CE0060	☐ Comp ☒ Grab	Collection (comp begin or grab) Date 5/9/19 Time 1044	Eastern Central	Composite end Date Time	Bottle Group(s) A
Field ID		Matrix (type, e.g., Salt, Fresh, etc)	Diss. Oxygen 7.01	☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	
WIN/S		Temp (C) 28.5	pH 6.64	Sample Depth 0.3	Sp. Conductance (umho/cm) 111.2	
Latitude ☐ dd ☐ dms	Longitude ☐ dd ☐ dms	Salinity (ppt) ☐ dd ☐ dms	Comments			
Location WIN ID / Field ID → Lake Concord at Center	 G2CE0059	☐ Comp ☒ Grab	Collection (comp begin or grab) Date 5/9/19 Time 1105	Eastern Central	Composite end Date Time	Bottle Group(s) A
Field ID		Matrix (type, e.g., Salt, Fresh, etc)	Diss. Oxygen 8.60	☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	
WIN/S		Temp (C) 28.3	pH 8.05	Sample Depth 0.3	Sp. Conductance (umho/cm) 226.4	
Latitude ☐ dd ☐ dms	Longitude ☐ dd ☐ dms	Salinity (ppt) ☐ dd ☐ dms	Comments			
Location		☐ Comp ☐ Grab	Collection (comp begin or grab) Date Time	Eastern Central	Composite end Date Time	Bottle Group(s)
Field ID		Matrix (type, e.g., Salt, Fresh, etc)	Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	
WIN/STORET #		Temp (C)	pH	Sample Depth	Sp. Conductance (umho/cm)	
Latitude ☐ dd ☐ dms	Longitude ☐ dd ☐ dms	Salinity (ppt) ☐ dd ☐ dms	Comments			

Relinquished By: MKL	Date/Time 5/9/19 1600	Shipping Method FedEx	Number of Coolers Shipped: 1	Received By: Tyler Reynolds	Date/Time 05/10/19 @ 10:30
-------------------------	--------------------------	--------------------------	---------------------------------	--------------------------------	-------------------------------

★ Please add 2 additional Bottle Group As

MKL

Group: A	Bottle Type:	P-1L	# of Bottles: 13	Preservative:	ICE	Enter Number of Bottles Sent to Lab	3
	ALKALINITY						
	TURBIDITY						
	W-CL-IC						
	W-COLOR						
	W-F						
	W-SO4-IC						
	W-TDS						
	W-TSS						
Group: A	Bottle Type:	BP-1L	# of Bottles: 13	Preservative:	ICE	Enter Number of Bottles Sent to Lab	3
	CHLSUITE-W						
Group: A	Bottle Type:	P-500ML	# of Bottles: 13	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	3
	W-NH3						
	W-NO2NO3						
	W-S-A-TP						
	W-TKN						
	W-TOC						
Group: A	Bottle Type:	P-125ML	# of Bottles: 13	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab	3
	W-PO4-F						

★ Please add 2 additional Bottle Group As

MKL

Date of Request: 18-APR-2019
 Created By: LINGER_M On: 18-APR-2019
 Modified By: JASROTIA_P On: 19-APR-2019
 Customer: CEN-DIST
 Project: SMP
 Division:
 District: Central District
 Sampling Event: Lk Ann + LVI

Send Coolers To:

Phone: 407-894-4180
 FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Mike Linger

Program Module Number: 1306
 Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 19-APR-2019
 Biology Request Reviewed By: JASROTIA_P On: 19-APR-2019
 Sampling Kit Required: YES Ship on: 26-APR-2019
 Sampling Kit Shipped: YES On: 23-APR-2019
 Sampling Kit Packed By: REAVES_S
 Preservatives Needed: NO
 Date to Receive Samples: 06-MAY-2019
 Received By:

Send Final Report To:

FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Mike Linger

Report Type: Final Only
 FTP Data: NO
 QC Report: YES
 Date Log: NO
 Authorization Log: NO

Comments:

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

