

RQ- 2019-01-28-53

Log-in Checklist

Login Station ID: #4Shipping Method: FedEx UPS | HD | GreyhoundDate/Time of Receipt: 01/31/2019 @ 10:00a

Cooler Temperature*	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Tracking # (fill out only if waybill copy is damaged)
				Present?		*Intact?		
	HNO ₃	Formalin		Yes	No	Yes	No	
1.1°C			11		x			4751 8775 8671
0.9°C			12		X			4751 8775 8660
0.2°C			15		X			4751 8775 8649
0.7°C			12		X			4751 8775 8650

* HNO₃ and Formalin persevered samples do **NOT** have a temperature requirement. For all others, if the temperature of a cooler is above 6.0 °C (or above 10.0 °C for W-1-4-DIOX), or if Evidence Seal is damaged. Identify the containers in the affected cooler(s) on back of this form.

****Note:** If "No" is checked below, fill out the back of this form (Field ID, Test IDs, etc.) and generate an NCR.

****Chain of Custody/ Field Sheet(s) Included?** Yes ☒ No ☐

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes ☐ No ☐ Date

CONTAINER CHECK

****Evidence Tape on Bottles?** Yes ☐ No ☒ If yes, is it intact? Yes ☐ No ☐

****Caps on tight?** Yes ☒ No ☐ ****Containers intact?** Yes ☒ No ☐

****Sufficient Sample Volume:** Yes ☒ No ☐

CHLORINE CHECK REQUIRED? (Blue dot on container) Yes ☒ No ☐ Init: MR

Check the Box marked "Yes" or "No" for the Presence of Chlorine. If Cl detected, an NCR is required.					
Analysis	Yes	No	Analysis	Yes	No
W-1,4 DIOX			W-PC-AA-SF		
W-E8321-DI, -MS, -21		X	W-NP-AA-SF		
W-BNA (-625, -R)			W-PDQUAT		
W-CARB-AA (-CAB-AA-R)		X	W-PCL-SQ-R		X
W-U2060-MS			W-TR-TQ		
W-PCB-R			W-CT-CI-R		X
W-PAH (-R)			W-PSNP-TQ		X
W-PFAS-MS					

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

****Acid Preserved Samples: pH ≤ 2.0?** Yes ☒ No ☐ NA ☐ Init: MR

****W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?** Yes ☐ No ☒ NA ☒ Init: MR

Coolers Unpacked/Checked by: Tyler Reynolds Date: 01/31/2019

NCRs (Y/N)? N

Event ID: 2019 SMP : P Cricks Part 2
SO-DIST-2019-01-31-01 (SMP)

NCR #

Date Received: 31-JAN-2019 10:0

Log-in Checklist

Samples with Incorrect pH Preservation or presence of Chlorine

Field ID	Bottle Test ID(s)	pH / Cl	Action Taken

Samples in Coolers with Incorrect Preservation or Damaged Evidence Tape

Cooler ID	Field ID	Bottle Test ID(s)

Bottles Not Intact

Field ID	Bottle Test ID(s)	Loose Cap	Damaged Cap		Damaged Container		Evidence Tape Not Intact
			CK	BR	CK	BR	

Samples with Insufficient Volume for Analyses

Field ID	Bottle Test ID(s)	Action Taken

Additional Comments:

Infrared Thermometer ID:	REC_04_2018
pH Paper 0.0 – 3.0 Lot #	
pH Paper 0 – 13 Lot #	222516EXP:09/15/2019
Chlorine Test Strips Lot #	091417V EXP:09/2021

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ No X

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ If No _____

no, were samples shipped on dry ice? Yes _____ No _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Florida Department of Environmental Protection
Central Laboratory Submittal Form

Customer: SO-DIST

Requester: Nicole Reistad

Field Report Prepared By: MARYANN DUGAN

Project ID: SMP

Collected By: MARYANN DUGAN, STEVEN LOFONE

Sampling Agency: S ROC

Location	Field ID/WIN ID		☐ Comp ☒ Grab	Collection (comp begin or grab) Date 01/30/2019 Time 0905	☒ Eastern ☐ Central	Composite end Date Time	Bottle Group(s) (See pg 2)
Field ID	Location	G3SD0011	Matrix (type, e.g., Salt, Fresh, etc)	FRESH	Diss. Oxygen 8.32 ☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	B
WIN/STORET #	HawthorneCreek@Reynolds		Temp (C) 14.0	pH 7.15	Sample Depth 0.3 ☐ ft ☒ m	Sp. Conductance (umho/cm) 574	
Latitude ☐ dd ☐ dms	Longitude ☐ dd ☐ dms		Salinity (ppt) 0.28	Comments E. coli @ BENCHMARK			
Location	Field ID/WIN ID		☐ Comp ☒ Grab	Collection (comp begin or grab) Date 01/30/2019 Time 0945	☒ Eastern ☐ Central	Composite end Date Time	Bottle Group(s)
Field ID	Location	G3SD0096	Matrix (type, e.g., Salt, Fresh, etc)	FRESH	Diss. Oxygen 6.52 ☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	A
WIN/STORET #	Hog Bay @ CR 763		Temp (C) 14.1	pH 6.92	Sample Depth 0.3 ☐ ft ☒ m	Sp. Conductance (umho/cm) 393	
Latitude ☐ dd ☐ dms	Longitude ☐ dd ☐ dms		Salinity (ppt) 0.19	Comments E. coli @ BENCHMARK			
Location	Field ID/WIN ID		☐ Comp ☒ Grab	Collection (comp begin or grab) Date 01/30/2019 Time 1030	☒ Eastern ☐ Central	Composite end Date Time	Bottle Group(s)
Field ID	Location	G3SD0095	Matrix (type, e.g., Salt, Fresh, etc)	FRESH	Diss. Oxygen 7.39 ☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	C
WIN/STORET #	MyrtleSlough@PinelIsland		Temp (C) 14.8	pH 7.07	Sample Depth 0.3 ☐ ft ☒ m	Sp. Conductance (umho/cm) 297	
Latitude ☐ dd ☐ dms	Longitude ☐ dd ☐ dms		Salinity (ppt) 0.14	Comments E. coli @ BENCHMARK			
Location	Field ID/WIN ID		☐ Comp ☒ Grab	Collection (comp begin or grab) Date 01/30/2019 Time 1111	☒ Eastern ☐ Central	Composite end Date Time	Bottle Group(s)
Field ID	Location	G3SD0097	Matrix (type, e.g., Salt, Fresh, etc)	FRESH	Diss. Oxygen 7.58 ☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	A
WIN/STORET #	Myrtle Slough @ SR 31		Temp (C) 15.8	pH 7.34	Sample Depth 0.3 ☐ ft ☒ m	Sp. Conductance (umho/cm) 815	
Latitude ☐ dd ☐ dms	Longitude ☐ dd ☐ dms		Salinity (ppt) 0.40	Comments E. coli @ BENCHMARK			

Relinquished By: Maryann Dugan	Date/Time: 01/30/2019	Shipping Method: FedEx	Number of Coolers Shipped: 4	Received By: Tyler R.	Date/Time: 1/31/19 @ 10:00
--------------------------------	-----------------------	------------------------	------------------------------	-----------------------	----------------------------

* collection time was recorded on sample container. TK

Group: A	Bottle Type:	P-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2
	ALKALINITY TURBIDITY W-CL-IC W-COLOR W-F W-SO4-IC W-TDS W-TSS						
Group: A	Bottle Type:	BP-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2
	CHLSUITE-W						
Group: A	Bottle Type:	P-250ML-WI-THI	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	① (2 @ BENCHMARK)
	SD-BES-ECQ						
Group: A	Bottle Type:	BG-500ML	# of Bottles: 2	Preservative:	CH2CICOOH Pre-Preserved	Enter Number of Bottles Sent to Lab	2
	W-CARB-AA						
Group: A	Bottle Type:	BG-500ML	# of Bottles: 6	Preservative:	ICE	Enter Number of Bottles Sent to Lab	6
	W-CT-CI-R W-PCL-SQ-R						
Group: A	Bottle Type:	BG-500ML	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2
	W-E8321-DI W-E8321-MS						
Group: A	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	HNO3 NA8197080 07/16/2019	Enter Number of Bottles Sent to Lab	2
	W-ICP W-ICPMS						
Group: A	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	ICE And H2SO4 SA8197090 07/16/2019	Enter Number of Bottles Sent to Lab	2
	W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC						
Group: A	Bottle Type:	P-125ML	# of Bottles: 2	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab	2
	W-PO4-F						

Group: A	Bottle Type: W-PSNP-TQ	BG-1L	# of Bottles: 6	Preservative: ICE	Enter Number of Bottles Sent to Lab	0
Group: B	Bottle Type: ALKALINITY TURBIDITY W-CL-IC W-COLOR W-F W-SO4-IC W-TDS W-TSS	P-1L	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	1
Group: B	Bottle Type: CHLSUITE-W	BP-1L	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	1
Group: B	Bottle Type: PCR-HF183	QPCR-P-500ML	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	1
Group: B	Bottle Type: SD-BES-ECQ	P-250ML-WI-THI	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	0 (1 @ BENCHMARK)
Group: B	Bottle Type: W-CARB-AA	BG-500ML	# of Bottles: 1	Preservative: CH2CICOOH Pre-Preserved	Enter Number of Bottles Sent to Lab	1
Group: B	Bottle Type: W-CT-CI-R W-PCL-SQ-R	BG-500ML	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab	2
Group: B	Bottle Type: W-E8321-DI W-E8321-MS	BG-500ML	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	1
Group: B	Bottle Type: W-ICP W-ICPMS	P-500ML	# of Bottles: 1	Preservative: HNO3 NA8197080 07/10/2019	Enter Number of Bottles Sent to Lab	1
Group: B	Bottle Type: W-NH3 W-NO2NO3 W-S-A-TP	P-500ML	# of Bottles: 1	Preservative: ICE And H2SO4 SA8197090 07/10/2019	Enter Number of Bottles Sent to Lab	1

Group: B	Bottle Type: W-TKN W-TOC	P-500ML	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab <u>1</u>
Group: B	Bottle Type: W-PO4-F	P-125ML	# of Bottles: 1	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab <u>1</u>
Group: B	Bottle Type: W-PSNP-TQ	BG-1L	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>2</u>
Group: C	Bottle Type: ALKALINITY TURBIDITY W-CL-IC W-COLOR W-F W-SO4-IC W-TDS W-TSS	P-1L	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>1</u>
Group: C	Bottle Type: CHLSUITE-W	BP-1L	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>1</u>
Group: C	Bottle Type: PCR-FILTER	QPCR-P-500ML	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>1</u>
Group: C	Bottle Type: SD-BES-ECQ	P-250ML-WI-THI	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>0 (1 @ Benchmark)</u>
Group: C	Bottle Type: W-CARB-AA	BG-500ML	# of Bottles: 1	Preservative: CH2CICOOH Pre-Preserved	Enter Number of Bottles Sent to Lab <u>1</u>
Group: C	Bottle Type: W-CT-CI-R W-PCL-SQ-R	BG-500ML	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>2</u>
Group: C	Bottle Type: W-E8321-DI W-E8321-MS	BG-500ML	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>1</u>
Group: C	Bottle Type: W-ICP	P-500ML	# of Bottles: 1	Preservative: HNO3	Enter Number of Bottles Sent to Lab <u>1</u>

NA8197000
07/16/2019

Group: C	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	HNO3	Enter Number of Bottles Sent to Lab	1
W-ICPMS							
Group: C	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	1
				SA8197090			
				07/14/2019			
W-NH3							
W-NO2NO3							
W-S-A-TP							
W-TKN							
W-TOC							
Group: C	Bottle Type:	P-125ML	# of Bottles: 1	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab	1
W-PO4-F							
Group: C	Bottle Type:	BG-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2
W-PSNP-TQ							

Cooler Packing Worksheet for Request: RQ-2019-01-28-53

2019 SMP : P Cricks Part 2

Ship Cooler On: 1/18/2019

Customer/Project: SO-DIST/SMP

Assigned To: REYNOLDS_T

Requester: Nicole Reistad

Priority: 3

239-344-5718
FLDEP South District Office
2295 Victoria Ave. Suite 364
Fort Myers, FL 33901-3381
Attn: Nicole Reistad

Please return
packing list with
sample submittal
forms.

Comments:

No preservatives needed.

Group A: (2001,2040) Freshwater with Metals, E.coli, Pesticides

Group B: (1997) Freshwater with Metals, E.coli, PCR-HF183, Pesticides

Group C: (1995) Freshwater with Metals, E.coli, M, Pesticides

Requested Analyses:

Bottle Group: A

of Sites: 2

Container ID: P-1L

Qty: 2 Preservation: ICE

Lot # 00073319

Description: Plastic Bottle 1L

Analysis

ALKALINITY

TURBIDITY

W-CL-IC

W-COLOR

W-F

W-SO4-IC

W-TDS

W-TSS

Description

Alkalinity in aqueous matrices as mg CaCO₃/L

Turbidity in aqueous matrices

Chloride in aqueous matrices

True Color measured at 450 nm

Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)

Sulfate in aqueous matrices

Total Dissolved Solids in aqueous matrices

Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Container ID: BP-1L

Qty: 2 Preservation: ICE

Lot # 1241807

Description: Brown Plastic Bottle 1L

Analysis

CHLSUITE-W

Description

Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Container ID: P-250ML-WI-THI

Qty: 2

Preservation: ICE

Lot # 018244

Description: 250 ml Sterilized with tablet

Analysis

SD-BES-ECQ

Description

Escherichia coli by Colilert 18 Quanti-Tray method by Benchmark EA South in North Port

Container ID: BG-500ML

Qty: 2

Preservation: CH₂ClCOOH Pre-Preserved

Lot # 00071185

Description: Brown Glass Bottle 500ML

Affix BLUE dot to container.

Analysis

W-CARB-AA

Description

Carbamates in water matrices by HPLC/MS/MS

Container ID: BG-500ML

Qty: 6

Preservation: ICE

Lot # 00071185

Description: Brown Glass Bottle 500ML

Affix BLUE dot to container.

Analysis

W-CT-CI-R

W-PCL-SQ-R

Description

Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization

Organochlorine pesticides in water matrices by GC/MS-SIM

Container ID: BG-500ML

Qty: 2

Preservation: ICE

Lot # 00071185

Description: Brown Glass Bottle 500ML

Affix BLUE dot to container.

Analysis

W-E8321-DI

W-E8321-MS

Description

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Container ID: P-500ML

Qty: 2

Preservation: HNO₃

Lot # 00072433

Description: Plastic Bottle 500 mL

Affix RED nitric acid dot to container.

Analysis

W-ICP

W-ICPMS

Description

Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects

Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects

Container ID: BP-1L

Qty: 1 Preservation: ICE

Lot # 1242507

Description: Brown Plastic Bottle 1L

Analysis

CHLSUITE-W

Description

Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Container ID: QPCR-P-500ML

Qty: 1 Preservation: ICE

Lot # 00071457

Description: 500ml Sterile Nalgene

Affix PCR Instruction Label to container

Analysis

PCR-HF183

Description

Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction

Container ID: P-250ML-WI-THI

Qty: 1 Preservation: ICE

Lot # 118244

Description: 250 ml Sterilized with tablet

Analysis

SD-BES-ECQ

Description

Escherichia coli by Collert 18 Quanti-Tray method by Benchmark EA South in North Port

Container ID: BG-500ML

Qty: 1 Preservation: CH2ClCOOH Pre-Preserved

Lot # 00071185

Description: Brown Glass Bottle 500ML

Affix BLUE dot to container.

Analysis

W-CARB-AA

Description

Carbamates in water matrices by HPLC/MS/MS

Container ID: BG-500ML

Qty: 2 Preservation: ICE

Lot # 00071185

Description: Brown Glass Bottle 500ML

Affix BLUE dot to container.

Analysis

W-CT-Cl-R

W-PCL-SQ-R

Description

Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization

Organochlorine pesticides in water matrices by GC/MS-SIM

Container ID: BG-500ML

Qty: 1 Preservation: ICE

Lot # 00071185

Description: Brown Glass Bottle 500ML

Affix BLUE dot to container.

Analysis

W-E8321-DI

Description

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Container ID: P-500ML

Qty: 2 Preservation: ICE And H2SO4

Lot # 00072433

Description: Plastic Bottle 500 mL

Affix YELLOW sulfuric acid dot to container.

Analysis

W-NH3
W-NO2NO3
W-S-A-TP
W-TKN
W-TOC

Description

Ammonia in aqueous matrices as mg N/L
Nitrite/Nitrate in aqueous matrices as mg N/L
Total Phosphorus in aqueous matrices as mg P/L
Total Kjeldahl Nitrogen in aqueous matrices
Nonpurgeable Organic Carbon in aqueous matrices

Container ID: P-125ML

Qty: 2 Preservation: FILTER-ICE

Lot # 00072954

Description: Plastic Bottle 125 mL

Analysis

W-PO4-F

Description

Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Container ID: BG-1L

Qty: 6 Preservation: ICE

Lot # 00071178

Description: Brown Glass Bottle 1L

Affix BLUE dot to container.

Analysis

W-PSNP-TQ

Description

Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS

Bottle Group: B

of Sites: 1

Container ID: P-1L

Qty: 1 Preservation: ICE

Lot # 00073319

Description: Plastic Bottle 1L

Analysis

ALKALINITY
TURBIDITY
W-CL-IC
W-COLOR
W-F
W-SO4-IC
W-TDS
W-TSS

Description

Alkalinity in aqueous matrices as mg CaCO3/L
Turbidity in aqueous matrices
Chloride in aqueous matrices
True Color measured at 450 nm
Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
Sulfate in aqueous matrices
Total Dissolved Solids in aqueous matrices
Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

TURBIDITY	Turbidity in aqueous matrices
W-CL-IC	Chloride in aqueous matrices
W-COLOR	True Color measured at 450 nm
W-F	Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Sulfate in aqueous matrices
W-TDS	Total Dissolved Solids in aqueous matrices
W-TSS	Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Container ID: BP-1L

Qty: 1 Preservation: ICE

Lot # 1241507

Description: Brown Plastic Bottle 1L

Analysis

CHLSUITE-W

Description

Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Container ID: QPCR-P-500ML

Qty: 1 Preservation: ICE

Lot # 00071457

Description: 500ml Sterile Nalgene

Affix PCR Instruction Label to container

Analysis

PCR-FILTER

Description

Preparation of Samples by Filtration and held for qPCR Analysis

Container ID: P-250ML-WI-THI

Qty: 1 Preservation: ICE

Lot # L18244

Description: 250 ml Sterilized with tablet

Analysis

SD-BES-ECQ

Description

Escherichia coli by Colilert 18 Quanti-Tray method by Benchmark EA South in North Port

Container ID: BG-500ML

Qty: 1 Preservation: CH2CICOOH Pre-Preserved Lot # 00071185

Description: Brown Glass Bottle 500ML

Affix BLUE dot to container.

Analysis

W-CARB-AA

Description

Carbamates in water matrices by HPLC/MS/MS

Container ID: BG-500ML

Qty: 2 Preservation: ICE

Lot # 00071185

Description: Brown Glass Bottle 500ML

Affix BLUE dot to container.

Analysis

W-CT-CI-R

W-PCL-SQ-R

Description

Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization

Organochlorine pesticides in water matrices by GC/MS-SIM

Container ID: P-500ML

Qty: 1

Preservation: HNO3

Lot # 00072433

Description: Plastic Bottle 500 mL

Affix RED nitric acid dot to container.

Analysis

W-ICP

W-ICPMS

Description

Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects

Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects

Container ID: P-500ML

Qty: 1

Preservation: ICE And H2SO4

Lot # 00072433

Description: Plastic Bottle 500 mL

Affix YELLOW sulfuric acid dot to container.

Analysis

W-NH3

W-NO2NO3

W-S-A-TP

W-TKN

W-TOC

Description

Ammonia in aqueous matrices as mg N/L

Nitrite/Nitrate in aqueous matrices as mg N/L

Total Phosphorus in aqueous matrices as mg P/L

Total Kjeldahl Nitrogen in aqueous matrices

Nonpurgeable Organic Carbon in aqueous matrices

Container ID: P-125ML

Qty: 1

Preservation: FILTER-ICE

Lot # 00072954

Description: Plastic Bottle 125 mL

Analysis

W-PO4-F

Description

Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Container ID: BG-1L

Qty: 2

Preservation: ICE

Lot # 1241507

Description: Brown Glass Bottle 1L

Affix BLUE dot to container.

Analysis

W-PSNP-TQ

Description

Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS

Bottle Group: C# of Sites: 1

Container ID: P-1L

Qty: 1

Preservation: ICE

Lot # 00073319

Description: Plastic Bottle 1L

Analysis

ALKALINITY

Description

Alkalinity in aqueous matrices as mg CaCO3/L

Container ID: BG-500ML

Qty: 1 Preservation: ICE

Lot # 00071185

Description: Brown Glass Bottle 500ML

Affix BLUE dot to container.

Analysis

W-E8321-DI

W-E8321-MS

Description

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Container ID: P-500ML

Qty: 1 Preservation: HNO3

Lot # 00072433

Description: Plastic Bottle 500 mL

Affix RED nitric acid dot to container.

Analysis

W-ICP

W-ICPMS

Description

Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects

Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects

Container ID: P-500ML

Qty: 1 Preservation: ICE And H2SO4

Lot # 00072433

Description: Plastic Bottle 500 mL

Affix YELLOW sulfuric acid dot to container.

Analysis

W-NH3

W-NO2NO3

W-S-A-TP

W-TKN

W-TOC

Description

Ammonia in aqueous matrices as mg N/L

Nitrite/Nitrate in aqueous matrices as mg N/L

Total Phosphorus in aqueous matrices as mg P/L

Total Kjeldahl Nitrogen in aqueous matrices

Nonpurgeable Organic Carbon in aqueous matrices

Container ID: P-125ML

Qty: 1 Preservation: FILTER-ICE

Lot # 00072954

Description: Plastic Bottle 125 mL

Analysis

W-PO4-F

Description

Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Container ID: BG-1L

Qty: 2 Preservation: ICE

Lot # 00071178

Description: Brown Glass Bottle 1L

Affix BLUE dot to container.

Analysis

W-PSNP-TQ

Description

Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS

Cooler Packed By: Tyler R.

Number of Coolers: 9

Date: 1/22/18

Kit must also include:

- ☒ Field Sheets
- ☒ Temperature Control Bottle
- ☒ FedEx Bills, if applicable
- ☒ Plastic Bags/Zip Ties
- ☐ Acid Labels (sets of 24)

If Preservation Included:

ID _____	Exp _____	Lot # _____
ID _____	Exp _____	Lot # _____
ID _____	Exp _____	Lot # _____
ID _____	Exp _____	Lot # _____
ID _____	Exp _____	Lot # _____

PLEASE RETURN ALL COOLERS FOR RQ-2019-01-28-53

Date of Request: 14-JAN-2019
 Created By: REISTAD_N On: 14-JAN-2019
 Modified By: JASROTIA_P On: 14-JAN-2019
 Customer: SO-DIST
 Project: SMP
 Division:
 District: South District
 Sampling Event: 2019 SMP : P Cricks Part 2

Send Coolers To:

Phone: 239-344-5718
 FLDEP South District Office
 2295 Victoria Ave. Suite 364
 Fort Myers, FL 33901-3381
 Attn: Nicole Reistad

Send Final Report To:

FLDEP South District Office
 2295 Victoria Ave. Suite 364
 Fort Myers, FL 33901-3381
 Attn: Nicole Reistad

Program Module Number:

Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 14-JAN-2019
 Biology Request Reviewed By: JASROTIA_P On: 14-JAN-2019
 Sampling Kit Required: YES Ship on: 18-JAN-2019
 Sampling Kit Shipped: YES On: 22-JAN-2019
 Sampling Kit Packed By: REYNOLDS_T
 Preservatives Needed: NO
 Date to Receive Samples: 28-JAN-2019
 Received By:

Report Type: Final Only
 FTP Data: NO
 QC Report: YES
 Date Log: NO
 Authorization Log: NO

Comments: Group A: (2001,2040) Freshwater with Metals, E.coli, Pesticides
 Group B: (1997) Freshwater with Metals, E.coli, PCR-HF183, Pesticides
 Group C: (1995) Freshwater with Metals, E.coli, M, Pesticides

Bottle Group A (Water) With 2 Samples:

Bottle Type: P-1L	Number of Bottles: 2	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BG-1L	Number of Bottles: 6	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270D) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS
Bottle Type: BP-1L	Number of Bottles: 2	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WI-THI	Number of Bottles: 2	Preserved With: ICE
SD-BES-ECQ	Template: DEFAULT	(SM 9223 Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method by Benchmark EA South in North Port
Bottle Type: BG-500ML	Number of Bottles: 2	Preserved With: CH ₂ ClCOOH Pre-Preserved
W-CARB-AA	Template: DEFAULT	(EPA 8321B) Carbamates in water matrices by HPLC/MS/MS
Bottle Type: BG-500ML	Number of Bottles: 6	Preserved With: ICE
W-CT-Cl-R	Template: DEFAULT	(EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization
W-PCL-SQ-R	Template: DEFAULT	(EPA 8270D) Organochlorine pesticides in water matrices by GC/MS-SIM
Bottle Type: BG-500ML	Number of Bottles: 2	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Bottle Group A (Water) With 2 Samples:

Bottle Type: BG-500ML	Number of Bottles: 2	Preserved With: ICE
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: HNO3
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects

Barium
Calcium
Iron
Magnesium
Potassium
Sodium
Zinc

W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
---------	-----------	---

*Boron
Aluminum
Antimony
Arsenic
Cadmium
Chromium
Copper
Lead
Nickel
Selenium
Silver
Thallium

Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 2	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction

Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
SD-BES-ECQ	Template: DEFAULT	(SM 9223 Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method by Benchmark EA South in North Port

Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: CH2CICOOH Pre-Preserved
W-CARB-AA	Template: DEFAULT	(EPA 8321B) Carbamates in water matrices by HPLC/MS/MS

Bottle Type: BG-500ML	Number of Bottles: 2	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization

Bottle Group B (Water) With 1 Samples:

Bottle Type: BG-500ML	Number of Bottles: 2	Preserved With: ICE
W-PCL-SQ-R	Template: DEFAULT	(EPA 8270D) Organochlorine pesticides in water matrices by GC/MS-SIM
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects

Barium
Calcium
Iron
Magnesium
Potassium
Sodium
Zinc

W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
---------	-----------	---

*Boron
Aluminum
Antimony
Arsenic
Cadmium
Chromium
Copper
Lead
Nickel
Selenium
Silver
Thallium

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
Bottle Type: BG-1L	Number of Bottles: 2	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270D) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-FILTER	Template: DEFAULT	(SOP-PCR-4.0) Preparation of Samples by Filtration and held for qPCR Analysis
Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
SD-BES-ECQ	Template: DEFAULT	(SM 9223 Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method by Benchmark EA South in North Port
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: CH2ClCOOH Pre-Preserved

Bottle Group C (Water) With 1 Samples:

Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: CH ₂ ClCOOH Pre-Preserved
W-CARB-AA	Template: DEFAULT	(EPA 8321B) Carbamates in water matrices by HPLC/MS/MS
Bottle Type: BG-500ML	Number of Bottles: 2	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization
W-PCL-SQ-R	Template: DEFAULT	(EPA 8270D) Organochlorine pesticides in water matrices by GC/MS-SIM
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO ₃
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Barium		
Calcium		
Iron		
Magnesium		
Potassium		
Sodium		
Zinc		
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
*Boron		
Aluminum		
Antimony		
Arsenic		
Cadmium		
Chromium		
Copper		
Lead		
Nickel		
Selenium		
Silver		
Thallium		
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO ₄ -F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
Bottle Type: BG-1L	Number of Bottles: 2	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270D) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.