

Log-in Checklist

RQ- 2019-04-01-56

Login Station ID: #4

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 04/09/19 @ 9:25

Cooler Temperature*	Samples Frozen	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Tracking # Damaged waybills only
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
0.9°C				12		X			4751 8777 9923

* HNO₃ and Formalin persevered samples do **NOT** have a temperature requirement. For all others, if the temperature of a cooler is above 6.0 °C (or above 10.0 °C for W-1-4-DIOX and microbiology), or if Evidence Seal is damaged. Identify the containers in the affected cooler(s) on back of this form. **DOH coolers can exceed 2.0 °C above standard temperature without customer notification/confirmation.**

****Note:** If "No" is checked below, fill out the back of this form (Field ID, Test IDs, etc.) and generate an NCR.

**Chain of Custody/ Field Sheet(s) Included? Yes ☒ No ☐

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes ☐ No ☒

CONTAINER CHECK

**Evidence Tape on Bottles? Yes ☐ No ☒ If yes, is it intact? Yes ☐ No ☐

**Caps on tight? Yes ☒ No ☐ **Containers intact? Yes ☒ No ☐

**Sufficient Sample Volume: Yes ☒ No ☐

CHLORINE CHECK REQUIRED? (Blue dot on container) Yes ☐ No ☒ Init: Tyler R.

Check the Box marked "Yes" or "No" for the Presence of Chlorine. If Cl detected, an NCR is required.					
Analysis	Yes	No	Analysis	Yes	No
W-1,4 DIOX			W-PC-AA-SF		
W-E8321-DI, -MS, -21			W-NP-AA-SF		
W-BNA (-625, -R)			W-PDQUAT		
W-CARB-AA (-CAB-AA-R)			W-PCL-SQ-R		
W-U2060-MS			W-TR-TQ		
W-PCB-R			W-CT-CI-R		
W-PAH (-R)			W-PSNP-TQ		
W-PFAS-MS					

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH ≤ 2.0? Yes ☒ No ☐ NA ☐ Init: Tyler R.

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes ☐ No ☒ NA ☒ Init: Tyler R.

Coolers Unpacked/Checked by: Tyler Reynolds

Date: 04/09/19

NCRs (Y/N)? N

Event ID: 2019 SMP : Canals
SO-DIST-2019-04-09-01 (SMP)

NCR #

Page 1 of 2, Date Received: 09-APR-2019 09:25
Federal Express PEE-4-2-1

Log-in Checklist

Samples with Incorrect pH Preservation or presence of Chlorine

Field ID	Bottle Test ID(s)	pH / Cl	Action Taken

Samples in Coolers with Incorrect Preservation or Damaged Evidence Tape

Cooler ID	Field ID	Bottle Test ID(s)

Bottles Not Intact

Field ID	Bottle Test ID(s)	Loose Cap	Damaged Cap		Damaged Container		Evidence Tape Not Intact
			CK	BR	CK	BR	

Samples with Insufficient Volume for Analyses

Field ID	Bottle Test ID(s)	Action Taken

Additional Comments:

Infrared Thermometer ID:	
pH Paper 0.0 – 3.0 Lot #	
pH Paper 0 – 13 Lot #	
Chlorine Test Strips Lot #	

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes_____ No X

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes_____ If No_____

no, were samples shipped on dry ice? Yes_____ No_____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes_____ No_____

Date and time samples preserved: _____

Florida Department of Environmental Protection

Central Laboratory Submittal Form

Customer: SO-DIST

Project ID: SMP

Requester: Nicole Reistad

Collected By: Gary Shorek

Field Report Prepared By: Nicole Reistad

Sampling Agency: POS2 SROC

Field ID/WIN ID G3SD0087		☐ Comp ☒ Grab		Collection (comp begin or grab) Date 4/8/19 Time 0955		Eastern Central		Composite end Date Time		Bottle Group(s) (See pg 2)	
Location C-19 @ US 27		Matrix (type, e.g., Salt, Fresh, etc) fresh		Diss. Oxygen 5.38		☒ mg/L ☐ % sat		Total Res. Chlorine (mg/L) —		A	
Temp (C) 25.4		pH 7.10		Sample Depth 0.3		☐ ft ☒ m		Sp. Conductance (umho/cm) 542			
Latitude ☐ dd ☐ dms		Longitude ☐ dd ☐ dms		Salinity (ppt) 0.26		Comments					
Field ID/WIN ID G3SD0102		☐ Comp ☒ Grab		Collection (comp begin or grab) Date 4/8/19 Time 1030		Eastern Central		Composite end Date Time		Bottle Group(s)	
Location Lake Hicpochee Canal		Matrix (type, e.g., Salt, Fresh, etc) fresh		Diss. Oxygen 6.81		☒ mg/L ☐ % sat		Total Res. Chlorine (mg/L) —		A	
Temp (C) 26.2		pH 7.59		Sample Depth 0.25		☐ ft ☒ m		Sp. Conductance (umho/cm) 439			
Latitude ☐ dd ☐ dms		Longitude ☐ dd ☐ dms		Salinity (ppt) 0.21		Comments					
Field ID/WIN ID G3SD0088		☐ Comp ☒ Grab		Collection (comp begin or grab) Date 4/8/19 Time 1100		Eastern Central		Composite end Date Time		Bottle Group(s)	
Location Nine Mile Canal @SR80		Matrix (type, e.g., Salt, Fresh, etc) fresh		Diss. Oxygen 6.05		☒ mg/L ☐ % sat		Total Res. Chlorine (mg/L) —		A	
Temp (C) 26.2		pH 7.52		Sample Depth 0.3		☐ ft ☒ m		Sp. Conductance (umho/cm) 426			
Latitude ☐ dd ☐ dms		Longitude ☐ dd ☐ dms		Salinity (ppt) 0.22		Comments					
Location		☐ Comp ☐ Grab		Collection (comp begin or grab) Date Time		Eastern Central		Composite end Date Time		Bottle Group(s)	
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)			
WIN/STORET #		Temp (C)		pH		Sample Depth		Sp. Conductance (umho/cm)			
Latitude ☐ dd ☐ dms		Longitude ☐ dd ☐ dms		Salinity (ppt)		Comments					

Relinquished By: Gary Shorek	Date/Time 4/8/19 1230	Shipping Method fedex	Number of Coolers Shipped: 1	Received By: Tyler Reynolds	Date/Time 04/09/19 @ 9:25
---------------------------------	--------------------------	--------------------------	---------------------------------	--------------------------------	------------------------------

Group: A	Bottle Type:	P-1L	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab	3
	ALKALINITY						
	TURBIDITY						
	W-CL-IC						
	W-COLOR						
	W-F						
	W-SO4-IC						
	W-TDS						
	W-TSS						
Group: A	Bottle Type:	BP-1L	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab	3
	CHLSUITE-W						
Group: A	Bottle Type:	P-250ML-WI-THI	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab	0
	SD-SND-ECQ						
Group: A	Bottle Type:	P-500ML	# of Bottles: 3	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	3
	W-NH3						
	W-NO2NO3						
	W-S-A-TP						
	W-TKN						
	W-TOC						
Group: A	Bottle Type:	P-125ML	# of Bottles: 3	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab	3
	W-PO4-F						

SA8344070

exp. 12/10/19

Date of Request: 19-MAR-2019
 Created By: REISTAD_N On: 19-MAR-2019
 Modified By: JASROTIA_P On: 25-MAR-2019
 Customer: SO-DIST
 Project: SMP
 Division:
 District: South District
 Sampling Event: 2019 SMP : Canals

Send Coolers To:

Phone: 239-344-5718
 FLDEP South District Office
 2295 Victoria Ave. Suite 364
 Fort Myers, FL 33901-3381
 Attn: Nicole Reistad

Send Final Report To:

FLDEP South District Office
 2295 Victoria Ave. Suite 364
 Fort Myers, FL 33901-3381
 Attn: Nicole Reistad

Program Module Number:

Priority: 3

Event Status: A

Criminal Investigation: NO

Chemistry Request Reviewed By: WATTS_J On: 21-MAR-2019

Biology Request Reviewed By: JASROTIA_P On: 25-MAR-2019

Sampling Kit Required: NO Ship on:

Sampling Kit Shipped: YES On: 20-MAR-2019

Sampling Kit Packed By: KLUG_K

Preservatives Needed: NO

Date to Receive Samples: 01-APR-2019

Received By:

Report Type: Final Only

FTP Data: NO

QC Report: YES

Date Log: NO

Authorization Log: NO

Comments: Group A: (3237E) Freshwater Nutrients, E.coli, PCR-BacR, PCR-HF183, Tracers
 Group B: (3237C,3237D) Freshwater Nutrients, E.coli

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
SD-SND-ECQ	Template: DEFAULT	(Colilert-18) Escherichia coli by Colilert 18 Quanti-Tray method by Sanders Laboratories in Fort Myers
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 2 Samples:

Bottle Type: P-250ML-WI-THI	Number of Bottles: 2	Preserved With: ICE
SD-SND-ECQ	Template: DEFAULT	(Colilert-18) Escherichia coli by Colilert 18 Quanti-Tray method by Sanders Laboratories in Fort Myers
Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 2	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
Bottle Type: P-1L	Number of Bottles: 2	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 2	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.