

RQ- 2019-01-21-49

Log-in Checklist

Login Station ID: #4Shipping Method: FedEx | UPS | HD | GreyhoundDate/Time of Receipt: 01/30/2019 @ 10:25am

Cooler Temperature*	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Tracking # (fill out only if waybill copy is damaged)
				Present?		*Intact?		
	HNO ₃	Formalin		Yes	No	Yes	No	
1.2°C			15		x			4751 8775 7274
1.0°C			10		x			4751 8775 7296
0.3°C			14		x			4751 8775 7285
-0.1°C			9		x			4751 8775 7300

* HNO₃ and Formalin persevered samples do **NOT** have a temperature requirement. For all others, if the temperature of a cooler is above 6.0 °C (or above 10.0 °C for W-1-4-DIOX), or if Evidence Seal is damaged. Identify the containers in the affected cooler(s) on back of this form.

****Note:** If "No" is checked below, fill out the back of this form (Field ID, Test IDs, etc.) and generate an NCR.

****Chain of Custody/ Field Sheet(s) Included?** Yes ☒ No ☐

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes ☐ No ☒ Date

CONTAINER CHECK

****Evidence Tape on Bottles?** Yes ☐ No ☒ If yes, is it intact? Yes ☐ No ☐

****Caps on tight?** Yes ☒ No ☐ ****Containers intact?** Yes ☒ No ☐

****Sufficient Sample Volume:** Yes ☒ No ☐

CHLORINE CHECK REQUIRED? (Blue dot on container) Yes ☒ No ☐ Init: NR

Check the Box marked "Yes" or "No" for the Presence of Chlorine. If Cl detected, an NCR is required.					
Analysis	Yes	No	Analysis	Yes	No
W-1,4 DIOX			W-PC-AA-SF		
W-E8321-DI, -MS, -21		X	W-NP-AA-SF		
W-BNA (-625, -R)			W-PDQUAT		
W-CARB-AA (-CAB-AA-R)		X	W-PCL-SQ-R		X
W-U2060-MS			W-TR-TQ		
W-PCB-R			W-CT-CI-R		X
W-PAH (-R)			W-PSNP-TQ		
W-PFAS-MS					

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

****Acid Preserved Samples: pH ≤ 2.0?** Yes ☒ No ☐ NA ☐ Init: NR

****W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?** Yes ☐ No ☒ NA ☒ Init: NR

Coolers Unpacked/Checked by: Tyler Reynolds Date: 01/30/2019 NCRs (Y/N)? N

Even SMP- Fort Lauderdale
SE-DIST-2019-01-30-01 (SMP)
Date Received: 30-JAN-2019 10:25
Page 1 of 2, 2nd Express REF-4-5-2

NCR #

Log-in Checklist

Samples with Incorrect pH Preservation or presence of Chlorine

Field ID	Bottle Test ID(s)	pH / Cl	Action Taken

Samples in Coolers with Incorrect Preservation or Damaged Evidence Tape

Cooler ID	Field ID	Bottle Test ID(s)

Bottles Not Intact

Field ID	Bottle Test ID(s)	Loose Cap	Damaged Cap		Damaged Container		Evidence Tape Not Intact
			CK	BR	CK	BR	

Samples with Insufficient Volume for Analyses

Field ID	Bottle Test ID(s)	Action Taken

Additional Comments:

Infrared Thermometer ID:	REC_04_2018
pH Paper 0.0 – 3.0 Lot #	
pH Paper 0 – 13 Lot #	222516EXP:09/15/2019
Chlorine Test Strips Lot #	091417V EXP:09/2021

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ No X

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ If No _____

no, were samples shipped on dry ice? Yes _____ No _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Florida Department of Environmental Protection

Central Laboratory Submittal Form

Customer: SE-DIST

Requester: Matt Sewell

Field Report Prepared By: Kristene Bonilla

Project ID: SMP

Collected By: Matt Sewell

Sampling Agency: 21FLWPB

Location West Lake @ Sheridan		☐ Comp ☒ Grab		Collection (comp begin or grab) Date 01/29/19 Time 12:50		☒ Eastern ☐ Central		Composite end Date _____ Time _____		Bottle Group(s) (See pg 2)	
Field ID G4SE0037		Matrix (type, e.g., Salt, Fresh, etc) Marine		Diss. Oxygen 8.12		☒ mg/L ☐ % sat		Total Res. Chlorine (mg/L)		A	
WIN/STORET # G4SE0037		Temp (C) 19.5		pH 7.84		Sample Depth 0.3		Sp. Conductance (umho/cm) 46886			
Latitude 26.0349378 ☐ dd ☐ dms		Longitude 80.1236956 ☐ dd ☐ dms		Salinity (ppt) 30.53		Comments					
Location Dania Cutoff @ Old Griffin		☐ Comp ☒ Grab		Collection (comp begin or grab) Date 01/29/2019 Time 13:30		☒ Eastern ☐ Central		Composite end Date _____ Time _____		Bottle Group(s)	
Field ID G4SE0106		Matrix (type, e.g., Salt, Fresh, etc) Marine		Diss. Oxygen 4.75		☒ mg/L ☐ % sat		Total Res. Chlorine (mg/L)		D	
WIN/STORET # G4SE0106		Temp (C) 20.3		pH 7.58		Sample Depth 0.3		Sp. Conductance (umho/cm) 11578			
Latitude 26.062833 ☒ dd ☐ dms		Longitude 80.159058 ☐ dd ☐ dms		Salinity (ppt) 6.60		Comments Dup included in other sheet					
Location North Fork New River @ Sistrunk		☐ Comp ☒ Grab		Collection (comp begin or grab) Date 01/29/19 Time 14:10		☒ Eastern ☐ Central		Composite end Date _____ Time _____		Bottle Group(s)	
Field ID G4SEB064		Matrix (type, e.g., Salt, Fresh, etc) Marine		Diss. Oxygen 5.13		☒ mg/L ☐ % sat		Total Res. Chlorine (mg/L)		B	
WIN/STORET # G4SEB064		Temp (C) 20.5		pH 7.57		Sample Depth 0.3		Sp. Conductance (umho/cm) 5765			
Latitude 26.128631 ☐ dd ☐ dms		Longitude 80.174729 ☒ dd ☐ dms		Salinity (ppt) 3.14		Comments					
Location New River @ NW 27th		☐ Comp ☒ Grab		Collection (comp begin or grab) Date 01/29/19 Time 14:35		☒ Eastern ☐ Central		Composite end Date _____ Time _____		Bottle Group(s)	
Field ID G4SE0085		Matrix (type, e.g., Salt, Fresh, etc) Marine		Diss. Oxygen 4.99		☒ mg/L ☐ % sat		Total Res. Chlorine (mg/L)		B	
WIN/STORET # G4SE0085		Temp (C) 20.1		pH 7.53		Sample Depth 0.3		Sp. Conductance (umho/cm) 2415			
Latitude 26.132707 ☐ dd ☐ dms		Longitude 80.178464 ☒ dd ☐ dms		Salinity (ppt) 1.25		Comments					

Relinquished By: Dep Southeast Rock	Date/Time 01/29/19 17:27	Shipping Method Fedex	Number of Coolers Shipped: 4	Received By: Tyler Reynolds	Date/Time 1/30/19 @ 10:25
--	-----------------------------	--------------------------	---------------------------------	--------------------------------	------------------------------

Group: A	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	ALKALINITY TURBIDITY W-BR-IC W-F W-TSS					
Group: A	Bottle Type:	BP-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	CHLSUITE-W					
Group: A	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab _____
	W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC					
Group: A	Bottle Type:	P-125ML	# of Bottles: 1	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab _____
	W-PO4-F					
Group: B	Bottle Type:	P-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	ALKALINITY TURBIDITY W-BR-IC W-F W-TSS					
Group: B	Bottle Type:	BP-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	CHLSUITE-W					
Group: B	Bottle Type:	QPCR-P-500ML	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	PCR-FILTER					
Group: B	Bottle Type:	P-250ML-WI-THI	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	SE-PCE-ENQ					
Group: B	Bottle Type:	BG-500ML	# of Bottles: 2	Preservative:	CH2CICOOH Pre-Preserved	Enter Number of Bottles Sent to Lab _____
	W-CARB-AA					
Group: B	Bottle Type:	BG-500ML	# of Bottles: 6	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	W-CT-CI-R					

Group: B	Bottle Type: W-PCL-SQ-R	BG-500ML	# of Bottles: 6	Preservative: ICE	Enter Number of Bottles Sent to Lab _____
Group: B	Bottle Type: W-E8321-DI W-E8321-MS	BG-500ML	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab _____
Group: B	Bottle Type: W-ICP W-ICPMS	P-500ML	# of Bottles: 2	Preservative: HNO3	Enter Number of Bottles Sent to Lab _____
Group: B	Bottle Type: W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC	P-500ML	# of Bottles: 2	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab _____
Group: B	Bottle Type: W-PO4-F	P-125ML	# of Bottles: 2	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab _____
Group: B	Bottle Type: W-PSNP-TQ	BG-1L	# of Bottles: 6	Preservative: ICE	Enter Number of Bottles Sent to Lab _____
Group: C	Bottle Type: PCR-FILTER	QPCR-P-500ML	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab _____
Group: C	Bottle Type: SE-PCE-ENQ	P-250ML-WI-THI	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab _____
Group: C	Bottle Type: W-E8321-DI W-E8321-MS	BG-500ML	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab _____
Group: D	Bottle Type: ALKALINITY TURBIDITY W-BR-IC W-F W-TSS	P-1L	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab _____
Group: D	Bottle Type:	BP-1L	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab _____

Group: D	Bottle Type:	BP-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	CHLSUITE-W					
Group: D	Bottle Type:	QPCR-P-500ML	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	PCR-FILTER					
Group: D	Bottle Type:	P-250ML-WI-THI	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	SE-PCE-ENQ					
Group: D	Bottle Type:	BG-500ML	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	W-E8321-DI					
	W-E8321-MS					
Group: D	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	HNO3	Enter Number of Bottles Sent to Lab _____
	W-ICP					
	W-ICPMS					
Group: D	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab _____
	W-NH3					
	W-NO2NO3					
	W-S-A-TP					
	W-TKN					
	W-TOC					
Group: D	Bottle Type:	P-125ML	# of Bottles: 2	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab _____
	W-PO4-F					

Florida Department of Environmental Protection

Central Laboratory Submittal Form

Customer: SE-DIST

Requester: Matt Sewell

Field Report Prepared By:

Kristene Bonilla

Project ID: SMP

Collected By: Matt Sewell

Sampling Agency:

21FLWPB

Location Dania Cutoff @ old Griffin		☐ Comp ☒ Grab	Collection (comp begin or grab) Date 01/29/19 Time 13:30		Eastern Central	Composite end Date Time		Bottle Group(s) (See pg 2) D
Field ID G4SE0106-Dup		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)		
WIN/STORET # G4SE0106-Dup		Temp (C)	pH	Sample Depth	☐ ft ☐ m	Sp. Conductance (umho/cm)		
Latitude ☐ dd ☐ dms	Longitude ☐ dd ☐ dms	Salinity (ppt)	Comments Duplicate					
Location		☐ Comp ☐ Grab	Collection (comp begin or grab) Date Time		Eastern Central	Composite end Date Time		Bottle Group(s)
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)		
WIN/STORET #		Temp (C)	pH	Sample Depth	☐ ft ☐ m	Sp. Conductance (umho/cm)		
Latitude ☐ dd ☐ dms	Longitude ☐ dd ☐ dms	Salinity (ppt)	Comments					
Location		☐ Comp ☐ Grab	Collection (comp begin or grab) Date Time		Eastern Central	Composite end Date Time		Bottle Group(s)
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)		
WIN/STORET #		Temp (C)	pH	Sample Depth	☐ ft ☐ m	Sp. Conductance (umho/cm)		
Latitude ☐ dd ☐ dms	Longitude ☐ dd ☐ dms	Salinity (ppt)	Comments					
Location		☐ Comp ☐ Grab	Collection (comp begin or grab) Date Time		Eastern Central	Composite end Date Time		Bottle Group(s)
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)		
WIN/STORET #		Temp (C)	pH	Sample Depth	☐ ft ☐ m	Sp. Conductance (umho/cm)		
Latitude ☐ dd ☐ dms	Longitude ☐ dd ☐ dms	Salinity (ppt)	Comments					
Location		☐ Comp ☐ Grab	Collection (comp begin or grab) Date Time		Eastern Central	Composite end Date Time		Bottle Group(s)
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)		
WIN/STORET #		Temp (C)	pH	Sample Depth	☐ ft ☐ m	Sp. Conductance (umho/cm)		
Latitude ☐ dd ☐ dms	Longitude ☐ dd ☐ dms	Salinity (ppt)	Comments					

Relinquished By: Dep Southeast Rock	Date/Time 01/29/19 17:27	Shipping Method Fedex	Number of Coolers Shipped: 4	Received By: Tyler Reynolds	Date/Time 1/30/19 @ 10:25
--	-----------------------------	--------------------------	---------------------------------	--------------------------------	------------------------------

Group: A	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	ALKALINITY TURBIDITY W-BR-IC W-F W-TSS					
Group: A	Bottle Type:	BP-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	CHLSUITE-W					
Group: A	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab _____
	W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC					
Group: A	Bottle Type:	P-125ML	# of Bottles: 1	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab _____
	W-PO4-F					
Group: B	Bottle Type:	P-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	ALKALINITY TURBIDITY W-BR-IC W-F W-TSS					
Group: B	Bottle Type:	BP-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	CHLSUITE-W					
Group: B	Bottle Type:	QPCR-P-500ML	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	PCR-FILTER					
Group: B	Bottle Type:	P-250ML-WI-THI	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	SE-PCE-ENQ					
Group: B	Bottle Type:	BG-500ML	# of Bottles: 2	Preservative:	CH2CICOOH Pre-Preserved	Enter Number of Bottles Sent to Lab _____
	W-CARB-AA					
Group: B	Bottle Type:	BG-500ML	# of Bottles: 6	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	W-CT-CI-R					

Group: B	Bottle Type: W-PCL-SQ-R	BG-500ML	# of Bottles: 6	Preservative: ICE	Enter Number of Bottles Sent to Lab _____
Group: B	Bottle Type: W-E8321-DI W-E8321-MS	BG-500ML	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab _____
Group: B	Bottle Type: W-ICP W-ICPMS	P-500ML	# of Bottles: 2	Preservative: HNO3	Enter Number of Bottles Sent to Lab _____
Group: B	Bottle Type: W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC	P-500ML	# of Bottles: 2	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab _____
Group: B	Bottle Type: W-PO4-F	P-125ML	# of Bottles: 2	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab _____
Group: B	Bottle Type: W-PSNP-TQ	BG-1L	# of Bottles: 6	Preservative: ICE	Enter Number of Bottles Sent to Lab _____
Group: C	Bottle Type: PCR-FILTER	QPCR-P-500ML	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab _____
Group: C	Bottle Type: SE-PCE-ENQ	P-250ML-WI-THI	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab _____
Group: C	Bottle Type: W-E8321-DI W-E8321-MS	BG-500ML	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab _____
Group: D	Bottle Type: ALKALINITY TURBIDITY W-BR-IC W-F W-TSS	P-1L	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab _____
Group: D	Bottle Type:	BP-1L	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab _____

Group: D	Bottle Type:	BP-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	CHLSUITE-W					
Group: D	Bottle Type:	QPCR-P-500ML	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	PCR-FILTER					
Group: D	Bottle Type:	P-250ML-WI-THI	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	SE-PCE-ENQ					
Group: D	Bottle Type:	BG-500ML	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	W-E8321-DI					
	W-E8321-MS					
Group: D	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	HNO3	Enter Number of Bottles Sent to Lab _____
	W-ICP					
	W-ICPMS					
Group: D	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab _____
	W-NH3					
	W-NO2NO3					
	W-S-A-TP					
	W-TKN					
	W-TOC					
Group: D	Bottle Type:	P-125ML	# of Bottles: 2	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab _____
	W-PO4-F					

Date of Request: 14-JAN-2019
 Created By: SEWELL_M On: 14-JAN-2019
 Modified By: WATTS_J On: 14-JAN-2019
 Customer: SE-DIST
 Project: SMP
 Division:
 District: Southeast District
 Sampling Event: SMP- Fort Lauderdale

Send Coolers To:

Phone: (772) 4485883
 FL Dept. of Environmental Protection
 2199 South Rock Road
 Fort Pierce, FL 34945
 Attn: Matthew Sewell

Send Final Report To:

FL Dept. of Environmental Protection
 2199 South Rock Road
 Fort Pierce, FL 34945
 Attn: Matthew Sewell

Program Module Number:
 Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 14-JAN-2019
 Biology Request Reviewed By: JASROTIA_P On: 14-JAN-2019
 Sampling Kit Required: YES Ship on: 17-JAN-2019
 Sampling Kit Shipped: YES On: 17-JAN-2019
 Sampling Kit Packed By: REYNOLDS_T
 Preservatives Needed: NO
 Date to Receive Samples: 21-JAN-2019
 Received By:

Report Type: Final Only
 FTP Data: NO
 QC Report: YES
 Date Log: NO
 Authorization Log: NO

Comments: Sampler Notes:
 Bottle Group A: G4SE0037
 Bottle Group B: G4SEB064; G4SE0085
 Bottle Group C: G4SE0121; G4SE0113
 Bottle Group D: G4SE0106; Field Replicate

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-BR-IC	Template: DEFAULT	(EPA 300.0) Bromide in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 2 Samples:

Bottle Type: BG-500ML	Number of Bottles: 6	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization
W-PCL-SQ-R	Template: DEFAULT	(EPA 8270D) Organochlorine pesticides in water matrices by GC/MS-SIM
Bottle Type: BG-500ML	Number of Bottles: 2	Preserved With: ICE
W-E8321-DI	Template:	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Bottle Group B (Water) With 2 Samples:

Bottle Type: BG-500ML	Number of Bottles: 2	Preserved With: ICE
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: HNO3
W-ICP	Template: S-METALS	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Iron		
Manganese		
Zinc		
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
Aluminum		
Antimony		
Arsenic		
Cadmium		
Chromium		
Copper		
Lead		
Nickel		
Selenium		
Silver		
Thallium		
Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 2	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
Bottle Type: BG-1L	Number of Bottles: 6	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270D) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS
Bottle Type: P-1L	Number of Bottles: 2	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-BR-IC	Template: DEFAULT	(EPA 300.0) Bromide in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 2	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: QPCR-P-500ML	Number of Bottles: 2	Preserved With: ICE
PCR-FILTER	Template: DEFAULT	(SOP-PCR-4.0) Preparation of Samples by Filtration and held for qPCR Analysis
Bottle Type: P-250ML-WI-THI	Number of Bottles: 2	Preserved With: ICE
SE-PCE-ENQ	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method by Pace Analytical Services in Pompano Beach
Bottle Type: BG-500ML	Number of Bottles: 2	Preserved With: CH2ClCOOH Pre-Preserved
W-CARB-AA	Template: DEFAULT	(EPA 8321B) Carbamates in water matrices by HPLC/MS/MS

Bottle Group C (Water) With 2 Samples:

Bottle Type: QPCR-P-500ML	Number of Bottles: 2	Preserved With: ICE
PCR-FILTER	Template: DEFAULT	(SOP-PCR-4.0) Preparation of Samples by Filtration and held for qPCR Analysis
Bottle Type: P-250ML-WI-THI	Number of Bottles: 2	Preserved With: ICE
SE-PCE-ENQ	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method by Pace Analytical Services in Pompano Beach
Bottle Type: BG-500ML	Number of Bottles: 2	Preserved With: ICE
W-E8321-DI	Template:	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Bottle Group D (Water) With 2 Samples:

Bottle Type: P-1L	Number of Bottles: 2	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L

Bottle Group D (Water) With 2 Samples:

Bottle Type: P-1L		Number of Bottles: 2	Preserved With: ICE
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices	
W-BR-IC	Template: DEFAULT	(EPA 300.0) Bromide in aqueous matrices	
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)	
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample	
Bottle Type: BP-1L		Number of Bottles: 2	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry	
Bottle Type: QPCR-P-500ML		Number of Bottles: 2	Preserved With: ICE
PCR-FILTER	Template: DEFAULT	(SOP-PCR-4.0) Preparation of Samples by Filtration and held for qPCR Analysis	
Bottle Type: P-250ML-WI-THI		Number of Bottles: 2	Preserved With: ICE
SE-PCE-ENQ	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method by Pace Analytical Services in Pompano Beach	
Bottle Type: BG-500ML		Number of Bottles: 2	Preserved With: ICE
W-E8321-DI	Template:	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS	
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS	
Bottle Type: P-500ML		Number of Bottles: 2	Preserved With: HNO3
W-ICP	Template: S-METALS	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects	
Iron			
Manganese			
Zinc			
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects	
Aluminum			
Antimony			
Arsenic			
Cadmium			
Chromium			
Copper			
Lead			
Nickel			
Selenium			
Silver			
Thallium			
Bottle Type: P-500ML		Number of Bottles: 2	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L	
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L	
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L	
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices	
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices	
Bottle Type: P-125ML		Number of Bottles: 2	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L	

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.

