

RQ- 2020-07-06-58

Login Checklist

Login Station ID: #2

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 7/10/2020 10:50

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
					Yes	No	Yes	No	
2.3 3.9		HNO ₃	Formalin	104		✓			1278 4014 8540 1278 4014 8539
						✓			

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 °C (above 10.0 °C for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No ☐

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes ☐ No ☒

CONTAINER CHECK

Evidence Tape on Bottles?

Yes ☐ No ☐ NA ☒Evidence Tape intact? Yes ☐ No ☐

If Criminal, photographs taken?

Yes ☐ No ☐Containers intact? Yes ☒ No ☐

Caps on tight?

Yes ☒ No ☐

Sufficient Sample Volume:

Yes ☒ No ☐If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ☐ No ☒ Init: IM

Chlorine detected? (One container checked per Field ID)

Yes ☐ No ☐ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes ☒ No ☐ NA ☐ Init: IM

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes ☐ No ☐ NA ☒ Init: IM

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: IM

Date: 7/10/2020

Event contains NCRs (Y/N)? ☒

Event ID:

Perdido Run

NW-DIST-2020-07-10-01 (SMP)

Page 1 of 2, 06/1

Date Received: 10-JUL-2020 10:50

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Infrared Thermometer ID:	IR TEMP GUN #2 exp: 11/5/20
pH Test Strips 0 – 6	
pH Paper 0 – 3	
pH Paper 0 – 13	231019 exp: 11/1/22
Chlorine Test Strips	8261 exp: 07/2021

Additional Comments:

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Perdido Run

Central Laboratory Submittal Form

last revised Jan 25, 2018

Customer: NW-DIST

Requester: Michael King

Field Report Prepared By: F. Butler

Project ID: SMP

Collected By: Stephen Slade, Frank Butler

Sampling Agency: FL DEP. NW ROC

Location		Field/WIN ID →				☐ Comp ☒ Grab		Collection (comp begin or grab)		☒ Eastern ☒ Central		Composite end		Bottle Group(s)	
Field ID		Location:		G5NW0153		Date		Time		Date		Time		(See pg 2)	
WIN/STORE		Bridge Creek near Bridge Creek Landing				Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☒ mg/L ☐ % sat		Total Res. Chlorine (mg/L)		B	
Latitude						Temp (C)		pH		Sample Depth		☐ ft ☒ m		Sp. Conductance (umho/cm)	
						Salinity (ppt)		Comments							
						4.35		Enterococci only.							
Location		Field/WIN ID →				☐ Comp ☒ Grab		Collection (comp begin or grab)		☒ Eastern ☒ Central		Composite end		Bottle Group(s)	
Field ID		Location:		G5NW0129		Date		Time		Date		Time		A	
WIN/STORE		Bridge Creek (Tidal Portion)				Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☒ mg/L ☐ % sat		Total Res. Chlorine (mg/L)			
Latitude						Temp (C)		pH		Sample Depth		☐ ft ☒ m		Sp. Conductance (umho/cm)	
						28.2		6.18		0.3				6970	
						Salinity (ppt)		Comments							
						3.56									
Location		Field/WIN ID →				☐ Comp ☒ Grab		Collection (comp begin or grab)		☒ Eastern ☒ Central		Composite end		Bottle Group(s)	
Field ID		Location:		G5NW0158		Date		Time		Date		Time		C	
WIN/STORE		Weekly Bayou Near Mouth				Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☒ mg/L ☐ % sat		Total Res. Chlorine (mg/L)			
Latitude						Temp (C)		pH		Sample Depth		☐ ft ☒ m		Sp. Conductance (umho/cm)	
						29.5		6.79		0.3				19175	
						Salinity (ppt)		Comments							
						11.32									
Location		Field/WIN ID →				☐ Comp ☒ Grab		Collection (comp begin or grab)		☒ Eastern ☒ Central		Composite end		Bottle Group(s)	
Field ID		Location:		G5NW0157		Date		Time		Date		Time		D	
WIN/STORE		Weekly Bayou Middle Portion				Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☒ mg/L ☐ % sat		Total Res. Chlorine (mg/L)			
Latitude						Temp (C)		pH		Sample Depth		☐ ft ☒ m		Sp. Conductance (umho/cm)	
						29.9		6.19		0.3				16100	
						Salinity (ppt)		Comments							
						9.34									

Relinquished By:	Date/Time	Shipping Method	Number of Coolers Shipped:	Received By:	Date/Time
F. Butler	07/09/2020	Fed Ex	2	IM	7/10/20 10:50

Group: A	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	ALKALINITY TURBIDITY W-BR-IC W-F W-TSS						
Group: A	Bottle Type:	BP-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	CHLSUITE-W						
Group: A	Bottle Type:	P-250ML-WO-THI	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	ENT-24-QT						
Group: A	Bottle Type:	BG-500ML	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	W-E8321-DI W-E8321-MS						
Group: A	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	1
	W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC						
Group: A	Bottle Type:	P-125ML	# of Bottles: 1	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab	1
	W-PO4-F						
Group: B	Bottle Type:	P-250ML-WO-THI	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	ENT-24-QT						
Group: C	Bottle Type:	P-1L	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2
	ALKALINITY TURBIDITY W-BR-IC W-F W-TSS						
Group: C	Bottle Type:	BP-1L	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2
	CHLSUITE-W						
Group: C	Bottle Type:	P-250ML-WO-THI	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2 (FB)

Perdido Run

Central Laboratory Submittal Form

last revised Jan 25, 2018

Customer: NW-DIST

Requester: Michael King

Field Report Prepared By: Frank Butera

Project ID: SMP

Collected By: Stephen Slade, Frank Butera

Sampling Agency: FL DEP, NWROC

Location		☐ Comp ☒ Grab		Collection (comp begin or grab) Date 07/09/2020 Time 11:40		Eastern ☐ Central ☒		Composite end Date Time		Bottle Group(s) (See pg 2)	
Field ID	Field/WIN ID →	Barcode		Matrix (type, e.g., Salt, Fresh, etc) Salt Surface		Diss. Oxygen 6.64		☒ mg/L ☐ % sat		Total Res. Chlorine (mg/L)	
WIN/STORET	Location:	G5NW0152		Temp (C) 29.8		pH 7.48		Sample Depth 0.3		Sp. Conductance (umho/cm) 257.44	
Latitude	Bayou Garcon	☐ dms		Salinity (ppt) 15.59		Comments					
Location		☐ Comp ☒ Grab		Collection (comp begin or grab) Date 07/09/2020 Time 11:10		Eastern ☐ Central ☒		Composite end Date Time		Bottle Group(s)	
Field ID	Field/WIN ID →	Barcode		Matrix (type, e.g., Salt, Fresh, etc) D.I. Water		Diss. Oxygen		☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)	
WIN/STORET	Location:	FB_07092020		Temp (C)		pH		Sample Depth		Sp. Conductance (umho/cm)	
Latitude	Bayou Garcon	☐ dms		Salinity (ppt)		Comments		Field Blank			
Location		☐ Comp ☐ Grab		Collection (comp begin or grab) Date Time		Eastern ☐ Central ☐		Composite end Date Time		Bottle Group(s)	
Field ID				Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)	
WIN/STORET #				Temp (C)		pH		Sample Depth		Sp. Conductance (umho/cm)	
Latitude	☐ dd ☐ dms	Longitude		☐ dd ☐ dms		Salinity (ppt)		Comments			
Location		☐ Comp ☐ Grab		Collection (comp begin or grab) Date Time		Eastern ☐ Central ☐		Composite end Date Time		Bottle Group(s)	
Field ID				Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)	
WIN/STORET #				Temp (C)		pH		Sample Depth		Sp. Conductance (umho/cm)	
Latitude	☐ dd ☐ dms	Longitude		☐ dd ☐ dms		Salinity (ppt)		Comments			

Relinquished By:	Date/Time	Shipping Method	Number of Coolers Shipped:	Received By: IM	Date/Time 7/10/20 10:50
------------------	-----------	-----------------	----------------------------	-----------------	-------------------------

Group: A	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	ALKALINITY TURBIDITY W-BR-IC W-F W-TSS					
Group: A	Bottle Type:	BP-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	CHLSUITE-W					
Group: A	Bottle Type:	P-250ML-WO-THI	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	ENT-24-QT					
Group: A	Bottle Type:	BG-500ML	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	W-E8321-DI W-E8321-MS					
Group: A	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab _____
	W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC					
Group: A	Bottle Type:	P-125ML	# of Bottles: 1	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab _____
	W-PO4-F					
Group: B	Bottle Type:	P-250ML-WO-THI	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	ENT-24-QT					
Group: C	Bottle Type:	P-1L	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	ALKALINITY TURBIDITY W-BR-IC W-F W-TSS					
Group: C	Bottle Type:	BP-1L	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	CHLSUITE-W					
Group: C	Bottle Type:	P-250ML-WO-THI	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____

Group: C	Bottle Type: P-250ML-WO-THI ENT-24-QT	# of Bottles: 3	Preservative: ICE	Enter Number of Bottles Sent to Lab	2
Group: C	Bottle Type: P-500ML W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC	# of Bottles: 3	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab	2
Group: C	Bottle Type: P-125ML W-PO4-F	# of Bottles: 3	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab	2
Group: D	Bottle Type: P-1L ALKALINITY TURBIDITY W-BR-IC W-F W-TSS	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	1
Group: D	Bottle Type: BP-1L CHLSUITE-W	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	1
Group: D	Bottle Type: P-500ML W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab	1
Group: D	Bottle Type: P-125ML W-PO4-F	# of Bottles: 1	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab	1
Group: E	Bottle Type: P-1L ALKALINITY TURBIDITY W-BR-IC W-F W-TSS	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	1
Group: E	Bottle Type: P-500ML	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab	1 (76)

Group: E	Bottle Type:	P-500ML	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab	<u>1</u>
	W-NH3					
	W-NO2NO3					
	W-S-A-TP					
	W-TKN					
	W-TOC					

Group: E	Bottle Type:	P-125ML	# of Bottles: 1	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab	<u>1</u>
	W-PO4-F					

Date of Request: 24-JUN-2020
 Created By: KING_M On: 24-JUN-2020
 Modified By: JASROTIA_P On: 30-JUN-2020
 Customer: NW-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Northwest District
 Event Description: Perdido Run

Send Coolers To:

Phone: 850-595-0605
 160 Government Center
 Suite 208A
 Pensacola, FL 32502-5794
 Attn: Michael King
 Cooler Ship EMail: michael.king@dep.state.fl.us

Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 30-JUN-2020
 Biology Request Reviewed By: JASROTIA_P On: 30-JUN-2020
 Sampling Kit Required: YES Ship on: 02-JUL-2020
 Sampling Kit Shipped: YES On: 02-JUL-2020
 Sampling Kit Packed By: SHAIK_A
 Preservatives Needed: NO
 Date to Receive Samples: 09-JUL-2020
 Logged In By:

Send Final Report To:

160 Government Center
 Suite 208
 Pensacola, FL 32502-5794
 Attn: Cheryl Bunch
 Report Notification EMail:
 michael.king@dep.state.fl.us;cheryl.bunch@dep.state.fl.us

Comments: Group A: (WBID 872B) Marine: Nutrients, Tracers,
 Contract Lab Bacteria

Group B: (WBID 872B) Marine: Bacteria

Group C: (WBID 935, 987) Marinewater
 Nutrients, Contract Lab Bacteria

Group D: (WBID 935) Marine: Nutrients

Group E: (WBID Field Blank)

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-BR-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Bromide in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahi Nitrogen in aqueous matrices

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems

Bottle Group C (Water) With 3 Samples:

Bottle Type: P-250ML-WO-THI	Number of Bottles: 3	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems
Bottle Type: P-500ML	Number of Bottles: 3	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 3	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
Bottle Type: P-1L	Number of Bottles: 3	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-BR-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Bromide in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 3	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Bottle Group D (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-BR-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Bromide in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group E (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-BR-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Bromide in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L

Bottle Group E (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.