

Login Checklist

RQ- 2021-07-12-56

Login Station ID: #5

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 7/ 14 /21 @ 9:20

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
-0.9				7		✓			9293 8013 0355
2.2				5		✓			9293 8013 0575

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included? Yes ☒ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes _____ No ☒

CONTAINER CHECK

Evidence Tape on Bottles? Yes _____ No _____ NA ☒ Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken? Yes _____ No _____ Containers intact? Yes ☒ No _____

Caps on tight? Yes ☒ No _____

Sufficient Sample Volume: Yes ☒ No _____

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container) Yes ☒ No _____ Init: KK

Chlorine detected? (One container checked per Field ID) Yes _____ No ☒ Init: KK

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0? Yes ☒ No _____ NA _____ Init: KK

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes _____ No _____ NA ☒ Init: KK

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: KK Date: 7/ 14 /21 Event contains NCRs (Y/N)? N

Event ID: Volusia Blue Spring
CEN-DIST-2021-07-14-01 (SMP)
Date Received: 14-JUL-2021 09:20

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #5 EXP:10-28-21
pH Test Strips 0 – 6	Lot#210620 EXP:4-15-23
pH Paper 0 – 3	
pH Paper 0 – 13	Lot#210620 EXP:4-15-23
Chlorine Test Strips	Lot#0261 EXP:5-23

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 7/13/2021
Customer: CEN-DIST
RQ: RQ-2021-07-12-56
Collected By: Elizabeth Bates, Matt Bearden
Sampling Agency: FDEP
Project ID: SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB


Number of Coolers Shipped: 2

Delivery Method: FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
Volusia Blue Spring near vent	 G2CE0242

RELINQUISHED BY(SIGNATURE):



DATE/TIME: 7/13/2021
1600 EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By: *WV*

Rec'd/Inspected

Date: 7-14-21/0920



RQ-2021-07-12-56

Collected By: Elizabeth Bates, Matt Bearden

Customer: FDEP

Field Report Prepared by: Elizabeth Bates, Matt Bearden

Project ID: SMP

Sampling Agency: FDEP

WIN ID/Field ID:



WIN ID/Field ID: G2CE0242

Comments:

total depth/secchi estimated (J)

bottom depth reading at max cord length

Location:

Location: Volusia Blue Spring near vent

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT)
7/13/2021 920	0.43	5	23.3	7.17	0.3	10 (J)	38 (J)	1413	0.71

Parameter Suite	Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group							
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	X	<2	1	A					
		Lot # SA1105060		Exp:	4/30/22												
Metals (P-500ML)		W-ICPMS		W-ICP		Ice		HNO3*		<2							
		Lot #		Exp:													
Filtered Nutrients (P125ML)	X	W-PO4-F		Field Filtered 0.45 um Filter		X	Ice				1	A					
		Filter Lot #		17135566													
		Syringe Lot #		1091364													
Chlorophyll (BP-1L)	X	CHLSUITE-W				X	Ice							1	A		
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-CL-IC / W-COLOR / W-SO4-IC / W-TDS				X	Ice							1	A		
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY					Ice										
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #										Formalin				
Periphyton (PT-50ML)		ALGAE-ID					Ice										
Microbiology (Contract Lab Bottle)		E Coli		F Coli	Enterococci		Ice										
		Contract Lab															
Molecular (QPCR-P-500ML)		PCR-HF183		PCR-BacR	PCR-DG3		Ice										
		PCR-GULL2		PCR-GFD													
Tracers (BG-500ML)		W-E8321-DI		W-E8321-MS			Ice										
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI	W-E8321-MS		X	W-PSNP-TQ	X	Ice		8	A						
	X	W-PCL-TQ-R	W-CARB-AA (5 ml of MCAA** Buffer Solution)		X	W-CT-CL-R											
Phytoplankton		DTY-QN-C		PKD-QN-BV			Ice										

Date of Request: 12-JUL-2021
 Created By: BOMAN_L On: 12-JUL-2021
 Modified By: JASROTIA_P On: 13-JUL-2021
 Customer: CEN-DIST
 Project: SMP
 Division:
 District: Central District
 Event Description: Volusia Blue Spring

Send Coolers To:

Phone: 407-897-4181
 FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Leif Boman
 Cooler Ship EMail: Leif.Boman@FloridaDEP.gov

Priority: 3
 Event Status: A
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 12-JUL-2021
 Biology Request Reviewed By: JASROTIA_P On: 13-JUL-2021
 Sampling Kit Required: NO Ship on:
 Sampling Kit Shipped:
 Sampling Kit Packed By:
 Preservatives Needed: NO
 Date to Receive Samples: 12-JUL-2021
 Logged In By:

Send Final Report To:

3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Matt Bearden
 Report Notification EMail: Matthew.Bearden@FloridaDEP.gov

Comments:**Bottle Group A (Water) With 1 Samples:**

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: BG-500ML	Number of Bottles: 4	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization
W-PCL-TQ-R	Template: DEFAULT	(EPA 8270E) Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO ₄ -F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
Bottle Type: BG-1L	Number of Bottles: 4	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.