

Login Checklist

RQ- 2021-03-15-44

Login Station ID: #5

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 3/ 16 /21 @ 10:40

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
1.1				13		✓			9293 8009 3441

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No ☒

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA ☒

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes ☒ No _____

Containers intact? Yes ☒ No _____

Caps on tight?

Yes ☒ No _____

Sufficient Sample Volume:

Yes ☒ No _____

If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ☒ No ☒ Init: KK

Chlorine detected? (One container checked per Field ID)

Yes _____ No ☒ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH< 2.0?

Yes _____ No _____ NA ☒ Init: KK

**W-1-4-DIOX (Green dot on container) preserved to pH<4.0?

Yes _____ No _____ NA ☒ Init: KK

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: KK

Date: 3/ 16 /21

Event contains NCRs (Y/N)? N

SMP - 3205B pickup

EventID: SE-DIST-2021-03-16-04 (SMP)

Date Received: 16-MAR-2021 10:40

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #5
pH Test Strips 0 – 6	
pH Paper 0 – 3	
pH Paper 0 – 13	Lot#210620 EXP:4-15-23
Chlorine Test Strips	Lot#0261 EXP:5-23

EXP:10-28-21

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 3/15/2021
Customer: _____
RQ: RQ-RQ-2021-03-15-44

Collected By: Jordan Skaggs, Drew Liddick
Sampling Agency: FDEP
Project ID: SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
Taylor Creek @ 70	 G1SE0011

RELINQUISHED BY(SIGNATURE):

DATE/TIME:

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By: KK

Rec'd/Inspected Date: 3-16-21/1040



RQ-RQ-2021-03-15-44

Customer: FDEP

Project ID: SMP

Collected By: Jordan Skaggs, Drew Liddick

Field Report Prepared by: Jordan Skaggs, Drew Liddick

Sampling Agency: FDEP

Comments:

WIN ID/Field ID:

WIN ID/Field ID: G1SE0011

Location: Taylor Creek @ 70

Matrix: Fresh

(Check One) ☒ Grab ☐ Composite

Date and Time	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT)				
3/15/2021 1130	7.1	83.2	23.2	7.44	0.3	0.6	1	607	0.29				
Central Lab please use top row for login purposes													
Parameter Suite	Parameter Methods					Preservation		pH Check	# Bottles sent to Lab	Bottle Group			
Preserved Nutrients (P-500ML)	X W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP Lot # SA0353110 Exp: 011122					X	Ice	X	H2SO4*	X	<2	1	A
Metals (P-500ML)	W-ICPMS W-ICP W-HARD Lot # Exp:						Ice		HNO3*		<2		
Filtered Nutrients (P125ML)	X W-PO4-F X Field Filtered 0.45 µm Filter Filter Lot # Syringe Lot #					X	Ice					1	A
Chlorophyll (BP-1L)	X CHLSUITE-W					X	Ice					1	A
Physical/Aggregate (Fresh) (P-1L)	X Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W-TDS					X	Ice					1	A
Physical/Aggregate (Marine) (P-1L)	Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY						Ice						
Macroinvertebrates (PJ-2L)	MI-FW-QLDC						Ice						
Periphyton (PT-50ML)	ALGAE-ID						Ice						
Microbiology (Contract Lab Bottle)	X E Coli F Coli Enterococci Contract Lab					X	Ice					1	A
Molecular (QPCR-P-500ML)	X PCR-HF183 X PCR-BacR X PCR-DG3 PCR-GULL2 PCR-GFD					X	Ice					1	A
Tracers (BG-500ML)	W-E8321-DI W-E8321-MS						Ice						
Pesticides (BG-500ML) (BG-1L)	X W-E8321-DI X W-E8321-MS W-PSNP-TQ X W-PCL-SQ-R W-CARB-AA (5 ml of MCAA** Buffer Solution) X W-DIELDRIN X W-CT-CL-R					X	Ice					5	A
Phytoplankton	X DTY-QN-C X PKD-QN-BV						Ice						

Printed: 3/16/2021 12:06:21 PM

Page 1 of 2

Date of Request: 25-FEB-2021
 Created By: SKAGGS_J On: 25-FEB-2021
 Modified By: JASROTIA_P On: 12-MAR-2021
 Customer: SE-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Southeast District
 Event Description: SMP - 3205B pickup

Send Coolers To:

Phone: (772) 448-5884
 FL Dept. of Environmental Protection
 2199 South Rock Road
 Fort Pierce, FL 34945
 Attn: Jordan Skaggs
 Cooler Ship EMail: jordan.skaggs@FloridaDEP.gov

Priority: 3
 Event Status: A
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 12-MAR-2021
 Biology Request Reviewed By: JASROTIA_P On: 12-MAR-2021
 Sampling Kit Required: NO Ship on:
 Sampling Kit Shipped: YES On: 02-MAR-2021
 Sampling Kit Packed By: MCCOY_I
 Preservatives Needed: NO
 Date to Receive Samples: 16-MAR-2021
 Logged In By:

Send Final Report To:

FL Dept. of Environmental Protection
 2199 South Rock Road
 Fort Pierce, FL 34945
 Attn: Drew Liddick
 Report Notification EMail:
 drew.liddick@FloridaDEP.gov;jordan.skaggs@floridadep.gov;and
 rew.luering@floridadep.gov

Comments: Lab Comments:
 *Receiving - please log algae samples (Bottle Group B) in under separate Event, Priority 12

Group A - 3205B - G1SE0011
 Group B - 3205B - G1SE0011

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: BG-500ML	Number of Bottles: 4	Preserved With: ICE

Printed: 3/16/2021 12:06:21 PM

Bottle Group A (Water) With 1 Samples:

Bottle Type: BG-500ML	Number of Bottles: 4	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization
W-DIELDRLIN	Template: DEFAULT	(EPA 8270E) Dieldrin (ultra low level) in water matrices by GC/MS/MS
W-PCL-SQ-R	Template: DFLT-MINUS	(EPA 8270E) Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS-SIM
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 1 Samples:

Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: Lugols
DTY-QN-C	Template: DEFAULT	(SOP-AB05_1) No. of diatom taxa of quantitative phytoplankton sample.
PKD-QN-BV	Template: DEFAULT	(SOP-AB05) No. of wet taxa of quantitative phytoplankton sample w/speciation and cell counts.

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.