

Chemical Analysis Report

SE-DIST-2021-07-13-02

Florida Department of Environmental Protection
Central Laboratory
2600 Blair Stone Road
Tallahassee, FL 32399-2400
DOH Accreditation E31780

Event Description: **SMP - Stuart Deploy 1 #1**
Request ID: **RQ-2021-07-12-54**
Customer: **SE-DIST**
Project ID: **SMP**

Send Reports to:
FL Dept. of Environmental Protection
FL Dept. of Environmental Protection
2199 South Rock Road
Fort Pierce, FL 34945
Attn: Drew Liddick

For additional information please contact
Colin Wright, Ph.D.
Liang-Tsair Lin, Ph.D.
Kerry Tate, Ph.D.
Dr. rer. nat. Bettina Steinbock
Thekkekalathil Chandrasekhar, Ph.D, QA Officer
Phone (850) 245-8085

Certified by: Liang Lin, Environmental Administrator

Date Certified: 10-AUG-2021 15:41

A handwritten signature in black ink, appearing to read "Liang Lin", on a light-colored background.

Case Narrative

Unless otherwise noted, all samples included in this report were received in accordance with protocols referenced in Chapter 62-160, Florida Administrative Code (F.A.C.). Results published in this report pertain only to the samples as submitted to, and received by the laboratory. All times in this report are adjusted to the applicable Eastern Time Zone (EST or EDT).

Results for the following analytical groups are included in this report: Metals, Nutrients and Pesticides.

Scientific notation may be used in reporting very large or small values. Values reported using scientific notation will take the form of the following example: 1.3E+03, which is equivalent to 1.3×10^3 or 1300.

Unless otherwise noted, analytical values for soil and sediment samples are reported on a dry weight basis, and analytical values for waste and tissue samples are reported on a wet weight basis.

Results for TNI accredited tests met requirements established by The NELAC Institute. A double asterisk (**) is used to indicate an analyte/matrix/method for which the laboratory is not TNI accredited by the Florida Department of Health Environmental Laboratory Certification Program or where accreditation for that field of testing is not applicable.

Any significant anomalies or deviations from established protocols are documented in Non-Conformance Reports, which, where appropriate, are included within this analytical report. Additional comments related to specific analytical tests may be included as remarks following the analytical results for each sample. Such comments and remarks are for informational purposes only and are not intended to convey judgement about the usability of the reported data.

A quality control report on the performance of the test method for the submitted samples is included. Uncertainty associated with the analytical results contained in this report can be estimated from the reported quality assurance results and from published quality control acceptance limits for each analytical test. Matrix quality control results (matrix spike recoveries and matrix sample precision) pertain only to the matrix sample tested and do not necessarily reflect test method performance for other samples.

Typical matrix quality control (QC) measurements may include matrix spike recovery, matrix spike duplicate recovery, matrix spike precision and matrix sample precision. Not all matrix QC results may be available or reportable; where they are not an explanation is provided. Typical reasons for unavailable QC results include, but are not limited to, a) insufficient matrix sample to perform some or all QC measurements; b) analyte concentration in the sample replicated was too low for a meaningful measurement of precision and c) analyte concentration in the matrix sample spiked was too high (relative to the amount of analyte spiked) for a meaningful measurement of recovery. Where matrix QC results are unavailable, other method performance metrics (e.g., LCS recovery, LCS precision, surrogate recovery) may be used to assess performance of the method. Comments explaining any missing QC measurements are not intended to convey any adverse conclusions about the quality of the reported data.

Precision is reported as relative percent difference unless otherwise noted.

Quality Control codes as defined below may be used in this report to indicate results that are associated with one or more quality control elements which did not fall within established test method criteria. Such results may be qualified as estimates using a J qualifier as required by 62-160 F.A.C. Explanations are included in the report for any results that were reported as estimates for other reasons.

QC Codes used in this report may include:

- LCS – Recovery for the batch Laboratory Control Sample (LCS) was outside existing control limits;
- MS – Recovery for the batch matrix spike (MS) was outside existing control limits;
- CCV – Recovery for a continuing calibration verification (CCV) standard was outside existing control limits;
- SUR – Recovery of a surrogate (SUR) for associated analytes was outside existing control limits;
- RPD – The precision, measured as relative percent difference (RPD), of batch replicate measurements was outside existing control limits;
- RSD – The precision, measured as relative standard deviation (RSD), of batch replicate measurements was outside existing control limits;
- SMP – Sample - used precision derived from replicate analyses of a sample;

The following data qualifiers are used, where applicable, in this report as specified in 62-160 F.A.C.

- A - Value reported is the mean of two or more determinations.
- B - Results based on colony counts outside the acceptable range.
- I - The reported value is between the laboratory method detection limit and the laboratory practical quantitation limit.
- J - Estimated value and/or the analysis did not meet established quality control criteria.
- K - Actual value is known to be less than value given.
- L - Actual value is known to be greater than value given.
- N - Presumptive evidence of presence of material.
- O - Sampled, but analysis lost or not performed.
- Q - Sample held beyond normal holding time.
- T - Value reported is less than the criterion of detection.
- U - Material was analyzed for but not detected. The reported value is the method detection limit for the sample analyzed.
- V - Analyte was detected in both sample and method blank.
- X - Too few individuals to calculate SCI value.
- Y - The laboratory analysis was from an unpreserved or improperly preserved sample. The data may not be accurate.
- Z - Colonies were too numerous to count (TNTC).

Quality control information from overflow laboratories may not be included in this report. Please refer to the associated report from the overflow laboratory for additional information.

Sample Location: Roebuck Creek @ Locks

Collection Date/Time: 07/12/2021 11:00

Field ID: G2SE0029

Matrix: W-SURF-SLT

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2261517	EPA 180.1 Rev. 2.0	Turbidity	5.9	A	NTU	P400905	
	SM 2320 B-2011	Total Alkalinity	212		mg CaCO3/L	P401128	
	SM 2540 D-2011	TSS	6	I	mg/L	P401123	
	SM 4500 F-C-2011	Fluoride	0.21		mg F/L	P401131	
2261519	EPA 350.1 Rev. 2.0	Ammonia-N	0.052		mg N/L	P401331	
	EPA 351.2 Rev. 2.0	Kjeldahl Nitrogen	0.59	V	mg N/L	P402127	
	EPA 353.2 Rev. 2.0	NO2NO3-N	0.12		mg N/L	P400999	
	EPA 365.1 Rev. 2.0	Total-P	0.44		mg P/L	P401103	
	SM 5310 B-2011	Organic Carbon	11		mg C/L	P401309	
2261521	EPA 365.1 Rev. 2.0 dissolved	O-Phosphate-P	0.29		mg P/L	P400866	
2261531	EPA 8321B	2,4-D	0.0020	U	ug/L	P400846	
		Acesulfame K	0.65		ug/L	P400842	
		2,4,5-T	0.0040	U	ug/L	P400846	
		AMPA	0.10	U	ug/L	P400842	
		Acetaminophen	0.0080	U	ug/L	P400846	
		Acetamiprid	0.0020	U	ug/L	P400846	
		Endothall	0.25	U	ug/L	P400842	
		Glufosinate	0.10	U	ug/L	P400842	
		Glyphosate	0.10	U	ug/L	P400842	
		Afidopyropen	0.0020	U	ug/L	P400846	
		Bentazon	0.037		ug/L	P400846	
		Sucralose	0.72		ug/L	P400842	
		Benzovindiflupyr	0.0020	U	ug/L	P400846	
		Carbamazepine	0.0011	I	ug/L	P400846	
		Clothianidin	0.0020	U	ug/L	P400846	
		Dinotefuran	0.0020	U	ug/L	P400846	
		Diuron	0.0020	U	ug/L	P400846	
		Fenuron	0.016	U	ug/L	P400846	
		Fluridone	8.0E-04	U	ug/L	P400846	
		Imazapyr	0.13		ug/L	P400846	MS, RPD
		Hydrocodone	0.0020	U	ug/L	P400846	
		Ibuprofen	0.020	U	ug/L	P400846	
		Imidacloprid	0.0036	I	ug/L	P400846	
		Linuron	0.0040	U	ug/L	P400846	
		Mandestrobin	0.0020	U	ug/L	P400846	
		MCP	0.0020	U	ug/L	P400846	
		Naproxen	0.0080	U	ug/L	P400846	
		Primidone	0.0040	U	ug/L	P400846	
		Pyraclostrobin	0.0020	U	ug/L	P400846	
		Thiamethoxam	0.0020	U	ug/L	P400846	MS
		Tolfenpyrad	0.0020	U	ug/L	P400846	
		Triclopyr	0.0040	U	ug/L	P400846	
2261533	EPA 200.7 Rev. 4.4	Calcium	95.2		mg/L	P400847	

Field ID: G2SE0029

Matrix: W-SURF-SLT

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2261533	EPA 200.7 Rev. 4.4	Iron	730		ug/L	P400847	
		Magnesium	3.38		mg/L	P400847	
		Manganese	43.1		ug/L	P400847	
		Zinc	14	I	ug/L	P400847	
	EPA 200.8 Rev. 5.4	Aluminum	71		ug/L	P400847	
		Antimony	0.050	U	ug/L	P400847	
		Arsenic	0.98		ug/L	P400847	
		Beryllium	0.014	I	ug/L	P400847	
		Cadmium	0.020	U	ug/L	P400847	
		Chromium	0.40	U	ug/L	P400847	
		Copper	0.61	I	ug/L	P400847	
		Lead	0.25	I	ug/L	P400847	
		Nickel	0.50	U	ug/L	P400847	
		Selenium	0.20	U	ug/L	P400847	
		Silver	0.010	U	ug/L	P400847	
		Thallium	0.10	U	ug/L	P400847	

Ref. Method and Comment:
EPA 351.2 Rev. 2.0: Analyte was detected above the MDL in both the method blank and sample.

Sample Location: South Fork SLR @ Hosford Park

Collection Date/Time: 07/12/2021 11:40

Field ID: G2SE0043

Matrix: W-SURF-SLT

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2261518	EPA 180.1 Rev. 2.0	Turbidity	9.5		NTU	P400905	
	SM 2320 B-2011	Total Alkalinity	204		mg CaCO3/L	P401128	
	SM 2540 D-2011	TSS	12	A	mg/L	P401123	
	SM 4500 F-C-2011	Fluoride	0.24		mg F/L	P401131	
2261520	EPA 350.1 Rev. 2.0	Ammonia-N	0.023		mg N/L	P401331	
	EPA 351.2 Rev. 2.0	Kjeldahl Nitrogen	0.98	V	mg N/L	P402127	
	EPA 353.2 Rev. 2.0	NO2NO3-N	0.019		mg N/L	P400999	
	EPA 365.1 Rev. 2.0	Total-P	0.20		mg P/L	P401180	
	SM 5310 B-2011	Organic Carbon	14		mg C/L	P401309	
2261522	EPA 365.1 Rev. 2.0 dissolved	O-Phosphate-P	0.11		mg P/L	P400866	
2261532	EPA 8321B	2,4-D	0.12		ug/L	P400846	
		Acesulfame K	0.10	U	ug/L	P400842	
		2,4,5-T	0.0040	U	ug/L	P400846	
		AMPA	0.45		ug/L	P400842	
		Acetaminophen	0.0080	U	ug/L	P400846	
		Acetamiprid	0.0020	U	ug/L	P400846	
		Endothall	0.25	U	ug/L	P400842	
		Glufosinate	0.10	U	ug/L	P400842	
		Glyphosate	2.2		ug/L	P400842	
		Afidopyropen	0.0020	U	ug/L	P400846	
		Bentazon	0.012		ug/L	P400846	
		Sucralose	0.12		ug/L	P400842	
		Benzovindiflupyr	0.0020	U	ug/L	P400846	
		Carbamazepine	8.0E-04	U	ug/L	P400846	
		Clothianidin	0.0069	I	ug/L	P400846	
		Dinotefuran	0.0020	U	ug/L	P400846	
		Diuron	0.0058	I	ug/L	P400846	
		Fenuron	0.016	U	ug/L	P400846	
		Fluridone	0.0041		ug/L	P400846	
		Imazapyr	0.91		ug/L	P400846	MS, RPD
		Hydrocodone	0.0020	U	ug/L	P400846	
		Ibuprofen	0.020	U	ug/L	P400846	
		Imidacloprid	0.0075	I	ug/L	P400846	
		Linuron	0.0040	U	ug/L	P400846	
		Mandestrobin	0.0020	U	ug/L	P400846	
		MCP	0.0020	U	ug/L	P400846	
		Naproxen	0.0080	U	ug/L	P400846	
		Primidone	0.0040	U	ug/L	P400846	
		Pyraclostrobin	0.0020	U	ug/L	P400846	
		Thiamethoxam	0.0059	I	ug/L	P400846	MS
		Tolfenpyrad	0.0020	U	ug/L	P400846	
		Triclopyr	0.0040	U	ug/L	P400846	
2261534	EPA 200.7 Rev. 4.4	Calcium	99.0		mg/L	P400847	

Field ID: G2SE0043

Matrix: W-SURF-SLT

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2261534	EPA 200.7 Rev. 4.4	Iron	260		ug/L	P400847	
		Magnesium	51.4		mg/L	P400847	
		Manganese	40.4		ug/L	P400847	
		Zinc	10	I	ug/L	P400847	
	EPA 200.8 Rev. 5.4	Aluminum	148		ug/L	P400847	
		Antimony	0.066	I	ug/L	P400847	
		Arsenic	3.47		ug/L	P400847	
		Beryllium	0.014	I	ug/L	P400847	
		Cadmium	0.020	U	ug/L	P400847	
		Chromium	0.59	I	ug/L	P400847	
		Copper	2.51		ug/L	P400847	
		Lead	0.27	I	ug/L	P400847	
		Nickel	0.50	U	ug/L	P400847	
		Selenium	0.20	U	ug/L	P400847	
		Silver	0.010	U	ug/L	P400847	
		Thallium	0.10	U	ug/L	P400847	

Ref. Method and Comment:
EPA 351.2 Rev. 2.0: Analyte was detected above the MDL in both the method blank and sample.

Quality Assurance Report Method Blank Results

Reference Method: EPA 180.1 Rev. 2.0
Batch ID: P400905

Component	Result	Code	Units
Turbidity	0.10	U	NTU

Reference Method: EPA 200.7 Rev. 4.4
Batch ID: P400847

Component	Result	Code	Units
Calcium	0.075	U	mg/L
Iron	30	U	ug/L
Magnesium	0.040	U	mg/L
Manganese	1.0	U	ug/L
Zinc	5.0	U	ug/L

Reference Method: EPA 200.8 Rev. 5.4
Batch ID: P400847

Component	Result	Code	Units
Aluminum	5.0	U	ug/L
Antimony	0.050	U	ug/L
Arsenic	0.050	U	ug/L
Beryllium	0.010	U	ug/L
Cadmium	0.020	U	ug/L
Chromium	0.40	U	ug/L
Copper	0.40	U	ug/L
Lead	0.20	U	ug/L
Nickel	0.50	U	ug/L
Selenium	0.20	U	ug/L
Silver	0.010	U	ug/L
Thallium	0.10	U	ug/L

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P401331

Component	Result	Code	Units
Ammonia-N	0.002	U	mg N/L

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P402127

Component	Result	Code	Units
Kjeldahl Nitrogen	0.11	I	mg N/L

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P400999

Component	Result	Code	Units
NO2NO3-N	0.004	U	mg N/L

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P401103

Component	Result	Code	Units
Total-P	0.002	U	mg P/L

Quality Assurance Report Method Blank Results

Reference Method: EPA 365.1 Rev. 2.0

Batch ID: P401180

Component	Result	Code	Units
Total-P	0.002	U	mg P/L

Reference Method: EPA 365.1 Rev. 2.0 dissolved

Batch ID: P400866

Component	Result	Code	Units
O-Phosphate-P	0.004	U	mg P/L

Reference Method: EPA 8321B

Batch ID: P400842

Component	Result	Code	Units
Acesulfame K	0.10	U	ug/L
AMPA	0.10	U	ug/L
Endothall	0.25	U	ug/L
Glufosinate	0.10	U	ug/L
Glyphosate	0.10	U	ug/L
Sucralose	0.010	U	ug/L

Reference Method: EPA 8321B

Batch ID: P400846

Component	Result	Code	Units
2,4-D	0.0020	U	ug/L
2,4,5-T	0.0040	U	ug/L
Acetaminophen	0.0080	U	ug/L
Acetamiprid	0.0020	U	ug/L
Afidopyropen	0.0020	U	ug/L
Bentazon	8.0E-04	U	ug/L
Benzovindiflupyr	0.0020	U	ug/L
Carbamazepine	8.0E-04	U	ug/L
Clothianidin	0.0020	U	ug/L
Dinotefuran	0.0020	U	ug/L
Diuron	0.0020	U	ug/L
Fenuron	0.016	U	ug/L
Fluridone	8.0E-04	U	ug/L
Hydrocodone	0.0020	U	ug/L
Ibuprofen	0.020	U	ug/L
Imazapyr	0.0040	U	ug/L
Imidacloprid	0.0020	U	ug/L
Linuron	0.0040	U	ug/L
Mandestrobin	0.0020	U	ug/L
MCPP	0.0020	U	ug/L
Naproxen	0.0080	U	ug/L
Primidone	0.0040	U	ug/L
Pyraclostrobin	0.0020	U	ug/L
Thiamethoxam	0.0020	U	ug/L
Tolfenpyrad	0.0020	U	ug/L
Triclopyr	0.0040	U	ug/L

Quality Assurance Report

Method Blank Results

Reference Method: SM 2320 B-2011
Batch ID: P401128

Component	Result	Code	Units
Total Alkalinity	0.65	U	mg CaCO ₃ /L

Reference Method: SM 2540 D-2011
Batch ID: P401123

Component	Result	Code	Units
TSS	2	U	mg/L

Reference Method: SM 4500 F-C-2011
Batch ID: P401131

Component	Result	Code	Units
Fluoride	0.035	U	mg F/L

Reference Method: SM 5310 B-2011
Batch ID: P401309

Component	Result	Code	Units
Organic Carbon	0.50	U	mg C/L

Quality Assurance Report Laboratory Control Sample Accuracy

Reference Method: EPA 200.7 Rev. 4.4
Batch ID: P400847

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Calcium	106		P	85 - 115
Iron	109		P	85 - 115
Magnesium	112		P	85 - 115
Manganese	101		P	85 - 115
Zinc	105		P	85 - 115

Reference Method: EPA 200.8 Rev. 5.4
Batch ID: P400847

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Aluminum	108		P	85 - 115
Antimony	112		P	85 - 115
Arsenic	105		P	85 - 115
Beryllium	110		P	85 - 115
Cadmium	111		P	85 - 115
Chromium	103		P	85 - 115
Copper	96.7		P	85 - 115
Lead	104		P	85 - 115
Nickel	95.8		P	85 - 115
Selenium	112		P	85 - 115
Silver	104		P	85 - 115
Thallium	111		P	85 - 115

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P401331

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Ammonia-N	99.0		P	90 - 110

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P402127

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Kjeldahl Nitrogen	98.1		P	90 - 110

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P400999

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
NO2NO3-N	102		P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P401103

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Total-P	107		P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P401180

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Total-P	105		P	90 - 110

Quality Assurance Report Laboratory Control Sample Accuracy

Reference Method: EPA 365.1 Rev. 2.0 dissolved
Batch ID: P400866

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
O-Phosphate-P	100		P	90 - 110

Reference Method: EPA 8321B
Batch ID: P400842

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Acesulfame K	103		P	40 - 150
AMPA	97.5		P	40 - 150
Endothall	97.5		P	40 - 150
Glufosinate	97.7		P	40 - 150
Glyphosate	97.0		P	40 - 150
Sucralose	102		P	40 - 150

Reference Method: EPA 8321B
Batch ID: P400846

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2,4-D	110		P	30 - 160
2,4,5-T	108		P	30 - 160
Acetaminophen	79.9		P	30 - 160
Acetamiprid	83.6		P	30 - 160
Afidopyropen	63.4		P	30 - 160
Bentazon	98.7		P	30 - 160
Benzovindiflupyr	89.1		P	30 - 160
Carbamazepine	99.5		P	30 - 160
Clothianidin	93.4		P	30 - 160
Dinotefuran	92.3		P	30 - 160
Diuron	88.5		P	30 - 160
Fenuron	99.4		P	30 - 160
Fluridone	94.9		P	30 - 160
Hydrocodone	95.5		P	30 - 160
Ibuprofen	91.9		P	30 - 160
Imazapyr	91.8		P	30 - 160
Imidacloprid	91.1		P	30 - 160
Linuron	80.9		P	30 - 160
Mandestrobin	91.5		P	30 - 160
MCPP	110		P	30 - 160
Naproxen	81.0		P	30 - 160
Primidone	93.9		P	30 - 160
Pyraclostrobin	84.4		P	30 - 160
Thiamethoxam	98.9		P	30 - 160
Tolfenpyrad	42.3		P	30 - 160
Triclopyr	108		P	30 - 160

Reference Method: SM 2320 B-2011
Batch ID: P401128

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Total Alkalinity	101		P	94 - 106

Quality Assurance Report

Laboratory Control Sample Accuracy

Reference Method: SM 4500 F-C-2011
Batch ID: P401131

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Fluoride	97.6		P	93 - 104

Reference Method: SM 5310 B-2011
Batch ID: P401309

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Organic Carbon	96.3		P	85 - 115

Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 200.7 Rev. 4.4

Batch ID: P400847

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2261183	Calcium	109		P	80 - 120
2261183	Iron	108		P	80 - 120
2261183	Magnesium	111		P	80 - 120
2261183	Manganese	103		P	80 - 120
2261183	Zinc	106		P	80 - 120
2261511	Calcium	106		P	80 - 120
2261511	Iron	112	114	P/P	80 - 120
2261511	Magnesium	115	117	P/P	80 - 120
2261511	Manganese	106	106	P/P	80 - 120
2261511	Zinc	110	110	P/P	80 - 120

Reference Method: EPA 200.8 Rev. 5.4

Batch ID: P400847

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2261183	Aluminum	107		P	80 - 120
2261183	Antimony	110		P	80 - 120
2261183	Arsenic	104		P	80 - 120
2261183	Beryllium	108		P	80 - 120
2261183	Cadmium	110		P	80 - 120
2261183	Chromium	103		P	80 - 120
2261183	Copper	96.0		P	80 - 120
2261183	Lead	106		P	80 - 120
2261183	Nickel	97.7		P	80 - 120
2261183	Selenium	109		P	80 - 120
2261183	Silver	103		P	80 - 120
2261183	Thallium	111		P	80 - 120
2261511	Aluminum	106	109	P/P	80 - 120
2261511	Antimony	115	118	P/P	80 - 120
2261511	Arsenic	106	108	P/P	80 - 120
2261511	Beryllium	114	115	P/P	80 - 120
2261511	Cadmium	111	112	P/P	80 - 120
2261511	Chromium	104	106	P/P	80 - 120
2261511	Copper	95.9	98.2	P/P	80 - 120
2261511	Lead	107	109	P/P	80 - 120
2261511	Nickel	96.1	97.4	P/P	80 - 120
2261511	Selenium	113	113	P/P	80 - 120
2261511	Silver	103	103	P/P	80 - 120
2261511	Thallium	112	115	P/P	80 - 120

Reference Method: EPA 350.1 Rev. 2.0

Batch ID: P401331

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2261520	Ammonia-N	98.2	98.6	P/P	90 - 110

Reference Method: EPA 351.2 Rev. 2.0

Batch ID: P402127

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2261984	Kjeldahl Nitrogen	97.3	105	P/P	90 - 110

Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 353.2 Rev. 2.0

Batch ID: P400999

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2261501	NO2NO3-N	103	103	P/P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0

Batch ID: P401103

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2261157	Total-P	106	107	P/P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0

Batch ID: P401180

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2261552	Total-P	107	105	P/P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0 dissolved

Batch ID: P400866

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2261503	O-Phosphate-P	97.0	98.2	P/P	90 - 110

Reference Method: EPA 8321B

Batch ID: P400842

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2261285	Acesulfame K	141	133	P/P	40 - 150
2261285	AMPA	96.8	91.8	P/P	40 - 150
2261285	Endothall	115	109	P/P	40 - 150
2261285	Glufosinate	111	110	P/P	40 - 150
2261285	Glyphosate	112	111	P/P	40 - 150
2261285	Sucralose	112	101	P/P	40 - 150

Reference Method: EPA 8321B

Batch ID: P400846

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2261122	2,4-D	110	126	P/P	30 - 160
2261122	2,4,5-T	111	117	P/P	30 - 160
2261122	Acetaminophen	101	112	P/P	30 - 160
2261122	Acetamiprid	86.9	105	P/P	30 - 160
2261122	Afidopyropen	73.5	82.5	P/P	30 - 160
2261122	Bentazon	93.1	95.4	P/P	30 - 160
2261122	Benzovindiflupyr	91.4	98.7	P/P	30 - 160
2261122	Carbamazepine	112	124	P/P	30 - 160
2261122	Clothianidin	102	116	P/P	30 - 160
2261122	Dinotefuran	116	131	P/P	30 - 160
2261122	Diuron	89.0	91.6	P/P	30 - 160
2261122	Fenuron	92.7	97.7	P/P	30 - 160
2261122	Fluridone	88.1	97.0	P/P	30 - 160
2261122	Hydrocodone	111	123	P/P	30 - 160
2261122	Ibuprofen	83.9	94.2	P/P	30 - 160
2261122	Imazapyr	100	161	P/F	30 - 160
2261122	Imidacloprid	122	151	P/P	30 - 160

Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 8321B
Batch ID: P400846

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2261122	Linuron	77.9	81.3	P/P	30 - 160
2261122	Mandestrobin	93.5	99.7	P/P	30 - 160
2261122	MCPP	111	122	P/P	30 - 160
2261122	Naproxen	83.2	78.0	P/P	30 - 160
2261122	Primidone	110	117	P/P	30 - 160
2261122	Pyraclostrobin	91.0	96.4	P/P	30 - 160
2261122	Thiamethoxam	130	161	P/F	30 - 160
2261122	Tolfenpyrad	52.7	56.8	P/P	30 - 160
2261122	Triclopyr	106	117	P/P	30 - 160

Reference Method: SM 4500 F-C-2011
Batch ID: P401131

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2261960	Fluoride	99.1	99.7	P/P	92 - 107

Reference Method: SM 5310 B-2011
Batch ID: P401309

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2261556	Organic Carbon	97.6	98.2	P/P	85 - 115

Quality Assurance Report Precision

Reference Method: EPA 180.1 Rev. 2.0

Batch ID: P400905

Replicated

Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2261517	Turbidity	4.60	Sample	P	0 - 20

Reference Method: EPA 200.7 Rev. 4.4

Batch ID: P400847

Replicated

Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2261511	Calcium	1.01	Spike	P	0 - 20
2261511	Iron	1.47	Spike	P	0 - 20
2261511	Magnesium	1.33	Spike	P	0 - 20
2261511	Manganese	0.136	Spike	P	0 - 20
2261511	Zinc	0.103	Spike	P	0 - 20

Reference Method: EPA 200.8 Rev. 5.4

Batch ID: P400847

Replicated

Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2261511	Aluminum	3.03	Spike	P	0 - 20
2261511	Antimony	1.73	Spike	P	0 - 20
2261511	Arsenic	2.28	Spike	P	0 - 20
2261511	Beryllium	0.862	Spike	P	0 - 20
2261511	Cadmium	0.703	Spike	P	0 - 20
2261511	Chromium	1.93	Spike	P	0 - 20
2261511	Copper	2.32	Spike	P	0 - 20
2261511	Lead	1.81	Spike	P	0 - 20
2261511	Nickel	1.41	Spike	P	0 - 20
2261511	Selenium	0.440	Spike	P	0 - 20
2261511	Silver	0.256	Spike	P	0 - 20
2261511	Thallium	2.34	Spike	P	0 - 20

Reference Method: EPA 350.1 Rev. 2.0

Batch ID: P401331

Replicated

Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2261520	Ammonia-N	0.278	Spike	P	0 - 20

Reference Method: EPA 351.2 Rev. 2.0

Batch ID: P402127

Replicated

Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2261984	Kjeldahl Nitrogen	6.20	Spike	P	0 - 20

Reference Method: EPA 353.2 Rev. 2.0

Batch ID: P400999

Replicated

Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2261501	NO2NO3-N	0.0	Spike	P	0 - 20

Quality Assurance Report Precision

Reference Method: EPA 365.1 Rev. 2.0

Batch ID: P401103

Replicated

Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2261157	Total-P	0.581	Spike	P	0 - 20

Reference Method: EPA 365.1 Rev. 2.0

Batch ID: P401180

Replicated

Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2261552	Total-P	2.17	Spike	P	0 - 20

Reference Method: EPA 365.1 Rev. 2.0 dissolved

Batch ID: P400866

Replicated

Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2261503	O-Phosphate-P	1.23	Spike	P	0 - 20

Reference Method: EPA 8321B

Batch ID: P400842

Replicated

Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2261285	Acesulfame K	6.15	Spike	P	0 - 30
2261285	AMPA	5.29	Spike	P	0 - 30
2261285	Endothall	5.83	Spike	P	0 - 30
2261285	Glufosinate	0.705	Spike	P	0 - 30
2261285	Glyphosate	1.11	Spike	P	0 - 30
2261285	Sucralose	9.51	Spike	P	0 - 30

Reference Method: EPA 8321B

Batch ID: P400846

Replicated

Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2261122	2,4-D	13.3	Spike	P	0 - 30
2261122	2,4,5-T	5.92	Spike	P	0 - 30
2261122	Acetaminophen	10.5	Spike	P	0 - 30
2261122	Acetamiprid	18.7	Spike	P	0 - 30
2261122	Afidopyropen	11.6	Spike	P	0 - 30
2261122	Bentazon	1.20	Spike	P	0 - 30
2261122	Benzovindiflupyr	7.64	Spike	P	0 - 30
2261122	Carbamazepine	6.80	Spike	P	0 - 30
2261122	Clothianidin	13.5	Spike	P	0 - 30
2261122	Dinotefuran	12.2	Spike	P	0 - 30
2261122	Diuron	2.66	Spike	P	0 - 30
2261122	Fenuron	5.26	Spike	P	0 - 30
2261122	Fluridone	8.29	Spike	P	0 - 30
2261122	Hydrocodone	10.1	Spike	P	0 - 30
2261122	Ibuprofen	11.7	Spike	P	0 - 30
2261122	Imazapyr	32.2	Spike	F	0 - 30
2261122	Imidacloprid	19.8	Spike	P	0 - 30
2261122	Linuron	4.29	Spike	P	0 - 30

Quality Assurance Report Precision

Reference Method: EPA 8321B
 Batch ID: P400846

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2261122	Mandestrobin	6.46	Spike	P	0 - 30
2261122	MCP	9.46	Spike	P	0 - 30
2261122	Naproxen	6.36	Spike	P	0 - 30
2261122	Primidone	5.62	Spike	P	0 - 30
2261122	Pyraclostrobin	5.77	Spike	P	0 - 30
2261122	Thiamethoxam	21.4	Spike	P	0 - 30
2261122	Tolfenpyrad	7.38	Spike	P	0 - 30
2261122	Triclopyr	10.3	Spike	P	0 - 30

Reference Method: SM 2320 B-2011
 Batch ID: P401128

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2261960	Total Alkalinity	1.37	Sample	P	0 - 5.2

Reference Method: SM 2540 D-2011
 Batch ID: P401123

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2261518	TSS	6.67	Sample	P	0 - 10

Reference Method: SM 4500 F-C-2011
 Batch ID: P401131

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2261960	Fluoride	0.506	Spike	P	0 - 2.1

Reference Method: SM 5310 B-2011
 Batch ID: P401309

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2261556	Organic Carbon	0.479	Spike	P	0 - 20

* Sample, spike and/or laboratory control sample precision (LCS) is reported.

Quality Assurance Report Surrogates

Lab Sample ID: 2261531
Field Sample ID: G2SE0029

Reference Method	Surrogate	% Rec.	Pass/Fail	Control Limits
EPA 8321B	2,4-D-d3	115	P	30 - 160
EPA 8321B	Acetaminophen-d4	104	P	30 - 160
EPA 8321B	Carbamazepine-d10	92.7	P	30 - 160
EPA 8321B	Diuron-d6	73.4	P	30 - 160
EPA 8321B	Endothall-d6	105	P	30 - 160
EPA 8321B	Glyphosate 13C 15N	78.0	P	30 - 160
EPA 8321B	Ibuprofen-d3	82.8	P	30 - 160
EPA 8321B	Primidone-d5	104	P	30 - 160
EPA 8321B	Sucralose-d6	101	P	30 - 160

Lab Sample ID: 2261532
Field Sample ID: G2SE0043

Reference Method	Surrogate	% Rec.	Pass/Fail	Control Limits
EPA 8321B	2,4-D-d3	116	P	30 - 160
EPA 8321B	Acetaminophen-d4	117	P	30 - 160
EPA 8321B	Carbamazepine-d10	100	P	30 - 160
EPA 8321B	Diuron-d6	76.7	P	30 - 160
EPA 8321B	Endothall-d6	103	P	30 - 160
EPA 8321B	Glyphosate 13C 15N	53.2	P	30 - 160
EPA 8321B	Ibuprofen-d3	90.8	P	30 - 160
EPA 8321B	Primidone-d5	110	P	30 - 160
EPA 8321B	Sucralose-d6	98.1	P	30 - 160

Quality Assurance Report Calibration Verification

Reference Method: EPA 365.1 Rev. 2.0 dissolved

Run ID: A106583

Included Lab Sample IDs: 2261521, 2261522

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
O-Phosphate-P	99.7	98.4	P/P	90 - 110

Reference Method: EPA 180.1 Rev. 2.0

Run ID: A106600

Included Lab Sample IDs: 2261517, 2261518

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Turbidity	102	102	P/P	95 - 105

Reference Method: EPA 353.2 Rev. 2.0

Run ID: A106631

Included Lab Sample IDs: 2261519, 2261520

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
NO2NO3-N	102	104	P/P	90 - 110

Reference Method: EPA 200.8 Rev. 5.4

Run ID: A106650

Included Lab Sample IDs: 2261533, 2261534

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Aluminum	101	97.4	P/P	90 - 110
Antimony	107	106	P/P	90 - 110
Arsenic	96.1	94.9	P/P	90 - 110
Beryllium	96.1	96.2	P/P	90 - 110
Cadmium	103	102	P/P	90 - 110
Chromium	98.4	96.8	P/P	90 - 110
Lead	100	98.3	P/P	90 - 110
Selenium	100	98.9	P/P	90 - 110
Silver	101	99.8	P/P	90 - 110
Thallium	96.5	95.5	P/P	90 - 110

Reference Method: EPA 8321B

Run ID: A106658

Included Lab Sample IDs: 2261531, 2261532

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
AMPA	102	107	P/P	60 - 160
Glufosinate	104	111	P/P	60 - 160
Glyphosate	103	107	P/P	60 - 160

Reference Method: EPA 200.8 Rev. 5.4

Run ID: A106671

Included Lab Sample IDs: 2261533, 2261534

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Copper	92.0	91.8	P/P	90 - 110
Nickel	92.9	92.0	P/P	90 - 110

Quality Assurance Report Calibration Verification

Reference Method: EPA 8321B

Run ID: A106673

Included Lab Sample IDs: 2261531, 2261532

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Acesulfame K	118	113	P/P	60 - 160
Endothall	97.1	97.0	P/P	60 - 160
Sucralose	101	96.0	P/P	60 - 160

Reference Method: SM 2320 B-2011

Run ID: A106677

Included Lab Sample IDs: 2261517, 2261518

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Total Alkalinity	102	99.4	P/P	90 - 110
Total Alkalinity	98.5	102	P/P	90 - 110

Reference Method: SM 4500 F-C-2011

Run ID: A106677

Included Lab Sample IDs: 2261517, 2261518

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Fluoride	101	103	P/P	90 - 110
Fluoride	102	101	P/P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0

Run ID: A106678

Included Lab Sample IDs: 2261519

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Total-P	102	104	P/P	90 - 110

Reference Method: EPA 8321B

Run ID: A106699

Included Lab Sample IDs: 2261531, 2261532

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
2,4-D	103	103	P/P	50 - 150
2,4,5-T	106	105	P/P	50 - 150
Acetaminophen	104	103	P/P	60 - 160
Acetamiprid	103	104	P/P	50 - 150
Afidopyropen	106	109	P/P	50 - 150
Bentazon	116	118	P/P	50 - 160
Benzovindiflupyr	108	110	P/P	50 - 160
Carbamazepine	106	105	P/P	60 - 150
Clothianidin	107	105	P/P	60 - 150
Dinotefuran	107	108	P/P	50 - 150
Diuron	113	115	P/P	60 - 160
Fenuron	110	110	P/P	60 - 150
Fluridone	106	110	P/P	60 - 160
Hydrocodone	106	108	P/P	60 - 150
Ibuprofen	103	113	P/P	50 - 160
Imazapyr	105	106	P/P	50 - 160
Imidacloprid	101	99.6	P/P	60 - 150
Linuron	103	106	P/P	60 - 150
Mandestrobin	107	109	P/P	50 - 150

Quality Assurance Report Calibration Verification

Reference Method: EPA 8321B

Run ID: A106699

Included Lab Sample IDs: 2261531, 2261532

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
MCP	104	104	P/P	50 - 150
Naproxen	101	97.0	P/P	50 - 160
Primidone	99.4	99.7	P/P	60 - 150
Pyraclostrobin	110	113	P/P	60 - 150
Thiamethoxam	106	108	P/P	50 - 150
Tolfenpyrad	103	105	P/P	60 - 150
Triclopyr	104	102	P/P	50 - 150

Reference Method: EPA 200.7 Rev. 4.4

Run ID: A106709

Included Lab Sample IDs: 2261533, 2261534

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Calcium	100	100	P/P	90 - 110
Iron	98.3	99.1	P/P	90 - 110
Magnesium	98.7	99.0	P/P	90 - 110
Manganese	98.9	99.0	P/P	90 - 110
Zinc	101	98.3	P/P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0

Run ID: A106732

Included Lab Sample IDs: 2261520

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Total-P	102	102	P/P	85 - 115

Reference Method: SM 5310 B-2011

Run ID: A106744

Included Lab Sample IDs: 2261519, 2261520

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Organic Carbon	96.2	97.6	P/P	90 - 110

Reference Method: EPA 350.1 Rev. 2.0

Run ID: A106748

Included Lab Sample IDs: 2261519, 2261520

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Ammonia-N	97.5	98.4	P/P	90 - 110

Reference Method: EPA 351.2 Rev. 2.0

Run ID: A107113

Included Lab Sample IDs: 2261519, 2261520

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Kjeldahl Nitrogen	92.8	90.3	P/P	90 - 110

* Pass/Fail determinations are made for each bracketing calibration verification check.

Control limits for initial calibration checks may be different from those for continuing checks, depending on method requirements.

Where they are different, both control limits are provided.

Quality Assurance Report Summary

Ref. Method	Analyte	LCS % Recovery	MS % Recovery			LCS	Precision SMP	MS
EPA 180.1 Rev. 2.0	Turbidity						4.60	
EPA 200.7 Rev. 4.4	Calcium	106	109	106				1.01
	Iron	109	108	112	114			1.47
	Magnesium	112	111	115	117			1.33
	Manganese	101	103	106	106			0.136
	Zinc	105	106	110	110			0.103
EPA 200.8 Rev. 5.4	Aluminum	108	106	109	107			3.03
	Antimony	112	115	118	110			1.73
	Arsenic	105	106	108	104			2.28
	Beryllium	110	114	115	108			0.862
	Cadmium	111	111	112	110			0.703
	Chromium	103	104	106	103			1.93
	Copper	96.7	95.9	98.2	96.0			2.32
	Lead	104	107	109	106			1.81
	Nickel	95.8	97.7	96.1	97.4			1.41
	Selenium	112	113	113	109			0.440
	Silver	104	103	103	103			0.256
	Thallium	111	112	115	111			2.34
EPA 350.1 Rev. 2.0	Ammonia-N	99.0	98.2	98.6				0.278
EPA 351.2 Rev. 2.0	Kjeldahl Nitrogen	98.1	97.3	105				6.20
EPA 353.2 Rev. 2.0	NO2NO3-N	102	103	103				0.0
EPA 365.1 Rev. 2.0	Total-P	107	106	107				0.581
	Total-P	105	107	105				2.17
EPA 365.1 Rev. 2.0 dissolved	O-Phosphate-P	100	97.0	98.2				1.23
EPA 8321B	2,4-D	110	110	126				13.3
	2,4,5-T	108	111	117				5.92
	Acesulfame K	103	141	133				6.15
	Acetaminophen	79.9	101	112				10.5
	Acetamiprid	83.6	86.9	105				18.7
	Afidopyropen	63.4	73.5	82.5				11.6
	AMPA	97.5	96.8	91.8				5.29
	Bentazon	98.7	93.1	95.4				1.20
	Benzovindiflupyr	89.1	91.4	98.7				7.64
	Carbamazepine	99.5	112	124				6.80
	Clothianidin	93.4	102	116				13.5
	Dinotefuran	92.3	116	131				12.2
	Diuron	88.5	89.0	91.6				2.66
	Endothall	97.5	115	109				5.83
	Fenuron	99.4	92.7	97.7				5.26
	Fluridone	94.9	88.1	97.0				8.29
	Glufosinate	97.7	111	110				0.705
	Glyphosate	97.0	112	111				1.11
	Hydrocodone	95.5	111	123				10.1
	Ibuprofen	91.9	83.9	94.2				11.7
	Imazapyr	91.8	100	161				32.2
	Imidacloprid	91.1	122	151				19.8
	Linuron	80.9	77.9	81.3				4.29
	Mandestrobin	91.5	93.5	99.7				6.46
	MCPP	110	111	122				9.46
	Naproxen	81.0	83.2	78.0				6.36
	Primidone	93.9	110	117				5.62
	Pyraclostrobin	84.4	91.0	96.4				5.77
	Sucralose	102	112	101				9.51
	Thiamethoxam	98.9	130	161				21.4

Quality Assurance Report Summary

Ref. Method	Analyte	LCS % Recovery	MS % Recovery	LCS	Precision SMP	MS
EPA 8321B	Tolfenpyrad	42.3	52.7 56.8			7.38
	Triclopyr	108	106 117			10.3
SM 2320 B-2011	Total Alkalinity	101			1.37	
SM 2540 D-2011	TSS				6.67	
SM 4500 F-C-2011	Fluoride	97.6	99.1 99.7			0.506
SM 5310 B-2011	Organic Carbon	96.3	97.6 98.2			0.479

Reference Method Descriptions

Method	Description	Associated Samples
EPA 180.1 Rev. 2.0	Turbidity in aqueous matrices	2261517, 2261518
EPA 200.7 Rev. 4.4	Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects	2261533, 2261534
EPA 200.8 Rev. 5.4	Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects	2261533, 2261534
EPA 350.1 Rev. 2.0	Ammonia in aqueous matrices as mg N/L	2261519, 2261520
EPA 351.2 Rev. 2.0	Total Kjeldahl Nitrogen in aqueous matrices	2261519, 2261520
EPA 353.2 Rev. 2.0	Nitrite/Nitrate in aqueous matrices as mg N/L	2261519, 2261520
EPA 365.1 Rev. 2.0	Total Phosphorus in aqueous matrices as mg P/L	2261519, 2261520
EPA 365.1 Rev. 2.0 dissolved	Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L	2261521, 2261522
EPA 8321B	Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS	2261531, 2261532
SM 2320 B-2011	Alkalinity in aqueous matrices as mg CaCO3/L	2261517, 2261518
SM 2540 D-2011	Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample	2261517, 2261518
SM 4500 F-C-2011	Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)	2261517, 2261518
SM 5310 B-2011	Nonpurgeable Organic Carbon in aqueous matrices	2261519, 2261520

Preparation and Analysis Log

Ref. Method	Received Date	Prep Date/Time	Prepared By	Analysis Date/Time	Analyzed By	Associated Samples
EPA 180.1 Rev. 2.0	07/13/2021			07/13/2021 16:23	Sarah A Nixon	2261517, 2261518
EPA 200.7 Rev. 4.4	07/13/2021	07/13/2021 14:10	Elliott D. Healy	07/16/2021 22:15	Josef B Mick	2261533
	07/13/2021	07/13/2021 14:10	Elliott D. Healy	07/16/2021 22:23	Josef B Mick	2261534
EPA 200.8 Rev. 5.4	07/13/2021	07/13/2021 14:10	Elliott D. Healy	07/15/2021 18:44	Alexander Thompson	2261533
	07/13/2021	07/13/2021 14:10	Elliott D. Healy	07/15/2021 18:54	Alexander Thompson	2261534
	07/13/2021	07/13/2021 14:10	Elliott D. Healy	07/16/2021 15:12	Alexander Thompson	2261533
	07/13/2021	07/13/2021 14:10	Elliott D. Healy	07/16/2021 15:19	Alexander Thompson	2261534
EPA 350.1 Rev. 2.0	07/13/2021			07/21/2021 15:29	Roberta Tatti	2261520
	07/13/2021			07/21/2021 15:43	Roberta Tatti	2261519
EPA 351.2 Rev. 2.0	07/13/2021	08/06/2021 13:50	Benjamin T. Nordmann	08/06/2021 21:06	Touraj Touran	2261519
	07/13/2021	08/06/2021 13:50	Benjamin T. Nordmann	08/06/2021 21:08	Touraj Touran	2261520
EPA 353.2 Rev. 2.0	07/13/2021			07/15/2021 10:05	Beverly Y. Sanders	2261519
	07/13/2021			07/15/2021 10:06	Beverly Y. Sanders	2261520
EPA 365.1 Rev. 2.0	07/13/2021	07/16/2021 17:30	Simonne.V. Calhoun	07/19/2021 10:23	Shengyu Ding	2261519
	07/13/2021	07/20/2021 13:32	Shengyu Ding	07/21/2021 10:16	Shengyu Ding	2261520
EPA 365.1 Rev. 2.0 dissolved	07/13/2021			07/13/2021 15:29	Ping Hua	2261521
	07/13/2021			07/13/2021 15:30	Ping Hua	2261522
EPA 8321B	07/13/2021	07/15/2021 08:00	Hoor Shaik	07/19/2021 20:11	Juyoung Kim	2261531
	07/13/2021	07/15/2021 08:00	Hoor Shaik	07/19/2021 20:45	Juyoung Kim	2261532
	07/13/2021	07/15/2021 10:00	Pramila Ghimire	07/15/2021 14:08	Juyoung Kim	2261531
	07/13/2021	07/15/2021 10:00	Pramila Ghimire	07/15/2021 14:19	Juyoung Kim	2261532
	07/13/2021	07/15/2021 10:00	Pramila Ghimire	07/16/2021 20:14	Pramila Ghimire	2261531
	07/13/2021	07/15/2021 10:00	Pramila Ghimire	07/16/2021 20:28	Pramila Ghimire	2261532
SM 2320 B-2011	07/13/2021			07/16/2021 01:46	Dale L. Simmons	2261517
	07/13/2021			07/16/2021 03:50	Dale L. Simmons	2261518
SM 2540 D-2011	07/13/2021			07/14/2021 14:02	Yijie Li	2261517, 2261518
SM 4500 F-C-2011	07/13/2021			07/16/2021 01:46	Dale L. Simmons	2261517
	07/13/2021			07/16/2021 03:50	Dale L. Simmons	2261518
SM 5310 B-2011	07/13/2021			07/20/2021 22:02	Touraj Touran	2261519
	07/13/2021			07/20/2021 22:14	Touraj Touran	2261520