

Login Checklist

RQ- 2022-12-12-19

Login Station ID: #4

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 11/29/2022 9:08

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
1.8				1		x			5859 4731 0748

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ✓ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No X

CONTAINER CHECK

Evidence Tape on Bottles? Yes _____ No _____ NA X Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken? Yes _____ No _____ Containers intact? Yes ✓ No _____

Caps on tight? Yes ✓ No _____

Sufficient Sample Volume: Yes ✓ No _____

If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container) Yes _____ No X Init: NR

Chlorine detected? (One container checked per Field ID) Yes _____ No _____ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH< 2.0? Yes ✓ No _____ NA _____ Init: NR

**W-1-4-DIOX (Green dot on container) preserved to pH< 4.0? Yes _____ No _____ NA X Init: NR

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: NR Date: 11/29/2022 Event contains NCRs (Y/N)? N

EventID: Stuart Deploy
SE-DIST-2022-11-29-01 (SMP)
Date Received: 29-NOV-2022 09:08

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #4 Exp:10/17/2023
pH Test Strips 0 – 6	LOT# 223819AV Exp: AUG 30, 2023
pH Paper 0 – 3	N/A
pH Paper 0 – 13	LOT# 207621 Exp: March 15, 2024
Chlorine Test Strips	LOT# 0070 Exp: Feb. 2023

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 11/28/2022 **Collected By:** Jordan Skaggs, Andrew Luering
Customer: **Sampling Agency:** FDEP
RQ: RQ-2022-12-12-19 **Project ID:** SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped:

Delivery Method:

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
Bessey Creek @ Murphy	 G2SE0017

RELINQUISHED BY(SIGNATURE):



DATE/TIME: 11/28/2022
EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By: 

Rec'd/Inspected Date: 11-29-2022



RQ-2022-12-12-19	Collected By: Jordan Skaggs, Andrew Luering
Customer: FDEP	Field Report Prepared by: Jordan Skaggs, Andrew Luering
Project ID: SMP	Sampling Agency: FDEP
WIN ID/Field ID:  WIN ID/Field ID: G2SE0017	Comments:

Location: Bessey Creek @ Murphy

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPTH)
11/28/2022 1300	3.12	38	24.8	6.96	0.3	0.8	2.3	537	0.26
Parameter Suite	Parameter Methods				Preservation		pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP				Ice	H2SO4*	<2	1	B
	Lot #		Exp:						
Metals (P-500ML)	W-ICPMS W-ICP				Ice	HNO3*			
	Lot #		Exp:						
Filtered Nutrients (P125ML)	W-PO4-F Field Filtered 0.45 µm Filter				Ice				
	Filter Lot #	Syringe Lot #							
BOD (BP-1L)	OV-BODUNIN				Ice				
Chlorophyll (BP-1L)	CHLSUITE-W				Ice				
Physical/Aggregate (Fresh) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W-TDS				Ice				
Physical/Aggregate (Marine) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY				Ice				
Macroinvertebrates (PJ-2L)	MI-FW-QLDC	Formalin Lot #			Formalin				
Periphyton (PT-50ML)	ALGAE-ID				Ice				
Microbiology (Contract Lab Bottle)	E Coli	F Coli	X	Enterococci	x Ice				
	Contract Lab								
Molecular (QPCR-P-500ML)	PCR-HF183	PCR-BacR		PCR-DG3	Ice				
	PCR-GULL2	PCR-GFD							
Tracers (BG-500ML)	W-E8321-DI		W-E8321-MS		Ice				
Pesticides (BG-500ML) (BG-1L)	W-E8321-DI	W-E8321-MS		W-PSNP-TQ	Ice	MCAA Exp.	MCAA Lot#		
	W-PCL-TQ-R	W-CARB-AA (5 ml of MCAA Buffer Solution)		W-CT-CL-R					
	W-TR-SQ-R	W-PCB-TQ-R							
Phytoplankton	DTY-QN-C		PKD-QN-BV		Ice				
DOC	W-DOC	Field Filtered 0.45 µm Filter			Ice	H2SO4*	<2		
		Acid Preservative Expiration Date							
		Acid Preservative Lot Number							

Date of Request: 17-NOV-2022
 Created By: LUERING_A On: 17-NOV-2022
 Modified By: AYRES_J On: 29-NOV-2022
 Customer: SE-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Southeast District
 Event Description: Stuart Deploy

Send Coolers To:

Phone: (772) 380-5572
 FL Dept. of Environmental Protection
 2199 South Rock Road
 Fort Pierce, FL 34945
 Attn: Jordan Skaggs
 Cooler Ship EMail: Jordan.Skaggs@FloridaDEP.gov

Priority: 3
 Event Status: P
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 29-NOV-2022
 Biology Request Reviewed By:
 Sampling Kit Required: YES Ship on: 28-NOV-2022
 Sampling Kit Shipped:
 Sampling Kit Packed By:
 Preservatives Needed: NO
 Date to Receive Samples: 14-DEC-2022
 Logged In By:

Send Final Report To:

FL Dept. of Environmental Protection
 2199 South Rock Road
 Fort Pierce, FL 34945
 Attn: Jordan Skaggs
 Report Notification EMail:
 Jordan.Skaggs@FloridaDEP.gov;Andrew.Luering@FloridaDEP.gov

Comments: Bottle Group B (single Entero) will be built in-house.

Bottle Group A (Nutrients, Entero)
 G2SE0017

Bottle Group B (Entero)<---Grab on deployment
 G2SE0017

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-250ML-WO-THI Number of Bottles: 1 Preserved With: ICE
ENT-24-QT Template: DEFAULT (Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems