

# Chemical Analysis Report

**NE-DIST-2023-02-10-01**

Florida DEP Laboratory  
2600 Blair Stone Road  
Tallahassee, FL 32399-2400  
DOH Accreditation E31780


Event Description: **Suwannee North 2023**  
Request ID: **RQ-2023-02-13-28**  
Customer: **NE-DIST**  
Project ID: **SMP**

Send Reports to:  
FL Dept. of Environmental Protection  
8800 Baymeadows Way West  
Suite 100  
Jacksonville, FL 32256  
Attn: Jeremy Parrish

For additional information please contact  
Colin Wright, Ph.D.  
Chris Bowen, B.S.  
Kerry Tate, Ph.D.  
Dr. rer. nat. Bettina Steinbock  
Thekkekalathil Chandrasekhar, Ph.D, QA Officer  
Phone (850) 245-8085

Certified by: Dr. rer. nat. Bettina Steinbock, Environmental Administrator

Date Certified: 24-FEB-2023 18:58



## Case Narrative

Unless otherwise noted, all samples included in this report were received in accordance with protocols referenced in Chapter 62-160, Florida Administrative Code (F.A.C.). Results published in this report pertain only to the samples as submitted to, and received by the laboratory. All times in this report are adjusted to the applicable Eastern Time Zone (EST or EDT).

Results for the following analytical group are included in this report: Pesticides.

Scientific notation may be used in reporting very large or small values. Values reported using scientific notation will take the form of the following example: 1.3E+03, which is equivalent to  $1.3 \times 10^3$  or 1300.

Unless otherwise noted, analytical values for soil and sediment samples are reported on a dry weight basis, and analytical values for waste and tissue samples are reported on a wet weight basis.

Results for TNI accredited tests met requirements established by The NELAC Institute. A double asterisk (\*\*) is used to indicate an analyte/matrix/method for which the laboratory is not TNI accredited by the Florida Department of Health Environmental Laboratory Certification Program or where accreditation for that field of testing is not applicable.

Any significant anomalies or deviations from established protocols are documented in Non-Conformance Reports, which, where appropriate, are included within this analytical report. Additional comments related to specific analytical tests may be included as remarks following the analytical results for each sample. Such comments and remarks are for informational purposes only and are not intended to convey judgement about the usability of the reported data.

A quality control report on the performance of the test method for the submitted samples is included. Uncertainty associated with the analytical results contained in this report can be estimated from the reported quality assurance results and from published quality control acceptance limits for each analytical test. Matrix quality control results (matrix spike recoveries and matrix sample precision) pertain only to the matrix sample tested and do not necessarily reflect test method performance for other samples.

Typical matrix quality control (QC) measurements may include matrix spike recovery, matrix spike duplicate recovery, matrix spike precision and matrix sample precision. Not all matrix QC results may be available or reportable; where they are not an explanation is provided. Typical reasons for unavailable QC results include, but are not limited to, a) insufficient matrix sample to perform some or all QC measurements; b) analyte concentration in the sample replicated was too low for a meaningful measurement of precision and c) analyte concentration in the matrix sample spiked was too high (relative to the amount of analyte spiked) for a meaningful measurement of recovery. Where matrix QC results are unavailable, other method performance metrics (e.g., LCS recovery, LCS precision, surrogate recovery) may be used to assess performance of the method. Comments explaining any missing QC measurements are not intended to convey any adverse conclusions about the quality of the reported data.

Precision is reported as relative percent difference unless otherwise noted.

Quality Control codes as defined below may be used in this report to indicate results that are associated with one or more quality control elements which did not fall within established test method criteria. Such results may be qualified as estimates using a J qualifier as required by 62-160 F.A.C. Explanations are included in the report for any results that were reported as estimates for other reasons.

QC Codes used in this report may include:

- LCS – Recovery for the batch Laboratory Control Sample (LCS) was outside existing control limits;
- MS – Recovery for the batch matrix spike (MS) was outside existing control limits;
- CCV – Recovery for a continuing calibration verification (CCV) standard was outside existing control limits;
- SUR – Recovery of a surrogate (SUR) for associated analytes was outside existing control limits;
- RPD – The precision, measured as relative percent difference (RPD), of batch replicate measurements was outside existing control limits;
- RSD – The precision, measured as relative standard deviation (RSD), of batch replicate measurements was outside existing control limits;
- SMP – Sample - used precision derived from replicate analyses of a sample;

The following data qualifiers are used, where applicable, in this report as specified in 62-160 F.A.C.

- A - Value reported is the mean of two or more determinations.
- B - Results based on colony counts outside the acceptable range.
- I - The reported value is between the laboratory method detection limit and the laboratory practical quantitation limit.
- J - Estimated value and/or the analysis did not meet established quality control criteria.
- K - Actual value is known to be less than value given.
- L - Actual value is known to be greater than value given.
- N - Presumptive evidence of presence of material.
- O - Sampled, but analysis lost or not performed.
- Q - Sample held beyond normal holding time.
- T - Value reported is less than the criterion of detection.
- U - Material was analyzed for but not detected. The reported value is the method detection limit for the sample analyzed.
- V - Analyte was detected in both sample and method blank.
- X - Too few individuals to calculate SCI value.
- Y - The laboratory analysis was from an unpreserved or improperly preserved sample. The data may not be accurate.
- Z - Colonies were too numerous to count (TNTC).

Quality control information from overflow laboratories may not be included in this report. Please refer to the associated report from the overflow laboratory for additional information.

Sample Location: HUNTERS CREEK AT SR 135

Collection Date/Time: 02/09/2023 10:50

Field ID: 21020063

Matrix: W-SURF-FRH

| Sample ID | Ref. Method | Component        | Result  | Code | Units | Batch ID | QC Codes |
|-----------|-------------|------------------|---------|------|-------|----------|----------|
| 2386793   | EPA 8321B   | 2,4-D            | 0.0029  | I    | ug/L  | P425700  |          |
|           |             | Acesulfame K     | 0.10    | U    | ug/L  | P425585  |          |
|           |             | 2,4,5-T          | 0.0040  | U    | ug/L  | P425700  |          |
|           |             | AMPA             | 0.10    | U    | ug/L  | P425585  |          |
|           |             | Acetaminophen    | 0.0080  | U    | ug/L  | P425700  |          |
|           |             | Acetamiprid      | 0.0020  | U    | ug/L  | P425700  |          |
|           |             | Endothall        | 0.25    | U    | ug/L  | P425585  | MS       |
|           |             | Glufosinate      | 0.10    | U    | ug/L  | P425585  |          |
|           |             | Glyphosate       | 0.10    | I    | ug/L  | P425585  |          |
|           |             | Afidopyropen     | 0.0020  | U    | ug/L  | P425700  |          |
|           |             | Bentazon         | 8.0E-04 | U    | ug/L  | P425700  |          |
|           |             | Sucralose        | 0.010   | U    | ug/L  | P425585  |          |
|           |             | Benzovindiflupyr | 0.0020  | U    | ug/L  | P425700  |          |
|           |             | Carbamazepine    | 8.0E-04 | U    | ug/L  | P425700  |          |
|           |             | Clothianidin     | 0.0020  | U    | ug/L  | P425700  |          |
|           |             | Dinotefuran      | 0.0020  | U    | ug/L  | P425700  |          |
|           |             | Diuron           | 0.0020  | U    | ug/L  | P425700  |          |
|           |             | Fenuron          | 0.032   | U    | ug/L  | P425700  |          |
|           |             | Fluridone        | 8.0E-04 | U    | ug/L  | P425700  |          |
|           |             | Imazapyr         | 0.0040  | U    | ug/L  | P425700  |          |
|           |             | Hydrocodone      | 0.0020  | U    | ug/L  | P425700  |          |
|           |             | Ibuprofen        | 0.080   | U    | ug/L  | P425700  |          |
|           |             | Imidacloprid     | 0.0020  | U    | ug/L  | P425700  |          |
|           |             | Linuron          | 0.0040  | U    | ug/L  | P425700  |          |
|           |             | Mandestrobin     | 0.0020  | U    | ug/L  | P425700  |          |
|           |             | MCPP             | 0.0020  | U    | ug/L  | P425700  |          |
|           |             | Naproxen         | 0.0080  | U    | ug/L  | P425700  |          |
|           |             | Primidone        | 0.0040  | U    | ug/L  | P425700  |          |
|           |             | Pyraclostrobin   | 0.0020  | U    | ug/L  | P425700  |          |
|           |             | Silvex           | 0.0040  | U    | ug/L  | P425700  |          |
|           |             | Thiamethoxam     | 0.0020  | U    | ug/L  | P425700  |          |
|           |             | Tolfenpyrad      | 0.0020  | U    | ug/L  | P425700  |          |
|           |             | Triclopyr        | 0.0040  | U    | ug/L  | P425700  |          |

Ref. Method and Comment:

EPA 8321B: MS accuracy for some analytes could not be assessed due to high concentration of parameter in the spiked sample.

**Sample Location: CANNON CR @ CANNON CR RD/BUSINESS  
PARK W CR 47**

**Collection Date/Time: 02/09/2023 11:45**

**Field ID: 21030138**

**Matrix: W-SURF-FRH**

| Sample ID | Ref. Method | Component           | Result | Code | Units | Batch ID | QC Codes |
|-----------|-------------|---------------------|--------|------|-------|----------|----------|
| 2386792   | EPA 8270E   | Aldrin              | 0.68   | U    | ng/L  | P425594  |          |
|           |             | Alpha-BHC           | 0.11   | U    | ng/L  | P425594  |          |
|           |             | Alpha-Chlordane     | 0.21   | U    | ng/L  | P425594  | MS       |
|           |             | PCB-1016            | 2.1    | U    | ng/L  | P425594  |          |
|           |             | Beta-BHC            | 0.11   | U    | ng/L  | P425594  |          |
|           |             | PCB-1221            | 2.1    | U    | ng/L  | P425594  |          |
|           |             | Beta-Cyfluthrin     | 1.3    | U    | ng/L  | P425594  |          |
|           |             | PCB-1232            | 2.1    | U    | ng/L  | P425594  |          |
|           |             | Bifenthrin          | 0.53   | U    | ng/L  | P425594  |          |
|           |             | PCB-1242            | 2.1    | U    | ng/L  | P425594  |          |
|           |             | PCB-1248            | 2.1    | U    | ng/L  | P425594  |          |
|           |             | Chlorothalonil      | 3.8    | U    | ng/L  | P425594  |          |
|           |             | PCB-1254            | 2.1    | U    | ng/L  | P425594  |          |
|           |             | Cis-Nonachlor       | 0.21   | U    | ng/L  | P425594  |          |
|           |             | PCB-1260            | 2.1    | U    | ng/L  | P425594  |          |
|           |             | Cypermethrin        | 1.6    | U    | ng/L  | P425594  |          |
|           |             | Dacthal             | 0.16   | U    | ng/L  | P425594  |          |
|           |             | DDD-p,p'            | 0.26   | U    | ng/L  | P425594  | MS       |
|           |             | DDE-p,p'            | 0.21   | U    | ng/L  | P425594  | MS       |
|           |             | DDT-p,p'            | 0.26   | U    | ng/L  | P425594  |          |
|           |             | Delta-BHC           | 0.42   | U    | ng/L  | P425594  |          |
|           |             | Deltamethrin        | 1.3    | U    | ng/L  | P425594  |          |
|           |             | Dichlobenil         | 0.26   | U    | ng/L  | P425594  |          |
|           |             | Dicofol             | 1.3    | U    | ng/L  | P425594  |          |
|           |             | Dieldrin            | 0.94   | I    | ng/L  | P425594  |          |
|           |             | Endosulfan I        | 0.42   | U    | ng/L  | P425594  |          |
|           |             | Endosulfan II       | 0.42   | U    | ng/L  | P425594  |          |
|           |             | Endosulfan Sulfate  | 0.32   | U    | ng/L  | P425594  |          |
|           |             | Endrin              | 0.42   | U    | ng/L  | P425594  | MS       |
|           |             | Endrin Aldehyde     | 0.79   | U    | ng/L  | P425594  |          |
|           |             | Endrin Ketone       | 0.42   | U    | ng/L  | P425594  |          |
|           |             | Esfenvalerate       | 0.79   | U    | ng/L  | P425594  |          |
|           |             | Ethalfuralin        | 0.16   | U    | ng/L  | P425594  |          |
|           |             | Fenpropathrin       | 0.26   | U    | ng/L  | P425594  |          |
|           |             | Gamma-BHC           | 0.13   | U    | ng/L  | P425594  |          |
|           |             | Gamma-Chlordane     | 0.21   | U    | ng/L  | P425594  |          |
|           |             | Heptachlor          | 0.21   | U    | ng/L  | P425594  |          |
|           |             | Heptachlor Epoxide  | 0.26   | U    | ng/L  | P425594  |          |
|           |             | Hexachlorobenzene** | 1.1    | U    | ng/L  | P425594  |          |
|           |             | Kepone              | 5.3    | U    | ng/L  | P425594  |          |
|           |             | Lambda-Cyhalothrin  | 0.79   | U    | ng/L  | P425594  |          |
|           |             | Methoprene          | 0.79   | U    | ng/L  | P425594  | MS       |
|           |             | Methoxychlor        | 0.32   | U    | ng/L  | P425594  |          |

Field ID: 21030138

Matrix: W-SURF-FRH

| Sample ID | Ref. Method | Component          | Result | Code | Units | Batch ID | QC Codes |
|-----------|-------------|--------------------|--------|------|-------|----------|----------|
| 2386792   | EPA 8270E   | MGK-264            | 0.21   | U    | ng/L  | P425594  |          |
|           |             | Mirex              | 0.37   | U    | ng/L  | P425594  |          |
|           |             | Oxychlordane       | 0.32   | U    | ng/L  | P425594  |          |
|           |             | Permethrin         | 1.7    | U    | ng/L  | P425594  |          |
|           |             | Phenothrin         | 0.95   | U    | ng/L  | P425594  |          |
|           |             | Piperonyl Butoxide | 0.16   | U    | ng/L  | P425594  |          |
|           |             | Prallethrin        | 2.1    | U    | ng/L  | P425594  | MS       |
|           |             | Tau-Fluvalinate    | 0.26   | U    | ng/L  | P425594  |          |
|           |             | Tetramethrin       | 0.79   | U    | ng/L  | P425594  |          |
|           |             | Trans-Nonachlor    | 0.21   | U    | ng/L  | P425594  |          |
|           |             | Triclosan Methyl   | 0.16   | U    | ng/L  | P425594  |          |
|           |             | Trifluralin        | 0.21   | U    | ng/L  | P425594  |          |
|           | EPA 8276    | Chlordane          | 2.1    | U    | ng/L  | P425594  |          |
|           |             | Toxaphene          | 16     | U    | ng/L  | P425594  |          |

Sample Location: CANNON CR @ S WARD ST

Collection Date/Time: 02/09/2023 12:00

Field ID: 21030016FLA

Matrix: W-SURF-FRH

| Sample ID | Ref. Method | Component        | Result  | Code | Units | Batch ID | QC Codes |
|-----------|-------------|------------------|---------|------|-------|----------|----------|
| 2386794   | EPA 8321B   | 2,4-D            | 0.0037  | I    | ug/L  | P425700  |          |
|           |             | Acesulfame K     | 0.13    | I    | ug/L  | P425585  |          |
|           |             | 2,4,5-T          | 0.0040  | U    | ug/L  | P425700  |          |
|           |             | AMPA             | 0.11    | I    | ug/L  | P425585  |          |
|           |             | Acetaminophen    | 0.0080  | U    | ug/L  | P425700  |          |
|           |             | Acetamiprid      | 0.0020  | U    | ug/L  | P425700  |          |
|           |             | Endothall        | 0.25    | U    | ug/L  | P425585  | MS       |
|           |             | Glufosinate      | 0.10    | U    | ug/L  | P425585  |          |
|           |             | Glyphosate       | 0.10    | U    | ug/L  | P425585  |          |
|           |             | Afidopyropen     | 0.0020  | U    | ug/L  | P425700  |          |
|           |             | Bentazon         | 9.7E-04 | I    | ug/L  | P425700  |          |
|           |             | Sucralose        | 0.24    |      | ug/L  | P425585  |          |
|           |             | Benzovindiflupyr | 0.0020  | U    | ug/L  | P425700  |          |
|           |             | Carbamazepine    | 8.0E-04 | U    | ug/L  | P425700  |          |
|           |             | Clothianidin     | 0.0020  | U    | ug/L  | P425700  |          |
|           |             | Dinotefuran      | 0.0020  | U    | ug/L  | P425700  |          |
|           |             | Diuron           | 0.0020  | U    | ug/L  | P425700  |          |
|           |             | Fenuron          | 0.032   | U    | ug/L  | P425700  |          |
|           |             | Fluridone        | 8.0E-04 | U    | ug/L  | P425700  |          |
|           |             | Imazapyr         | 0.17    |      | ug/L  | P425700  |          |
|           |             | Hydrocodone      | 0.0020  | U    | ug/L  | P425700  |          |
|           |             | Ibuprofen        | 0.080   | U    | ug/L  | P425700  |          |
|           |             | Imidacloprid     | 0.0032  | I    | ug/L  | P425700  |          |
|           |             | Linuron          | 0.0040  | U    | ug/L  | P425700  |          |
|           |             | Mandestrobin     | 0.0020  | U    | ug/L  | P425700  |          |
|           |             | MCPP             | 0.0020  | U    | ug/L  | P425700  |          |
|           |             | Naproxen         | 0.0080  | U    | ug/L  | P425700  |          |
|           |             | Primidone        | 0.0040  | U    | ug/L  | P425700  |          |
|           |             | Pyraclostrobin   | 0.0020  | U    | ug/L  | P425700  |          |
|           |             | Silvex           | 0.0040  | U    | ug/L  | P425700  |          |
|           |             | Thiamethoxam     | 0.0020  | U    | ug/L  | P425700  |          |
|           |             | Tolfenpyrad      | 0.0020  | U    | ug/L  | P425700  |          |
|           |             | Triclopyr        | 0.0040  | U    | ug/L  | P425700  |          |

Ref. Method and Comment:

EPA 8321B: MS accuracy for some analytes could not be assessed due to high concentration of parameter in the spiked sample.

## Quality Assurance Report

### Method Blank Results

Reference Method: EPA 8270E

Batch ID: P425594

| Component          | Result | Code | Units |
|--------------------|--------|------|-------|
| Aldrin             | 0.65   | U    | ng/L  |
| Aldrin             | 0.65   | U    | ng/L  |
| Alpha-BHC          | 0.10   | U    | ng/L  |
| Alpha-BHC          | 0.10   | U    | ng/L  |
| Alpha-Chlordane    | 0.20   | U    | ng/L  |
| Alpha-Chlordane    | 0.20   | U    | ng/L  |
| Beta-BHC           | 0.10   | U    | ng/L  |
| Beta-BHC           | 0.10   | U    | ng/L  |
| Beta-Cyfluthrin    | 1.2    | U    | ng/L  |
| Beta-Cyfluthrin    | 1.2    | U    | ng/L  |
| Bifenthrin         | 0.50   | U    | ng/L  |
| Bifenthrin         | 0.50   | U    | ng/L  |
| Chlorothalonil     | 3.6    | U    | ng/L  |
| Chlorothalonil     | 3.6    | U    | ng/L  |
| Cis-Nonachlor      | 0.20   | U    | ng/L  |
| Cis-Nonachlor      | 0.20   | U    | ng/L  |
| Cypermethrin       | 1.5    | U    | ng/L  |
| Cypermethrin       | 1.5    | U    | ng/L  |
| Dacthal            | 0.15   | U    | ng/L  |
| Dacthal            | 0.15   | U    | ng/L  |
| DDD-p,p'           | 0.25   | U    | ng/L  |
| DDD-p,p'           | 0.25   | U    | ng/L  |
| DDE-p,p'           | 0.20   | U    | ng/L  |
| DDE-p,p'           | 0.20   | U    | ng/L  |
| DDT-p,p'           | 0.25   | U    | ng/L  |
| DDT-p,p'           | 0.25   | U    | ng/L  |
| Delta-BHC          | 0.40   | U    | ng/L  |
| Delta-BHC          | 0.40   | U    | ng/L  |
| Deltamethrin       | 1.2    | U    | ng/L  |
| Deltamethrin       | 1.2    | U    | ng/L  |
| Dichlobenil        | 0.25   | U    | ng/L  |
| Dichlobenil        | 0.25   | U    | ng/L  |
| Dicofol            | 1.2    | U    | ng/L  |
| Dicofol            | 1.2    | U    | ng/L  |
| Dieldrin           | 0.40   | U    | ng/L  |
| Dieldrin           | 0.40   | U    | ng/L  |
| Endosulfan I       | 0.40   | U    | ng/L  |
| Endosulfan I       | 0.40   | U    | ng/L  |
| Endosulfan II      | 0.40   | U    | ng/L  |
| Endosulfan II      | 0.40   | U    | ng/L  |
| Endosulfan Sulfate | 0.30   | U    | ng/L  |
| Endosulfan Sulfate | 0.30   | U    | ng/L  |
| Endrin             | 0.40   | U    | ng/L  |
| Endrin             | 0.40   | U    | ng/L  |
| Endrin Aldehyde    | 0.75   | U    | ng/L  |
| Endrin Aldehyde    | 0.75   | U    | ng/L  |
| Endrin Ketone      | 0.40   | U    | ng/L  |
| Endrin Ketone      | 0.40   | U    | ng/L  |
| Esfenvalerate      | 0.75   | U    | ng/L  |
| Esfenvalerate      | 0.75   | U    | ng/L  |
| Ethalfuralin       | 0.15   | U    | ng/L  |
| Ethalfuralin       | 0.15   | U    | ng/L  |

## Quality Assurance Report Method Blank Results

Reference Method: EPA 8270E

Batch ID: P425594

| Component          | Result | Code | Units |
|--------------------|--------|------|-------|
| Fenpropathrin      | 0.25   | U    | ng/L  |
| Fenpropathrin      | 0.25   | U    | ng/L  |
| Gamma-BHC          | 0.12   | U    | ng/L  |
| Gamma-BHC          | 0.12   | U    | ng/L  |
| Gamma-Chlordane    | 0.20   | U    | ng/L  |
| Gamma-Chlordane    | 0.20   | U    | ng/L  |
| Heptachlor         | 0.20   | U    | ng/L  |
| Heptachlor         | 0.20   | U    | ng/L  |
| Heptachlor Epoxide | 0.25   | U    | ng/L  |
| Heptachlor Epoxide | 0.25   | U    | ng/L  |
| Hexachlorobenzene  | 1.0    | U    | ng/L  |
| Hexachlorobenzene  | 1.0    | U    | ng/L  |
| Kepone             | 5.0    | U    | ng/L  |
| Kepone             | 5.0    | U    | ng/L  |
| Lambda-Cyhalothrin | 0.75   | U    | ng/L  |
| Lambda-Cyhalothrin | 0.75   | U    | ng/L  |
| Methoprene         | 0.75   | U    | ng/L  |
| Methoprene         | 0.75   | U    | ng/L  |
| Methoxychlor       | 0.30   | U    | ng/L  |
| Methoxychlor       | 0.30   | U    | ng/L  |
| MGK-264            | 0.20   | U    | ng/L  |
| MGK-264            | 0.20   | U    | ng/L  |
| Mirex              | 0.35   | U    | ng/L  |
| Mirex              | 0.35   | U    | ng/L  |
| Oxychlordane       | 0.30   | U    | ng/L  |
| Oxychlordane       | 0.30   | U    | ng/L  |
| PCB-1016           | 2.0    | U    | ng/L  |
| PCB-1016           | 2.0    | U    | ng/L  |
| PCB-1221           | 2.0    | U    | ng/L  |
| PCB-1221           | 2.0    | U    | ng/L  |
| PCB-1232           | 2.0    | U    | ng/L  |
| PCB-1232           | 2.0    | U    | ng/L  |
| PCB-1242           | 2.0    | U    | ng/L  |
| PCB-1242           | 2.0    | U    | ng/L  |
| PCB-1248           | 2.0    | U    | ng/L  |
| PCB-1248           | 2.0    | U    | ng/L  |
| PCB-1254           | 2.0    | U    | ng/L  |
| PCB-1254           | 2.0    | U    | ng/L  |
| PCB-1260           | 2.0    | U    | ng/L  |
| PCB-1260           | 2.0    | U    | ng/L  |
| Permethrin         | 1.6    | U    | ng/L  |
| Permethrin         | 1.6    | U    | ng/L  |
| Phenothrin         | 0.90   | U    | ng/L  |
| Phenothrin         | 0.90   | U    | ng/L  |
| Piperonyl Butoxide | 0.15   | U    | ng/L  |
| Piperonyl Butoxide | 0.15   | U    | ng/L  |
| Prallethrin        | 2.0    | U    | ng/L  |
| Prallethrin        | 2.0    | U    | ng/L  |
| Tau-Fluvalinate    | 0.25   | U    | ng/L  |
| Tau-Fluvalinate    | 0.25   | U    | ng/L  |
| Tetramethrin       | 0.75   | U    | ng/L  |
| Tetramethrin       | 0.75   | U    | ng/L  |

## Quality Assurance Report Method Blank Results

Reference Method: EPA 8270E

Batch ID: P425594

| Component        | Result | Code | Units |
|------------------|--------|------|-------|
| Trans-Nonachlor  | 0.20   | U    | ng/L  |
| Trans-Nonachlor  | 0.20   | U    | ng/L  |
| Triclosan Methyl | 0.15   | U    | ng/L  |
| Triclosan Methyl | 0.15   | U    | ng/L  |
| Trifluralin      | 0.20   | U    | ng/L  |
| Trifluralin      | 0.20   | U    | ng/L  |

Reference Method: EPA 8276

Batch ID: P425594

| Component | Result | Code | Units |
|-----------|--------|------|-------|
| Chlordane | 2.0    | U    | ng/L  |
| Chlordane | 2.0    | U    | ng/L  |
| Toxaphene | 15     | U    | ng/L  |
| Toxaphene | 15     | U    | ng/L  |

Reference Method: EPA 8321B

Batch ID: P425585

| Component    | Result | Code | Units |
|--------------|--------|------|-------|
| Acesulfame K | 0.10   | U    | ug/L  |
| AMPA         | 0.10   | U    | ug/L  |
| Endothall    | 0.25   | U    | ug/L  |
| Glufosinate  | 0.10   | U    | ug/L  |
| Glyphosate   | 0.10   | U    | ug/L  |
| Sucralose    | 0.010  | U    | ug/L  |

Reference Method: EPA 8321B

Batch ID: P425700

| Component        | Result  | Code | Units |
|------------------|---------|------|-------|
| 2,4-D            | 0.0020  | U    | ug/L  |
| 2,4,5-T          | 0.0040  | U    | ug/L  |
| Acetaminophen    | 0.0080  | U    | ug/L  |
| Acetamiprid      | 0.0020  | U    | ug/L  |
| Afidopyropen     | 0.0020  | U    | ug/L  |
| Bentazon         | 8.0E-04 | U    | ug/L  |
| Benzovindiflupyr | 0.0020  | U    | ug/L  |
| Carbamazepine    | 8.0E-04 | U    | ug/L  |
| Clothianidin     | 0.0020  | U    | ug/L  |
| Dinotefuran      | 0.0020  | U    | ug/L  |
| Diuron           | 0.0020  | U    | ug/L  |
| Fenuron          | 0.032   | U    | ug/L  |
| Fluridone        | 8.0E-04 | U    | ug/L  |
| Hydrocodone      | 0.0020  | U    | ug/L  |
| Ibuprofen        | 0.080   | U    | ug/L  |
| Imazapyr         | 0.0040  | U    | ug/L  |
| Imidacloprid     | 0.0020  | U    | ug/L  |
| Linuron          | 0.0040  | U    | ug/L  |
| Mandestrobin     | 0.0020  | U    | ug/L  |
| MCPP             | 0.0020  | U    | ug/L  |
| Naproxen         | 0.0080  | U    | ug/L  |

---

## Quality Assurance Report

### Method Blank Results

Reference Method: EPA 8321B  
Batch ID: P425700

| Component      | Result | Code | Units |
|----------------|--------|------|-------|
| Primidone      | 0.0040 | U    | ug/L  |
| Pyraclostrobin | 0.0020 | U    | ug/L  |
| Silvex         | 0.0040 | U    | ug/L  |
| Thiamethoxam   | 0.0020 | U    | ug/L  |
| Tolfenpyrad    | 0.0020 | U    | ug/L  |
| Triclopyr      | 0.0040 | U    | ug/L  |

## Quality Assurance Report

### Laboratory Control Sample Accuracy

Reference Method: EPA 8270E

Batch ID: P425594

| Component          | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|--------------------|---------|---------|-----------|----------------|
| Aldrin             | 61.7    |         | P         | 10 - 92.0      |
| Alpha-BHC          | 90.2    |         | P         | 75 - 107       |
| Alpha-Chlordane    | 105     |         | P         | 50 - 108       |
| Beta-BHC           | 114     |         | P         | 36 - 138       |
| Beta-Cyfluthrin    | 88.2    |         | P         | 20 - 161       |
| Bifenthrin         | 72.8    |         | P         | 10 - 119       |
| Chlorothalonil     | 120     |         | P         | 26 - 186       |
| Cis-Nonachlor      | 74.4    |         | P         | 42 - 119       |
| Cypermethrin       | 59.0    |         | P         | 22 - 150       |
| Dacthal            | 92.3    |         | P         | 72 - 119       |
| DDD-p,p'           | 99.8    |         | P         | 45 - 107       |
| DDE-p,p'           | 102     |         | P         | 48 - 106       |
| DDT-p,p'           | 75.8    |         | P         | 48 - 110       |
| Delta-BHC          | 111     |         | P         | 54 - 140       |
| Deltamethrin       | 79.8    |         | P         | 22 - 189       |
| Dichlobenil        | 88.5    |         | P         | 36 - 117       |
| Dicofol            | 87.2    |         | P         | 46 - 155       |
| Dieldrin           | 103     |         | P         | 54 - 110       |
| Endosulfan I       | 91.8    |         | P         | 59 - 105       |
| Endosulfan II      | 115     |         | P         | 51 - 118       |
| Endosulfan Sulfate | 114     |         | P         | 57 - 121       |
| Endrin             | 106     |         | P         | 10 - 120       |
| Endrin Aldehyde    | 71.7    |         | P         | 34 - 118       |
| Endrin Ketone      | 75.2    |         | P         | 69 - 177       |
| Esfenvalerate      | 98.1    |         | P         | 23 - 168       |
| Ethalfuralin       | 82.5    |         | P         | 49 - 99.0      |
| Fenpropathrin      | 73.8    |         | P         | 34 - 117       |
| Gamma-BHC          | 84.7    |         | P         | 72 - 117       |
| Gamma-Chlordane    | 75.9    |         | P         | 43 - 106       |
| Heptachlor         | 80.0    |         | P         | 41 - 98.0      |
| Heptachlor Epoxide | 92.4    |         | P         | 57 - 106       |
| Hexachlorobenzene  | 85.4    |         | P         | 36 - 99.0      |
| Kepone             | 183     |         | P         | 16 - 215       |
| Lambda-Cyhalothrin | 72.2    |         | P         | 21 - 177       |
| Methoprene         | 96.8    |         | P         | 10 - 119       |
| Methoxychlor       | 88.5    |         | P         | 60 - 112       |
| MGK-264            | 92.9    |         | P         | 26 - 122       |
| Mirex              | 63.5    |         | P         | 10 - 169       |
| Oxychlordane       | 89.8    |         | P         | 43 - 105       |
| PCB-1016           | 90.0    |         | P         | 48 - 112       |
| PCB-1260           | 83.9    |         | P         | 44 - 118       |
| Permethrin         | 118     |         | P         | 24 - 148       |
| Phenothrin         | 65.3    |         | P         | 10 - 106       |
| Piperonyl Butoxide | 116     |         | P         | 10 - 139       |
| Prallethrin        | 109     |         | P         | 17 - 109       |
| Tau-Fluvalinate    | 81.5    |         | P         | 13 - 131       |
| Tetramethrin       | 112     |         | P         | 10 - 132       |
| Trans-Nonachlor    | 88.9    |         | P         | 44 - 106       |
| Triclosan Methyl   | 86.2    |         | P         | 59 - 109       |
| Trifluralin        | 85.9    |         | P         | 44 - 101       |

## Quality Assurance Report Laboratory Control Sample Accuracy

Reference Method: EPA 8276  
Batch ID: P425594

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Chlordane | 110     |         | P         | 53 - 126       |
| Toxaphene | 128     |         | P         | 56 - 211       |

Reference Method: EPA 8321B  
Batch ID: P425585

| Component    | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|--------------|---------|---------|-----------|----------------|
| Acesulfame K | 96.2    |         | P         | 40 - 150       |
| AMPA         | 99.0    |         | P         | 40 - 150       |
| Endothall    | 98.4    |         | P         | 40 - 150       |
| Glufosinate  | 99.2    |         | P         | 40 - 150       |
| Glyphosate   | 98.5    |         | P         | 40 - 150       |
| Sucralose    | 96.7    |         | P         | 40 - 150       |

Reference Method: EPA 8321B  
Batch ID: P425700

| Component        | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|------------------|---------|---------|-----------|----------------|
| 2,4-D            | 84.5    |         | P         | 40 - 150       |
| 2,4,5-T          | 72.1    |         | P         | 40 - 150       |
| Acetaminophen    | 87.3    |         | P         | 30 - 150       |
| Acetamiprid      | 85.7    |         | P         | 40 - 150       |
| Afidopyropen     | 73.1    |         | P         | 30 - 150       |
| Bentazon         | 106     |         | P         | 30 - 150       |
| Benzovindiflupyr | 80.5    |         | P         | 40 - 150       |
| Carbamazepine    | 82.0    |         | P         | 40 - 150       |
| Clothianidin     | 91.5    |         | P         | 40 - 150       |
| Dinotefuran      | 95.5    |         | P         | 40 - 150       |
| Diuron           | 72.3    |         | P         | 40 - 150       |
| Fenuron          | 91.7    |         | P         | 40 - 150       |
| Fluridone        | 79.0    |         | P         | 40 - 150       |
| Hydrocodone      | 75.8    |         | P         | 40 - 150       |
| Ibuprofen        | 84.7    |         | P         | 40 - 150       |
| Imazapyr         | 80.8    |         | P         | 40 - 150       |
| Imidacloprid     | 84.6    |         | P         | 40 - 150       |
| Linuron          | 69.1    |         | P         | 40 - 150       |
| Mandestrobin     | 85.9    |         | P         | 40 - 150       |
| MCPP             | 88.3    |         | P         | 40 - 150       |
| Naproxen         | 66.2    |         | P         | 40 - 150       |
| Primidone        | 77.7    |         | P         | 40 - 150       |
| Pyraclostrobin   | 75.3    |         | P         | 40 - 150       |
| Silvex           | 76.8    |         | P         | 40 - 150       |
| Thiamethoxam     | 84.6    |         | P         | 40 - 150       |
| Tolfenpyrad      | 51.6    |         | P         | 30 - 150       |
| Triclopyr        | 68.8    |         | P         | 40 - 150       |

## Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 8270E

Batch ID: P425594

| Spiked Sample | Component          | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|--------------------|---------|---------|-----------|----------------|
| 2386475       | Aldrin             | 53.2    | 59.6    | P/P       | 20 - 82.0      |
| 2386475       | Alpha-BHC          | 87.2    | 87.6    | P/P       | 71 - 109       |
| 2386475       | Alpha-Chlordane    | 108     | 113     | F/F       | 42 - 106       |
| 2386475       | Beta-BHC           | 130     | 134     | P/P       | 69 - 180       |
| 2386475       | Beta-Cyfluthrin    | 130     | 139     | P/P       | 18 - 175       |
| 2386475       | Bifenthrin         | 70.5    | 78.6    | P/P       | 21 - 128       |
| 2386475       | Chlorothalonil     | 111     | 122     | P/P       | 10 - 300       |
| 2386475       | Cis-Nonachlor      | 72.1    | 78.5    | P/P       | 34 - 106       |
| 2386475       | Cypermethrin       | 76.2    | 84.2    | P/P       | 22 - 158       |
| 2386475       | Dacthal            | 90.3    | 87.4    | P/P       | 54 - 116       |
| 2386475       | DDD-p,p'           | 118     | 114     | F/F       | 34 - 107       |
| 2386475       | DDE-p,p'           | 117     | 118     | F/F       | 33 - 110       |
| 2386475       | DDT-p,p'           | 76.6    | 78.1    | P/P       | 50 - 122       |
| 2386475       | Delta-BHC          | 129     | 131     | P/P       | 77 - 193       |
| 2386475       | Deltamethrin       | 139     | 117     | P/P       | 10 - 195       |
| 2386475       | Dichlobenil        | 70.0    | 63.7    | P/P       | 25 - 113       |
| 2386475       | Dicofol            | 84.1    | 90.6    | P/P       | 38 - 247       |
| 2386475       | Dieldrin           | 112     | 116     | P/P       | 45 - 118       |
| 2386475       | Endosulfan I       | 81.9    | 81.9    | P/P       | 51 - 106       |
| 2386475       | Endosulfan II      | 107     | 108     | P/P       | 37 - 122       |
| 2386475       | Endosulfan Sulfate | 125     | 115     | P/P       | 43 - 132       |
| 2386475       | Endrin             | 116     | 120     | F/F       | 29 - 101       |
| 2386475       | Endrin Aldehyde    | 71.1    | 71.9    | P/P       | 19 - 110       |
| 2386475       | Endrin Ketone      | 80.3    | 83.1    | P/P       | 60 - 140       |
| 2386475       | Esfenvalerate      | 144     | 158     | P/P       | 26 - 199       |
| 2386475       | Ethalfuralin       | 84.5    | 84.9    | P/P       | 45 - 99.0      |
| 2386475       | Fenpropathrin      | 82.5    | 81.9    | P/P       | 35 - 120       |
| 2386475       | Gamma-BHC          | 76.8    | 78.8    | P/P       | 63 - 128       |
| 2386475       | Gamma-Chlordane    | 75.2    | 82.7    | P/P       | 40 - 104       |
| 2386475       | Heptachlor         | 68.2    | 72.7    | P/P       | 36 - 97.0      |
| 2386475       | Heptachlor Epoxide | 81.3    | 79.9    | P/P       | 49 - 184       |
| 2386475       | Hexachlorobenzene  | 80.7    | 81.2    | P/P       | 39 - 96.0      |
| 2386475       | Kepone             | 180     | 182     | P/P       | 10 - 217       |
| 2386475       | Lambda-Cyhalothrin | 94.6    | 100     | P/P       | 21 - 193       |
| 2386475       | Methoprene         | 116     | 122     | F/F       | 20 - 106       |
| 2386475       | Methoxychlor       | 86.4    | 93.0    | P/P       | 53 - 118       |
| 2386475       | MGK-264            | 76.4    | 82.6    | P/P       | 40 - 118       |
| 2386475       | Mirex              | 76.1    | 74.6    | P/P       | 26 - 92.0      |
| 2386475       | Oxychlordane       | 77.8    | 80.1    | P/P       | 44 - 99.0      |
| 2386475       | Permethrin         | 127     | 151     | P/P       | 33 - 182       |
| 2386475       | Phenothrin         | 84.6    | 93.8    | P/P       | 10 - 129       |
| 2386475       | Piperonyl Butoxide | 109     | 109     | P/P       | 10 - 211       |
| 2386475       | Prallethrin        | 107     | 120     | P/F       | 24 - 113       |
| 2386475       | Tau-Fluvalinate    | 132     | 144     | P/P       | 14 - 149       |
| 2386475       | Tetramethrin       | 113     | 120     | P/P       | 17 - 151       |
| 2386475       | Trans-Nonachlor    | 80.1    | 84.1    | P/P       | 42 - 102       |
| 2386475       | Triclosan Methyl   | 83.5    | 86.1    | P/P       | 48 - 108       |
| 2386475       | Trifluralin        | 83.5    | 85.1    | P/P       | 47 - 96.0      |
| 2386481       | PCB-1016           | 85.6    | 88.5    | P/P       | 46 - 111       |
| 2386481       | PCB-1260           | 80.4    | 81.5    | P/P       | 45 - 114       |

## Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 8276  
Batch ID: P425594

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 2386481       | Chlordane | 108     | 115     | P/P       | 53 - 126       |
| 2386481       | Toxaphene | 120     | 136     | P/P       | 56 - 211       |

Reference Method: EPA 8321B  
Batch ID: P425585

| Spiked Sample | Component    | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|--------------|---------|---------|-----------|----------------|
| 2386143       | Acesulfame K | 77.6    | 79.3    | P/P       | 40 - 150       |
| 2386143       | AMPA         | 95.2    | 101     | P/P       | 40 - 150       |
| 2386143       | Endothall    | 153     | 152     | F/F       | 40 - 150       |
| 2386143       | Glufosinate  | 117     | 116     | P/P       | 40 - 150       |
| 2386143       | Glyphosate   | 126     | 133     | P/P       | 40 - 150       |
| 2386143       | Sucralose    | 62.3    | 65.5    | P/P       | 40 - 150       |

Reference Method: EPA 8321B  
Batch ID: P425700

| Spiked Sample | Component        | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|------------------|---------|---------|-----------|----------------|
| 2386373       | 2,4-D            | 99.3    | 104     | P/P       | 40 - 150       |
| 2386373       | 2,4,5-T          | 86.0    | 86.9    | P/P       | 40 - 150       |
| 2386373       | Acetaminophen    | 101     | 106     | P/P       | 30 - 150       |
| 2386373       | Acetamiprid      | 102     | 95.7    | P/P       | 40 - 150       |
| 2386373       | Afidopyropen     | 60.6    | 77.7    | P/P       | 30 - 150       |
| 2386373       | Benzovindiflupyr | 82.2    | 86.0    | P/P       | 40 - 150       |
| 2386373       | Carbamazepine    | 91.7    | 89.8    | P/P       | 40 - 150       |
| 2386373       | Clothianidin     | 99.0    | 106     | P/P       | 40 - 150       |
| 2386373       | Dinotefuran      | 106     | 114     | P/P       | 40 - 150       |
| 2386373       | Diuron           | 74.1    | 81.6    | P/P       | 40 - 150       |
| 2386373       | Fenuron          | 89.2    | 91.5    | P/P       | 40 - 150       |
| 2386373       | Fluridone        | 60.4    | 81.7    | P/P       | 40 - 150       |
| 2386373       | Hydrocodone      | 99.1    | 82.9    | P/P       | 40 - 150       |
| 2386373       | Ibuprofen        | 96.2    | 97.5    | P/P       | 40 - 150       |
| 2386373       | Imidacloprid     | 122     | 126     | P/P       | 40 - 150       |
| 2386373       | Linuron          | 72.5    | 70.7    | P/P       | 40 - 150       |
| 2386373       | Mandestrobin     | 90.6    | 88.9    | P/P       | 40 - 150       |
| 2386373       | MCPP             | 104     | 104     | P/P       | 40 - 150       |
| 2386373       | Naproxen         | 85.9    | 96.2    | P/P       | 40 - 150       |
| 2386373       | Primidone        | 94.1    | 85.5    | P/P       | 40 - 150       |
| 2386373       | Pyraclostrobin   | 84.2    | 87.7    | P/P       | 40 - 150       |
| 2386373       | Silvex           | 85.7    | 98.7    | P/P       | 40 - 150       |
| 2386373       | Thiamethoxam     | 98.2    | 108     | P/P       | 40 - 150       |
| 2386373       | Tolfenpyrad      | 50.5    | 53.7    | P/P       | 30 - 150       |
| 2386373       | Triclopyr        | 85.0    | 82.7    | P/P       | 40 - 150       |

## Quality Assurance Report Precision

Reference Method: EPA 8270E  
Batch ID: P425594

| Replicated<br>Lab Sample | Component          | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|--------------------|-----------|-------------------|-----------|----------------|
| 2386475                  | Aldrin             | 11.4      | Spike             | P         | 0 - 41         |
| 2386475                  | Alpha-BHC          | 0.461     | Spike             | P         | 0 - 25         |
| 2386475                  | Alpha-Chlordane    | 4.46      | Spike             | P         | 0 - 33         |
| 2386475                  | Beta-BHC           | 2.85      | Spike             | P         | 0 - 36         |
| 2386475                  | Beta-Cyfluthrin    | 6.38      | Spike             | P         | 0 - 42         |
| 2386475                  | Bifenthrin         | 11.0      | Spike             | P         | 0 - 53         |
| 2386475                  | Chlorothalonil     | 9.51      | Spike             | P         | 0 - 71         |
| 2386475                  | Cis-Nonachlor      | 8.53      | Spike             | P         | 0 - 29         |
| 2386475                  | Cypermethrin       | 9.98      | Spike             | P         | 0 - 40         |
| 2386475                  | Dacthal            | 3.35      | Spike             | P         | 0 - 26         |
| 2386475                  | DDD-p,p'           | 3.48      | Spike             | P         | 0 - 39         |
| 2386475                  | DDE-p,p'           | 0.886     | Spike             | P         | 0 - 33         |
| 2386475                  | DDT-p,p'           | 1.89      | Spike             | P         | 0 - 40         |
| 2386475                  | Delta-BHC          | 1.25      | Spike             | P         | 0 - 37         |
| 2386475                  | Deltamethrin       | 16.9      | Spike             | P         | 0 - 100        |
| 2386475                  | Dichlobenil        | 9.41      | Spike             | P         | 0 - 40         |
| 2386475                  | Dicofol            | 7.41      | Spike             | P         | 0 - 31         |
| 2386475                  | Dieldrin           | 3.27      | Spike             | P         | 0 - 27         |
| 2386475                  | Endosulfan I       | 0.0825    | Spike             | P         | 0 - 23         |
| 2386475                  | Endosulfan II      | 0.549     | Spike             | P         | 0 - 28         |
| 2386475                  | Endosulfan Sulfate | 7.79      | Spike             | P         | 0 - 38         |
| 2386475                  | Endrin             | 3.18      | Spike             | P         | 0 - 63         |
| 2386475                  | Endrin Aldehyde    | 1.21      | Spike             | P         | 0 - 60         |
| 2386475                  | Endrin Ketone      | 3.33      | Spike             | P         | 0 - 37         |
| 2386475                  | Esfenvalerate      | 9.47      | Spike             | P         | 0 - 52         |
| 2386475                  | Ethalfuralin       | 0.493     | Spike             | P         | 0 - 23         |
| 2386475                  | Fenpropathrin      | 0.707     | Spike             | P         | 0 - 32         |
| 2386475                  | Gamma-BHC          | 2.48      | Spike             | P         | 0 - 17         |
| 2386475                  | Gamma-Chlordane    | 9.53      | Spike             | P         | 0 - 40         |
| 2386475                  | Heptachlor         | 6.31      | Spike             | P         | 0 - 29         |
| 2386475                  | Heptachlor Epoxide | 1.75      | Spike             | P         | 0 - 25         |
| 2386475                  | Hexachlorobenzene  | 0.594     | Spike             | P         | 0 - 36         |
| 2386475                  | Kepone             | 0.742     | Spike             | P         | 0 - 93         |
| 2386475                  | Lambda-Cyhalothrin | 5.83      | Spike             | P         | 0 - 55         |
| 2386475                  | Methoprene         | 4.60      | Spike             | P         | 0 - 53         |
| 2386475                  | Methoxychlor       | 7.33      | Spike             | P         | 0 - 29         |
| 2386475                  | MGK-264            | 7.79      | Spike             | P         | 0 - 35         |
| 2386475                  | Mirex              | 1.97      | Spike             | P         | 0 - 46         |
| 2386475                  | Oxychlordane       | 2.95      | Spike             | P         | 0 - 29         |
| 2386475                  | Permethrin         | 17.4      | Spike             | P         | 0 - 44         |
| 2386475                  | Phenothrin         | 10.3      | Spike             | P         | 0 - 56         |
| 2386475                  | Piperonyl Butoxide | 0.774     | Spike             | P         | 0 - 100        |
| 2386475                  | Prallethrin        | 11.3      | Spike             | P         | 0 - 42         |
| 2386475                  | Tau-Fluvalinate    | 8.42      | Spike             | P         | 0 - 54         |
| 2386475                  | Tetramethrin       | 5.67      | Spike             | P         | 0 - 51         |
| 2386475                  | Trans-Nonachlor    | 4.84      | Spike             | P         | 0 - 37         |
| 2386475                  | Triclosan Methyl   | 3.04      | Spike             | P         | 0 - 31         |
| 2386475                  | Trifluralin        | 1.86      | Spike             | P         | 0 - 30         |
| 2386481                  | PCB-1016           | 3.27      | Spike             | P         | 0 - 32         |
| 2386481                  | PCB-1260           | 1.38      | Spike             | P         | 0 - 31         |

## Quality Assurance Report Precision

Reference Method: EPA 8276  
Batch ID: P425594

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 2386481                  | Chlordane | 6.27      | Spike             | P         | 0 - 25         |
| 2386481                  | Toxaphene | 12.3      | Spike             | P         | 0 - 26         |

Reference Method: EPA 8321B  
Batch ID: P425585

| Replicated<br>Lab Sample | Component    | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|--------------|-----------|-------------------|-----------|----------------|
| 2386143                  | Acesulfame K | 2.19      | Spike             | P         | 0 - 30         |
| 2386143                  | AMPA         | 5.09      | Spike             | P         | 0 - 30         |
| 2386143                  | Endothall    | 1.24      | Spike             | P         | 0 - 30         |
| 2386143                  | Glufosinate  | 0.483     | Spike             | P         | 0 - 30         |
| 2386143                  | Glyphosate   | 5.44      | Spike             | P         | 0 - 30         |
| 2386143                  | Sucralose    | 4.88      | Spike             | P         | 0 - 30         |

Reference Method: EPA 8321B  
Batch ID: P425700

| Replicated<br>Lab Sample | Component        | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|------------------|-----------|-------------------|-----------|----------------|
| 2386373                  | 2,4-D            | 4.46      | Spike             | P         | 0 - 30         |
| 2386373                  | 2,4,5-T          | 1.08      | Spike             | P         | 0 - 30         |
| 2386373                  | Acetaminophen    | 4.87      | Spike             | P         | 0 - 30         |
| 2386373                  | Acetamiprid      | 5.90      | Spike             | P         | 0 - 30         |
| 2386373                  | Afidopyropen     | 24.7      | Spike             | P         | 0 - 30         |
| 2386373                  | Bentazon         | 1.35      | Spike             | P         | 0 - 30         |
| 2386373                  | Benzovindiflupyr | 4.56      | Spike             | P         | 0 - 30         |
| 2386373                  | Carbamazepine    | 2.12      | Spike             | P         | 0 - 30         |
| 2386373                  | Clothianidin     | 7.24      | Spike             | P         | 0 - 30         |
| 2386373                  | Dinotefuran      | 6.79      | Spike             | P         | 0 - 30         |
| 2386373                  | Diuron           | 8.93      | Spike             | P         | 0 - 30         |
| 2386373                  | Fenuron          | 2.56      | Spike             | P         | 0 - 30         |
| 2386373                  | Fluridone        | 14.1      | Spike             | P         | 0 - 30         |
| 2386373                  | Hydrocodone      | 17.9      | Spike             | P         | 0 - 30         |
| 2386373                  | Ibuprofen        | 1.35      | Spike             | P         | 0 - 30         |
| 2386373                  | Imazapyr         | 3.17      | Spike             | P         | 0 - 30         |
| 2386373                  | Imidacloprid     | 2.75      | Spike             | P         | 0 - 30         |
| 2386373                  | Linuron          | 2.54      | Spike             | P         | 0 - 30         |
| 2386373                  | Mandestrobin     | 1.97      | Spike             | P         | 0 - 30         |
| 2386373                  | MCPP             | 0.137     | Spike             | P         | 0 - 30         |
| 2386373                  | Naproxen         | 11.4      | Spike             | P         | 0 - 30         |
| 2386373                  | Primidone        | 9.64      | Spike             | P         | 0 - 30         |
| 2386373                  | Pyraclostrobin   | 4.08      | Spike             | P         | 0 - 30         |
| 2386373                  | Silvex           | 14.1      | Spike             | P         | 0 - 30         |
| 2386373                  | Thiamethoxam     | 9.83      | Spike             | P         | 0 - 30         |
| 2386373                  | Tolfenpyrad      | 6.14      | Spike             | P         | 0 - 30         |
| 2386373                  | Triclopyr        | 2.79      | Spike             | P         | 0 - 30         |

\* Sample, spike and/or laboratory control sample precision (LCS) is reported.

## Quality Assurance Report Surrogates

Lab Sample ID: 2386792  
Field Sample ID: 21030138

| Reference Method | Surrogate            | % Rec. | Pass/Fail | Control Limits |
|------------------|----------------------|--------|-----------|----------------|
| EPA 8270E        | Decachlorobiphenyl   | 81.1   | P         | 29 - 130       |
| EPA 8270E        | Decachlorobiphenyl   | 70.6   | P         | 30 - 118       |
| EPA 8270E        | Tetrachloro-m-xylene | 74.7   | P         | 29 - 104       |
| EPA 8270E        | Tetrachloro-m-xylene | 65.4   | P         | 30 - 97.0      |
| EPA 8276         | Decachlorobiphenyl   | 63.5   | P         | 30 - 101       |
| EPA 8276         | PCNB                 | 97.5   | P         | 48 - 121       |

Lab Sample ID: 2386793  
Field Sample ID: 21020063

| Reference Method | Surrogate          | % Rec. | Pass/Fail | Control Limits |
|------------------|--------------------|--------|-----------|----------------|
| EPA 8321B        | 2,4-D-d3           | 126    | P         | 30 - 160       |
| EPA 8321B        | Acetaminophen-d4   | 104    | P         | 30 - 160       |
| EPA 8321B        | Carbamazepine-d10  | 76.5   | P         | 30 - 160       |
| EPA 8321B        | Diuron-d6          | 51.5   | P         | 30 - 160       |
| EPA 8321B        | Endothall-d6       | 82.5   | P         | 30 - 160       |
| EPA 8321B        | Glyphosate 13C 15N | 106    | P         | 30 - 160       |
| EPA 8321B        | Ibuprofen-d3       | 84.4   | P         | 30 - 160       |
| EPA 8321B        | Primidone-d5       | 80.5   | P         | 30 - 160       |
| EPA 8321B        | Sucralose-d6       | 84.5   | P         | 30 - 160       |

Lab Sample ID: 2386794  
Field Sample ID: 21030016FLA

| Reference Method | Surrogate          | % Rec. | Pass/Fail | Control Limits |
|------------------|--------------------|--------|-----------|----------------|
| EPA 8321B        | 2,4-D-d3           | 112    | P         | 30 - 160       |
| EPA 8321B        | Acetaminophen-d4   | 109    | P         | 30 - 160       |
| EPA 8321B        | Carbamazepine-d10  | 70.9   | P         | 30 - 160       |
| EPA 8321B        | Diuron-d6          | 44.5   | P         | 30 - 160       |
| EPA 8321B        | Endothall-d6       | 104    | P         | 30 - 160       |
| EPA 8321B        | Glyphosate 13C 15N | 107    | P         | 30 - 160       |
| EPA 8321B        | Ibuprofen-d3       | 87.3   | P         | 30 - 160       |
| EPA 8321B        | Primidone-d5       | 87.7   | P         | 30 - 160       |
| EPA 8321B        | Sucralose-d6       | 108    | P         | 30 - 160       |

## Quality Assurance Report Calibration Verification

Reference Method: EPA 8321B

Run ID: A117416

Included Lab Sample IDs: 2386793, 2386794

| Component    | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|--------------|---------|---------|------------|----------------|
| Acesulfame K | 102     | 103     | P/P        | 60 - 160       |
| Acesulfame K | 103     | 99.2    | P/P        | 60 - 160       |
| Sucralose    | 101     | 105     | P/P        | 60 - 160       |
| Sucralose    | 105     | 103     | P/P        | 60 - 160       |

Reference Method: EPA 8321B

Run ID: A117425

Included Lab Sample IDs: 2386793, 2386794

| Component   | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-------------|---------|---------|------------|----------------|
| AMPA        | 100     | 101     | P/P        | 60 - 160       |
| Endothall   | 63.9    | 89.4    | P/P        | 60 - 160       |
| Glufosinate | 84.5    | 88.1    | P/P        | 60 - 160       |
| Glyphosate  | 91.5    | 104     | P/P        | 60 - 160       |

Reference Method: EPA 8270E

Run ID: A117438

Included Lab Sample IDs: 2386792

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| PCB-1016  | 98.7    |         | P          | 80 - 120       |
| PCB-1260  | 94.4    |         | P          | 80 - 120       |

Reference Method: EPA 8321B

Run ID: A117459

Included Lab Sample IDs: 2386793, 2386794

| Component        | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|------------------|---------|---------|------------|----------------|
| 2,4-D            | 95.1    | 122     | P/P        | 50 - 150       |
| 2,4,5-T          | 115     | 103     | P/P        | 50 - 150       |
| Acetaminophen    | 103     | 105     | P/P        | 60 - 160       |
| Acetamiprid      | 105     | 103     | P/P        | 50 - 150       |
| Afidopyropen     | 114     | 87.6    | P/P        | 50 - 150       |
| Bentazon         | 121     | 137     | P/P        | 50 - 160       |
| Benzovindiflupyr | 101     | 107     | P/P        | 50 - 150       |
| Carbamazepine    | 119     | 148     | P/P        | 60 - 150       |
| Clothianidin     | 105     | 109     | P/P        | 60 - 150       |
| Dinotefuran      | 104     | 104     | P/P        | 50 - 150       |
| Diuron           | 104     | 121     | P/P        | 60 - 160       |
| Fenuron          | 103     | 100     | P/P        | 60 - 150       |
| Fluridone        | 121     | 104     | P/P        | 60 - 160       |
| Hydrocodone      | 95.1    | 100     | P/P        | 60 - 150       |
| Ibuprofen        | 144     | 119     | P/P        | 50 - 160       |
| Imazapyr         | 100     | 96.2    | P/P        | 50 - 150       |
| Imidacloprid     | 99.0    | 105     | P/P        | 60 - 150       |
| Linuron          | 105     | 101     | P/P        | 60 - 150       |
| Mandestrobin     | 101     | 105     | P/P        | 50 - 150       |
| MCPP             | 115     | 102     | P/P        | 50 - 150       |
| Naproxen         | 144     | 99.4    | P/P        | 50 - 160       |
| Primidone        | 94.7    | 98.1    | P/P        | 60 - 150       |
| Pyraclostrobin   | 111     | 107     | P/P        | 60 - 150       |

## Quality Assurance Report Calibration Verification

Reference Method: EPA 8321B

Run ID: A117459

Included Lab Sample IDs: 2386793, 2386794

| Component    | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|--------------|---------|---------|------------|----------------|
| Silvex       | 90.0    | 97.2    | P/P        | 50 - 150       |
| Thiamethoxam | 110     | 104     | P/P        | 50 - 150       |
| Tolfenpyrad  | 101     | 104     | P/P        | 60 - 150       |
| Triclopyr    | 102     | 97.0    | P/P        | 50 - 150       |

Reference Method: EPA 8270E

Run ID: A117532

Included Lab Sample IDs: 2386792

| Component          | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|--------------------|---------|---------|------------|----------------|
| Aldrin             | 105     |         | P          | 80 - 120       |
| Alpha-BHC          | 103     |         | P          | 80 - 120       |
| Alpha-Chlordane    | 101     |         | P          | 80 - 120       |
| Beta-BHC           | 105     |         | P          | 80 - 120       |
| Beta-Cyfluthrin    | 102     |         | P          | 80 - 120       |
| Bifenthrin         | 101     |         | P          | 80 - 120       |
| Chlorothalonil     | 93.2    |         | P          | 80 - 120       |
| Cis-Nonachlor      | 96.6    |         | P          | 80 - 120       |
| Cypermethrin       | 97.4    |         | P          | 80 - 120       |
| Dacthal            | 103     |         | P          | 80 - 120       |
| DDD-p,p'           | 95.7    |         | P          | 80 - 120       |
| DDE-p,p'           | 103     |         | P          | 80 - 120       |
| DDT-p,p'           | 101     |         | P          | 80 - 120       |
| Delta-BHC          | 98.9    |         | P          | 80 - 120       |
| Deltamethrin       | 99.2    |         | P          | 80 - 120       |
| Dichlobenil        | 101     |         | P          | 80 - 120       |
| Dicofol            | 99.7    |         | P          | 80 - 120       |
| Dieldrin           | 101     |         | P          | 80 - 120       |
| Endosulfan I       | 101     |         | P          | 80 - 120       |
| Endosulfan II      | 95.9    |         | P          | 80 - 120       |
| Endosulfan Sulfate | 100     |         | P          | 80 - 120       |
| Endrin             | 105     |         | P          | 80 - 120       |
| Endrin Aldehyde    | 96.4    |         | P          | 80 - 120       |
| Endrin Ketone      | 93.7    |         | P          | 80 - 120       |
| Esfenvalerate      | 96.1    |         | P          | 80 - 120       |
| Ethalfuralin       | 102     |         | P          | 80 - 120       |
| Fenpropathrin      | 104     |         | P          | 80 - 120       |
| Gamma-BHC          | 105     |         | P          | 80 - 120       |
| Gamma-Chlordane    | 98.2    |         | P          | 80 - 120       |
| Heptachlor         | 102     |         | P          | 80 - 120       |
| Heptachlor Epoxide | 105     |         | P          | 80 - 120       |
| Hexachlorobenzene  | 98.4    |         | P          | 80 - 120       |
| Kepone             | 87.2    |         | P          | 80 - 120       |
| Lambda-Cyhalothrin | 106     |         | P          | 80 - 120       |
| Methoprene         | 100     |         | P          | 80 - 120       |
| Methoxychlor       | 101     |         | P          | 80 - 120       |
| MGK-264            | 98.9    |         | P          | 80 - 120       |
| Mirex              | 104     |         | P          | 80 - 120       |
| Oxychlordane       | 106     |         | P          | 80 - 120       |
| Permethrin         | 104     |         | P          | 80 - 120       |
| Phenothrin         | 103     |         | P          | 80 - 120       |

## Quality Assurance Report Calibration Verification

Reference Method: EPA 8270E  
Run ID: A117532  
Included Lab Sample IDs: 2386792

| Component          | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|--------------------|---------|---------|------------|----------------|
| Piperonyl Butoxide | 85.6    |         | P          | 80 - 120       |
| Prallethrin        | 97.0    |         | P          | 80 - 120       |
| Tau-Fluvalinate    | 98.7    |         | P          | 80 - 120       |
| Tetramethrin       | 91.5    |         | P          | 80 - 120       |
| Trans-Nonachlor    | 103     |         | P          | 80 - 120       |
| Triclosan Methyl   | 97.4    |         | P          | 80 - 120       |
| Trifluralin        | 106     |         | P          | 80 - 120       |

Reference Method: EPA 8276  
Run ID: A117561  
Included Lab Sample IDs: 2386792

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Chlordane | 103     |         | P          | 80 - 120       |
| Toxaphene | 111     |         | P          | 80 - 120       |

\* Pass/Fail determinations are made for each bracketing calibration verification check.  
Control limits for initial calibration checks may be different from those for continuing checks, depending on method requirements.  
Where they are different, both control limits are provided.

## Quality Assurance Report Summary

| Ref. Method | Analyte            | LCS % Recovery |  | MS % Recovery |      | Precision |
|-------------|--------------------|----------------|--|---------------|------|-----------|
|             |                    |                |  | LCS           | SMP  | MS        |
| EPA 8270E   | Aldrin             | 61.7           |  | 53.2          | 59.6 | 11.4      |
|             | Alpha-BHC          | 90.2           |  | 87.2          | 87.6 | 0.461     |
|             | Alpha-Chlordane    | 105            |  | 108           | 113  | 4.46      |
|             | Beta-BHC           | 114            |  | 130           | 134  | 2.85      |
|             | Beta-Cyfluthrin    | 88.2           |  | 130           | 139  | 6.38      |
|             | Bifenthrin         | 72.8           |  | 70.5          | 78.6 | 11.0      |
|             | Chlorothalonil     | 120            |  | 111           | 122  | 9.51      |
|             | Cis-Nonachlor      | 74.4           |  | 72.1          | 78.5 | 8.53      |
|             | Cypermethrin       | 59.0           |  | 76.2          | 84.2 | 9.98      |
|             | Dacthal            | 92.3           |  | 90.3          | 87.4 | 3.35      |
|             | DDD-p,p'           | 99.8           |  | 118           | 114  | 3.48      |
|             | DDE-p,p'           | 102            |  | 117           | 118  | 0.886     |
|             | DDT-p,p'           | 75.8           |  | 76.6          | 78.1 | 1.89      |
|             | Delta-BHC          | 111            |  | 129           | 131  | 1.25      |
|             | Deltamethrin       | 79.8           |  | 139           | 117  | 16.9      |
|             | Dichlobenil        | 88.5           |  | 70.0          | 63.7 | 9.41      |
|             | Dicofol            | 87.2           |  | 84.1          | 90.6 | 7.41      |
|             | Dieldrin           | 103            |  | 112           | 116  | 3.27      |
|             | Endosulfan I       | 91.8           |  | 81.9          | 81.9 | 0.0825    |
|             | Endosulfan II      | 115            |  | 107           | 108  | 0.549     |
|             | Endosulfan Sulfate | 114            |  | 125           | 115  | 7.79      |
|             | Endrin             | 106            |  | 116           | 120  | 3.18      |
|             | Endrin Aldehyde    | 71.7           |  | 71.1          | 71.9 | 1.21      |
|             | Endrin Ketone      | 75.2           |  | 80.3          | 83.1 | 3.33      |
|             | Esfenvalerate      | 98.1           |  | 144           | 158  | 9.47      |
|             | Ethalfuralin       | 82.5           |  | 84.5          | 84.9 | 0.493     |
|             | Fenpropathrin      | 73.8           |  | 82.5          | 81.9 | 0.707     |
|             | Gamma-BHC          | 84.7           |  | 76.8          | 78.8 | 2.48      |
|             | Gamma-Chlordane    | 75.9           |  | 75.2          | 82.7 | 9.53      |
|             | Heptachlor         | 80.0           |  | 68.2          | 72.7 | 6.31      |
|             | Heptachlor Epoxide | 92.4           |  | 81.3          | 79.9 | 1.75      |
|             | Hexachlorobenzene  | 85.4           |  | 80.7          | 81.2 | 0.594     |
|             | Kepone             | 183            |  | 180           | 182  | 0.742     |
|             | Lambda-Cyhalothrin | 72.2           |  | 94.6          | 100  | 5.83      |
|             | Methoprene         | 96.8           |  | 116           | 122  | 4.60      |
|             | Methoxychlor       | 88.5           |  | 86.4          | 93.0 | 7.33      |
|             | MGK-264            | 92.9           |  | 76.4          | 82.6 | 7.79      |
|             | Mirex              | 63.5           |  | 76.1          | 74.6 | 1.97      |
|             | Oxychlordane       | 89.8           |  | 77.8          | 80.1 | 2.95      |
|             | PCB-1016           | 90.0           |  | 85.6          | 88.5 | 3.27      |
|             | PCB-1260           | 83.9           |  | 80.4          | 81.5 | 1.38      |
|             | Permethrin         | 118            |  | 127           | 151  | 17.4      |
|             | Phenothrin         | 65.3           |  | 84.6          | 93.8 | 10.3      |
|             | Piperonyl Butoxide | 116            |  | 109           | 109  | 0.774     |
|             | Prallethrin        | 109            |  | 107           | 120  | 11.3      |
|             | Tau-Fluvalinate    | 81.5           |  | 132           | 144  | 8.42      |
|             | Tetramethrin       | 112            |  | 113           | 120  | 5.67      |
|             | Trans-Nonachlor    | 88.9           |  | 80.1          | 84.1 | 4.84      |
|             | Triclosan Methyl   | 86.2           |  | 83.5          | 86.1 | 3.04      |
|             | Trifluralin        | 85.9           |  | 83.5          | 85.1 | 1.86      |
| EPA 8276    | Chlordane          | 110            |  | 108           | 115  | 6.27      |
|             | Toxaphene          | 128            |  | 120           | 136  | 12.3      |
| EPA 8321B   | 2,4-D              | 84.5           |  | 104           | 99.3 | 4.46      |
|             | 2,4,5-T            | 72.1           |  | 86.9          | 86.0 | 1.08      |

## Quality Assurance Report Summary

| Ref. Method | Analyte          | LCS % Recovery | MS % Recovery |      | Precision<br>SMP | MS    |
|-------------|------------------|----------------|---------------|------|------------------|-------|
|             |                  |                | LCS           | MS   |                  |       |
| EPA 8321B   | Acesulfame K     | 96.2           | 77.6          | 79.3 |                  | 2.19  |
|             | Acetaminophen    | 87.3           | 101           | 106  |                  | 4.87  |
|             | Acetamiprid      | 85.7           | 102           | 95.7 |                  | 5.90  |
|             | Afidopyropen     | 73.1           | 60.6          | 77.7 |                  | 24.7  |
|             | AMPA             | 99.0           | 95.2          | 101  |                  | 5.09  |
|             | Bentazon         | 106            |               |      |                  | 1.35  |
|             | Benzovindiflupyr | 80.5           | 86.0          | 82.2 |                  | 4.56  |
|             | Carbamazepine    | 82.0           | 91.7          | 89.8 |                  | 2.12  |
|             | Clothianidin     | 91.5           | 99.0          | 106  |                  | 7.24  |
|             | Dinotefuran      | 95.5           | 106           | 114  |                  | 6.79  |
|             | Diuron           | 72.3           | 74.1          | 81.6 |                  | 8.93  |
|             | Endothall        | 98.4           | 153           | 152  |                  | 1.24  |
|             | Fenuron          | 91.7           | 89.2          | 91.5 |                  | 2.56  |
|             | Fluridone        | 79.0           | 81.7          | 60.4 |                  | 14.1  |
|             | Glufosinate      | 99.2           | 117           | 116  |                  | 0.483 |
|             | Glyphosate       | 98.5           | 126           | 133  |                  | 5.44  |
|             | Hydrocodone      | 75.8           | 99.1          | 82.9 |                  | 17.9  |
|             | Ibuprofen        | 84.7           | 97.5          | 96.2 |                  | 1.35  |
|             | Imazapyr         | 80.8           |               |      |                  | 3.17  |
|             | Imidacloprid     | 84.6           | 122           | 126  |                  | 2.75  |
|             | Linuron          | 69.1           | 70.7          | 72.5 |                  | 2.54  |
|             | Mandestrobin     | 85.9           | 88.9          | 90.6 |                  | 1.97  |
|             | MCPP             | 88.3           | 104           | 104  |                  | 0.137 |
|             | Naproxen         | 66.2           | 96.2          | 85.9 |                  | 11.4  |
|             | Primidone        | 77.7           | 94.1          | 85.5 |                  | 9.64  |
|             | Pyraclostrobin   | 75.3           | 87.7          | 84.2 |                  | 4.08  |
|             | Silvex           | 76.8           | 98.7          | 85.7 |                  | 14.1  |
|             | Sucralose        | 96.7           | 62.3          | 65.5 |                  | 4.88  |
|             | Thiamethoxam     | 84.6           | 98.2          | 108  |                  | 9.83  |
|             | Tolfenpyrad      | 51.6           | 53.7          | 50.5 |                  | 6.14  |
|             | Triclopyr        | 68.8           | 82.7          | 85.0 |                  | 2.79  |

## Reference Method Descriptions

| Method    | Description                                                                            | Associated Samples |
|-----------|----------------------------------------------------------------------------------------|--------------------|
| EPA 8270E | Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS/MS       | 2386792            |
| EPA 8270E | PCBs in water matrices by GC/MS/MS                                                     | 2386792            |
| EPA 8276  | Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization | 2386792            |
| EPA 8321B | Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS            | 2386793, 2386794   |

## Preparation and Analysis Log

| Ref. Method | Received Date | Prep Date/Time   | Prepared By      | Analysis Date/Time | Analyzed By      | Associated Samples |
|-------------|---------------|------------------|------------------|--------------------|------------------|--------------------|
| EPA 8270E   | 02/10/2023    | 02/13/2023 08:00 | Fe-Val Siddell   | 02/15/2023 01:10   | Vandana T. Nagar | 2386792            |
|             | 02/10/2023    | 02/13/2023 08:00 | Fe-Val Siddell   | 02/17/2023 21:13   | Vandana T. Nagar | 2386792            |
| EPA 8276    | 02/10/2023    | 02/13/2023 08:00 | Fe-Val Siddell   | 02/17/2023 12:36   | Lipi Saha        | 2386792            |
| EPA 8321B   | 02/10/2023    | 02/13/2023 10:00 | Manjita Shrestha | 02/13/2023 16:59   | Manjita Shrestha | 2386793            |
|             | 02/10/2023    | 02/13/2023 10:00 | Manjita Shrestha | 02/13/2023 17:27   | Manjita Shrestha | 2386794            |
|             | 02/10/2023    | 02/13/2023 10:00 | Manjita Shrestha | 02/14/2023 00:05   | Manjita Shrestha | 2386793            |
|             | 02/10/2023    | 02/13/2023 10:00 | Manjita Shrestha | 02/14/2023 00:18   | Manjita Shrestha | 2386794            |
|             | 02/10/2023    | 02/14/2023 12:00 | June Rhew        | 02/15/2023 01:13   | Juyoung Kim      | 2386793            |
|             | 02/10/2023    | 02/14/2023 12:00 | June Rhew        | 02/15/2023 01:32   | Juyoung Kim      | 2386794            |